APPENDIX D-5

FLOW TRANSMITTER AND CONTROL

- Endress+Hauser Promag 30 Series
- Endress+Hauser Promag 50 Series




















Description of Device Functions

Proline Promag 50

Electromagnetic Flow Measuring System







Contents

1	Function matrix Promag 50 5
1.1 1.2	The function matrix: layout and use
2	Group MEASURING VALUES 7
3	Group SYSTEM UNITS 8
4	Group QUICK SETUP10
5	Group OPERATION11
6	Group USER INTERFACE13
7	Group TOTALIZER 1/216
8	Group HANDLING TOTALIZER18
9	Group CURRENT OUTPUT19
10	Group PULSE/FREQUENCY OUTPUT 23
11 11.1	Group STATUS OUTPUT
11.2	Switching response of the status output 38
11.2 12	Group STATUS INPUT40
12	Group STATUS INPUT40
12 13	Group STATUS INPUT
12 13 14	Group STATUS INPUT
12 13 14 15	Group STATUS INPUT
12 13 14 15 16 17	Group STATUS INPUT
12 13 14 15 16 17	Group STATUS INPUT

Z I	Factory settings 58
	SI units (not for USA and Canada)
22	Index of key words

Registered trademarks

HART®

Registered trademark of the HART Communication Foundation, Austin, USA

 $HistoROM^{TM},$ S-DAT $^{\circledR},$ FieldCare $^{\circledR}$ Registered trademarks of Endress+Hauser Flowtec AG, Reinach, CH

 $Endress\!+\!Hauser$

1 Function matrix Promag 50

1.1 The function matrix: layout and use

The function matrix is a two-level construct: the groups form one level and the groups' functions the other.

The groups are the highest-level grouping of the operating options for the measuring device. A number of functions is assigned to each group.

You select a group in order to access the individual functions for operating and parameterizing the measuring device.


An overview of all the groups available is provided in the table of contents on Page 3 and in the graphical representation of the function matrix on Page 6.

An overview of all the functions available is provided on Page 6, complete with page references to the detailed function descriptions.

The descriptions of the individual functions start on Page 7.

Example of how to parameterize a function (in this case changing the language for the UI):

- 1. Enter into the function matrix (E-key).
- 2. Select the OPERATION group.
- 3. Select the LANGUAGE function, change the setting from ENGLISH to DEUTSCH with = and save with = (all text on the display now appears in German).
- 4. Exit the function matrix (ESC > 3 seconds).



A0001142

Function groups \blacktriangleright Functions \rightarrow

1.2 Illustration of the function matrix

								SIMUL. FREO. (P. 28)					ECC CLEAN, CYCL. (P. 48)						
								ACTUAL FREO. (P. 27)					ECC RECOVERY TIME (P. 48)			OPERAT. HRS. (P. 55)			
				DISPLAY TEST (P. 15)			VALUE SIM. CURRENT (P. 22)	FAILSAFE VALUE (P. 27)	VALUE SIM. PULSE (P. 33)				ECC DURATION (P. 47)		POLARITY ECC (P. 53)	SYSTEM RESET (P. 55)			
				BACKLIGHT (P. 15)			SIMUL. CURRENT (P. 22)	FAILSAFE MODE (P. 27)	SIMULATION PULSE (P. 32)	VAL. SIM. SWIT. PT. (P. 36)		DEVICE REVISION (P. 42)	ECC (P. 47)		EPD ELECTRODE (P. 53)	ALARM DELAY (P. 55)			
				CONTRAST LCD (P. 14)	RESET TOTALIZ. (P. 17)		ACTUAL CURRENT (P. 21)	TIME CONSTANT (P. 27)	FAILSAFE MOD E (P. 32)	SIM. SWITCH POINT (P. 35)		DEVICE ID (P. 42)	EPD/OED RES.TIME (P. 47)		OVERVLTG TIME (P. 53)	ERROR CATEG. (P. 55)			
			ACCESS CODE COUNTER (P. 12)	DISPL. DAMPING (P. 14)	TOTALIZER MODE (P. 17)		FAILSAFE MODE (P. 21)	OUTPUT SIGNAL (P. 25)	OUTPUT SIGNAL (P. 30)	ACTUAL STATUS (P. 35)	VALUE SIM. STATUS (P. 41)	MANUFACT. ID (P. 42)	EPD/OED ADJ. (P. 46)	INTEGRAT. TIME (P. 51)	MEAS. PERIOD (P. 53)	ASSIGN PROC. ERR. (P. 54)			SW REV. L/O MOD. (P. 57)
	FORMAT DATE/TIME (P. 9)		STATUS ACCESS (P. 12)	FORMAT (P. 14)	UNIT TOTALIZER (P. 16)		TIME CONSTANT (P. 21)	VALUE-f HIGH (P. 24)	PULSE WIDTH (P. 29)	TIME CONSTANT (P. 35)	SIM. STATUS INP. (P. 40)	HART PROTOCOL (P. 42)	EMPTY PIPE DET. (P. 44)	SYSTEM DAMPING (P. 51)	NOM. DIAMETER (P. 52)	ERROR CATEG. (P. 54)		SW REV. NO. S-DAT (P. 57)	I/O MODULE TYPE (P. 57)
	UNIT LENGTH (P. 9)		PRIVATE CODE (P. 12)	100% VALUE (P. 13)	OVERFLOW (P. 16)		VALUE 20 mA (P. 21)	END VALUE FREQ. (P. 23)	PULSE VALUE (P. 29)	OFF-VALUE (P. 35)	MIN. PULSE WIDTH (P. 40)	BUS ADDRESS (P. 42)	OFF-VALUE (P. 43)	POS. ZERO RETURN (P. 50)	ZERO POINT (P. 52)	ASSIGN SYS. ERR. (P. 54)	VAL.SIM.MEAS.VAR. (P. 56)	HW REV. SENS. (P. 57)	LANGUAGE GROUP (P. 57)
	UNIT VOLUME (P. 8)		ACCESS CODE (P. 12)	ASSIGN LINE 2 (P. 13)	SUM (P. 16)	FAILSAFE MODE (P. 18)	CURRENT SPAN (P. 20)	ASSIGN FREO. (P. 23)	ASSIGN PULSE (P. 28)	ON-VALUE (P. 34)	ACTIVE LEVEL (P. 40)	TAG DESCR. (P. 42)	ON-VALUE (P. 43)	MEASURING MODE (P. 49)	K-FACTOR (P. 52)	PREV. SYS. COND. (P. 54)	SIM. MEAS. VARIAB. (P. 56)	SENSOR TYPE (P. 57)	SW REV. AMPL. (P. 57)
VOLUME FLOW (P. 7)	UNIT VOL. FLOW (P. 8)	OUICK SETUP COMMISSION (P. 10)	LANGUAGE (P. 11)	ASSIGN LINE 1 (P. 13)	ASSIGN TOTALIZER (P. 16)	RESET ALL TOTAL. (P. 18)	ASSIGN CURRENT OUTP. (P. 19)	OPERATION MODE (P. 23)	VALUE SIM. FREO. (P. 28)	ASSIGN STATUS (P. 34)	ASSIGN STATUS (P. 40)	TAG NAME (P. 42)	ASSIGN LF CUT OFF (P. 43)	INSTALL. DIRECT. (P. 49)	CALIBRATION DATE (P. 52)	CURR. SYS. COND. (P. 54)	SIM. FAILS. MODE (P. 56)	SERIAL NUMBER (P. 57)	DEVICE SOFTWARE (P. 57)
MEASURING VALUES (P. 7)	SYSTEM UNITS (P. 8)	QUICK SETUP (P. 10)	OPERATION (P. 11)	USER INTERFACE (P. 13)	TOTALIZER 1/2 (P. 16)	HANDLING TOTALIZ. (P. 18)	CURRENT OUTPUT (P. 19)	PULSE/FREO. OUTP. (P. 23)		STATUS OUTPUT (P. 34)	STATUS INPUT (P. 40)	COMMUNICATION (P. 42)	PROCESS PARAM. (P. 43)	SYSTEM PARAM. (P. 49)	SENSOR DATA (P. 52)	SUPERVISION (P. 54)	SIMULAT. SYSTEM (P. 56)	SENSOR VERSION (P. 57)	AMPLIFIER VERS. (P. 57)

2 Group MEASURING VALUES

Function description MEASURING VALUES Note! • The engineering unit of the measured variable displayed here can be set in the SYSTEM UNITS group, (see Page 8). ■ If the fluid in the pipe flows backwards, a negative sign prefixes the flow reading on the display. **VOLUME FLOW** The volume flow currently measured appears on the display. User interface: 5-digit floating-point number, including unit and sign (e.g. $5.5445 \text{ dm}^3/\text{min}$; $1.4359 \text{ m}^3/\text{h}$; -731.63 gal/d; etc.)

3 Group SYSTEM UNITS

Function description SYSTEM UNITS

Use this function group to select the unit for the measured variable.

UNIT VOLUME FLOW

Use this function to select the unit for displaying the volume flow.

The unit you select here is also valid for:

- Current output
- Frequency output
- Switch points (limit value for volume flow, flow direction)
- Low flow

Options:

Metric:

Cubic centimeter \rightarrow cm³/s; cm³/min; cm³/h; cm³/day Cubic decimeter \rightarrow dm³/s; dm³/min; dm³/h; dm³/day Cubic meter \rightarrow m³/s; m³/min; m³/h; m³/day Milliliter \rightarrow ml/s; ml/min; ml/h; ml/day Liter \rightarrow l/s; l/min; l/h; l/day Hectoliter \rightarrow hl/s; hl/min; hl/h; hl/day Megaliter \rightarrow Ml/s; Ml/min; Ml/h; Ml/day

Cubic centimeter \rightarrow cc/s; cc/min; cc/h; cc/day

115.

Acre foot \rightarrow af/s; af/min; af/h; af/day Cubic foot \rightarrow ft³/s; ft³/min; ft³/h; ft³/day Fluid ounce \rightarrow oz f/s; oz f/min; oz f/h; oz f/day Gallon \rightarrow gal/s; gal/min; gal/h; gal/day Kilo gallon \rightarrow Kgal/s; Kgal/min; Kgal/h; Kgal/day Million gallon \rightarrow Mgal/s; Mgal/min; Mgal/h; Mgal/day Barrel (normal fluids: 31.5 gal/bbl) \rightarrow bbl/s; bbl/min; bbl/h; bbl/day Barrel (beer: 31.0 gal/bbl) \rightarrow bbl/s; bbl/min; bbl/h; bbl/day Barrel (petrochemicals: 42.0 gal/bbl) \rightarrow bbl/s; bbl/min; bbl/h; bbl/day Barrel (filling tanks: 55.0 gal/bbl) \rightarrow bbl/s; bbl/min; bbl/h; bbl/day

Imperial:

Gallon \rightarrow gal/s; gal/min; gal/h; gal/day Mega gallon \rightarrow Mgal/s; Mgal/min; Mgal/h; Mgal/day Barrel (beer: 36.0 gal/bbl) \rightarrow bbl/s; bbl/min; bbl/h; bbl/day Barrel (petrochemicals: 34.97 gal/bbl) \rightarrow bbl/s; bbl/min; bbl/h; bbl/day

Factory setting:

Depends on nominal diameter and country (see Page 58 ff.).

UNIT VOLUME

Use this function to select the unit for displaying the volume.

The unit you select here is also valid for:

■ Pulse weighting (e.g. m³/p)

Options:

Metric \rightarrow cm³; dm³; m³; m!; l; hl; Ml Mega US \rightarrow cc; af; ft³; oz f; gal; Kgal; Mgal; bbl (normal fluids); bbl (beer); bbl (petrochemicals) \rightarrow bbl (filling tanks) Imperial \rightarrow gal; Mgal; bbl (beer); bbl (petrochemicals)

Factory setting:

Depends on nominal diameter and country (see Page 58 ff.).



The unit of the totalizers is independent of your choice here. The unit for each totalizer is selected separately for the totalizer in question.

	Function description SYSTEM UNITS					
UNIT LENGTH	Use this function to select the unit for displaying the length of the nominal diameter.					
	The unit you select here is also valid for: Nominal diameter of sensor (see function NOMINAL DIAMETER on Page 48)					
	Options: MILLIMETER INCH					
	Factory setting: MILLIMETER (SI units: not for USA and Canada) INCH (US units: only for USA and Canada)					
FORMAT DATE/TIME	Use this function to select the format for the date and the time.					
	The unit you select here is also valid for: Displaying the current calibration date (function CALIBRATION DATE on Seite 52)					
	Options: DD.MM.YY 24H MM/DD/YY 12H A/P DD.MM.YY 12H A/P MM/DD/YY 24H					
	Factory setting: DD.MM.YY 24H (SI units) MM/DD/YY 12H A/P (US units)					


4 Group QUICK SETUP

	Function description QUICK SETUP
QUICK SETUP COMMISSION	Use this function to start the Quick Setup menu for commissioning.
	Options: YES
	NO
	Factory setting:
	NO



Note!

The display returns to the QUICK SETUP COMMISSION cell if you press the ESC key combination during interrogation.



a0005413-en

10

5 Group OPERATION

Function description OPERATION LANGUAGE Use this function to select the language for all texts, parameters and messages shown on the local display. Note! The displayed options depend on the available language group shown in the LANGUAGE GROUP function. Options: Language group WEST EU / USA: **ENGLISH DEUTSCH FRANCAIS ESPANOL** ITALIANO **NEDERLANDS PORTUGUESE** Language group EAST EU / SCAND: **ENGLISH** NORSK SVENSKA SUOMI POLISH RUSSIAN CZECH Language group ASIA: **ENGLISH** BAHASA INDONESIA JAPANESE (Silbenschrift) Factory setting: Country-dependent (see Page 58 ff.) Note! ■ If you press the 🕒 keys simultaneously at startup, the language defaults to $\,\blacksquare\,$ You can change the language group via the configuration program FieldCare. Please do not hesitate to contact your Endress+Hauser sales office if you have any questions.

Function description OPERATION				
ACCESS CODE	All data of the measuring system are protected against inadvertent change. Programming is disabled and the settings cannot be changed until a code is entered in this function. If you press the '- keys in any function, the measuring system automatically goes to this function and the prompt to enter the code appears on the display (when programming is disabled).			
	You can enable programming by entering your personal code, (factory setting = 50, see function PRIVATE CODE on Page 12)			
	User input: max. 4-digit number: 09999			
	 Note! The programming levels are disabled if you do not press a key within 60 seconds following automatic return to the HOME position. You can also disable programming in this function by entering any number (other than the defined private code). The Endress+Hauser service organization can be of assistance if you mislay your personal code. 			
PRIVATE CODE	Use this function to enter a personal code number for enabling programming.			
	User input: 09999 (max. 4-digit number)			
	Factory setting: 50			
	 Note! Programming is always enabled with the code "0". Programming has to be enabled before this code can be changed. When programming is disabled this function is not available, thus preventing others from accessing your personal code. 			
STATUS ACCESS	Use this function to check the access status for the function matrix. User interface: ACCESS CUSTOMER (parameterization possible) LOCKED (parameterization disabled)			
ACCESS CODE COUNTER	Displays how often the customer code, service code or the digit "0" (code-free) has been entered to gain access to the function matrix. Display:			
	max. 7-digit number: 09999999			
	Factory setting: 0			

6 Group USER INTERFACE

Function description USER INTERFACE				
ASSIGN LINE 1	Use this function to define which display value is assigned to the main line (top line of the local display) for display during normal measuring operation. Options: OFF VOLUME FLOW VOLUME FLOW IN % TOTALIZER 1			
	TOTALIZER 2 Factory setting: VOLUME FLOW			
ASSIGN LINE 2	Use this function to define which display value is assigned to the additional line (bottom line of the local display) for display during normal measuring operation. Options: OFF VOLUME FLOW VOLUME FLOW IN % VOLUME FLOW BARGRAPH IN % TOTALIZER 1 TAG NAME OPERATING/SYSTEM CONDITION FLOW DIRECTION TOTALIZER 2 Factory setting: TOTALIZER 1			
100% VALUE	This function is only available if VOLUME FLOW IN % or VOLUME FLOW BARGRAPH IN % was selected in the function ASSIGN LINE 1 or ASSIGN LINE 2. Use this function to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: Depends on nominal diameter and country (see Page 58 ff.).			

	Function description USER INTERFACE				
FORMAT	Use this function to define the maximum number of places after the decimal point displayed for the reading in the main line.				
	Options: XXXXX XXXX.X - XXX.XX - XX.XXX				
	Factory setting: X.XXXX				
	 Note! Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → 1/h), indicating that the measuring system is computing with more decimal places than can be shown on the display. 				
DISPLAY DAMPING	Use this function to enter a time constant defining how the display reacts to severely fluctuating flow variables, either very quickly (enter a low time constant) or with damping (enter a high time constant).				
	User input: 0100 seconds				
	Factory setting: 3 s				
	Note! Setting the time constant to zero seconds switches off damping.				
CONTRAST LCD	Use this function to optimize display contrast to suit local operating conditions.				
	User input: 10100%				
	Factory setting: 50%				

Function description USER INTERFACE					
BACKLIGHT	Use this function to optimize the backlight to suit local operating conditions.				
	User input: 0100%				
	Note! Entering the value "0" means that the backlight is "switched off". The display then no longer emits any light, i.e. the display texts can no longer be read in the dark.				
	Factory setting: 50%				
DISPLAY TEST	Use this function to test the operability of the local display and its pixels.				
	Options: OFF ON				
	Factory setting:				
	OFF				
	Test sequence: 1. Start the test by selecting ON.				
	2. All pixels of the main line and additional line are darkened for at least 0.75 seconds.				
	3. The main line and additional line show an "8" in each field for at least 0.75 seconds.				
	4. The main line and additional line show a "0" in each field for at least 0.75 seconds.				
	5. The main line and additional line show nothing (blank display) for at least 0.75 seconds.				
	When the test completes the local display returns to its initial state and the setting changes to OFF.				

7 Group TOTALIZER 1/2

Function description TOTALIZER 1/2							
ASSIGN TOTALIZER	ASSIGN TOTALIZER Use this function to assign a measured variable (volume flow) to the totalizer.						
	Options: OFF VOLUME FLOW Factory setting: VOLUME FLOW Note! The totalizer is reset to "0" as soon as the selection is changed.						
SUM	Use this function to view the total for the totalizer measured variable aggregated since measuring commenced. The value can be positive or negative.						
	User interface: max. 7-digit floating-point number, including sign and unit (e.g. 896,845.7 dm ³) Note! The totalizer response to faults is defined in the FAILSAFE MODE function (see Page 18).						
OVERFLOW	Use this function to view the overflow for the totalizer aggregated since measuring commenced.						
	Total flow quantity is represented by a floating decimal point number consisting of max. 7 digits. You can use this function to view higher numerical values (>9 999 999) as overflows. The effective quantity is thus the total of OVERFLOW plus the value returned by the SUM function.						
	Example: Reading for 2 overflows: 2 E7 kg (= $2~000~000~dm^3$) The value returned by the SUM function = $896,845.7~dm^3$ Effective total quantity = $2,896,845.7~dm^3$						
	Display shows: Integer with exponent, including sign and unit, e.g. 2 E7 dm ³						
UNIT TOTALIZER	Use this function to define the unit for the totalizer.						
	Options: Metric \rightarrow cm ³ ; dm ³ ; ml; l; hl; Ml Mega						
	US \rightarrow cc; af; ft ³ ; oz f; gal; Kgal; Mgal; bbl (normal fluids); bbl (beer); bbl (petrochemicals); bbl (filling tanks)						
	Imperial \rightarrow gal; Mgal; bbl (beer); bbl (petrochemicals)						
	Factory setting: Depends on nominal diameter and country (see Page 58 ff.).						

16

Use this function to define how the flow components are to be totalized. Options: BALANCE Positive and negative flow components. The positive and negative flow components are balanced. In other words, net flow in the flow direction is registered. FORWARD Positive flow components only REVERSE Negative flow components only Factory setting: Totalizer I = BALANCE Totalizer 2 = FORWARD RESET TOTALIZER Use this function to reset the sum and the overflow of the totalizer to "zero" (= RESET). Options: NO YES Factory setting: NO Note! If the device is equipped with a status input and if it is appropriately configured, totalizer resetting can also be triggered by a pulse.	Function description TOTALIZER 1/2					
Positive and negative flow components. The positive and negative flow components are balanced. In other words, net flow in the flow direction is registered. FORWARD Positive flow components only REVERSE Negative flow components only Factory setting: Totalizer 1 = BALANCE Totalizer 2 = FORWARD Use this function to reset the sum and the overflow of the totalizer to "zero" (= RESET). Options: NO YES Factory setting: NO YES Note! If the device is equipped with a status input and if it is appropriately configured, totalizer	TOTALIZER MODE	Options:				
Positive flow components only REVERSE Negative flow components only Factory setting: Totalizer 1 = BALANCE Totalizer 2 = FORWARD Use this function to reset the sum and the overflow of the totalizer to "zero" (= RESET). Options: NO YES Factory setting: NO Note! If the device is equipped with a status input and if it is appropriately configured, totalizer		Positive and negative flow components. The positive and negative flow components are				
RESET TOTALIZER Use this function to reset the sum and the overflow of the totalizer to "zero" (= RESET). Options: NO YES Factory setting: NO Note! If the device is equipped with a status input and if it is appropriately configured, totalizer		Positive flow components only				
Totalizer 1 = BALANCE Totalizer 2 = FORWARD Use this function to reset the sum and the overflow of the totalizer to "zero" (= RESET). Options: NO YES Factory setting: NO Note! If the device is equipped with a status input and if it is appropriately configured, totalizer		Negative flow components only				
Options: NO YES Factory setting: NO Note! If the device is equipped with a status input and if it is appropriately configured, totalizer		Totalizer 1 = BALANCE				
NO YES Factory setting: NO Note! If the device is equipped with a status input and if it is appropriately configured, totalizer	RESET TOTALIZER	Use this function to reset the sum and the overflow of the totalizer to "zero" (= RESET).				
NO Note! If the device is equipped with a status input and if it is appropriately configured, totalizer		NO				
If the device is equipped with a status input and if it is appropriately configured, totalizer						
		If the device is equipped with a status input and if it is appropriately configured, totalizer				

8 Group HANDLING TOTALIZER

Function description HANDLING TOTALIZER				
Use this function to reset the totals (including all overflows) of the totalizers (12) to "zero". Options: NO YES Factory setting: NO Note! If the device has a status input and if it is appropriately configured, a reset for the totalizer (12) can also be triggered by a pulse (see the ASSIGN STATUS INPUT function on				
Page 31). Use this function to define the totalizer response in case of fault. Options: STOP The totalizer is paused until the fault is rectified. ACTUAL VALUE The totalizer continues to count on the basis of the current flow measuring value. The				
HOLD VALUE The totalizer continues to count the flow that is based on the last valid flow measuring value (before the fault occurred). Factory setting: STOP				

18

9 Group CURRENT OUTPUT

Function description CURRENT OUTPUT		
ASSIGN CURRENT OUT- PUT	Use this function to assign a measured variable to the current output.	
roi	Options: OFF	
	VOLUME FLOW	
	Factory setting: VOLUME FLOW	
	Note! If you select OFF, the only function shown in this group is the function (ASSIGN CURRENT OUTPUT).	

Function description CURRENT OUTPUT

CURRENT SPAN

Use this function to define the current span. The selection specifies the operational range and the lower and upper signal on alarm. For the current output the option HART can be defined additionally.


Options:

- 0-20 mA
- 4-20 mA
- 4-20 mA HART
- 4-20 mA NAMUR
- 4-20 mA HART NAMUR
- 4-20 mA US
- 4-20 mA HART US
- 0-20 mA (25 mA)
- 4-20 mA (25 mA)
- 4-20 mA (25 mA) HART

Factory setting:

4-20 mA HART NAMUR

Current span, operational range and signal on alarm level



а	1	2	3
0-20 mA	0 - 20.5 mA	0	22
4-20 mA	4 - 20.5 mA	2	22
4-20 mA HART	4 - 20.5 mA	2	22
4-20 mA NAMUR	3.8 - 20.5 mA	3.5	22.6
4-20 mA HART NAMUR	3.8 - 20.5 mA	3.5	22.6
4-20 mA US	3.9 - 20.8 mA	3.75	22.6
4-20 mA HART US	3.9 - 20.8 mA	3.75	22.6
0-20 mA (25 mA)	0 - 24 mA	0	25
4-20 mA (25 mA)	4 - 24 mA	2	25
4-20 mA (25 mA) HART	4 - 24 mA	2	25

A0001222

- a = Current span
- 1 = Operational range (measuring information)
- 2 = Lower signal on alarm level
- 3 = Upper signal on alarm level



Note!

- When switching the hardware from an active (factory setting) to a passive output signal select a current span of 4-20 mA.
- $\,\blacksquare\,$ If the measured value exceeds the measuring range a notice message is generated (#351...354, current span).
- In case of a fault the behaviour of the current output is according to the selected option in the function FAILSAFE MODE (see Page 21). Change the error category in the function ASSIGN SYSTEM ERROR (see Page 54) to generate a fault message instead of a notice message.

20

	Function description CURRENT OUTPUT
VALUE 20 mA	Use this function to assign the 20 mA current a full scale value. Positive and negative values are permissible. The required measuring range is defined by defining the VALUE 20 mA. In the SYMMETRY measuring mode, (see Page 45), the value assigned applies to both flow directions; in the STANDARD measuring mode it applies only to the flow direction selected.
	User input: 5-digit floating-point number, with sign Factory setting:
	Depends on nominal diameter and country (see Page 58 ff.).
	 Note! The appropriate unit is taken from the group SYSTEM UNITS, (see Page 8). The value for 0 or 4 mA always corresponds to the zero flow (0 [unit]). This value is fixed and cannot be edited.
TIME CONSTANT	Use this function to enter a time constant defining how the current output signal reacts to severely fluctuating measured variables, either very quickly (enter a low time constant) or with damping (enter a high time constant).
	User input: fixed-point number 0.01100.00 s
	Factory setting: 3.00 s
FAILSAFE MODE	For safety reasons it is advisable to ensure that the current output assumes a predefined state in the event of a fault. The setting you select here affects only the current output. The failsafe mode of other outputs and the totalizers is defined in the corresponding function groups.
	Options: MIN. CURRENT The current output adopts the value of the lower signal on alarm level (as defined in the function CURRENT SPAN).
	MAX. CURRENT The current output adopts the value of the upper signal on alarm level (as defined in the function CURRENT SPAN).
	HOLD VALUE (not recommended) Measuring value output is based on the last measuring value saved before the error occurred .
	ACTUAL VALUE Measured value output is based on the current flow measurement. The fault is ignored.
	Factory setting: MIN. CURRENT
ACTUAL CURRENT	Use this function to view the computed actual value of the output current.
	User interface: 0.0025.00 mA

Function description CURRENT OUTPUT SIMULATION CURRENT Use this function to activate simulation of the current output. Options: OFF ON Factory setting: OFF Note! ■ The "SIMULATION CURRENT OUTPUT" notice message indicates that simulation is ■ The measuring device continues to measure while simulation is in progress, i.e. the current measuring values are output correctly via the other outputs. Caution! The setting is not saved if the power supply fails. **VALUE SIMULATION** Note! **CURRENT** This function is not available unless the function SIMULATION CURRENT is active (= ON).Use this function to define a selectable value (e.g. 12 mA) to be output at the current output. This value is used to test downstream devices and the measuring device itself. User input: Floating-point number: 0.00...25.00 mA Factory setting: 0.00 mA Caution! The setting is not saved if the power supply fails.

10 Group PULSE/FREQUENCY OUTPUT

Function description PULSE/FREQUENCY OUTPUT This group is not available unless the measuring device is equipped with a pulse/frequency output.		
ASSIGN FREQUENCY	Note! This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE. Use this function to assign a measured variable to the frequency output. Options: OFF VOLUME FLOW Factory setting: VOLUME FLOW Note! If you select OFF, the only functions shown in this function group are the functions ASSIGN FREQUENCY and OPERATION MODE.	
END VALUE FREQ.	Note! This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE. Use this function to define a full scale frequency for the frequency output. You define the associated measured value of the measuring range in the function VALUE-f HIGH on Page 24. User input: 4-digit fixed-point number 21250 Hz Factory setting: 1000 Hz Example: VALUE-f HIGH = 1000 l/h, end frequency = 1000 Hz: i.e. at a flow of 1000 l/h, a frequency of 1000 Hz is output. VALUE-f HIGH = 3600 l/h, end frequency = 1000 Hz: i.e. at a flow of 3600 l/h, a frequency of 1000 Hz is output. Note! In the FREQUENCY operating mode the output signal is symmetrical (on/off ratio = 1:1). At low frequencies the pulse duration is limited to a maximum of 2 seconds, i.e. the on/off ratio is no longer symmetrical. The initial frequency is always 0 Hz. This value is fixed and cannot be edited.	

VALUE-f HIGH



This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE.

Use this function to assign a value to the end value frequency.


Positive and negative values are permissible. The required measuring range is defined by defining the VALUE-f HIGH. In the SYMMETRY measuring mode, (see Page 45), the value assigned applies to both flow directions; in the STANDARD measuring mode it applies only to the flow direction selected.

User input:

5-digit floating-point number

Factory setting:

Depends on nominal diameter and country, [value] / [dm³...m³ or US-gal...US-Mgal] corresponds to the factory setting for the final value (see Page $58\ \text{ff.}$)



A0001279

1 = Value-f min.

2 = Value-f high



- \blacksquare The appropriate unit is taken from the group SYSTEM UNITS, (see Page 8).
- The value-f min. for the initial frequency always corresponds to the zero flow (0 [unit]). This value is fixed and cannot be edited.

OUTPUT SIGNAL



Function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function.

For selecting the output configuration of the frequency output.

Options:

PASSIVE - POSITIVE PASSIVE - NEGATIVE

Factory setting: PASSIVE - POSITIVE

Explanation

■ PASSIVE = power is supplied to the frequency output by means of an external power supply.

Configuring the output signal level (POSITIVE or NEGATIVE) determines the quiescent behaviour (at zero flow) of the frequency output.

The internal transistor is activated as follows:

- If POSITIVE is selected, the internal transistor is activated with a **positive** signal level.
- If NEGATIVE is selected, the internal transistor is activated with a **negative** signal level (0 V).




Note!

With the passive output configuration, the output signal levels of the frequency output depend on the external circuit (see examples).

Example for passive output circuit (PASSIVE)

If PASSIVE is selected, the frequency output is configured as an open collector.



A0001225

- ① = Open collector
- ② = External power supply




Note!

For continuous currents up to 25 mA (I_{max} = 250 mA / 20 ms).

Example for output configuration PASSIVE-POSITIVE:

Output configuration with an external pull-up resistance.


In the quiescent state (at zero flow), the output signal level at the terminals is 0 V.



A0004687

- ① = Open collector
- 2 = Pull-up resistance
- ③ = Transistor activation in "POSITIVE" quiescent state (at zero flow)
- (4) = Output signal level in quiescent state (at zero flow)

In the operating status (flow present), the output signal level changes from 0 V to a positive voltage level.



A0001975

(continued on next page)


OUTPUT SIGNAL

(continued)

Example for output configuration PASSIVE-POSITIVE:

Output configuration with an external pull-down resistance.

In the quiescent state (at zero flow), a positive voltage level is measured via the $\operatorname{pull-down}$ resistance.



① = Open collector

A0004689

- ② = Pull-down resistance
- ③ = Transistor activation in "POSITIVE" quiescent state (at zero flow)
- (at zero flow)

In the operating status (flow present), the output signal level changes from a positive voltage level to 0 $\mbox{V}.$




A0001981

Example for output configuration PASSIVE-NEGATIVE:

Output configuration with an external pull-up resistance.


In the quiescent state (at zero flow), the output signal level at the terminals is at a positive voltage level.



A0004690

- ① = Open collector
- ② = Pull-up resistance
- @= Transistor activation in "NEGATIVE" quiescent state (at zero flow)
- 4 = Output signal level in quiescent state (at zero flow)

In the operating status (flow present), the output signal level changes from a positive voltage level to 0 $\ensuremath{\text{V}}.$



A0001981

Function description PULSE/FREQUENCY OUTPUT	
TIME CONSTANT	Note! This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE.
	Use this function to enter a time constant defining how the frequency output signal reacts to severely fluctuating measured variables, either very quickly (enter a low time constant) or with damping (enter a high time constant).
	User input: Floating-point number 0.00100.00 s
	Factory setting: 0.00 s
FAILSAFE MODE	Note! This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE.
	For safety reasons it is advisable to ensure that the frequency output assumes a predefined state in the event of a fault. Use this function to define this state. The setting you select here affects only the frequency output. It has no effect on other outputs and the display (e.g. totalizers).
	Options: FALLBACK VALUE Output is 0 Hz.
	FAILSAFE LEVEL Output is the frequency specified in the FAILSAFE VALUE function.
	HOLD VALUE Measuring value output is based on the last measuring value saved before the error occurred.
	ACTUAL VALUE Measuring value output is based on the current flow measurement. The fault is ignored.
	Factory setting: FALLBACK VALUE
FAILSAFE VALUE	Note! This function is not available unless FREQUENCY was selected in the OPERATION MODE function and FAILSAFE LEVEL was selected in the function FAILSAFE MODE.
	Use this function to define the frequency that the measuring device should output in the event of a fault.
	User input: max. 4-digit number: 01250 Hz
	Factory setting: 1250 Hz
ACTUAL FREQUENCY	Note! This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE.
	Use this function to view the computed value of the output frequency.
	User interface: 01250 Hz

Function description PULSE/FREQUENCY OUTPUT **SIMULATION FREQUENCY** This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE. Use this function to activate simulation of the frequency output. Options: OFF ON Factory setting: OFF Note! ■ The "SIMULATION FREQUENCY OUTPUT" notice message indicates that simulation $\,\blacksquare\,$ The measuring device continues to measure while simulation is in progress, i.e. the current measuring values are output correctly via the other outputs. Caution! The setting is not saved if the power supply fails. **VALUE SIMULATION** Note! **FREQUENCY** This function is not available unless FREQUENCY was selected in the OPERATION MODE function and the function VALUE SIMULATION FREQUENCY is active (= ON). Use this function to define a selectable frequency value (e.g. 500 Hz) to be output at the frequency output. This value is used to test downstream devices and the measuring device itself. User input: 0...1250 Hz Factory setting: 0 Hz Caution! The setting is not saved if the power supply fails. **ASSIGN PULSE** Note! This function is not available unless the PULSE setting was selected in the OPERATION MODE function. Use this function to assign a measured variable to the pulse output. **Options:** OFF VOLUME FLOW Factory setting: VOLUME FLOW Note! If you select OFF, the only functions shown in this function group are the functions ASSIGN PULSE and OPERATION MODE.

PULSE VALUE



This function is not available unless the PULSE setting was selected in the OPERATION MODE function.

Use this function to define the flow at which a pulse is triggered.

These pulses can be totalled by an external totalizer and in this way the total flow since measuring commenced can be registered.

User input:

5-digit floating-point number, [unit]

Factory setting:

Depends on nominal diameter and country (see Page 58 ff.).



Note!

The appropriate unit is taken from the group SYSTEM UNITS (see Page 8).

PULSE WIDTH



Note!

This function is not available unless the PULSE setting was selected in the $\ensuremath{\mathsf{OPERATION}}$ MODE function.

Use this function to enter the maximum pulse width of the output pulses.


User input:


0.5...2000 ms

Factory setting:

100 ms

Pulse output is **always** with the pulse width (B) entered in this function. The intervals (P) between the individual pulses are automatically configured. However, they must at least correspond to the pulse width (B = P).





B = Pulse width entered (the illustration applies to positive pulses) P= Intervals between the individual pulses



Note!

When entering the pulse width, select a value that can still be processed by an external totalizer (e.g. mechanical totalizer, PLC, etc.).



Caution!

If the pulse number or frequency resulting from the pulse value entered, (see function PULSE VALUE on Page 27), and from the current flowis too large to maintain the pulse width selected (interval P is smaller than the pulse width B entered), a system error message (pulse memory) is generated after buffering/balancing time.

OUTPUT SIGNAL



Function is not available unless the PULSE setting was selected in the OPERATION MODE function.

For selecting the output configuration of the pulse output.

PASSIVE - POSITIVE PASSIVE - NEGATIVE

Factory setting: PASSIVE - POSITIVE

Explanation

■ PASSIVE = power is supplied to the pulse output by means of an external power supply.

Configuring the output signal level (POSITIVE or NEGATIVE) determines the quiescent behaviour (at zero flow) of the pulse output.

The internal transistor is activated as follows:


- If POSITIVE is selected, the internal transistor is activated with a **positive** signal level.
- If NEGATIVE is selected, the internal transistor is activated with a **negative** signal level (0 V).



With the passive output configuration, the output signal levels of the pulse output $\[$ depend on the external circuit (see examples).

Example for passive output circuit (PASSIVE)

If PASSIVE is selected, the pulse output is configured as an open collector.



A0001225

1 = Open Collector

② = External power supply




Note!

For continuous currents up to 25 mA ($I_{max} = 250 \text{ mA} / 20 \text{ ms}$).

Example for output configuration PASSIVE-POSITIVE:

Output configuration with an external pull-up resistance.

In the quiescent state (at zero flow), the output signal level at the terminals is 0 V.



1 = Open Collector

② = Pull-Up-Resistance

③ = Transistor activation in "POSITIVE" quiescent state (at zero flow)

④ = Output signal level in quiescent state (at zero flow)

In the operating status (flow present), the output signal level changes from 0 V to a positive voltage level.




A0001975

(continued on next page)

OUTPUT SIGNAL (continued)

Example for output configuration PASSIVE-POSITIVE:

Output configuration with an external pull-down resistance. In the quiescent state (at zero flow), a positive voltage level is measured via the pull-down resistance.




① = Open Collector

② = Pull-Down-Resistance

③ = Transistor activation in "POSITIVE" quiescent state (at zero flow)

(at zero flow)

In the operating status (flow present), the output signal level changes from a positive voltage level to 0 $\ensuremath{\mathrm{V}}.$




A0001981

A0004689

Example for output configuration PASSIVE-NEGATIVE:

Output configuration with an external pull-up resistance. In the quiescent state (at zero flow), the output signal level at the terminals is at a positive voltage level.



A0004690

① = Open Collector

2 = Pull-Up-Resistance

③ = Transistor activation in "NEGATIVE" quiescent state (at zero flow)

④ = Output signal level in quiescent state (at zero flow)

In the operating status (flow present), the output signal level changes from a positive voltage level to 0 $\ensuremath{\text{V}}.$



A0001981

FAILSAFE MODE



This function is not available unless the PULSE setting was selected in the function OPERATION MODE.

For safety reasons it is advisable to ensure that the pulse output assumes a predefined state in the event of a fault. Use this function to define this state. The setting you select here affects only the pulse output. It has no effect on other outputs and the display (e.g. totalizers).

Options:

FALLBACK VALUE

Output is 0 pulse.

ACTUAL VALUE

Measuring value output is based on the current flow measurement. The fault is ignored.

Factory setting:

FALLBACK VALUE

SIMULATION PULSE



This function is not available unless the PULSE option was selected in the OPERATION MODE function.

Use this function to activate simulation of the pulse output.

Options:

OFF

COUNTDOWN

The pulses specified in the VALUE SIMULATION PULSE function are output.

CONTINUOUSLY

Pulses are continuously output with the pulse width specified in the PULSE WIDTH function. Simulation is started once the CONTINUOUSLY option is confirmed with the E key.



Note!

Simulation is started by confirming the CONTINUOUSLY option with the 🗉 key. The simulation can be switched off again via the SIMULATION PULSE function.

Factory setting:

OFF



- Note!
- The notice message #631 "SIM. PULSE" indicates that simulation is active.
- The on/off ratio is 1:1 for both types of simulation.
- The measuring device continues to measure while simulation is in progress, i.e. the current measured values are output correctly via the other outputs.



Caution!

The setting is not saved if the power supply fails.

VALUE SIMULATION PULSE



This function is not available unless the COUNTDOWN option was selected in the SIMULATION PULSE function.

Use this function to specify the number of pulses (e.g. 50) which are output during the simulation. This value is used to test downstream devices and the measuring device itself. The pulses are output with the pulse width specified in the PULSE WIDTH function. The on/off ratio is 1:1.

Simulation is started once the specified value is confirmed with the E key. The display remains at "0" if the specified pulses have been output.

User input:

0...10000

Factory setting:



Note!

Simulation is started by confirming the simulation value with the 🗉 key. The simulation can be switched off again via the SIMULATION PULSE function.



Caution!

The setting is not saved if the power supply fails.

11 **Group STATUS OUTPUT**

Function description STATUS OUTPUT

This group is not available unless the measuring device is equipped with a status output.

ASSIGN STATUS OUTPUT

Use this function to assign a switching function to the status output.

Options:

OFF

ON (operation) FAULT MESSAGE

NOTICE MESSAGE

FAULT MESSAGE or NOTICE MESSAGE

EPD or OED (Empty Pipe Detection / Open Electrode Detection, only if active)

FLOW DIRECTION

VOLUME FLOW LIMIT VALUE

Factory setting:

FAULT MESSAGE



Note!

- The behaviour of the status output is a normally closed behaviour, in other words the output is closed (transistor conductive) when normal, error-free measuring is in progress.
- It is very important to read and comply with the information on the switching characteristics of the status output, (see Page 34).
- If you select OFF, the only function shown in this function group is the function ASSIGN STATUS OUTPUT.

ON-VALUE



Note!

This function is not available unless LIMIT VALUE or FLOW DIRECTION was selected in the function ASSIGN STATUS OUTPUT.

Use this function to assign a value to the switch-on point (status output pulls up). The value can be equal to, greater than or less than the switch-off point. Positive and negative values are permissible.

User input:

5-digit floating-point number, [unit]

Factory setting:

0 [unit]



Note!

- \blacksquare The appropriate unit is taken from the group SYSTEM UNITS, (see Page 8).
- Only the switch-on point is available for flow direction output (no switch-off point). If you enter a value not equal to the zero flow (e.g. 5), the difference between the zero flow and the value entered corresponds to half the switchover hysteresis.

Function description STATUS OUTPUT		
OFF-VALUE	Note! This function is not available unless LIMIT VALUE was selected in the function ASSIGN STATUS OUTPUT. Use this function to assign a value to the switch-off point (status output drops out). The value can be equal to, greater than or less than the switch-on point. Positive and negative values are permissible. User input: 5-digit floating-point number, [unit] Factory setting:	
	Note! The appropriate unit is taken from the group SYSTEM UNITS, (see Page 8). If SYMMETRY is selected in the function MEASURING MODE (Page 45) and values with different signs are entered for the switch-on and switch-off points, the notice message "INPUT RANGE EXCEEDED" appears.	
TIME CONSTANT	Use this function to enter a time constant defining how the measuring signal reacts to severely fluctuating measured variables, either very quickly (enter a low time constant) or with damping (enter a high time constant). The purpose of damping, therefore, is to prevent the status output changing state continuously in response to fluctuations in flow. User input:	
	fixed-point number 0.00100.00 s	
	Factory setting: 0.00 s	
ACTUAL STATUS OUTPUT	Use this function to check the current status of the status output. User interface: NOT CONDUCTIVE CONDUCTIVE	
SIMULATION SWITCH POINT	Use this function to activate simulation of the status output. Options: OFF ON Factory setting: OFF Note! The "SIMULATION STATUS OUTPUT" message indicates that simulation is active. The measuring device continues to measure while simulation is in progress, i.e. the current measuring values are output correctly via the other outputs. Caution! The setting is not saved if the power supply fails.	

Function description STATUS OUTPUT VALUE SIMULATION Note! **SWITCH POINT** This function is not available unless the function SIMULATION SWITCH POINT is active (= ON). Use this function to define the switching response of the status output during the simulation. This value is used to test downstream devices and the measuring device itself. Options: NOT CONDUCTIVE CONDUCTIVE Factory setting: NOT CONDUCTIVE Caution! The setting is not saved if the power supply fails.


11.1 Information on the response of the status output

General

If you have configured the status output for "LIMIT VALUE" or "FLOW DIRECTION", you can configure the requisite switch points in the functions ON-VALUE and OFF-VALUE. When the measured variable in question reaches these predefined values, the status output switches as shown in the illustrations below.

Status output configured for limit value

The status output switches as soon as the measured variable undershoots or overshoots a defined switch point. Application: Monitoring flow or process-related boundary conditions.





A0001235

- $A = Maximum safety \rightarrow ① SWITCH-OFF POINT > ② SWITCH-ON POINT$
- $B = Maximum safety \rightarrow ① SWITCH-OFF POINT < ② SWITCH-ON POINT$
- $C = Maximum safety \rightarrow \textcircled{1} SWITCH-OFF POINT = \textcircled{2} SWITCH-ON POINT (this configuration is to avoid)$
- ③ = Status output switched off (not conductive)

Status output configured for flow direction

The value entered in the function SWITCH–ON POINT defines the switch point for the positive and negative directions of flow. If, for example, the switch point entered is = $1 \text{ m}^3/\text{h}$, the status output switches off at $-1 \text{ m}^3/\text{h}$ (not conductive) and switches on again at $+1 \text{ m}^3/\text{h}$ (conductive). Set the switch point to 0 if your process calls for direct switchover (no switching hysteresis). If low flow cut off is used, it is advisable to set hysteresis to a value greater than or equal to the low flow rate.





A0001236

- a = Status output conductive
- b = Status output not conductive

11.2 Switching response of the status output

Function	Status			ector response ensistor)
ON (operation)	System in measuring mode	XXX.XXX.XX A0001052	conduc- tive	A0001237
	System not in measuring mode (power supply failed)	XXX.XXXXX A0001291	not conduc- tive	A0001238
Fault message	System OK	XXX.XXX.XX Second of the control of	conduc- tive	A0001237
	(System or process error) Fault → Error response of outputs/Inputs and totalizer	XXX.XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX	not conduc- tive	A0001238
Notice message	System OK	XXX.XXX.XX Esc. A0001052	conduc- tive	A0001237
	(System or process error) Fault → Continuation of measuring	XXX.XXXX A0001291	not conduc- tive	A0001238
Fault message or notice message	System OK	XXX.XXX.XX Esc A0001052	conduc- tive	A0001237
	(System or process error) Fault → Response to error or Note → Continuation of measuring	XXX.XXXX A0001291	not conduc- tive	A0001238
Empty pipe detection (EPD) / Open electrode detection (OED)	Measuring tube full	A0001292	conduc- tive	A0001237
	Measuring tube partially filled / empty measuring tube	A0001293	not conduc- tive	A0001238

Function	Status			llector response ransistor)
Flow direction	Forward	A0001241	conduc- tive	A0001237
	Reverse	A0001242	not conduc- tive	A0001238
Limit value Volume flow	Limit value not overshot or undershot	A0001243	conduc- tive	A0001237
	Limit value overshot or undershot	A0001244	not conduc- tive	A0001238

12 Group STATUS INPUT

Function description STATUS INPUT		
This group is not available unless the measuring device is equipped with a status input.		
ASSIGN STATUS INPUT	Use this function to assign a switching function to the status input. Options: OFF RESET TOTALIZER 1 POSITIVE ZERO RETURN RESET TOTALIZER 2 RESET ALL TOTALIZERS Factory setting: OFF Note! Positive zero return is active as long as the active level is available at the status input (continuous signal). All other assignments react to a change in level (pulse) at the status input.	
ACTIVE LEVEL	Use this function to define whether the assigned switch function, (see function ASSIGN STATUS INPUT) is released or sustained when the level is present (HIGH) or not present (LOW). Options: HIGH LOW Factory setting: HIGH	
MINIMUM PULSE WIDTH	Use this function to define a minimum pulse width which the input pulse must achieve in order to trigger the selected switching function. User input: 20100 ms Factory setting: 50 ms	
SIMULATION STATUS INPUT	Use this function to activate simulation of the status input, i.e. to trigger the function assigned to the status input, (see function ASSIGN STATUS INPUT on Page 31). Options: OFF ON Factory setting: OFF Note! The "SIMULATION STATUS INPUT" notice message indicates that simulation is active. The measuring device continues to measure while simulation is in progress, i.e. the current measuring values are output correctly via the outputs. Caution! The setting is not saved if the power supply fails.	

13 Group COMMUNICATION

	Function description COMMUNICATION
TAG NAME	Use this function to enter a tag name for the measuring device. You can edit and read this tag name at the local display or via the HART protocol.
	User input: max. 8-character text, permitted characters are: A–Z, 0–9, +, –, punctuation marks
	Factory setting: "" (no text)
TAG DESCRIPTION	Use this function to enter a tag description for the measuring device. You can edit and read this tag description at the local display or via the HART protocol.
	User input: max. 16-character text, permitted characters are: A–Z, 0–9, +, –, punctuation marks
	Factory setting: "" (No text)
BUS ADDRESS	Use this function to define the address for the exchange of data with the HART protocol.
	User input: 015
	Factory setting:
	Note! Addresses 115: a constant 4 mA current is applied.
HART PROTOCOL	Use this function to display if the HART protocol is active.
	User interface: OFF = HART protocol not active ON = HART protocol active
	Note! The HART protocol is activated by selecting 4–20 mA HART or 4–20 mA (25 mA) HART in the function CURRENT SPAN (see Page 20).
MANUFACTURER ID	Use this function to view the manufacturer.
	User interface: - Endress+Hauser - 17 (≅ 11 hex) for Endress+Hauser
DEVICE ID	Use this function to view the device ID in hexadecimal numerical format.
	User interface: 41 (≅ 65 dez) for Promag 50
DEVICE REVISION	Use this function to view the device-specific revision of the HART command interface.
	User interface: E.g.: 5

14 Group PROCESS PARAMETER

I	Function description PROCESS PARAMETER
ASSIGN LOW FLOW CUT	Use this function to assign the switch point for low flow cut off.
	Options:
	OFF VOLUME FLOW
	Factory setting: VOLUME FLOW
ON-VALUE LOW FLOW CUT OFF	Use this function to enter the switch-on point for low flow cut off.
001 011	Low flow cut off is active if the value entered is not equal to 0. The sign of the flow value is highlighted on the display to indicate that low flow cut off is active.
	User input: 5-digit floating-point number, [unit]
	Factory setting: Depends on nominal diameter and country (see Page 58 ff.).
	Note! The appropriate unit is taken from the group SYSTEM UNITS (see Page 8).
OFF-VALUE LOW FLOW CUT OFF	Use this function to enter the switch-off point for low flow cut off. Enter the switch-off point as a positive hysteresis value from the switch-on point.
	User input: Integer 0100%
	Factory setting: 50%
	Q ① = switch-on point, ② = switch-off point $a = Low flow cut off is switched on$ $b = Low flow cut off is switched off (a + a \cdot H)$ $H = Hysteresis value: 0 to 100%$ ■ = Low flow cut off active $Q = Flow$

EMPTY PIPE DETECTION (EPD)

Flow cannot be measured correctly unless the measuring tube is full. This status can be monitored at all times with the Empty Pipe Detection function. Use this function to activate Empty Pipe Detection (EPD) or Open Electrode Detection (OED).

- EPD = Empty Pipe Detection (with the help of an EPD electrode)
- OED = Open Electrode Detection (empty pipe detection with the help of the measuring electrodes, if the sensor is not equipped with an EPD electrode or the orientation is not suitable for using EPD).

Options:

OFF - ON SPECIAL - OED - ON STANDARD

OFF (neither EPD nor OED are active)

ON SPECIAL (only for DN <400):

Switching on the Empty Pipe Detection (EPD) for devices in remote version (transmitter and sensor are installed separately).

OED:

Switching on the Open Electrode Detection (OED).

ON STANDARD:

Switching on the Empty Pipe Detection (EPD) for:

- Devices in compact version (transmitter and sensor form a single mechanical unit).
- Applications where a facing and coating of the fluid on the measuring tube line and measuring electrode accrues.

Factory setting:

OFF



- The options ON STANDARD and ON SPECIAL are not available unless the sensor is equipped with an EPD electrode.
- The default setting for the EPD/OED functions when the device is delivered is OFF. The functions must be activated as required.
- \blacksquare The devices are calibrated at the factory with water (approx. 500 $\mu\text{S/cm}$). If the conductivity of certain fluids deviates from this reference, empty pipe/full pipe adjustment must be performed again on site (see function EPD/OED ADJUSTMENT on page 46).
- The adjustment coefficients must be valid before you can switch on the EPD or OED. If these coefficients are not available, the function EPD/OED ADJUSTMENT is displayed (see Page 44).
- If there are problems with the adjustment, the following error messages appear on the
 - ADJUSTMENT FULL = EMPTY:

The adjustment values for empty pipe and full pipe are identical. In such instances, empty pipe adjustment/full pipe adjustment must be carried out again.

ADJUSTMENT NOT OK:

Adjustment is not possible as the fluid conductivity values are outside the permitted

(continued on next page)

EMPTY PIPE DETECTION (EPD) (continued)

Notes on empty pipe detection (EPD and OED)

- Flow cannot be measured correctly unless the measuring pipe is completely full. This status can be monitored at all times by means of the EPD/OED.
- An empty or partially filled pipe is a process error. A default factory setting defines that
 a fault message is issued and that this process error has an effect on the outputs.
- The EPD/OED process error can be output via the configurable status output.
- Use the function ASSIGN PROCESS ERROR to define whether a notice or fault message should be triggered (see Page 54).
- A plausibility check of the adjustment values will only be executed by activating the empty pipe detection. If an empty or full pipe adjustment is performed during the empty pipe detection is active, the empty pipe detection has to be de- and again activated, after finishing the adjustment, to start the plausibility check.

Response to partially filled pipes

If the EPD/OED is switched on and responds to a partially filled or empty pipe, the fault message "EMPTY PIPE" appears on the display. If the pipe is partially empty and the EPD/OED is ${\bf not}$ switched on, the response can vary in identically configured systems:

- Flow reading fluctuates
- Zero flow
- Excessively high flow values

Notes on Open Electrode Detection (OED)

Open Electrode Detection (OED) functions like the Empty Pipe Detection (EPD). In contrast to the EPD where the measuring device must be equipped with a separate (optional) electrode, the OED detects partial filling by means of the two measuring electrodes which are present as standard (fluid no longer covers the measuring electrodes).

Open electrode detection can also be used if:

- the sensor is not installed in the optimal position for using EPD (optimal = installed horizontally).
- the sensor is not equipped with an additional (optional) EPD electrode.



■ Cable connection length:

When mounting a remote version, please observe the maximum permissible cable length of 15 metres in order to keep the OED function.

■ OED empty pipe adjustment:

To achieve the best results for the open electrode detection, it is important to have the electrodes surface as dry as possible (no liquid film) while the empty-pipe adjustment is being made.

Even during normal operation, the OED function is only secured if there is no longer any liquid film present on the electrodes when the measuring pipe is empty.

EPD/OED ADJUSTMENT

Use this function to activate the $\ensuremath{\mathsf{EPD/OED}}$ adjustment for an empty or full measuring tube.



Note!

A detailed description and other helpful hints for the empty-pipe/full-pipe adjustment procedure can be found on Page 44.

Options:

OFF FULL PIPE ADJUST EMPTY PIPE ADJUST OED FULL ADJUST OED EMPTY ADJUST

Factory setting:

OFF

Procedure for EPD or OED empty-pipe / full-pipe adjustment

- Empty the piping. In case of an EPD adjustment, the wall of the measuring tube should be wetted with fluid for the adjustment procedure but this is not the case with an OED adjustment!
- 2. Start empty-pipe adjustment: Select "EMPTY PIPE ADJUST" or "OED EMPTY ADJUST" and press to confirm.
- 3. After empty-pipe adjustment, fill the piping with fluid.
- 4. Start full-pipe adjustment: Select "FULL PIPE ADJUST" or "OED FULL ADJUST" and press ₤ to confirm.
- 5. Having completed the adjustment, select the setting "OFF" and exit the function by pressing $\[\]$
- 6. Now select the "EMPTY PIPE DETECTION" function. Switch on Empty Pipe Detection by selecting the following settings:
 - EPD \rightarrow Select ON STANDARD or ON SPECIAL and press ${\ensuremath{\,^{\tiny \blacksquare}}}$ to confirm.
 - OED ightarrow Select OED and confirm with ${\ensuremath{\,^{ar{ar{ar}}}}}$.



Caution!

The adjustment coefficients must be valid before you can activate the EPD/OED function. If adjustment is incorrect the following messages might appear on the display:

- FULL = EMPTY

The adjustment values for empty pipe and full pipe are identical. In cases of this nature you **must** repeat empty-pipe or full-pipe adjustment **again!**

- ADJUSTMENT NOT OK

Adjustment is not possible because the fluid's conductivity is out of range.

Function description PROCESS PARAMETER This function is not available unless ON STANDARD, ON SPECIAL or OED was selected in the EMPTY PIPE DETECTION function. Use this function to enter the time span for which the criteria for an "empty" pipe have to be satisfied without interruption before a notice message or fault message is generated. The setting defined here is used by the active empty pipe detection (EPD) or open electrode detection (OED).

User input:

fixed-point number 1.0...100 s

Factory setting:

1.0 s



Note!

OED detection time:

The recognition of open electrodes is, in contrast to the empty pipe detection (EPD), very slow reacting (delay at least 25 seconds) and is only activated after an aditional delay from the programmed response time!

We recommend in most applications to use the empty pipe detection (EPD) which is an optimal solution for detecting partly filled measuring tubes.

ECC

EPD/OED RESPONSE

TIME



This function is not available unless the measuring device is equipped with the optional electrode cleaning function (ECC).

Use this function to activate cyclical electrode cleaning.

Options:

OFF ON

Factory setting:

ON (only if the optional electrode cleaning function ECC is available)

Notes on electrode cleaning (ECC)

Conductive deposits on the electrodes and on the walls of the measuring tube (e.g. magnetite) can falsify measurement values. The Electrode Cleaning Circuitry (ECC) was developed to prevent such conductive deposits accreting in the vicinity of the electrodes. ECC functions as described above for all available electrode materials except tantalum. If tantalum is used as the electrode material, the ECC protects the electrode surface only against oxidation.



Caution!

If the ECC is switched off for a prolonged period in applications with conductive deposits, a layer forms inside the measuring tube and this can falsify measurement values. If the layer is allowed to accrete beyond a certain level, it might no longer be possible to remove it by switching on the ECC. If this happens the measuring tube must be cleaned and the layer removed.

ECC DURATION



Note!

This function is not available unless the measuring device is equipped with the optional electrode cleaning function (ECC).

Use this function to specify the electrode cleaning duration.

User input:

fixed-point number 0.01...30.0 s

Factory setting:

 $2.0 \, s$

ECC RECOVERY TIME



This function is not available unless the measuring device is equipped with the optional electrode cleaning function (ECC).

Use this function to specify the recovery time for which the last flow value measured prior to cleaning is retained. A recovery time is necessary as the signal outputs can fluctuate after electrode cleaning on account of electrochemical interference voltages.

User input:

max. 3-digit number: 1... 600 s

Factory setting:



Caution!

The last value measured prior to cleaning is output for the duration of the recovery time (max. 600 s). This in turn means that the measuring system does not register changes in flow, e.g. stoppage, during this time span.

ECC CLEANING CYCLE



This function is not available unless the measuring device is equipped with the optional electrode cleaning function (ECC).

Use this function to specify the cleaning cycle for electrode cleaning.

User input:

Integer: 30...10080 min

Factory setting:

40 min

15 Group SYSTEM PARAMETERS

Function description SYSTEM PARAMETERS

INSTALLATION DIRECTION SENSOR

Use this function to reverse the sign of the flow quantity, if necessary.

Options:

NORMAL (flow as indicated by the arrow)

INVERSE (flow opposite to direction indicated by the arrow)

Factory setting:

NORMAL



Ascertain the actual direction of fluid flow with reference to the direction indicated by the arrow on the sensor (nameplate).

MEASURING MODE

Use this function to select the measuring mode for all outputs.

Options:

STANDARD SYMMETRY

Factory setting:

STANDARD


The responses of the individual outputs in each of the measuring modes are described in detail on the following pages:

Current output and frequency output

STANDARD

Only the flow components for the selected flow direction are totalled, (positive or negative full scale value @= flow direction). Flow components in the opposite direction are not taken into account (suppression).

Example for current output:



A0001248


SYMMETRY

The output signals of the current and frequency outputs are independent of the direction of flow (absolute amount of the measured variable).

The "VALUE 20 mA" or "VALUE-f HIGH" \cite{Migma} (e.g. backflow) corresponds to the mirrored VALUE 20 mA or VALUE-f HIGH \cite{Migma} (e.g. flow).

Positive and negative flow components are taken into account.

Example for current output:



A0001249



Note

The direction of flow can be output via the configurable status output.

(continued on next page)

Function description SYSTEM PARAMETERS

MEASURING MODE

(continued)

Pulse output

STANDARD

Only positive flow components are totalled. Negative components are not taken into account.

SYMMETRY

Positive and negative flow components are taken into account.



Note!

The direction of flow can be output via the configurable status output.

Status output



The information is only applicable if LIMIT VALUE was selected in the function ASSIGN STATUS OUTPUT.

STANDARD

The status output signal switches at the defined switch points.


The status output signal switches at the defined switch points, irrespective of the sign. In other words, if you define a switch point with a positive sign, the status output signal switches as soon as the value is reached in the negative direction (negative sign), (see illustration).

Example for the SYMMETRY measuring mode:

Switch-on point: Q = 4Switch-off point: Q = 10

① = Status output switched on (conductive)

2 = Status output switched off (not conductive)



A0001247

POSITIVE ZERO RETURN

Use this function to interrupt evaluation of measured variables.

This is necessary when a piping system is being cleaned, for example.

This setting acts on all function and outputs of the measuring device.

Options:

 $ON \longrightarrow Signal$ output is set to the "ZERO FLOW" value.

Factory setting:

OFF

50

Function description SYSTEM PARAMETERS SYSTEM DAMPING Use this function to set the filter depth of the digital filter. This reduces the sensitivity of the measuring signal to interference peaks (e.g. high solids content, gas bubbles in the fluid, etc.). The system reaction time decreases with an increasing filter setting. User input: 0...15 Factory setting: Note! The system damping acts on all functions and outputs of the measuring device. INTEGRATION TIME Use this function to set the integration time. Under normal circumstances it is not necessary to change the factory settings. User input: 3.3...65 ms Factory setting: 20 ms at 50 Hz \rightarrow mains frequency (e.g. Europe) 16.7 ms at 60 Hz \rightarrow mains frequency (e.g. USA) Caution! The integration time must not be selected with a greater value than the measuring period (see Page 53). Note! The integration time defines the duration of internal totaling of the induced voltage in the fluid (measured by the measuring electrode), i.e. the time in which the measuring device records the true flow (afterwards the magnetic field for the next integration is created from the opposite pole).

16 Group SENSOR DATA

Function description SENSOR DATA

All sensor data (calibration factors, zero point and nominal diameter etc.) are set at the factory and saved on the S-DAT sensor memory chip.



Caution!

Under normal circumstances you should not change the following parameter settings, because changes affect numerous functions of the entire measuring facility in general and the accuracy of the measuring system in particular. For this reason, the functions described below cannot be changed even when you enter your personal code.

Contact the Endress+Hauser service organization if you have any questions about these functions.

CALIBRATION DATE	Use this function to view the current calibration date and time for the sensor.
	User interface: Calibration date and time
	Factory setting: Calibration date and time of the current calibration.
	$\ \ \ \ $ Note! The calibration date and time format is defined in the FORMAT DATE TIME function, \rightarrow Page 9.
K-FACTOR	Use this function to display the current calibration factor for the sensor. The calibration factor is determined and set at the factory.
	User interface: 5-digit fixed-point number: 0.50002.0000
	Factory setting: Depends on nominal diameter and calibration
	Note! This value is also provided on the sensor nameplate.
ZERO POINT	This function shows the current zero-point correction value for the sensor. Zero-point correction is determined and set at the factory.
	User interface: max. 4-digit number: -1000+1000
	Factory setting: Depends on nominal diameter and calibration
	Note! This value is also provided on the sensor nameplate.
NOMINAL DIAMETER	This function shows the nominal diameter for the sensor. The nominal diameter depends on the size of the sensor and is set at the factory.
	User interface: 22000 mm or 1/1278"
	Factory setting: Depends on the size of the sensor
	Note! This value is also provided on the sensor nameplate.
1	

Function description SENSOR DATA		
MEASURING PERIOD	Use this function to set the time for a full measuring period. The duration of the measuring period is calculated from the rise time of the magnetic field, the brief recovery time, the integration time (which can be set) and the empty pipe detection time. User input: 0.01000 ms Factory setting: Depends on nominal diameter	
	Note! The system checks the time entered and sets the measuring period which is actually used internally to a plausible value. If you enter 0 ms, the system automatically computes the shortest time.	
OVERVOLTAGE TIME	Use this function to specify the time in which overvoltage is applied to the coil circuit in order to build up the magnetic field as fast as possible. The overvoltage time is adjusted automatically while measuring is in progress. The overvoltage time depends on the sensor type and the nominal diameter and is set at the factory. User interface: 4-digit floating-point number: 0.0100.0 ms Factory setting: Depends on nominal diameter	
EPD ELECTRODE	Use this function to check whether the sensor is equipped with an EPD electrode. User interface: YES NO Factory setting: YES → Electrode fitted as standard	
POLARITY ECC	Use this function to display the actual current polarity for optional electrode cleaning (ECC). Electrode cleaning uses either a positive or negative current, depending on the electrode material. The measuring device automatically selects the correct polarity on the basis of the electrode-material data stored in the S-DAT. User interface: POSITIVE → for electrodes made of: 1.4435, Hastelloy C, platinum, titanium NEGATIVE → for electrodes made of: tantalum Caution! If the incorrect current is applied to the electrodes, the electrode material is destroyed.	

17 Group SUPERVISION

Function description SUPERVISION		
CURRENT SYSTEM	Use this function to check the present system status.	
CONDITION	User interface: "SYSTEM OK" or the fault / notice message with the highest priority.	
PREVIOUS SYSTEM CONDITIONS	Use this function to view the fifteen most recent fault and notice messages since measuring last started.	
	User interface: The last 15 fault/notice messages appear on the display	
ASSIGN SYSTEM ERROR	Use this function to view all system errors and the associated error categories (fault message or notice message). By selecting a certain system error, its error category can be changed in the subsequent function ERROR CATEGORY.	
	Options: CANCEL List of system errors	
	Note! You can exit this function as follows: select "CANCEL" and confirm with A list of possible system errors is provided in the Operating Instructions Promag 50, BA 046D/06/en	
ERROR CATEGORY	Note! This function is only available if a system error has been selected in the function ASSIGN SYSTEM ERROR.	
	Use this function to define whether a system error triggers a notice message or a fault message. If you select FAULT MESSAGES, all outputs respond to an error in accordance with their defined error response patterns.	
	Options: NOTICE MESSAGES (display only) FAULT MESSAGES (outputs and display)	
	Note! Press the $\[\]$ key twice to call up the ASSIGN SYSTEM ERROR function.	
ASSIGN PROCESS ERROR	Use this function to view all process errors and the associated error categories (fault message or notice message). By selecting an individual process error, its error category can be changed in the subsequent function ERROR CATEGORY.	
	Options: CANCEL List of process errors	
	Note! You can exit this function as follows: select "CANCEL" and confirm with A list of possible process errors is provided in the Operating Instructions Promag 50, BA 046D/06/en	

Function description SUPERVISION		
ERROR CATEGORY	Note! This function is only available if a process error has been selected in the function ASSIGN PROCESS ERROR. Use this function to define whether a process error triggers a notice message or a fault message. If you select FAULT MESSAGES, all outputs respond to an error in accordance	
	with their defined error response patterns. Options: NOTICE MESSAGES (display only) FAULT MESSAGES (outputs and display) Note! Press the E key twice to call up the ASSIGN PROCESS ERROR function.	
ALARM DELAY	Use this function to define a time span in which the criteria for an error have to be satisfied without interruption before an error or notice message is generated. Depending on the setting and the type of error, this suppression acts on: Display Status output Current output	
	User input: 0100 s (in steps of one second) Factory setting: 0 s	
	If this function is activated error and notice messages are delayed by the time corresponding to the setting before being forwarded to the higher-order controller (process controller, etc.). It is therefore imperative to check in advance in order to make sure whether a delay of this nature could affect the safety requirements of the process. If error and notice messages cannot be suppressed, a value of 0 seconds must be entered here.	
SYSTEM RESET	Use this function to perform a reset of the measuring system. Options: NO	
	RESTART SYSTEM (restart without interrupting power supply) Factory setting: NO	
OPERATION HOURS	The hours of operation of the device appear on the display. Display: Depends on the number of hours of operation elapsed: Hours of operation < 10 hours → display format = 0:00:00 (hr:min:sec) Hours of operation 1010,000 hours → display format = 0000:00 (hr:min) Hours of operation > 10,000 hours → display format = 000000 (hr)	
PERMANENT STORAGE	This function indicates whether permanent storage of all parameters in the EEPROM has been switched on or off.	
	Factory setting: ON	

18 Group SIMULATION SYSTEM

Function description CHAIL ATION OVOTERS		
	Function description SIMULATION SYSTEM	
SIMULATION FAILSAFE MODE	Use this function to set all inputs, outputs and the totalizer to their defined failsafe modes, in order to check whether they respond correctly. During this time, the words "SIMULATION FAILSAFE MODE" appear on the display.	
	Options: ON OFF	
	Factory setting: OFF	
SIMULATION MEASURED VARIABLE	Use this function to set all inputs, outputs and the totalizer to their defined flow-response modes, in order to check whether they respond correctly. During this time, the words "SIMULATION MEASURAND" appear on the display.	
	Options: OFF VOLUME FLOW	
	Factory setting: OFF	
	Caution! The measuring device cannot be used for measuring while this simulation is in progress. The setting is not saved if the power supply fails.	
VALUE SIMULATION MEASURED VARIABLE	Note! This function is not available unless the SIMULATION MEASURED VARIABLE function is active (= VOLUME FLOW).	
	Use this function to specify a selectable value (e.g. $12~\mathrm{m}^3/\mathrm{s}$). This value is used to test downstream devices and the measuring device itself.	
	User input: 5-digit floating-point number, [unit]	
	Factory setting: 0 [unit]	
	Caution! The setting is not saved if the power supply fails.	
	Note! The appropriate unit is taken from the group SYSTEM UNITS, (see Page 8)	

19 Group SENSOR VERSION

	Function description SENSOR VERSION
SERIAL NUMBER	Use this function to view the serial number of the sensor.
SENSOR TYPE	Use this function to view the sensor type.
HARDWARE REVISION NUMBER SENSOR	Use this function to view the hardware revision number of the sensor.
SOFTWARE REVISION NUMBER S-DAT	Use this function to view the software revision number of the software used to create the content of the S-DAT

20 Group AMPLIFIER VERSION

Function description AMPLIFIER VERSION						
DEVICE SOFTWARE	Displays the current device software version.					
SOFTWARE REVISION NUMBER AMPLIFIER	Use this function to view the software revision number of the amplifier.					
LANGUAGE GROUP	Use this function to view the language group. The following language groups can be ordered: WEST EU / USA, EAST EU / SCAND., ASIA. Display: available language group Note! The language options of the available language group are displayed in the LANGUAGE function. You can change the language group via the configuration software FieldCare. Please do not hesitate to contact your Endress+Hauser sales office if you have any questions.					
I/O MODULE TYPE	Use this function to view the configuration of the I/O module complete with terminal numbers.					
SOFTWARE REVISION NUMBER I/O MODULE	Use this function to view the software revision number of the I/O module.					

21 Factory settings

21.1 SI units (not for USA and Canada)

Low flow, full scale value, pulse value, totalizer

Nominal	diameter	Low	flow	Full sca	ale value	Pulse	value	Totalizer
[mm]	[inch]	(approx. v	= 0.04 m/s)	(approx. v = 2.5 m/s)		(approx. 2 pulses/s at v = 2.5 m/s)		
2	1/12"	0.01	dm ³ /min	0.5	dm ³ /min	0.005	dm ³	dm ³
4	5/32"	0.05	dm ³ /min	2	dm ³ /min	0.025	dm ³	dm ³
8	⁵ / ₁₆ "	0.1	dm ³ /min	8	dm ³ /min	0.10	dm^3	dm^3
15	1/2"	0.5	dm ³ /min	25	dm ³ /min	0.20	dm ³	dm^3
25	1"	1	dm ³ /min	75	dm ³ /min	0.50	dm ³	dm^3
32	1 1/4"	2	dm ³ /min	125	dm ³ /min	1.00	dm ³	dm^3
40	1 1/2"	3	dm ³ /min	200	dm ³ /min	1.50	dm ³	dm ³
50	2"	5	dm ³ /min	300	dm ³ /min	2.50	dm^3	dm^3
65	2 1/2"	8	dm ³ /min	500	dm ³ /min	5.00	dm ³	dm^3
80	3"	12	dm ³ /min	750	dm ³ /min	5.00	dm ³	dm^3
100	4"	20	dm ³ /min	1200	dm ³ /min	10.00	dm ³	dm^3
125	5"	30	dm ³ /min	1850	dm ³ /min	15.00	dm ³	dm^3
150	6"	2.5	m ³ /h	150	m ³ /h	0.025	m^3	m^3
200	8"	5.0	m ³ /h	300	m ³ /h	0.05	m^3	m^3
250	10"	7.5	m ³ /h	500	m ³ /h	0.05	m^3	m^3
300	12"	10	m ³ /h	750	m ³ /h	0.10	m^3	m^3
350	14"	15	m ³ /h	1000	m ³ /h	0.10	m^3	m^3
400	16"	20	m ³ /h	1200	m ³ /h	0.15	m ³	m^3
450	18"	25	m ³ /h	1500	m ³ /h	0.25	m ³	m^3
500	20"	30	m ³ /h	2000	m ³ /h	0.25	m ³	m^3
600	24"	40	m ³ /h	2500	m ³ /h	0.30	m^3	m^3
700	28"	50	m ³ /h	3500	m ³ /h	0.50	m^3	m^3
_	30"	60	m ³ /h	4000	m ³ /h	0.50	m ³	m^3
800	32"	75	m ³ /h	4500	m ³ /h	0.75	m ³	m^3
900	36"	100	m ³ /h	6000	m ³ /h	0.75	m ³	m^3
1000	40"	125	m ³ /h	7000	m ³ /h	1.00	m ³	m^3
_	42"	125	m ³ /h	8000	m ³ /h	1.00	m ³	m^3
1200	48"	150	m ³ /h	10000	m ³ /h	1.50	m ³	m^3
_	54"	200	m ³ /h	13000	m ³ /h	1.50	m ³	m^3
1400	-	225	m ³ /h	14000	m ³ /h	2.00	m ³	m^3
_	60"	250	m ³ /h	16000	m ³ /h	2.00	m ³	m^3
1600	-	300	m ³ /h	18000	m ³ /h	2.50	m ³	m^3
_	66"	325	m ³ /h	20500	m ³ /h	2.50	m ³	m^3
1800	72"	350	m ³ /h	23000	m ³ /h	3.00	m ³	m^3
-	78"	450	m ³ /h	28500	m ³ /h	3.50	m ³	m^3
2000	_	450	m ³ /h	28500	m ³ /h	3.50	m ³	m^3

Language

Country	Language
Australia	English
Austria	Deutsch
Belgium	English
Czech Republic	Czech
Denmark	English
England	English
Finland	Suomi
France	Français
Germany	Deutsch
Hong Kong	English
Hungary	English
India	English
Indonesia	Bahasa Indonesia
Instruments International	English
Italy	Italiano
Japan	Japanese
Malaysia	English
Netherlands	Nederlands
Norway	Norsk
Poland	Polish
Portugal	Portuguese
Russia	Russian
Singapore	English
South Africa	English
Spain	Espanol
Sweden	Svenska
Switzerland	Deutsch
Thailand	English

Length

	Unit
Length	mm

21.2 US units (only for USA and Canada)

Low flow, full scale value, pulse value, totalizer

Nominal diameter		Low flow		Full scale value		Pulse value		Totalizer
[inch]	[mm]	(approx. v	= 0.04 m/s)	(approx. $v = 2.5 \text{ m/s}$)		(approx. 2 pulses/s at $v = 2.5 \text{ m/s}$)		
1/12"	2	0.002	gal/min	0.1	gal/min	0.001	gal	gal
5/32"	4	0.008	gal/min	0.5	gal/min	0.005	gal	gal
5/16"	8	0.025	gal/min	2	gal/min	0.02	gal	gal
1/2"	15	0.10	gal/min	6	gal/min	0.05	gal	gal
1"	25	0.25	gal/min	18	gal/min	0.20	gal	gal
1 1/4"	32	0.50	gal/min	30	gal/min	0.20	gal	gal
1 1/2"	40	0.75	gal/min	50	gal/min	0.50	gal	gal
2"	50	1.25	gal/min	75	gal/min	0.50	gal	gal
2 1/2"	65	2.0	gal/min	130	gal/min	1	gal	gal
3"	80	2.5	gal/min	200	gal/min	2	gal	gal
4"	100	4.0	gal/min	300	gal/min	2	gal	gal
5"	125	7.0	gal/min	450	gal/min	5	gal	gal
6"	150	12	gal/min	600	gal/min	5	gal	gal
8"	200	15	gal/min	1200	gal/min	10	gal	gal
10"	250	30	gal/min	1500	gal/min	15	gal	gal
12"	300	45	gal/min	2400	gal/min	25	gal	gal
14"	350	60	gal/min	3600	gal/min	30	gal	gal
16"	400	60	gal/min	4800	gal/min	50	gal	gal
18"	450	90	gal/min	6000	gal/min	50	gal	gal
20"	500	120	gal/min	7500	gal/min	75	gal	gal
24"	600	180	gal/min	10500	gal/min	100	gal	gal
28"	700	210	gal/min	13500	gal/min	125	gal	gal
30"	_	270	gal/min	16500	gal/min	150	gal	gal
32"	800	300	gal/min	19500	gal/min	200	gal	gal
36"	900	360	gal/min	24000	gal/min	225	gal	gal
40"	1000	480	gal/min	30000	gal/min	250	gal	gal
42"	_	600	gal/min	33000	gal/min	250	gal	gal
48"	1200	600	gal/min	42000	gal/min	400	gal	gal
54"	_	1.3	Mgal/d	75	Mgal/d	0.0005	Mgal	Mgal
_	1400	1.3	Mgal/d	85	Mgal/d	0.0005	Mgal	Mgal
60"	-	1.3	Mgal/d	95	Mgal/d	0.0005	Mgal	Mgal
-	1600	1.7	Mgal/d	110	Mgal/d	0.0008	Mgal	Mgal
66"	-	2.2	Mgal/d	120	Mgal/d	0.0008	Mgal	Mgal
72"	1800	2.6	Mgal/d	140	Mgal/d	0.0008	Mgal	Mgal
78"	_	3.0	Mgal/d	175	Mgal/d	0.001	Mgal	Mgal
_	2000	3.0	Mgal/d	175	Mgal/d	0.001	Mgal	Mgal

Language, length

	Unit
Language	English
Length	inch

22	Index of key words	Response time
		End value frequency
Nume	rics	Error category
100% V	alue	Process error
_		System error
Α		F
	code	
	evel (status input)	Factory settings
Actual	21	Current output
	rent	Frequency output
-	uency	Pulse output
	elay (notice or fault messages)	Totalizer
Assign	ciay (nouce of fault incoolages)	Flow damping (system damping) 51
0	rent output	Format (display)
	lay line 1	Frequency (High value)
_	lay line 2	Function matrix
_	uency	Layout and use
Low	flow cut off	Overview 6
	ess error	G
	e	
	as input	Group Amplifier version
	is output	Communication
	em error	Current output
Lota	lizer	Handling totalizer
В		Measuring values
	ress	Operation
Dab aaa		Process parameter
C		Pulse/frequency output
Code		Quick Setup
	ess code	Sensor data
	nter (Unlocking)	Sensor version
	ate code	Simulation system
	sioning Quick Setup	Status input
	t LCD	Status output
Current	Spail 20	System parameters
D		System units
Device 1	D	Totalizer
	Revision	User interface
Device s	software 57	
Display		H
	dight	Hardware revision number (sensor)
	trast LCD	HART Protocol
	ping	I
	nat	I/O module type (input/output type)
Test		Installation direction sensor
Е		Integration time
	ectrode cleaning)	
,	ning cycle	K
	ation	K-Factor
	rity	T
Reco	very time	L
	Pipe Detection (EPD/OED)	Language
	electrode	Factory settings
	/OED adjustment	Language group (display)
Gen	eral information	Selection

Low flow cut off	1	Measured variable	56
Off value	43	Pulses	32
On value	43	Status input	40
		Switch point	35
M		Software revision number	
Manufacturer ID		Amplifier	
Measuring mode		Device Software	
Measuring period		I/O Module	
Minimum pulse width	40	S-DAT	
N		Status access	12
Nominal diameter	52	Status output	0.5
Nonliniai diameter	<i>J</i> Z	Flow direction	
0		General	
OED (Open electrode detection)		Limit value	
see Empty Pipe Detection	44	Storage	JC
Off value		permanent	55
Low flow cut off	43	Sum (totalizer)	
Status output	35	System	10
On value		Current conditions	54
Low flow cut off	43	Damping (flow damping)	
Status output		Operation hours	
Operation hours		Previous conditions	
Operation mode (pulse/frequency output)	23	Reset	
Output signal	0.4		
Frequency output		T	
Pulse		Tag	
Overflow (totalizer)		Description	
Overvoltage time	33	Name	
P		Test display	15
Permanent storage	55	Time constant	0.1
Polarity ECC		Current output	
Positive zero return		Frequency output	
Previous system conditions		Status output	
Pulse value		Totalizer Assign	
Pulse width		Failsafe mode	
		Mode	
Q		Overflow	
Quick Setup commissioning	10	Reset	
R		Reset all totalizers	
		Unit selection	
Reset All totalizers	1 Ω		
System		U	
Totalizer		Unit	
Totalizor	•	Length	
S		Totalizer	
Sensor		Volume	
Installation direction	49	Volume flow	. ბ
K-Factor	52	V	
Measuring period	53	Value	
Overvoltage time		20 mA	21
Sensor type		f high	
Serial number		Failsafe level	
Zero point	52	Value simulation	
Simulation		Current	22
Current		Frequency	
Failsafe mode		Measured variable	
Frequency	ZÖ	Pulse	

Status input	41
Switch point	36
Volume flow (display)	. 7
Z	
Zero point	52

www.endress.com/worldwide



People for Process Automation



















Technical Information

Proline Promag 50P, 53P

Electromagnetic Flow Measuring System Flow measurement of liquids in chemical or process applications





Application

Electromagnetic flowmeter for bidirectional measurement of liquids with a minimum conductivity of $\geq 5~\mu S/cm$:

- Acid, alkalis
- Paints
- Pastes
- Water, wastewater etc.
- Flow measurement up to 9600 m³/h (42268 gal/min)
- Fluid temperature up to +180 °C (356 °F)
- Process pressures up to 40 bar (580 psi)
- Lengths in accordance with DVGW/ISO

Application-specific lining materials:

- PTFE
- PFA

Approvals for hazardous area:

- ATEX
- IECEx
- FM
- CSA
- NEPSI
- TIIS

Connection to process control system:

- HART
- PROFIBUS DP/PA
- FOUNDATION Fieldbus
- MODBUS RS485

Your benefits

Promag measuring devices offer you cost-effective flow measurement with a high degree of accuracy for a wide range of process conditions.

The uniform Proline transmitter concept comprises:

- Modular device and operating concept resulting in a higher degree of efficiency
- Software options for batching, electrode cleaning and for measuring pulsating flow
- High degree of reliability and measuring stability
- Uniform operating concept

The tried-and-tested Promag sensors offer:

- No pressure loss
- Not sensitive to vibrations
- Simple installation and commissioning



Table of contents

Function and system design
Measuring principle
Measuring system
Input
Measured variable
Measuring ranges
Operable flow range
Input signal
input signal4
Output
Output signal
Signal on alarm
Load6
Low flow cutoff
Galvanic isolation
Switching output
Power supply
Electrical connection, measuring unit
Electrical connection, terminal assignment
Electrical connection, remote version
Supply voltage (power supply)
Cable entry
Remote version cable specifications
Power consumption
Power supply failure
Potential equalization
Performance characteristics13
Reference operating conditions
Maximum measured error
Repeatability
Operating conditions: Installations
Installation instructions
Installation instructions
Adapters
Length of connecting capie
Operating conditions: Environment20
Ambient temperature range
Storage temperature
Degree of protection
Shock and vibration resistance
Electromagnetic compatibility (EMC)20
Operating conditions: Process
Medium temperature range
Conductivity
Medium pressure range monunal pressurer
Medium pressure range (nominal pressure)
Pressure tightness
Pressure tightness


Mechanical construction	25
Design, dimensions	. 25
Weight	
Measuring tube specifications	
Material	
Material load diagram	
Fitted electrodes	
Process connections	
Surface roughness	. 40
Human interface	41
Display elements	. 41
Operating elements	
Language groups	. 41
Remote operation	. 41
Certificates and approvals	42
CE mark	
C-tick mark	
Pressure measuring device approval	
Ex approval	
Other standards and guidelines	
FOUNDATION Fieldbus certification	
MODBUS RS485 certification	
PROFIBUS DP/PA certification	. 42
Ordering information	43
Accessories	43
Documentation	43
Registered trademarks	43

Function and system design

Measuring principle

Following Faraday's law of magnetic induction, a voltage is induced in a conductor moving through a magnetic field.

In the electromagnetic measuring principle, the flowing medium is the moving conductor. The voltage induced is proportional to the flow velocity and is supplied to the amplifier by means of two measuring electrodes. The flow volume is calculated by means of the pipe cross-sectional area. The DC magnetic field is created through a switched direct current of alternating polarity.



 $Ue = B \cdot L \cdot v$ $Q = A \cdot v$

Ue Induced voltage

B Magnetic induction (magnetic field)

L Electrode spacing
v Flow velocity
Q Volume flow
A Pipe cross-section
I Current strength

Measuring system

The measuring system consists of a transmitter and a sensor.

Two versions are available:

- Compact version: Transmitter and sensor form a mechanical unit.

Transmitter:

- Promag 50 (user interface with push buttons for operation, two-line display, illuminated)
- Promag 53 ("Touch Control" without opening the housing, four-line display, unilluminated)

Sensor

■ Promag P (DN 15 to 600 / ½ to 24")

Input

Measured variable	Flow velocity (proportional to induced voltage)	
Measuring ranges	Measuring ranges for liquids Typically $v=0.01$ to 10 m/s (0.03 to 33 ft/s) with the specified accuracy	
Operable flow range	Over 1000 : 1	
Input signal	Status input (auxiliary input) $U = 3 \text{ to } 30 \text{ V DC}, R_i = 5 \text{ k}\Omega$, galvanically isolated Configurable for: totalizer(s) reset, measured value suppression, error-message reset	
	Status input (auxiliary input) with PROFIBUS DP and MODBUS RS485 • $U = 3 \text{ to } 30 \text{ V DC}$, $R_i = 3 \text{ k}\Omega$, galvanically isolated	

- Switching level: 3 to 30 V DC, independent of polarity
- Configurable for: totalizer(s) reset, measured value suppression, error-message reset, batching start/stop (optional), batch totalizer reset (optional)

Current input (only Promag 53)

- active/passive selectable, galvanically isolated, full scale value selectable, resolution: 3 μA, temperature coefficient: typ. 0.005% o.r./°C (o.r. = of reading)
- active: 4 to 20 mA, $R_i \le 150 \Omega$, max. 24 V DC, short-circuit-proof
- passive: 0/4 to 20 mA, $R_i < 150 \Omega$, max. 30 V DC

Output

Output signal

Promag 50

Current output

active/passive selectable, galvanically isolated, time constant selectable (0.01 to 100 s),

full scale value selectable, temperature coefficient: typ. 0.005% o.r./°C (o.r. = of reading), resolution: 0.5 μA

- active: 0/4 to 20 mA, $R_L < 700 \Omega$ (HART: $R_L \ge 250 \Omega$)
- passive: 4 to 20 mA, operating voltage V_s : 18 to 30 V DC, $R_i \ge 150 \Omega$

Pulse/frequency output

passive, open collector, 30 V DC, 250 mA, galvanically isolated

- Frequency output: full scale frequency 2 to 1000 Hz (f_{max} = 1250 Hz), on/off ratio 1:1, pulse width max. 10s
- Pulse output: pulse value and pulse polarity selectable, max. pulse width configurable (0.5 to 2000 ms)

PROFIBUS DP interface

- Transmission technology (Physical Layer): RS485 in accordance with ANSI/TIA/EIA-485-A: 1998, galvanically isolated
- Profil version 3.0
- Data transmission rate: 9,6 kBaud to 12 MBaud
- Automatic data transmission rate recognition
- Function blocks: 1 × analog Input, 1 × totalizer
- Output data: volume flow, totalizer
- Input data: positive zero return (ON/OFF), totalizer control, value for local display
- Cyclic data transmission compatible with previous model Promag 33
- Bus address adjustable via miniature switches or local display (optional) at the measuring device

PROFIBUS PA interface

- Transmission technology (Physical Layer): IEC 61158-2 (MBP), galvanically isolated
- Profil version 3.0
- Current consumption: 11 mA
- Permissible supply voltage: 9 to 32 V
- Bus connection with integrated reverse polarity protection
- Error current FDE (Fault Disconnection Electronic): 0 mA
- Function blocks: 1 × analog input, 2 × totalizer
- Output data: volume flow, totalizer
- Input data: positive zero return (ON/OFF), control totalizer, value for local display
- Cyclic data transmission compatible with previous model Promag 33
- Bus address adjustable via miniature switches or local display (optional) at the measuring device

Promag 53

Current output

active/passive selectable, galvanically isolated, time constant selectable (0.01 to 100 s),

full scale value selectable, temperature coefficient: typ. 0.005% o.r./°C (o.r. = of reading), resolution: 0.5 μA

- active: 0/4 to 20 mA, $R_I < 700 \Omega$ (HART: $R_I \ge 250 \Omega$)
- \blacksquare passive: 4 to 20 mA, operating voltage V_S : 18 to 30 V DC, $R_i \geq$ 150 Ω

Pulse/frequency output

active/passive selectable, galvanically isolated (Ex i version: only passive)

- active: 24 V DC, 25 mA (max. 250 mA during 20 ms), $R_L > 100 \Omega$
- passive: open collector, 30 V DC, 250 mA
- Frequency output: full scale frequency 2 to 10000 Hz ($f_{max} = 12500 \text{ Hz}$), EEx-ia: 2 to 5000 Hz; on/off ratio 1:1, pulse width max. 10 s
- Pulse output: pulse value and pulse polarity selectable, max. pulse width configurable (0.05 to 2000 ms)

PROFIBUS DP interface

- Transmission technology (Physical Layer): RS485 in accordance with ANSI/TIA/EIA-485-A: 1998, galvanically isolated
- Profil version 3.0
- Data transmission rate: 9,6 kBaud to 12 MBaud
- Automatic data transmission rate recognition
- Function blocks: 2 × analog Input, 3 × totalizer
- Output data: volume flow, calculated mass flow, totalizer 1 to 3
- Input data: positive zero return (ON/OFF), totalizer control, value for local display
- Cyclic data transmission compatible with previous model Promag 33
- Bus address adjustable via miniature switches or local display (optional) at the measuring device
- Available output combination \rightarrow $\stackrel{\triangle}{=}$ 8

PROFIBUS PA interface

- Transmission technology (Physical Layer): IEC 61158-2 (MBP), galvanically isolated
- Profil version 3.0
- Current consumption: 11 mA
- Permissible supply voltage: 9 to 32 V
- \blacksquare Bus connection with integrated reverse polarity protection
- Error current FDE (Fault Disconnection Electronic): 0 mA
- Function blocks: 2 × analog input, 3 × totalizer
- Output data: volume flow, calculated mass flow, totalizer 1 to 3
- Input data: positive zero return (ON/OFF), totalizer control, value for local display
- Cyclic data transmission compatible with previous model Promag 33
- Bus address adjustable via miniature switches or local display (optional) at the measuring device

MODBUS RS485 interface

- Transmission technology (Physical Layer): RS485 in accordance with ANSI/TIA/EIA-485-A: 1998, galvanically isolated
- MODBUS device type: Slave
- Adress range: 1 to 247
- Bus address adjustable via miniature switches or local display (optional) at the measuring device
- Supported MODBUS function codes: 03, 04, 06, 08, 16, 23
- Broadcast: supported with the function codes 06, 16, 23
- Übertragungsmodus: RTU oder ASCII
- Supported baudrate: 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200 Baud
- Response time:
 - Direct data access = typically 25 to 50 ms
 - Auto-scan buffer (data range) = typically 3 to 5 ms
- Available output combination \rightarrow $\stackrel{\triangle}{=}$ 8

FOUNDATION Fieldbus interface

- FOUNDATION Fieldbus H1
- Transmission technology (Physical Layer): IEC 61158-2 (MBP), galvanically isolated
- ITK version 5.01
- Current consumption: 12 mA
- Error current FDE (Fault Disconnection Electronic): 0 mA
- Bus connection with integrated reverse polarity protection
- Function blocks:
 - $-5 \times$ Analog Input (execution time: 18 ms each)
 - $-1 \times PID (25 \text{ ms})$
 - 1 × Digital Output (18 ms)
 - 1 × Signal Characterizer (20 ms)
 - $-1 \times \text{Input Selector}$ (20 ms)
 - $-1 \times Arithmetic (20 ms)$
 - $-1 \times Integrator (18 ms)$
- Output data: volume flow, calculated mass flow, temperature, totalizer 1 to 3
- Input data: positive zero return (ON/OFF), reset totalizer
- Link Master (LM) functionality is supported

Signal on alarm

- Current output → failure response selectable (e.g. in accordance with NAMUR recommendation NE 43)
- Pulse/frequency output → failure response selectable
- Status output (Promag 50) → non-conductive by fault or power supply failure
- Relay output (Promag 53) \rightarrow de-energized by fault or power supply failure

Load

see "Output signal"

Low flow cutoff

Switch points for low flow cutoff are selectable.

Galvanic isolation

All circuits for inputs, outputs and power supply are galvanically isolated from each other.

Switching output

Status output (Promag 50, Promag 53)

Open collector, max. 30 V DC / 250 mA, galvanically isolated.


Configurable for: error messages, Empty Pipe Detection (EPD), flow direction, limit values.

Relay outputs (Promag 53)

Normally closed (NC or break) or normally open (NO or make) contacts available (default: relay 1 = NO, relay 2 = NC), max. 30 V / 0,5 A AC; 60 V / 0,1 A DC, galvanically isolated. Configurable for: error messages, Empty Pipe Detection (EPD), flow direction, limit values, batching contacts.

Power supply

Electrical connection, measuring unit



Connecting the transmitter, cable cross-section max. 2.5 mm² (14 AWG)

- A View A (field housing)
- B View B (stainless steel field housing)
- C View C (wall-mount housing)
- *) fixed communication boards
- **) flexible communication boards
- a Connection compartment cover
- Cable for power supply: 85 to 260 V AC / 20 to 55 V AC / 16 to 62 V DC
 - Terminal No. 1: L1 for AC, L+ for DC
 - Terminal No. 2: N for AC, L- for DC
- c Ground terminal for protective conductor
- d Signal cable: see "Electrical connection, terminal assignment" $\rightarrow \triangle$ 8 Fieldbus cable:
 - Terminal No. 26: DP (B) / PA + / FF + / MODBUS RS485 (B) / (PA, FF: with polarity protection)
 - Terminal No. 27: DP (A) / PA / FF / MODBUS RS485 (A) / (PA, FF: with polarity protection)
- e Ground terminal for signal cable shield / Fieldbus cable / RS485 line
- f Service adapter for connecting service interface FXA193 (Fieldcheck, FieldCare)
- g Signal cable: see "Electrical connection, terminal assignment" → 🖹 8 Cable for external termination (only for PROFIBUS DP with fixed assignment communication board):
 - Terminal No. 24: +5 V
 - Terminal No. 25: DGND

Electrical connection, terminal assignment

Terminal assignment, Promag 50

Order variant		Termir	nal No. (inputs/outputs)	
	20 (+) / 21 (-)	22 (+) / 23 (-)	24 (+) / 25 (-)	26 (+) / 27 (-)
50***_*******	-	_	_	Current output HART
50***-********A	_	_	Frequency output	Current output HART
50***-********D	Status input	Status output	Frequency output	Current output HART
50***-*********	-	_	-	PROFIBUS PA
50***_***********J	-	-	+5 V (external termination)	PROFIBUS DP
50***_******	-	-	Frequency output, Ex i, passive	Current output, Ex i, passive, HART
50***_*********T	-	-	Frequency output, Ex i, passive	Current output, Ex i, passive, HART

Ground terminal $\rightarrow 17$


Terminal assignment, Promag 53

The inputs and outputs on the communication board can be either permanently assigned or variable, depending on the version ordered (see table). Replacements for modules which are defective or which have to be replaced can be ordered as accessories.

Order variant	Terminal No. (inputs/outputs)									
	20 (+) / 21 (-)	22 (+) / 23 (-)	24 (+) / 25 (-)	26 (+) / 27 (-)						
Fixed communication boo	ards (fixed assignm	ent)								
53***-********A	_	-	Frequency output	Current output HART						
53***-********B	Relay output 2	Relay output 1	Frequency output	Current output HART						
53***-*********F	_	-	_	PROFIBUS PA, Ex i						
53***-*********G	_	-	_	FOUNDATION Fieldbus, Ex i						
53***-*********	_	-	_	PROFIBUS PA						
53***-*********J	_	-	_	PROFIBUS DP						
53***-*******	_	-	_	FOUNDATION Fieldbus						
53***-********	_	-	Status input	MODBUS RS485						
53***_******	_	-	Frequency output, Ex i	Current output, Ex i, passive, HART						
53***_********	_	-	Frequency output, Ex i	Current output, Ex i, passive, HART						
Flexible communication l	boards									
53***-*********C	Relay output 2	Relay output 1	Frequency output	Current output HART						
53***-********D	Status input	Relay output	Frequency output	Current output HART						
53***-*********L	Status input	Relay output 2	Relay output 1	Current output HART						
53***-********M	Status input	Frequency output	Frequency output	Current output HART						
53***-********N	Current output	Frequency output	Status input	MODBUS RS485						
53***-*********P	Current output	Frequency output	Status input	PROFIBUS DP						
53***-********V	Relay output 2	Relay output 1	Status input	PROFIBUS DP						
53***-*********2	Relay output	Current output	Frequency output	Current output HART						
53***-********	Current input	Relay output	Frequency output	Current output HART						
53***-********	Status input	Current input	Frequency output	Current output HART						
53***-*********	Relay output 2	Relay output 1	Status input	MODBUS RS485						

Ground terminal \rightarrow $\stackrel{\triangle}{=}$ 7

Electrical connection, remote version



Connecting the remote version

- a Wall-mount housing connection compartment
- b Sensor connection housing cover
- c Signal cable
- d Coil current cable
- n.c. Not connected, insulated cable shields

Terminal no. and cable colors: 6/5 = brown; 7/8 = white; 4 = green; 36/37 = yellow

Supply voltage (power supply)

- 85 to 260 V AC, 45 to 65 Hz
- 20 to 55 V AC, 45 to 65 Hz
- 16 to 62 V DC

PROFIBUS PA and FOUNDATION Fieldbus

- Non-Ex: 9 to 32 V DC
- Ex i: 9 to 24 V DC
- Ex d: 9 to 32 V DC

Cable entry

Power supply and signal cables (inputs/outputs):

- Cable entry M20 \times 1.5 (8 to 12 mm / 0.31 to 0.47")
- Sensor cable entry for armoured cables $M20 \times 1.5$ (9.5 to 16 mm / 0.37 to 0.63")
- Thread for cable entries, ½" NPT, G ½"

Connecting cable for remote version:

- Cable entry M20 × 1.5 (8 to 12 mm / 0.31 to 0.47")
- Sensor cable entry for armoured cables $M20 \times 1.5$ (9.5 to 16 mm / 0.37 to 0.63")
- Thread for cable entries, ½" NPT, G ½"


Remote version cable specifications

Coil cable

- $2 \times 0.75 \text{ mm}^2$ (18 AWG) PVC cable with common, braided copper shield ($\varnothing \sim 7 \text{ mm} / 0.28$ ")
- Conductor resistance: $\leq 37 \Omega/\text{km} (\leq 0.011 \Omega/\text{ft})$
- Capacitance core/core, shield grounded: ≤ 120 pF/m (≤ 37 pF/ft)
- Operating temperature: -20 to +80 °C (-68 to +176 °F)
- Cable cross-section: max. 2.5 mm² (14 AWG)
- Test voltage for cable insulation: ≤ 1433 AC r.m.s. 50/60 Hz or ≥ 2026 V DC

Signal cable

- $3 \times 0.38 \text{ mm}^2$ (20 AWG) PVC cable with common, braided copper shield ($\varnothing \sim 7 \text{ mm} / 0.28$ ") and individual shielded cores
- With empty pipe detection (EPD): $4 \times 0.38 \text{ mm}^2$ (20 AWG) PVC cable with common, braided copper shield ($\varnothing \sim 7 \text{ mm} / 0.28$ ") and individual shielded cores
- Conductor resistance: $\leq 50 \Omega/\text{km} (\leq 0.015 \Omega/\text{ft})$
- Capacitance core/shield: ≤ 420 pF/m (≤ 128 pF/ft)
- Operating temperature: -20 to +80 °C (-68 to +176 °F)
- Cable cross-section: max. 2.5 mm² (14 AWG)



- a Signal cable
- b Coil current cable
- 1 Core
- 2 Core insulation
- 3 Core shield
- 4 Core jacket
- 5 Core reinforcement
- 6 Cable shield
- 7 Outer jacket

Operation in zones of severe electrical interference

The measuring device complies with the general safety requirements in accordance with EN 61010 and the EMC requirements of IEC/EN 61326 and NAMUR recommendation NE 21.



Caution!

Grounding is by means of the ground terminals provided for the purpose inside the connection housing. Ensure that the stripped and twisted lengths of cable shield to the ground terminal are as short as possible.

Power consumption

- AC: < 15 VA (incl. sensor)
- \blacksquare DC: < 15 W (incl. sensor)

Switch-on current:

- Max. 3 A (< 5 ms) for 260 V AC
- Max. 13.5 A (< 50 ms) for 24 V DC

Power supply failure

Lasting min. $\frac{1}{2}$ cycle frequency: EEPROM saves measuring system data

- EEPROM or T-DAT (Promag 53 only) retain the measuring system data in the event of a power supply failure
- S-DAT: exchangeable data storage chip which stores the data of the sensor (nominal diameter, serial number, calibration factor, zero point etc.)

Potential equalization



Warning!

The measuring system must be included in the potential equalization.

Perfect measurement is only ensured when the fluid and the sensor have the same electrical potential. This is ensured by the reference electrode integrated in the sensor as standard.

The following should also be taken into consideration for potential equalization:

- Internal grounding concepts in the company
- Operating conditions, such as the material/ grounding of the pipes (see table)

Standard situation

Operating conditions Potential equalization When using the measuring device in a: ■ Metal, grounded pipe Potential equalization takes place via the ground terminal of the transmitter. Note! When installing in metal pipes, we recommend you connect the ground terminal of the transmitter housing with the piping. Via the ground terminal of the transmitter

Special situations

Operating conditions

When using the measuring device in a:

■ Metal pipe that is not grounded

This connection method also applies in situations where:

- Customary potential equalization cannot be ensured.
- Excessively high equalizing currents can be expected.

Both sensor flanges are connected to the pipe flange by means of a ground cable (copper wire, at least 6 $\mbox{mm}^2 \, / \, 0.0093 \ \mbox{in}^2)$ and grounded. Connect the transmitter or sensor connection housing, as applicable, to ground potential by means of the ground terminal provided for the purpose.


- DN \leq 300 (12"): the ground cable is mounted directly on the conductive flange coating with the flange screws.
- DN \geq 350 (14"): the ground cable is mounted directly on the transportation metal support.



Note!

The ground cable for flange-to-flange connections can be ordered separately as an accessory from Endress+Hauser.

Potential equalization



Via the ground terminal of the transmitter and the flanges of the pipe


When using the measuring device in a:

- Plastic pipe
- Pipe with insulating lining

This connection method also applies in situations where:

- Customary potential equalization cannot be ensured.
- Excessively high equalizing currents can be expected.

Potential equalization takes place using additional ground disks, which are connected to the ground terminal via a ground cable (copper wire, at least 6 mm² / 0.0093 in²). When installing the ground disks, please comply with the enclosed Installation Instructions.



Via the ground terminal of the transmitter and the optionally available ground disks

Operating conditions

When using the measuring device in a:


■ Pipe with a cathodic protection unit

The device is installed potential-free in the pipe. Only the two flanges of the pipe are connected with a ground cable (copper wire, at least 6 $\,\mathrm{mm^2}$ / 0.0093 in²). Here, the ground cable is mounted directly on the conductive flange coating with flange screws.

Note the following when installing:

- The applicable regulations regarding potential-free installation must be observed.
- There should be **no** electrically conductive connection between the pipe and the device.
- The mounting material must withstand the applicable torques.

Potential equalization



Potential equalization and cathodic protection

- Power supply isolation transformer
- P. Electrically isolated

12

Performance characteristics

Reference operating conditions

As per DIN EN 29104 and VDI/VDE 2641:

- Fluid temperature: +28 °C \pm 2 K (+82 °F \pm 2 K)
- Ambient temperature: +22 °C ± 2 K (+72 °F ± 2 K)
- Warm-up period: 30 minutes

Installation conditions:

- Inlet run $> 10 \times DN$
- Outlet run $> 5 \times DN$
- Sensor and transmitter grounded.
- The sensor is centered in the pipe.

Maximum measured error


Promag 50:

- Current output: also typically \pm 5 μA
- Pulse output: $\pm 0.5\%$ o.r. ± 1 mm/s ($\pm 0.5\%$ o.r. ± 0.04 in/s) optional: $\pm 0.2\%$ o.r. ± 2 mm/s ($\pm 0.2\%$ o.r. ± 0.08 in/s) (o.r. = of reading)

Promag 53:

- Current output: also typically \pm 5 μ A
- Pulse output: $\pm 0.2\%$ o.r. ± 2 mm/s ($\pm 0.2\%$ o.r. ± 0.08 in/s) (o.r. = of reading)

Fluctuations in the supply voltage do not have any effect within the specified range.



Max. measured error in % of reading

Repeatability

Max. $\pm 0.1\%$ o.r. ± 0.5 mm/s ($\pm 0.1\%$ o.r. ± 0.02 in/s) (o.r. = of reading)


Operating conditions: Installations

Installation instructions

Mounting location

Entrained air or gas bubble formation in the measuring tube can result in an increase in measuring errors. **Avoid** the following installation locations in the pipe:


- Highest point of a pipeline. Risk of air accumulating!
- Directly upstream from a free pipe outlet in a vertical pipeline.



Mounting location

Installation of pumps

Sensors may not be installed on the pump suction side. This precaution is to avoid low pressure and the consequent risk of damage to the lining of the measuring tube. Information on the pressure tightness of the measuring tube lining $\rightarrow \stackrel{\text{\tiny lin}}{=} 22$, Section "Pressure tightness".



Installation of pumps

Partially filled pipes


Partially filled pipes with gradients necessitate a drain-type configuration.

The empty pipe detection function (EPD) provides additional security in detecting empty or partially filled pipes.



Caution!


Risk of solids accumulating. Do not install the sensor at the lowest point in the drain. It is advisable to install a cleaning valve.



Installation with partially filled pipes

Down pipes

Install a siphon or a vent valve downstream of the sensor in down pipes $h \ge 5$ m (16.4 ft). This precaution is to avoid low pressure and the consequent risk of damage to the lining of the measuring tube. This measure also prevents the liquid current stopping in the pipe which could cause air locks. Information on the pressure tightness of the measuring tube lining $\rightarrow \stackrel{\triangle}{=} 22$, Section "Pressure tightness".



A0011

Installation measures for vertical pipes


- 1 Vent valve
- 2 Pipe siphon
- h Length of the down pipe

Orientation

An optimum orientation helps avoid gas and air accumulations and deposits in the measuring tube. However, the measuring device also offers the additional function of empty pipe detection (EPD) for detecting partially filled measuring tubes or if outgassing fluids or fluctuating operating pressures are present.

Vertical orientation

This is the ideal orientation for self-emptying piping systems and for use in conjunction with empty pipe detection.



Vertical orientation


Horizontal orientation

The measuring electrode axis should be horizontal. This prevents brief insulation of the two measuring electrodes by entrained air bubbles.



Caution

Empty pipe detection only works correctly with horizontal orientation if the transmitter housing is facing upwards. Otherwise there is no guarantee that empty pipe detection will respond if the measuring tube is only partially filled or empty.



Horizontal orientation

- 1 EPD electrode for empty pipe detection
- 2 Measuring electrodes for signal detection
- 3 Reference electrode for potential equalization

16


Vibrations

Secure the piping and the sensor if vibration is severe.



Caution!

If vibrations are too severe, we recommend the sensor and transmitter be mounted separately. Information on the permitted shock and vibration resistance $\rightarrow \stackrel{\text{\tiny le}}{=} 20$, Section "Shock and vibration resistance".



Measures to prevent vibration of the measuring device

L > 10 m (33 ft)


Foundations, supports

If the nominal diameter is DN \geq 350, mount the transmitter on a foundation of adequate load-bearing strength.



Caution!

Do not allow the casing to take the weight of the sensor. This would buckle the casing and damage the internal magnetic coils.




Inlet and outlet run

If possible, install the sensor well clear of assemblies such as valves, T-pieces, elbows etc.

Note the following inlet and outlet runs to comply with measuring accuracy specifications:

Inlet run: ≥ 5 × DNOutlet run: ≥ 2 × DN



Inlet and outlet run

Adapters


Suitable adapters to DIN EN 545 (double-flange reducers) can be used to install the sensor in larger-diameter pipes. The resultant increase in the rate of flow improves measuring accuracy with very slow-moving fluids. The nomogram shown here can be used to calculate the pressure loss caused by reducers and expanders.



Note!

The nomogram only applies to liquids of viscosity similar to water.

- 1. Calculate the ratio of the diameters d/D.
- 2. From the nomogram read off the pressure loss as a function of flow velocity (downstream from the reduction) and the d/D ratio.




Pressure loss due to adapters

18

Length of connecting cable

When mounting the remote version, please note the following to achieve correct measuring results:

- Fix cable run or lay in armored conduit. Cable movements can falsify the measuring signal especially in the case of low fluid conductivities.
- Route the cable well clear of electrical machines and switching elements.
- If necessary, ensure potential equalization between sensor and transmitter.
- The permitted cable length L_{max} is determined by the fluid conductivity. A minimum conductivity of 20 μ S/cm is required for measuring demineralized water.
- When the empty pipe detection function is switched on (EPD), the maximum connecting cable length is 10 m (33 ft).



Permitted length of connecting cable for remote version Area marked in gray = permitted range; L_{max} = length of connecting cable in [m] ([ft]); fluid conductivity in [μ S/cm]

Operating conditions: Environment

Ambient temperature range

Transmitter

- Standard: -20 to +60 °C (-4 to +140 °F)
- Optional: -40 to +60 °C (-40 to +140 °F)



Note

At ambient temperatures below -20 °C (-4 °F)the readability of the display may be impaired.

Sensor

- Flange material carbon steel: -10 to +60 °C (+14 to +140 °F)
- Flange material stainless steel: -40 to +60 °C (-40 to +140 °F)



Caution!

The permitted temperature range of the measuring tube lining may not be undershot or overshot $\rightarrow \stackrel{\triangle}{=} 21$, Section "Medium temperature range".

Please note the following points:

- Install the device in a shady location. Avoid direct sunlight, particularly in warm climatic regions.
- The transmitter must be mounted separate from the sensor if both the ambient and fluid temperatures are high.

Storage temperature

The storage temperature corresponds to the operating temperature range of the measuring transmitter and the appropriate measuring sensors.



Caution!

- The measuring device must be protected against direct sunlight during storage in order to avoid unacceptably high surface temperatures.
- A storage location must be selected where moisture does not collect in the measuring device. This will help prevent fungus and bacteria infestation which can damage the liner.
- Do not remove the protective plates or caps on the process connections until the device is ready to install.

Degree of protection

- Standard: IP 67 (NEMA 4X) for transmitter and sensor.
- Optional: IP 68 (NEMA 6P) for sensor for remote version.
- For information regarding applications where the device is buried directly in the soil or is installed in a flooded wastewater basin please contact your local Endress+Hauser Sales Center.

Shock and vibration resistance

Acceleration up to 2 g following IEC 600 68-2-6

Electromagnetic compatibility (EMC)


■ As per IEC/EN 61326 and NAMUR recommendation NE 21.

Operating conditions: Process

Medium temperature range

The permitted temperature depends on the lining of the measuring tube:

- PTFE: -40 to +130 °C (-40 to +266 °F) (DN 15 to 600 / ½ to 24"), restrictions \rightarrow see diagrams
- PFA: -20 to +180 °C (-4 to +356 °F) (DN 25 to 200 / 1 to 8"), restrictions \rightarrow see diagrams




Compact version (with PFA or PTFE lining)

 T_A = Ambient temperature, T_F = Fluid temperature, HT = High temperature version with insulatio

① Gray shaded area \rightarrow temperature range from -10 to -40 °C (-14 to -40 °F) applies only to stainless steel flanges

② HE + IP 68 to 130 °C (266 °F) only



Remote version (with PFA or PTFE lining)

 $T_A = Ambient temperature, T_F = Fluid temperature, HT = High temperature version with insulation$

① Gray shaded area \rightarrow temperature range from -10 to -40 °C (-14 to -40 °F) applies only to stainless steel flanges

② HE + IP 68 to 130 °C (266 °F) only

Conductivity

The minimum conductivity is:

- $\geq 5 \mu S/cm$ for fluids generally
- \geq 20 µS/cm for demineralized water



Notel

In the remote version, the necessary minimum conductivity also depends on the cable length ($\rightarrow \stackrel{\text{le}}{=} 19$, Section "Length of connecting cable").

Medium pressure range (nominal pressure)

- EN 1092-1 (DIN 2501)
 - PN 10 (DN 200 to 600 / 8 to 24")
 - PN 16 (DN 65 to 600 / 3 to 24")
 - $-\,$ PN 25 (DN 200 to 600 / 8 to 24")
 - PN 40 (DN 15 to 150 / ½ to 6")
- ANSI B 16.5
 - Class 150 (DN ½ to 24")
 - Class 300 (DN ½ to 6")
- JIS B2220
 - 10 K (DN 50 to 300 / 2 to 12")
 - 20 K (DN 15 to 300 / ½ to 12")
- AS 2129
 - Table E (DN 25, 50 / 1", 2")
- AS 4087
 - PN 16 (DN 50 / 2")

Pressure tightness

Measuring tube lining: PTFE

Nominal	diameter		Limit value	es for abs. p	ressure [m	bar] ([psi])	at fluid ter	nperatures:	:		
		25 °C	(77 °F)	80 °C (176 °F)	100 °C	(212 °F)	130 °C	(266 °F)		
[mm]	[inch]	[mbar]	[psi]	[mbar]	[psi]	[mbar]	[psi]	[mbar]	[psi]		
15	1/2"	0	0	0	0	0	0	100	1.45		
25	1"	0	0	0	0	0	0	100	1.45		
32	_	0	0	0	0	0	0	100	1.45		
40	11/2"	0	0	0	0	0	0	100	1.45		
50	2"	0	0	0	0	0	0	100	1.45		
65	_	0	0	*	*	40	0.58	130	1.89		
80	3"	0	0	*	*	40	0.58	130	1.89		
100	4"	0	0	*	*	135	1.96	170	2.47		
125	-	135	1.96	*	*	240	3.48	385	5.58		
150	6"	135	1.96	*	*	240	3.48	385	5.58		
200	8"	200	2.90	*	*	290	4.21	410	5.95		
250	10"	330	4.79	*	*	400	5.80	530	7.69		
300	12"	400	5.80	*	*	500	7.25	630	9.14		
350	14"	470	6.82	*	*	600	8.70	730	10.6		
400	16"	540 7.83 * * 670 9.72 800 11.0									
450	18"										
500	20"			Part	ial vacuum i	is impermissi	ble!				
600	24"										

^{*} No value can be specified.

22

Measuring tube lining: PFA

Nominal	diameter	Liı	mit values for	abs. pressure	[mbar] ([psi]) at fluid tempera	atures:	
		25 °C	(77 °F)	80 °C (176 °F)	100 to 180 °C (212 to 356 °F)		
[mm]	[inch]	[mbar]	[psi]	[mbar]	[psi]	[mbar]	[psi]	
25	1"	0	0	0	0	0	0	
32	-	0	0	0	0	0	0	
40	11/2"	0	0	0	0	0	0	
50	2"	0	0	0	0	0	0	
65	_	0	0	*	*	0	0	
80	3"	0	0	*	*	0	0	
100	4"	0	0	*	*	0	0	
125	-	0	0	*	*	0	0	
150	6"	0	0	*	*	0	0	
200	8"	0	0	*	*	0	0	

^{*} No value can be specified.

Limiting flow

The diameter of the pipe and the flow rate determine the nominal diameter of the sensor.

The optimum flow velocity is between 2 to 3 m/s (6.5 to 9.8 ft/s). The velocity of flow (v), moreover, has to be matched to the physical properties of the fluid:

- v < 2 m/s (6.5 ft/s): for abrasive fluids such as potter's clay, lime milk, ore slurry etc.
- v > 2 m/s (6.5 ft/s): for fluids causing build-up such as wastewater sludges etc.

Flow characteristic values (SI units)											
Diam	neter	Recommended flow rate	Fact	ory settings							
[mm]	[inch]	Min./max. full scale value (v ~ 0.3 or 10 m/s)	Full scale value, current output $(v \sim 2.5 \text{ m/s})$	Pulse value (~ 2 pulses/s)	Low flow cut off (v ~ 0.04 m/s)						
15	1/2"	4 to 100 dm ³ /min	25 dm ³ /min	0.20 dm ³	0.50 dm ³ /min						
25	1"	9 to 300 dm ³ /min	75 dm ³ /min	$0.50 dm^3$	1.00 dm ³ /min						
32	-	15 to 500 dm ³ /min	125 dm ³ /min	1.00 dm ³	2.00 dm ³ /min						
40	11/2"	25 to 700 dm ³ /min	200 dm ³ /min	1.50 dm ³	3.00 dm ³ /min						
50	2"	35 to 1100 dm ³ /min	300 dm ³ /min	$2.50 dm^3$	5.00 dm ³ /min						
65	_	60 to 2000 dm ³ /min	500 dm ³ /min	5.00 dm ³	8.00 dm ³ /min						
80	3"	90 to 3000 dm ³ /min	750 dm ³ /min	5.00 dm ³	12.0 dm ³ /min						
100	4"	145 to 4700 dm ³ /min	1200 dm ³ /min	10.0 dm ³	20.0 dm ³ /min						
125	_	220 to 7500 dm ³ /min	1850 dm ³ /min	15.0 dm ³	30.0 dm ³ /min						
150	6"	20 to 600 m ³ /h	150 m ³ /h	0.03 m ³	2.50 m ³ /h						
200	8"	35 to 1100 m ³ /h	300 m ³ /h	0.05 m ³	5.00 m ³ /h						
250	10"	55 to 1700 m ³ /h	500 m ³ /h	0.05 m ³	7.50 m ³ /h						
300	12"	80 to 2400 m ³ /h	750 m ³ /h	0.10 m ³	10.0 m ³ /h						
350	14"	110 to 3300 m ³ /h	1000 m ³ /h	0.10 m ³	15.0 m ³ /h						
400	16"	140 to 4200 m ³ /h	1200 m ³ /h	0.15 m ³	20.0 m ³ /h						
450	18"	180 to 5400 m ³ /h	1500 m ³ /h	0.25 m ³	25.0 m ³ /h						
500	20"	220 to 6600 m ³ /h	2000 m ³ /h	0.25 m ³	30.0 m ³ /h						
600	24"	310 to 9600 m ³ /h	2500 m ³ /h	0.30 m ³	40.0 m ³ /h						


Flow cl	haracteri	istic values (US u	nits)						
Dian	neter	Recommended	flow rate		Fact	ory settings	3		
[inch]	[mm]	Min./max. full so (v ~ 0.3 or 10			, current output 5 m/s)	Pulse va (~ 2 puls			ow cut off 0.04 m/s)
1/2"	25	1.0 to 26	gal/min	6	gal/min	0.10	gal	0.15	gal/min
1"	25	2.5 to 80	gal/min	18	gal/min	0.20	gal	0.25	gal/min
11/2"	40	7 to 190	gal/min	50	gal/min	0.50	gal	0.75	gal/min
2"	50	10 to 300	gal/min	75	gal/min	0.50	gal	1.25	gal/min
3"	80	24 to 800	gal/min	200	gal/min	2.00	gal	2.50	gal/min
4"	100	40 to 1250	gal/min	300	gal/min	2.00	gal	4.00	gal/min
6"	150	90 to 2650	gal/min	600	gal/min	5.00	gal	12.0	gal/min
8"	200	155 to 4850	gal/min	1200	gal/min	10.0	gal	15.0	gal/min
10"	250	250 to 7500	gal/min	1500	gal/min	15.0	gal	30.0	gal/min
12"	300	350 to 10600	gal/min	2400	gal/min	25.0	gal	45.0	gal/min
14"	350	500 to 15000	gal/min	3600	gal/min	30.0	gal	60.0	gal/min
16"	400	600 to 19000	gal/min	4800	gal/min	50.0	gal	60.0	gal/min
18"	450	800 to 24000	gal/min	6000	gal/min	50.0	gal	90.0	gal/min
20"	500	1000 to 30000	gal/min	7500	gal/min	75.0	gal	120.0	gal/min
24"	600	1400 to 44000	gal/min	10500	gal/min	100.0	gal	180.0	gal/min

Pressure loss

Mechanical construction

Design, dimensions

Transmitter remote version, wall-mount housing (non Ex-zone and II3G/Zone 2)



Dimensions (SI units)

A	В	С	D	Е	F	G	Н	J
215	250	90.5	159.5	135	90	45	> 50	81
K	L	М	N	0	Р	α	R	S
53	95	53	102	81.5	11.5	192	8 × M5	20


All dimensions in [mm]

Dimensions (US units)

A	В	С	D	Е	F	G	Н	J
8.46	9.84	3.56	6.27	5.31	3.54	1.77	> 1.97	3.18
K	L	М	N	0	P	α	R	S
2.08	3.74	2.08	4.01	3.20	0.45	7.55	8 × M5	0.79

All dimensions in [inch]

Transmitter remote version, connection housing (II2GD/Zone 1)



A0002128

Dimensions (SI units)

А	A*	В	В*	С	D	Е	ØF	G	Н	J	K	L	М
265	242	240	217	206	186	178	8.6 (M8)	100	130	100	144	170	355

All dimensions in [mm]

Dimensions (US units)


Α	A*	В	В*	С	D	Е	ØF	G	Н	J	K	L	М
10.4	9.53	9.45	8.54	8.11	7.32	7.01	0.34 (M8)	3.94	5.12	3.94	5.67	6.69	14.0

All dimensions in [inch]


There is a separate mounting kit for the wall-mounted housing. It can be ordered from Endress+Hauser as an accessory. The following installation variants are possible:

- lacktriangle Panel-mounted installation
- Pipe mounting


Installation in control panel




Pipe mounting



$Compact\ version\ DN \leq 300\ (12")$



High temperature version DN \leq 300 (12")



Measurement D1, E1 = Measurement D, E of the standard compact version plus 110 mm (4.33")

Dimensions (SI units)

DN	L 1)	A	A*	В	С	D	Е	F	G	Н	K
EN (DIN) / JIS / AS ²⁾											
15	200						341	257	84	94	120
25	200						341	257	84	94	120
32	200						341	257	84	94	120
40	200						341	257	84	94	120
50	200						341	257	84	94	120
65	200						391	282	109	94	180
80	200	227	207	187	168	160	391	282	109	94	180
100	250						391	282	109	94	180
125	250						472	322	150	140	260
150	300						472	322	150	140	260
200	350						527	347	180	156	324
250	450						577	372	205	166	400
300	500						627	397	230	166	460


Dimensions (US units)

DN	L 1)	А	A*	В	С	D	Е	F	G	Н	K
ANSI											
1/2"	7.87						13.4	10.1	3.31	3.70	4.72
1"	7.87						13.4	10.1	3.31	3.70	4.72
11/2"	7.87						13.4	10.1	3.31	3.70	4.72
2"	7.87						13.4	10.1	3.31	3.70	4.72
3"	7.87	8.94	8.15	7.36	6.61	6.30	15.4	11.1	4.29	3.70	7.09
4"	9.84	0.94	0.13	7.30	0.01	0.30	15.4	11.1	4.29	3.70	7.09
6"	11.8						18.6	12.7	5.91	5.51	10.2
8"	13.8						20.8	13.7	7.09	6.14	12.8
10"	17.7						22.7	14.7	8.07	6.54	15.8
12"	19.7						24.7	15.6	9.06	6.54	18.1

 $^{^{1)}}$ The length is regardless of the pressure rating selected. Fitting length to DVGW. All dimensions in [inch]

¹⁾ The length is regardless of the pressure rating selected. Fitting length to DVGW.
²⁾ Only DN 25 and DN 50 are available for flanges according to AS.
All dimensions in [mm]

$Compact\ version\ DN \geq 350\ (14")$



A000542

Dimensions (SI units)

DN	L 1)	A	A*	В	С	D	Е	F	G	Н	J
EN (DIN)											
350	550						738.5	456.5	282.0	564	276
400	600						790.5	482.5	308.0	616	276
450	650	227	207	187	168	160	840.5	507.5	333.0	666	292
500	650						891.5	533.0	358.5	717	292
600	780						995.5	585.0	410.5	821	402

 $^{^{1)}\,\}mbox{The length}$ is regardless of the pressure rating selected. Fitting length to DVGW. All dimensions in [mm]


Dimensions (US units)

DN	L 1)	A	A*	В	С	D	Е	F	G	Н	J
ANSI											
14"	21.7						29.1	18.0	11.1	22.2	10.9
16"	23.6						31.1	19.0	12.1	24.3	10.9
18"	25.6	8.94	8.15	7.36	6.61	6.30	33.1	20.0	13.1	26.2	11.5
20"	25.6						35.1	21.0	14.1	28.2	11.5
24"	30.7						39.2	23.0	16.2	32.3	15.8


 $^{^{1)}}$ The length is regardless of the pressure rating selected. Fitting length to DVGW. All dimensions in [inch] $\,$

30

Sensor, remote version DN $\leq 300 \ (12")$



High temperature version $DN \le 300 (12")$



Measurement D1, E1 = Measurement D, E of the standard remote version plus 110 mm (4.33")

Dimensions (SI units)

DN	L 1)	А	В	С	D	Е	F	G	Н	J
EN (DIN) / JIS / AS ²⁾										
15	200					286	202	84	120	94
25	200					286	202	84	120	94
32	200					286	202	84	120	94
40	200					286	202	84	120	94
50	200					286	202	84	120	94
65	200					336	227	109	180	94
80	200	129	163	143	102	336	227	109	180	94
100	250					336	227	109	180	94
125	250					417	267	150	260	140
150	300					417	267	150	260	140
200	350					472	292	180	324	156
250	450					522	317	205	400	166
300	500					572	342	230	460	166


Dimensions (US units)

DN	L 1)	А	В	С	D	Е	F	G	Н	J
ANSI										
1/2"	7.87					11.3	7.95	3.31	4.72	3.70
1"	7.87					11.3	7.95	3.31	4.72	3.70
11/2"	7.87					11.3	7.95	3.31	4.72	3.70
2"	7.87					11.3	7.95	3.31	4.72	3.70
3"	7.87	E 00	6.40	5.63	4.02	13.2	8.94	4.29	7.09	3.70
4"	9.84	5.08	6.42	3.03	4.02	13.2	8.94	4.29	7.09	3.70
6"	11.8					16.4	10.5	5.91	10.2	5.51
8"	13.8					18.6	11.5	7.08	12.8	6.14
10"	17.7					20.6	12.5	8.07	15.8	6.54
12"	19.7					22.5	13.5	9.06	18.1	6.54

 $^{^{1)}}$ The length is regardless of the pressure rating selected. Fitting length to DVGW. All dimensions in [inch]

¹⁾ The length is regardless of the pressure rating selected. Fitting length to DVGW. ²⁾ Only DN 25 and DN 50 are available for flanges according to AS. All dimensions in [mm]

Sensor, remote version $DN \geq 350 \ (14")$



Dimensions (SI units)

DN	L 1)	А	В	С	D	Е	F	G	Н	J
EN (DIN)										
350	550					683.5	401.5	282.0	564	276
400	600					735.5	427.5	308.0	616	276
450	650	129	163	143	102	785.5	452.5	333.0	666	292
500	650					836.5	478.0	358.5	717	292
600	780					940.5	530.0	410.5	821	402


 $^{^{\}rm 1)}$ The length is regardless of the pressure rating selected. Fitting length to DVGW. All dimensions in [mm]

Dimensions (US units)

DN	L 1)	А	В	С	D	Е	F	G	Н	J
ANSI										
14"	21.7					26.9	15.8	11.1	22.2	10.9
16"	23.6					29.0	16.8	12.1	24.3	10.9
18"	25.6	5.08	6.42	5.63	4.02	30.9	17.8	13.1	26.2	11.5
20"	25.6					32.9	18.8	14.1	28.2	11.5
24"	30.7					37.0	20.9	16.2	32.3	15.8

 $^{^{\}rm 1)}$ The length is regardless of the pressure rating selected. Fitting length to DVGW. All dimensions in [inch]

Ground disk for flange connections



Dimensions (SI units)

DN 1)	A	В	С	D	Е	t
EN (DIN) / JIS / AS ²⁾	PTFE, PFA					
15	16	43	61.5	73		
25	26	62	77.5	87.5		
32	35	80	87.5	94.5		
40	41	82	101	103		
50	52	101	115.5	108		
65	68	121	131.5	118		
80	80	131	154.5	135	6 E	
100	104	156	186.5	153	6.5	
125	130	187	206.5	160		
150	158	217	256	184		2
200	206	267	288	205		
250	260	328	359	240		
3003)	312	375	413	273		
3004)	310	375	404	268		
350 ³⁾	343	433	479	365		
4003)	393	480	542	395		
450 ³⁾	439	538	583	417	9.0	
500 ³⁾	493	592	650	460		
6003)	593	693	766	522		

 $^{^{1)}}$ Ground disks at DN 15 to 250 (½ to 10") can be used for all flange standards/pressure ratings. $^{2)}$ Only DN 25 and DN 50 are available for flanges according to AS.

³⁾ PN 10/16 4) PN 25, JIS 10K/20K

All dimensions in [mm]

Dimensions (US units)

DN 1)	A	В	С	D	Е	t
ANSI	PTFE, PFA					
1/2"	0.63	1.69	2.42	2.87		
1"	1.02	2.44	3.05	3.44		
11/2"	1.61	3.23	3.98	4.06		
2"	2.05	3.98	4.55	4.25		
3"	3.15	5.16	6.08	5.31	0.26	
4"	4.09	6.14	7.34	6.02	0.20	
6"	6.22	8.54	10.08	7.24		
8"	8.11	10.5	11.3	8.07		0.08
10"	10.2	12.9	14.1	9.45		
12"	12.3	14.8	16.3	10.8		
14"	13.5	17.1	18.9	14.4		
16"	15.45	18.9	21.3	15.6		
18"	17.3	21.2	23.0	16.4	0.35	
20"	19.4	23.3	25.6	18.1		
24"	23.4	27.3	30.1	20.6		

¹⁾ Ground disks can be used for all flange standards/pressure ratings. All dimensions in [inch]

Weight Weight in SI units

Weigh	t data i	n kg														
	ninal		C	omp	act versi	on				Re	mote vei	sion	(withou	t cable)		
diam	neter									S	ensor			Transmitter		
[mm]	[inch]		(DIN) / AS ¹⁾		JIS		ANSI		(DIN) / AS ¹⁾		JIS		ANSI	Wall-mount housing		
15	1/2"		6.5		6.5		6.5		4.5		4.5		4.5			
25	1"		7.3		7.3		7.3		5.3		5.3		5.3			
32	-	PN 40	8.0		7.3		-	PN 40	6.0		5.3		-			
40	11/2"	H	9.4		8.3		9.4	Щ.	7.4		6.3		7.4			
50	2"		10.6		9.3		10.6		8.6		7.3		8.6			
65	-		12.0		11.1		-		10.0		9.1					
80	3"		14.0	10K	12.5		14.0		12.0	10K	10.5		12.0			
100	4"	PN 16	16.0		14.7		16.0	PN 16	14.0		12.7		14.0			
125	-	Д	21.5		21.0	150	-	Д,-	19.5		19.0	150	-	6.0		
150	6"		25.5		24.5	Class 150	25.5		23.5		22.5	Class	23.5	0.0		
200	8"		45		41.9		45		43		39.9		43			
250	10"		65		69.4		75		63		67.4		73			
300	12"		70		72.3		110		68		70.3		108			
350	14"	10	115				175	10	113				173			
400	16"	PN	135				205	PN	133				203			
450	18"		175				255		173				253			
500	20"		175				285		173				283			
600	24"		235				405		233				403			

¹⁾ For flanges to AS, only DN 25 and 50 are available.

Transmitter (compact version): 3.4 kg, high temperature version: +1.5 kg
 Weight data valid for standard pressure ratings and without packaging material.

Weight in US units (only ANSI)

Weight data	a in lbs								
Nominal	diameter		Compact version		Remote version (v	vithout cable)			
					Sensor	Transmitter			
[mm]	[inch]		ANSI		ANSI	Wall-mount housing			
15	1/2"		14.3		9.92				
25	1"		16.1		11.7				
40	1½"		20.7		16.3				
50	2"		23.4		19.0				
80	3"		30.9		26.5				
100	4"		35.3		30.9				
150	6"	20	56.2	00	51.8				
200	8"	Class 150	99.2	Class 150	94.8	13.2			
250	10"	ਹੋ	165.4	ਹੋ	161.0				
300	12"		242.6		238.1				
350	14"		385.9		381.5				
400	16"		452.0		447.6				
450	18"		562.3		557.9				
500	20"		628.4		624.0				
600	24"		893.0		888.6				

- Transmitter (compact version): 7.50 lbs, high temperature version: +3.31 lbs
 Weight data valid for standard pressure ratings and without packaging material.

Measuring tube specifications

Dian	neter		P	ressure ratin	ıg]	Internal	diamete	r
		EN (DIN)	AS 2129	AS 4087	ANSI	JIS	Pl	FA	PT	'FE
[mm]	[inch]	[bar]			[lbs]		[mm]	[inch]	[mm]	[inch]
15	1/2"	PN 40	-	-	C1.150	20K	-	-	15	0.59
25	1"	PN 40	Table E	-	Cl.150	20K	23	0.91	26	1.02
32	_	PN 40	-	-	-	20K	32	1.26	35	1.38
40	11/2"	PN 40	_	_	Cl.150	20K	36	1.42	41	1.61
50	2"	PN 40	Table E	PN 16	Cl.150	10K	48	1.89	52	2.05
65	_	PN 16	-	-	-	10K	63	2.48	67	2.64
80	3"	PN 16	_	-	Cl.150	10K	75	2.95	80	3.15
100	4"	PN 16	_	_	Cl.150	10K	101	3.98	104	4.09
125	-	PN 16	_	-	-	10K	126	4.96	129	5.08
150	6"	PN 16	-	-	Cl.150	10K	154	6.06	156	6.14
200	8"	PN 10	_	-	Cl.150	10K	201	7.91	202	7.95
250	10"	PN 10	_	-	Cl.150	10K	-		256	10.1
300	12"	PN 10	_	-	Cl.150	10K	-		306	12.0
350	14"	PN 10	_	_	Cl.150	-	-	-	337	13.3
400	16"	PN 10	_	-	Cl.150	-	-	-	387	15.2
450	18"	PN 10	-	-	Cl.150	-			432	17.0
500	20"	PN 10	-	-	Cl.150	-	-	-	487	19.2
600	24"	PN 10	-	-	C1.150	-	-	23	593	23.3

Material

- Transmitter housing
 - Compact housing: powder-coated die-cast aluminum
 - Wall-mount housing: powder-coated die-cast aluminum
- Sensor housing
 - DN 25 to 300 (1 to 12"): powder-coated die-cast aluminum
 - DN 350 to 600 (14 to 24"): with protective lacquering
- Measuring tube
 - DN \leq 300 (12"): stainless steel 1.4301 or 1.4306/304L; (for flanges made of carbon steel with Al/Zn protective coating)
 - DN \ge 350 (14"): stainless steel 1.4301 or 1.4306/304L; (for flanges made of carbon steel with protective lacquering)
- Electrodes: 1.4435, Platinum, Alloy C-22, Tantalum, Titanium
- Flanges
 - EN 1092-1 (DIN 2501): 1.4571/316L; RSt37-2 (S235JRG2); C22; FE 410W B (DN \leq 300 (12"): with Al/Zn protective coating; DN \geq 350 (14") with protective lacquering)
 - ANSI: A105; F316L
 - (DN \leq 300 (12"): with Al/Zn protective coating; DN \geq 350 (14") with protective lacquering)
 - AWWA: 1.0425
 - JIS: RSt37-2 (S235JRG2); HII; 1.0425/316L $(DN \le 300 (12"))$; with Al/Zn protective coating; $DN \ge 350 (14")$ with protective lacquering)
 - - DN 25 (1"): A105 or RSt37-2 (S235JRG2)
 - DN 40 (1 ½"): A105 or St44-2 (S275JR)
 - AS 4087: A105 or St44-2 (S275JR)
- Seals: to DIN EN 1514-1
- Ground disks: 1.4435/316L or Alloy C-22

Material load diagram




Caution!

The following diagrams contain material load diagrams (reference curves) for flange materials with regard to the medium temperature. However, the maximum medium temperatures permitted always depend on the lining material of the sensor and/or the sealing material ($\rightarrow \stackrel{\triangle}{=} 21$).


Flange connection to EN 1092-1 (DIN 2501)

Material: RSt37-2 (S235JRG2) / C22 / Fe 410W B




Flange connection to EN 1092-1 (DIN 2501)

Material: 316L / 1.4571




Flange connection to ANSI B16.5

Material: A 105



Flange connection to ANSI B16.5


Material: F316L



A000530

Flange connection to JIS B2220


Material: RSt37-2 (S235JRG2) / HII / 1.0425 / 316L



A000322

Flange connection to AS 2129 Table E or AS 4087 PN 16

Material: A105 / RSt37-2 (S235JRG2) / St44-2 (S275JR)



A0005595

Fitted electrodes

Measuring electrodes, reference electrodes and empty pipe detection electrodes:

- Standard available with 1.4435, Alloy C-22, tantalum, platinum/rhodium 80/20, titanium
- Optional: measuring electrodes made of platinum/rhodium 80/20

Process connections

Flange connection:

- EN 1092-1 (DIN 2501), DN \leq 300 (12") form A, DN \geq 350 (14") form B (Dimensions to DIN 2501, DN 65 PN 16 and DN 600 (24") PN 16 exclusively to EN 1092-1)
- ANSI B16.5
- JIS B2220
- AS 2129 Table E
- AS 4087 PN 16

Surface roughness

- PFA liner: $\leq 0.4 \, \mu \text{m} \, (15.7 \, \mu \text{in})$
- Elektroden
 - 1.4435, Alloy C-22, titanium: \leq 0.3 to 0.5 μ m (\leq 11.8 to 19.7 μ in)
 - − Tantal, Platin/Rhodium: ≤ 0.3 to 0.5 µm (≤ 11.8 to 19.7 µin)

(All data refer to parts in contact with medium)

Human interface

Display elements

- Liquid crystal display: backlit, two lines (Promag 50) or four lines (Promag 53) with 16 characters per line
- Custom configurations for presenting different measured-value and status variables
- Totalizer
 - Promag 50: 2 totalizers
 - Promag 53: 3 totalizers

Operating elements

Unified operation concept for both types of transmitter:

Promag 50:

- Local operation via three keys (□, ±, ₺)
- Quick Setup menus for straightforward commissioning

Promag 53:

- Local operation via three keys (□, ±, ₺)
- Application-specific Quick Setup menus for straightforward commissioning

Language groups

Language groups available for operation in different countries:

Promag 50, Promag 53:

- Western Europe and America (WEA):
 English, German, Spanish, Italian, French, Dutch, Portuguese
- Eastern Europe and Scandinavia (EES):
 English, Russian, Polish, Norwegian, Finnish, Swedish, Czech
- South and east Asia (SEA): English, Japanese, Indonesian

Promag 53:

■ China (CN): English, Chinese

You can change the language group via the operating program "FieldCare".

Remote operation

- Promag 50: Remote control via HART, PROFIBUS DP/PA
- Promag 53: Remote control via HART, PROFIBUS DP/PA, MODBUS RS485, FOUNDATION Fieldbus

Certificates and approvals

CE mark The measuring system is in conformity with the statutory requirements of the EC Directives. Endress+Hauser confirms successful testing of the device by affixing to it the CE mark. C-tick mark The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)". Pressure measuring device Measuring devices with a nominal diameter smaller than or equal to DN 25 correspond to Article 3(3) of the EC Directive 97/23/EC (Pressure Equipment Directive) and have been designed and manufactured approval according to good engineering practice. Where necessary (depending on the medium and process pressure), there are additional optional approvals to Category II/III for larger nominal diameters. Ex approval Information about currently available Ex versions (ATEX, IECEx, FM, CSA, NEPSI) can be supplied by your Endress+Hauser Sales Center on request. All explosion protection data are given in a separate documentation which is available upon request. Other standards and ■ EN 60529 guidelines Degrees of protection by housing (IP code) Protection Measures for Electrical Equipment for Measurement, Control, Regulation and Laboratory Procedures. ■ IEC/EN 61326 "Emission in accordance with requirements for Class A". Electromagnetic compatibility (EMC requirements) ■ NAMUR NE 21: Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment. ■ NAMUR NE 43: Standardization of the signal level for the breakdown information of digital transmitters with analog output signal. ■ NAMUR NE 53: Software of field devices and signal-processing devices with digital electronics. ■ ANSI/ISA-S82.01 Safety Standard for Electrical and Electronic Test, Measuring, Controlling and related Equipment - General Requirements Pollution degree 2, Installation Category II. ■ CAN/CSA-C22.2 No. 1010.1-92 Safety requirements for Electrical Equipment for Measurement and Control and Laboratory Use. Pollution degree 2, Installation Category II **FOUNDATION Fieldbus** The flow device has successfully passed all the test procedures carried out and is certified and registered by the certification Fieldbus Foundation. The device thus meets all the requirements of the following specifications: ■ Certified to FOUNDATION Fieldbus Specification ■ The device meets all the specifications of the FOUNDATION Fieldbus H1. ■ Interoperability Test Kit (ITK), revision status 5.01 (device certification number: on request) ■ The device can also be operated with certified devices of other manufacturers ■ Physical Layer Conformance Test of the Fieldbus Foundation The measuring device meets all the requirements of the MODBUS/TCP conformity test and has the "MOD-**MODBUS RS485 certification**

The measuring device meets all the requirements of the MODBUS/TCP conformity test and has the "MODBUS/TCP Conformance Test Policy, Version 2.0". The measuring device has successfully passed all the test procedures carried out and is certified by the "MODBUS/TCP Conformance Test Laboratory" of the University of Michigan.

PROFIBUS DP/PA certification

The flow device has successfully passed all the test procedures carried out and is certified and registered by the PNO (PROFIBUS User Organisation). The device thus meets all the requirements of the following specifications:

- Certified to PROFIBUS PA, profile version 3.0 (device certification number: on request)
- The device can also be operated with certified devices of other manufacturers (interoperability)

Ordering information

Your Endress+Hauser service organization can provide detailed ordering information and information on the order codes on request.

Accessories

Various accessories, which can be ordered separately from Endress+Hauser, are available for the transmitter and the sensor. Your Endress+Hauser service organization can provide detailed information on the order codes in question.

Documentation

- Flow Measurement (FA005D/06)
- Operating Instructions Promag Promag 50 (BA046D/06 and BA049D/06)
- Operating Instructions Promag Promag 50 PROFIBUS PA (BA055D/06 and BA056D/06)
- Operating Instructions Promag Promag 53 (BA047D/06 and BA048D/06)
- Operating Instructions Promag Promag 53 FOUNDATION Fieldbus (BA051D/06 and BA052D/06)
- Operating Instructions Promag Promag 53 MODBUS RS485 (BA117D/06 and BA118D/06)
- Operating Instructions Promag Promag 53 PROFIBUS DP/PA (BA053D/06 and BA054D/06)
- Supplementary documentation on Ex-ratings: ATEX, IECEx, FM, CSA, NEPSI

Registered trademarks

HART®

Registered trademark of the HART Communication Foundation, Austin, USA

PROFIBUS[®]

Registered trademark of the PROFIBUS Nutzerorganisation e.V., Karlsruhe, D

FOUNDATIONTM Fieldbus

Registered trademark of the Fieldbus Foundation, Austin, USA

MODBUS®

Registered trademark of the MODBUS Organisation

HistoROM[™], S-DAT[®], T-DAT[™], F-CHIP[®], FieldCare[®], FieldCheck[®], FieldXpert[™], Applicator[®] Registered or registration-pending trademarks of Endress+Hauser Flowtec AG, Reinach, CH

Instruments International

Endress+Hauser Instruments International AG Kaegenstrasse 2 4153 Reinach Switzerland

Tel. +41 61 715 81 00 Fax +41 61 715 25 00 www.endress.com info@ii.endress.com




Products


Valid as of version V 2.04.XX (device software)


Operating Instructions **Proline Promag 50 HART**

Electromagnetic flowmeter














Table of contents

1	Safety instructions 4
1.1 1.2 1.3 1.4 1.5	Designated use
2	Identification6
2.1 2.2 2.3	Device designation6Certificates and approvals8Registered trademarks9
3	Installation
3.1 3.2 3.3 3.4	Incoming acceptance, transport and storage10Installation conditions12Installation instructions20Post-installation check45
4	Wiring46
4.1 4.2 4.3 4.4 4.5	Connecting the remote version46Connecting the measuring unit52Potential equalization55Degree of protection58Post-connection check59
5	Operation60
5.1 5.2 5.3 5.4	Display and operating elements 60 Brief operating instructions on the function matrix 61 Displaying error messages 63 Communication 64
6	Commissioning72
6.1 6.2 6.3 6.4 6.5 6.6	Function check72Switching on the measuring device72Quick Setup73Configuration74Adjustment75Data storage device (HistoROM)76
7	Maintenance77
7.1	Exterior despina
7.2	Exterior cleaning
7.Z 8	

9	Troubleshooting	81
9.1	Troubleshooting instructions	. 81
9.2	System error messages	
9.3	Process error messages	
9.4	Process errors without messages	
9.5	Response of outputs to errors	. 86
9.6	Spare parts	
9.7	Return	. 96
9.8	Disposal	. 96
9.9	Software history	. 96
10	Technical data	98
10.1	Technical data at a glance	. 98
	J	
	Index	125
		_

Safety instructions Promag 50

1 Safety instructions

1.1 Designated use

The measuring device described in this Operating Manual is to be used only for measuring the flow rate of conductive fluids in closed pipes.

A minimum conductivity of 20 μ S/cm is required for measuring demineralized water. Most liquids can be measured as of a minimum conductivity of 5 μ S/cm.

Examples:

- Acids, alkalis
- Drinking water, wastewater, sewage sludge
- Milk, beer, wine, mineral water, etc.

Resulting from incorrect use or from use other than that designated the operational safety of the measuring devices can be suspended. The manufacturer accepts no liability for damages being produced from this.

1.2 Installation, commissioning and operation

Please note the following:

- Installation, connection to the electricity supply, commissioning and maintenance of the device must be carried out by trained, qualified specialists authorized to perform such work by the facility's owner-operator. The specialist must have read and understood this Operating Manual and must follow the instructions it contains.
- The device must be operated by persons authorized and trained by the facility's owneroperator. Strict compliance with the instructions in the Operating Manual is mandatory.
- With regard to special fluids, including fluids used for cleaning, Endress+Hauser will be happy to assist in clarifying the corrosion-resistant properties of wetted materials. However, minor changes in temperature, concentration or in the degree of contamination in the process may result in variations in corrosion resistance. For this reason, Endress+Hauser does not accept any responsibility with regard to the corrosion resistance of wetted materials in a specific application.
 - The user is responsible for the choice of suitable wetted materials in the process.
- If welding work is performed on the piping system, do not ground the welding appliance through the Promag flowmeter.
- The installer must ensure that the measuring system is correctly wired in accordance with the wiring diagrams. The transmitter must be grounded apart from when special protective measures are taken (e.g. galvanically isolated SELV or PELV power supply)
- Invariably, local regulations governing the opening and repair of electrical devices apply.

1.3 Operational safety

Please note the following:

- Measuring systems for use in hazardous environments are accompanied by separate Ex documentation, which is an integral part of this Operating Manual. Strict compliance with the installation instructions and ratings as stated in this supplementary documentation is mandatory. The symbol on the front of this Ex documentation indicates the approval and the certification body (e.g. 🖾 Europe, 🤝 USA, @ Canada).
- The measuring device complies with the general safety requirements in accordance with EN 61010-1, the EMC requirements of IEC/EN 61326 and NAMUR Recommendations NE 21 and NE 43.
- Depending on the application, the seals of the process connections of the Promag H sensor require periodic replacement.

Promag 50 Safety instructions

When hot fluid passes through the measuring tube, the surface temperature of the housing increases. In the case of the sensor, in particular, users should expect temperatures that can be close to the fluid temperature. If the temperature of the fluid is high, implement sufficient measures to prevent burning or scalding.

 The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser distributor will supply you with current information and updates to these Operating Instructions.

1.4 Return

- Do not return a measuring device if you are not absolutely certain that all traces of hazardous substances have been removed, e.g. substances which have penetrated crevices or diffused through plastic.
- Costs incurred for waste disposal and injury (burns, etc.) due to inadequate cleaning will be charged to the owner-operator.

1.5 Notes on safety conventions and icons

The devices are designed to meet state-of-the-art safety requirements, have been tested, and left the factory in a condition in which they are safe to operate. The devices comply with the applicable standards and regulations in accordance with EN 61010-1 "Safety requirements for electrical equipment for measurement, control and laboratory use". The devices can, however, be a source of danger if used incorrectly or for anything other than the designated use. Consequently, always pay particular attention to the safety instructions indicated in this Operating Manual by the following icons:



Warning!

"Warning" indicates an action or procedure which, if not performed correctly, can result in injury or a safety hazard. Comply strictly with the instructions and proceed with care.



Caution!

"Caution" indicates an action or procedure which, if not performed correctly, can result in incorrect operation or destruction of the device. Comply strictly with the instructions.



Note!

"Note" indicates an action or procedure which, if not performed correctly, can have an indirect effect on operation or trigger an unexpected response on the part of the device.

Identification Promag 50

Identification 2


2.1 **Device designation**

The flow measuring system consists of the following components:

- Promag 50 transmitter
- Promag D/E/H/L/P/W sensor

In the *compact version*, the transmitter and sensor form a single mechanical unit; in the remote version they are installed separately.

2.1.1 Nameplate of the transmitter



Nameplate specifications for the "Promag 50" transmitter (example) Fig. 1:

 ${\it Ordering\ code/serial\ number: See\ the\ specifications\ on\ the\ order\ confirmation\ for\ the\ meanings\ of\ the\ individual\ letters\ and\ order\ or$ 1 digits.
Power supply, frequency, power consumption

- Additional information:
 - EPD/MSÜ: with Empty Pipe Detection
- ECC: with electrode cleaning 4
- Outputs available:

 - I-OUT (HART): with current output (HART) f-OUT (HART): with frequency output STATUS-IN: with status input (power supply)
- Reserved for information on special products
- Observe device documentation
- Reserved for additional information on device version (approvals, certificates)
- 6 7 8 9 Permitted ambient temperature range
- Degree of protection

Promag 50 Identification

2.1.2 Nameplate of the sensor




Fig. 2: Nameplate specifications for the "Promag" sensor (example)

- 1 Ordering code/serial number: See the specifications on the order confirmation for the meanings of the individual letters and digits.
- Calibration factor with zero point
- Nominal diameter / Pressure rating
- Fluid temperature range 4 5 6 7
- Materials: lining/measuring electrodes
- Reserved for information on special products Permitted ambient temperature range Observe device documentation
- 8
- Reserved for additional information on device version (approvals, certificates)
- Calibration tolerance
- 11 Additional information (examples):
 - EPD/MSÜ: with Empty Pipe Detection electrode R/B: with reference electrode
- Degree of protection Flow direction
- 12
- 13

Identification Promag 50

2.1.3 Nameplate, connections




Fig. 3: Nameplate specifications for transmitter (example)

- 1 Serial number
- 2 Possible configuration of current output
- 3 Possible configuration of relay contacts
- Terminal assignment, cable for power supply: 85 to 260 V AC, 20 to 55 V AC, 16 to 62 V DC Terminal No. 1: L1 for AC, L+ for DC Terminal No. 2: N for AC, L- for DC
- 5 Signals present at inputs and outputs, possible configuration and terminal assignment (20 to 27), see also "Electrical values of inputs/outputs"
- 6 Version of device software currently installed
- 7 Installed communication type, e.g.: HART, PROFIBUS PA, etc.
- 8 Information on current communication software (Device Revision and Device Description), e.g.:
 Dev. 01 / DD 01 for HART
- 9 Date of installation
- 10 Current updates to data specified in points 6 to 9

2.2 Certificates and approvals

The devices are designed to meet state-of-the-art safety requirements in accordance with sound engineering practice. They have been tested and left the factory in a condition in which they are safe to operate.

The devices comply with the applicable standards and regulations in accordance with EN 61010-1 "Safety requirements for electrical equipment for measurement, control and laboratory use" and with the EMC requirements of IEC/EN 61326/A1.

The measuring system described in this Operating Manual is therefore in conformity with the statutory requirements of the EC Directives. Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.

The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".

Promag 50 Identification

2.3 Registered trademarks

 $KALREZ^{\circledR}$ and $VITON^{\circledR}$

Registered trademarks of E.I. Du Pont de Nemours & Co., Wilmington, USA

TRI-CLAMP®

Registered trademark of Ladish & Co., Inc., Kenosha, USA

HART®

Registered trademark of the HART Communication Foundation, Austin, USA

HistoROM™, S-DAT®, Field Xpert™, FieldCare®, Fieldcheck®, Applicator®

Registered or registration-pending trademarks of Endress+Hauser Flowtec AG, Reinach, CH

3 Installation

3.1 Incoming acceptance, transport and storage

3.1.1 Incoming acceptance

On receipt of the goods, check the following:

- Check the packaging and the contents for damage.
- Check the shipment, make sure nothing is missing and that the scope of supply matches your order.

3.1.2 Transport

The following instructions apply to unpacking and to transporting the device to its final location:

- Transport the devices in the containers in which they are delivered.
- Do not remove the protective plates or caps on the process connections until you are ready to install the device. This is particularly important in the case of sensors with PTFE linings.

Special notes on flanged devices



Caution!

- The wooden covers mounted on the flanges from the factory protect the linings on the flanges during storage and transportation. In case of Promag L they are additionally used to hold the lap joint flanges in place. Do not remove these covers until **immediately before** the device in the pipe.
- Do not lift flanged devices by the transmitter housing, or the connection housing in the case of the remote version.

Transporting flanged devices DN \leq 300 (12")

Use webbing slings slung round the two process connections. Do not use chains, as they could damage the housing.



Warning!

Risk of injury if the measuring device slips. The center of gravity of the assembled measuring device might be higher than the points around which the slings are slung.

At all times, therefore, make sure that the device does not unexpectedly turn around its axis or slip.




Fig. 4: Transporting sensors with DN \leq 300 (12")

Transporting flangeddevices DN > 300 (12")

Use only the metal eyes on the flanges for transporting the device, lifting it and positioning the sensor in the piping.



Caution!

Do not attempt to lift the sensor with the tines of a fork-lift truck beneath the metal casing. This would buckle the casing and damage the internal magnetic coils.




Fig. 5: Transporting sensors with DN > 300 (12")

3.1.3 Storage

Please note the following:

- Pack the measuring device in such a way as to protect it reliably against impact for storage (and transportation). The original packaging provides optimum protection.
- The storage temperature corresponds to the operating temperature range of the measuring transmitter and the appropriate measuring sensors →
 □ 101.
- Do not remove the protective plates or caps on the process connections until you are ready to install the device. This is particularly important in the case of sensors with PTFE linings.
- The measuring device must be protected against direct sunlight during storage in order to avoid unacceptably high surface temperatures.
- Choose a storage location where moisture does not collect in the measuring device. This will help prevent fungus and bacteria infestation which can damage the liner.

3.2 Installation conditions

3.2.1 Dimensions

3.2.2 Mounting location

Entrained air or gas bubble formation in the measuring tube can result in an increase in measuring errors.

Avoid the following locations:

- Highest point of a pipeline. Risk of air accumulating!
- Directly upstream from a free pipe outlet in a vertical pipeline.




Fig. 6: Mounting location

Installation of pumps

Do **not** install the sensor on the intake side of a pump. This precaution is to avoid low pressure and the consequent risk of damage to the lining of the measuring tube. Information on the lining's resistance to partial vacuum can be found on $\rightarrow \blacksquare 106$.




Fig. 7: Installation of pumps

Partially filled pipes

Partially filled pipes with gradients necessitate a drain-type configuration.



Caution!

Risk of solids accumulating. Do not install the sensor at the lowest point in the drain. It is advisable to install a cleaning valve.




Fig. 8: Installation in a partially filled pipe

Down pipes

Install a siphon or a vent valve downstream of the sensor in down pipes whose length $h \ge 5$ m (16.4 ft). This precaution is to avoid low pressure and the consequent risk of damage to the lining of the measuring tube.

This measure also prevents the system losing prime, which could cause air pockets. Information on the lining's resistance to partial vacuum can be found on $\Rightarrow \triangleq 106$.




Fig. 9: Measures for installation in a down pipe

1 Vent valve

2 Pipe siphon

h Length of down pipe

3.2.3 Orientation

An optimum orientation position helps avoid gas and air accumulations and deposits in the measuring tube. However, Promag offers the additional Empty Pipe Detection (EPD) function to ensure the detection of partially filled measuring tubes, e.g. in the case of degassing fluids or varying process pressure:

- Electrode Cleaning Circuit (ECC) for applications with accretive fluids, e.g. electrically conductive deposits (\rightarrow "Description of Device Functions" manual).
- Empty Pipe Detection (EPD) ensures the detection of partially filled measuring tubes, e.g. in the case of degassing fluids ($\rightarrow \square$ 75)
- Exchangeable Measuring Electrodes for abrasive fluids (→ 🗎 94)

Vertical orientation

This is the ideal orientation for self-emptying piping systems and for use in conjunction with Empty Pipe Detection.




Fig. 10: Vertical orientation

Horizontal orientation

The measuring electrode plane should be horizontal. This prevents brief insulation of the two measuring electrodes by entrained air bubbles.



Caution!

Empty Pipe Detection functions correctly only when the measuring device is installed horizontally and the transmitter housing is facing upward ($\rightarrow \blacksquare 10$). Otherwise there is no quarantee that Empty Pipe Detection will respond if the measuring tube is only partially filled or empty.




Fig. 11: Horizontal orientation

- EPD electrode for the detection of empty pipes (not with Promag D and Promag H (DN 2 to 15 / 1/12 to $\frac{1}{2}$ "))
- Measuring electrodes for signal detection Reference electrode for the potential equalization (not with Promag D and H)

Inlet and outlet run

If possible, install the sensor upstream from fittings such as valves, T-pieces, elbows, etc. The following inlet and outlet runs must be observed in order to meet accuracy specifications:

Inlet run: ≥ 5 × DNOutlet run: ≥ 2 × DN




Fig. 12: Inlet and outlet runs

3.2.4 Vibrations

Secure the piping and the sensor if vibration is severe.



Caution!

If vibrations are too severe, we recommend the sensor and transmitter be mounted separately. Information on resistance to vibration and shock can be found on $\rightarrow \triangleq 102$.




Fig. 13: Measures to prevent vibration of the device (L > 10 m (32.8 ft))

3.2.5 Foundations, supports

If the nominal diameter is DN \geq 350 (14"), mount the sensor on a foundation of adequate load-bearing strength.



Caution!

Risk of damage.

Do not support the weight of the sensor on the metal casing: the casing would buckle and damage the internal magnetic coils.




Fig. 14: Correct support for large nominal diameters (DN \geq 350 / 14")

3.2.6 Adapters

Suitable adapters to DIN EN 545 (double-flange reducers) can be used to install the sensor in larger-diameter pipes.

The resultant increase in the rate of flow improves measuring accuracy with very slow-moving fluids. The nomogram shown here can be used to calculate the pressure loss caused by reducers and expanders.



Note

The nomogram only applies to liquids of viscosity similar to water.

- 1. Calculate the ratio of the diameters d/D.
- 2. From the nomogram read off the pressure loss as a function of flow velocity (*downstream* from the reduction) and the d/D ratio.




Fig. 15: Pressure loss due to adapters

3.2.7 Nominal diameter and flow rate

The diameter of the pipe and the flow rate determine the nominal diameter of the sensor. The optimum velocity of flow is between 2 and 3 m/s (6.5 to 9.8 ft/s).

The velocity of flow (v), moreover, has to be matched to the physical properties of the fluid:

- v < 2 m/s (v < 6.5 ft/s): for abrasive fluids
- v > 2 m/s (v > 6.5 ft/s): for fluids producing buildup



Note!

Recommended flow (SI units)

Nominal diameter	Promag D	Promag E/P	Promag H	Promag L	Promag W
[mm]	1	Min./max. full sca	le value (v ≈ 0.3 o	r 10 m/s) in [dm ³ /	min]
2	-	-	0.06 to 1.8	-	-
4	_	-	0.25 to 7	_	-
8	_	-	1 to 30	_	-
15	-	4 to 100	4 to 100	-	-
25	9 to 300	9 to 300	9 to 300	-	9 to 300
32	_	15 to 500	_	_	15 to 500
40	25 to 700	25 to 700	25 to 700	_	25 to 700
50	35 to 1100	35 to 1100	35 to 1100	35 to 1100	35 to 1100
65	60 to 2000	60 to 2000	60 to 2000	60 to 2000	60 to 2000
80	90 to 3000	90 to 3000	90 to 3000	90 to 3000	90 to 3000
100	145 to 4700	145 to 4700	145 to 4700	145 to 4700	145 to 4700
125	-	220 to 7500	-	220 to 7500	220 to 7500
[mm]		Min./max. full so	cale value (v ≈ 0.3	or 10 m/s) in [m ³ /	/h]
150	-	20 to 600	-	20 to 600	20 to 600
200	-	35 to 1100	-	35 to 1100	35 to 1100
250	-	55 to 1700	-	55 to 1700	55 to 1700
300	-	80 to 2400	-	80 to 2400	80 to 2400
350	-	110 to 3300	-	110 to 3300	110 to 3300
375	-	-	-	140 to 4200	140 to 4200
400	-	140 to 4200	-	140 to 4200	140 to 4200
450	-	180 to 5400	-	180 to 5400	180 to 5400
500	-	220 to 6600	-	220 to 6600	220 to 6600
600	-	310 to 9600	-	310 to 9600	310 to 9600
700	_	-	_	420 to 13500	420 to 13500
750	-	-	-	480 to 15200	480 to 15200
800	-	-	-	550 to 18000	550 to 18000
900	-	-	-	690 to 22500	690 to 22500
1000	-	-	-	850 to 28000	850 to 28000
1050	-	-	-	950 to 40000	950 to 40000
1200	-	-	-	1250 to 40000	1250 to 40000
1400	-	-	-	-	1700 to 55000
1600	-	-	-	-	2200 to 70000
1800	-	-	-	-	2800 to 90000
2000	_	-	_	-	3400 to 110000

Recommended flow (US units)

Nominal diameter	Promag D	Promag E/P	Promag H	Promag L	Promag W
[inch]		Min./max. full scal	 e value (v ≈ 0.3	or 10 m/s) in [gal/	min]
1 1/12"	-	_	0.015 to 0.5	-	-
5/32"	-	-	0.07 to 2	-	-
5/16"	-	_	0.25 to 8	-	-
1/2"	-	1.0 to 27	1.0 to 27	-	-
1"	2.5 to 80	2.5 to 80	2.5 to 80	-	2.5 to 80
1 1/4"	-	4 to 130	-	-	4 to 130
1 1/2"	7 to 190	7 to 190	7 to 190	7 to 190	7 to 190
2"	10 to 300	10 to 300	10 to 300	10 to 300	10 to 300
2 1/2"	16 to 500	16 to 500	16 to 500	16 to 500	16 to 500
3"	24 to 800	24 to 800	24 to 800	24 to 800	24 to 800
4"	40 to 1250	40 to 1250	40 to 1250	40 to 1250	40 to 1250
5"	-	60 to 1950	-	60 to 1950	60 to 1950
6"	-	90 to 2650	-	90 to 2650	90 to 2650
8"	-	155 to 4850	-	155 to 4850	155 to 4850
10"	-	250 to 7500	-	250 to 7500	250 to 7500
12"	-	350 to 10600	-	350 to 10600	350 to 10600
14"	-	500 to 15000	-	500 to 15000	500 to 15000
15"	-	-	_	600 to 19000	600 to 19000
16"	-	600 to 19000	-	600 to 19000	600 to 19000
18"	-	800 to 24000	-	800 to 24000	800 to 24000
20"	-	1000 to 30000	_	1000 to 30000	1000 to 30000
24"	-	1400 to 44000	-	1400 to 44000	1400 to 44000
28"	-	-	_	1900 to 60000	1900 to 60000
30"	-	_	-	2150 to 67000	2150 to 67000
32"	-	-	-	2450 to 80000	2450 to 80000
36"	-	-	_	3100 to 100000	3100 to 100000
40"	-	-	_	3800 to 125000	3800 to 125000
42"	-	-	-	4200 to 135000	4200 to 135000
48"	-	-	-	5500 to 175000	5500 to 175000
[inch]		Min./max. full scal	le value (v ≈ 0.3	or 10 m/s) in [Mga	al/d]
54"	-	-	_	-	9 to 300
60"	_	-	_	-	12 to 380
66"	_	-	-	-	14 to 500
72"	-	_	-	_	16 to 570
78"	-	-	_	-	18 to 650

3.2.8 Length of connecting cable

In order to ensure measuring accuracy, comply with the following instructions when installing the remote version:

- Fix cable run or lay in armored conduit. Cable movements can falsify the measuring signal especially in the case of low fluid conductivities.
- Route the cable well clear of electrical machines and switching elements.
- Ensure potential equalization between sensor and transmitter, if necessary.
- The permitted connecting cable length L_{max} is determined by the fluid conductivity (\rightarrow 🖸 16). A minimum conductivity of 20 μ S/cm is required for measuring demineralized water. Most liquids can be measured as of a minimum conductivity of 5 μ S/cm.
- The maximum connecting cable length is 10 m (32.8 ft) when empty pipe detection (EPD \rightarrow \trianglerighteq 75) is switched on.




Fig. 16: Permissible cable length for the remote version

Area shaded gray = permitted range Lmax = connecting cable length in [m] Fluid conductivity in [µS/cm]

3.3 Installation instructions

3.3.1 Installing the Promag D sensor

The sensor is installed between the pipe flanges with a mounting kit. The device is centered using recesses on the sensor ($\rightarrow \stackrel{\triangle}{=} 21$).



Note!

A mounting kit consisting of mounting bolts, seals, nuts and washers can be ordered separately ($\Rightarrow \stackrel{\triangle}{=} 78$). Centering sleeves are provided with the device if they are required for the installation.



Caution!

When installing the transmitter in the pipe, observe the necessary torques ($\Rightarrow \stackrel{\triangle}{=} 22$).




Fig. 17: Mounting the sensor

- 1 Nut
- 2 Washer
- 3 Mounting bolt
- 4 Centering sleeve
- 5 Seal

Seals

When installing the sensor, make sure that the seals used do not project into the pipe cross-section.



Caution!

Risk of short circuit! Do not use electrically conductive sealing compounds such as graphite! An electrically conductive layer could form on the inside of the measuring tube and short-circuit the measuring signal.



Note!

Use seals with a hardness rating of 70° Shore.

Arrangement of the mounting bolts and centering sleeves

The device is centered using recesses on the sensor. The arrangement of the mounting bolts and the use of the centering sleeves supplied depend on the nominal diameter, the flange standard und the pitch circle diameter.

		Process connection	
	EN (DIN)	ASME	JIS
DN 25 to 40 (1 to 1 ½")			
	A0010896	A0010824	A0010896
DN 50 (2")			
D27.65.(.)	A0010897	A0010825	A0010825
DN 65 (-)	3 2 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3		A0012171
DN 80 (3")	1 0 1 1 A0010898	A0010827	A0010826
DN 100 (4")	1 1 1 1 A0012168	1 1 1 A0012168	A0012169

- 1 = Mounting bolts with centering sleeves
- 2 = EN (DIN) flanges: 4-hole \rightarrow with centering sleeves
- 3 = EN (DIN) flanges: 8-hole \rightarrow without centering sleeves

Screw tightening torques (Promag D)

Please note the following:

- The tightening torques listed below are for lubricated threads only.
- Always tighten the screws uniformly and in diagonally opposite sequence.
- Overtightening the screws will deform the sealing faces or damage the seals.
- The tightening torques listed below apply only to pipes not subjected to tensile stress.

The tightening torques apply to situations where an EPDM soft material flat seal (e.g. 70 Shore) is used.

Tightening torques, mounting bolts and centering sleeves for EN (DIN) PN 16

Nominal diameter	Mounting bolts	Centering sleeve length	Tightening torque [Nm] with a process flange with a	
[mm]	[mm]	[mm]	smooth seal face raised face	
25	4 × M12 × 145	54	19	19
40	4 × M16 × 170	68	33	33
50	4 × M16 × 185	82	41	41
65 ¹⁾	4 × M16 × 200	92	44	44
65 ²⁾	8 × M16 × 200	_ 3)	29	29
80	8 × M16 × 225	116	36	36
100	8 × M16 × 260	147	40	40

¹⁾ EN (DIN) flanges: 4-hole \rightarrow with centering sleeves

Tightening torques, mounting bolts and centering sleeves for JIS 10K

Nominal diameter	Mounting bolts	Centering sleeve length	Tightening torque [Nm] with a process flange with a	
[mm]	[mm]	[mm]	smooth seal face raised face	
25	4 × M16 × 170	54	24	24
40	4 × M16 × 170	68	32	25
50	4 × M16 × 185	- *	38	30
65	4 × M16 × 200	- *	42	42
80	8 × M16 × 225	_ *	36	28
100	8 × M16 × 260	- *	39	37
* A centering sle	eeve is not required. The o	device is centered directly	via the sensor housing.	

Tightening torques, mounting bolts and centering sleeves for ASME Class 150

Nominal diameter	Mounting bolts	Centering sleeve length	Tightening torque [lbf · ft] with a process flange with a		
[inch]	[inch]	[inch]	smooth seal face raised face		
1"	4 × UNC 1/2" × 5.70"	_ *	14	7	
1 1/2"	4 × UNC 1/2" × 6.50"	- *	21	14	
2"	4 × UNC 5/8" × 7.50"	_ *	30	27	
3"	4 × UNC 5/8" × 9.25"	- *	31	31	
4"	8 × UNC 5/8" × 10,4"	5,79	28	28	
* A centering sl	eeve is not required. The o	device is centered directly	via the sensor housing.	,	

 $^{^{2)}\,\}text{EN}$ (DIN) flanges: 8-hole \rightarrow without centering sleeves

³⁾ A centering sleeve is not required. The device is centered directly via the sensor housing.

3.3.2 Installing the Promag E sensor



Caution!

• The protective covers mounted on the two sensor flanges guard the PTFE, which is turned over the flanges. Consequently, do not remove these covers until **immediately before** the sensor is installed in the pipe.

- The covers must remain in place while the device is in storage.
- Make sure that the lining is not damaged or removed from the flanges.



Note:

Bolts, nuts, seals, etc. are not included in the scope of supply and must be supplied by the customer.

The sensor is designed for installation between the two piping flanges.

- Observe in any case the necessary screw tightening torques on $\rightarrow \triangleq 24$
- If grounding disks are used, follow the mounting instructions which will be enclosed with the shipment




Fig. 18: Installing the Promag E sensor

Seals

Comply with the following instructions when installing seals:

- PFA or PTFE lining → No seals are required!
- For DIN flanges, use only seals according to EN 1514-1.
- Make sure that the seals do not protrude into the piping cross-section.



Caution

Risk of short circuit! Do not use electrically conductive sealing compounds such as graphite! An electrically conductive layer could form on the inside of the measuring tube and short-circuit the measuring signal.

Ground cable

- If necessary, special ground cables for potential equalization can be ordered as an accessory ($\rightarrow \cong 78$).
- Information on potential equalization and detailed mounting instructions for the use of ground cables can be found on \rightarrow $\stackrel{ riangle}{=}$ 55

Tightening torques for threaded fasteners (Promag E)

Please note the following:

- The tightening torques listed below are for lubricated threads only.
- Always tighten the screws uniformly and in diagonally opposite sequence.
- Overtightening the screws will deform the sealing faces or damage the seals.
- The tightening torques listed below apply only to pipes not subjected to tensile stress.

Tightening torques for:

- EN (DIN) → 🖺 24
- ASME → 🖺 25
- JIS → 🖺 25

Promag E tightening torques for EN (DIN)

Nominal diameter [mm]	EN (DIN) Pressure rating [bar]	Threaded fasteners	Max. tightening torque [Nm]
15	PN 40	4 × M 12	11
25	PN 40	4 × M 12	26
32	PN 40	4 × M 16	41
40	PN 40	4 × M 16	52
50	PN 40	4 × M 16	65
65 *	PN 16	8 × M 16	43
80	PN 16	8 × M 16	53
100	PN 16	8 × M 16	57
125	PN 16	8 × M 16	75
150	PN 16	8 × M 20	99
200	PN 10	8 × M 20	141
200	PN 16	12 × M 20	94
250	PN 10	12 × M 20	110
250	PN 16	12 × M 24	131
300	PN 10	12 × M 20	125
300	PN 16	12 × M 24	179
350	PN 6	12 × M 20	200
350	PN 10	16 × M 20	188
350	PN 16	16 × M 24	254
400	PN 6	16 × M 20	166
400	PN 10	16 × M 24	260
400	PN 16	16 × M 27	330
450	PN 6	16 × M 20	202
450	PN 10	20 × M 24	235
450	PN 16	20 × M 27	300
500	PN 6	20 × M 20	176
500	PN 10	20 × M 24	265
500	PN 16	20 × M 30	448
600	PN 6	20 × M 24	242
600	PN 10	20 × M 27	345
600 *	PN 16	20 × M 33	658
* Designed acc. to EN 109	2-1 (not to DIN 2501)		

Promag E tightening torques for ASME

Nominal	diameter	ASME		Max. tighte	ning torque
		Pressure rating		PTFE	
[mm]	[inch]	[lbs]	Threaded fasteners	[Nm]	[lbf⋅ft]
15	1/2"	Class 150	4 × ½"	6	4
25	1"	Class 150	4 × ½"	11	8
40	1 ½"	Class 150	4 × ½"	24	18
50	2"	Class 150	4 × 5/8"	47	35
80	3"	Class 150	4 × 5/8"	79	58
100	4"	Class 150	8 × 5/8"	56	41
150	6"	Class 150	8 × ¾"	106	78
200	8"	Class 150	8 × ¾"	143	105
250	10"	Class 150	12 × 7/8"	135	100
300	12"	Class 150	12 × 7/8"	178	131
350	14"	Class 150	12 × 1"	260	192
400	16"	Class 150	16 × 1"	246	181
450	18"	Class 150	16 × 1 1/8"	371	274
500	20"	Class 150	20 × 1 1/8"	341	252
600	24"	Class 150	20 × 1 1/4"	477	352

Promag E tightening torques for JIS

Nominal diameter	JIS		Max. tightening torque [Nm]
[mm]	Pressure rating	Threaded fasteners	PTFE
15	20K	4 × M 12	16
25	20K	4 × M 16	32
32	20K	4 × M 16	38
40	20K	4 × M 16	41
50	10K	4 × M 16	54
65	10K	4 × M 16	74
80	10K	8 × M 16	38
100	10K	8 × M 16	47
125	10K	8 × M 20	80
150	10K	8 × M 20	99
200	10K	12 × M 20	82
250	10K	12 × M 22	133
300	10K	16 × M 22	99


3.3.3 Installing the Promag H sensor

The sensor is supplied to order, with or without pre-installed process connections. Preinstalled process connections are secured to the sensor with 4 or 6 hex-head threaded fasteners.



Caution!

The sensor might require support or additional attachments, depending on the application and the length of the piping run. When plastic process connections are used, the sensor must be additionally supported mechanically. A wall-mounting kit can be ordered separately from Endress+Hauser as an accessory ($\rightarrow \triangleq 78$).



Promag H process connections (DN 2 to 25 / 1/12 to 1", DN 40 to 100 / 1½ to 4") Abb. 19:

 $A = DN \ 2$ to $25 \ / \ 1/12$ to 1": process connections with O-ring

- welding flanges (DIN EN ISO 1127, ODT / SMS),
- flange (EN (DIN), ASME, JIS), flange PVDF (EN (DIN), ASME, JIS)
- external and internal thread, hose connection, PVC adhesive fitting

 $B = DN\ 2$ to 25 / 1/12 to 1": process connections with aseptic gasket vseal

- weld nipples (DIN 11850, ODT/SMS)
- Clamp (ISO 2852, DIN 32676, L14 AM7)
- coupling (DIN 11851, DIN 11864-1, SMS 1145)
- flange DIN 11864-2

C = DN 40 to 100 / $1\frac{1}{2}$ to 4": process connections with aseptic gasket seal – weld nipples (DIN 11850, ODT/SMS)

- Clamp (ISO 2852, DIN 32676, L14 AM7)
- coupling (DIN 11851, DIN 11864-1, ISO 2853, SMS 1145)
- flange DIN 11864-2

Seals

When installing the process connections, make sure that the seals are clean and correctly centered.



Caution!

- With metal process connections, you must fully tighten the screws. The process connection forms a metallic connection with the sensor, which ensures a defined compression of the seal.
- With plastic process connections, note the max. torques for lubricated threads (7 Nm / 5.2 lbf ft). With plastic flanges, always use seals between connection and counter flange.
- The seals must be replaced periodically, depending on the application, particularly in the case of gasket seals (aseptic version)!

The period between changes depends on the frequency of cleaning cycles, the cleaning temperature and the fluid temperature. Replacement seals can be ordered as accessories → 🖺 78.

Usage and assembly of ground rings (DN 2 to 25 / 1/12 to 1")

In case the process connections are made of plastic (e.g. flanges or adhesive fittings), the potential between the sensor and the fluid must be equalized using additional ground rings. If the ground rings are not installed this can affect the accuracy of the measurements or cause the destruction of the sensor through the electrochemical erosion of the electrodes.



Caution!

- Depending on the option ordered, plastic disks may be installed at the process connections instead of ground rings. These plastic disks serve only as spacers and have no potential equalization function. In addition, they provide a sealing function at the interface between the sensor and process connection. For this reason, with process connections without ground rings, these plastic disks/seals must not be removed, or must always be installed.
- Ground rings can be ordered separately from Endress+Hauser as accessories ($\rightarrow \boxminus 78$). When placing the order, make certain that the ground ring is compatible with the material used for the electrodes. Otherwise, there is a risk that the electrodes may be destroyed by electrochemical corrosion! Information about the materials can be found on $\rightarrow \boxminus 117$.
- Ground rings, including the seals, are mounted within the process connections. Therefore, the fitting length is not affected.
- 1. Loosen the four or six hexagonal headed bolts (1) and remove the process connection from the sensor (4).
- 2. Remove the plastic disk (3), including the two O-ring seals (2).
- 3. Place one seal (2) in the groove of the process connection.
- 4. Place the metal ground ring (3) on the process connection.
- 5. Now place the second seal (2) in the groove of the ground ring.
- Finally, mount the process connection on the sensor again.
 With plastic process connections, note the max. torques for lubricated threads (7 Nm / 5.2 lbf ft).




Fig. 20: Installing ground rings with Promag H (DN 2 to 25 / 1/12 to 1")

- 1 = Hexagonal-headed bolt (process connection)
- 2 = O-ring seals
- 3 = Ground ring or plastic disk (spacer)
- 4 = Sensor

Welding the transmitter into the piping (weld nipples)



Caution!

Risk of destroying the measuring electronics. Make sure that the welding machine is *not* grounded via the sensor or the transmitter.

- 1. Tack-weld the sensor into the pipe. A suitable welding jig can be ordered separately as an accessory ($\rightarrow \stackrel{\triangle}{=} 78$).
- 2. Loosen the screws on the process connection flange and remove the sensor, complete with the seal, from the pipe.
- 3. Weld the process connection to the pipe.
- 4. Reinstall the sensor in the pipe. Make sure that everything is clean and that the seal is correctly seated.



Note!

- If thin-walled foodstuffs pipes are not welded correctly, the heat could damage the installed seal. It is therefore advisable to remove the sensor and the seal prior to welding.
- The pipe has to be spread approximately 8 mm to permit disassembly.

Cleaning with pigs

If pigs are used for cleaning, it is essential to take the inside diameters of the measuring tube and process connection into account. All the dimensions and lengths of the sensor and transmitter are provided in the separate documentation "Technical Documentation" $\rightarrow \blacksquare$ 124.

3.3.4 Installing the Promag L sensor



Caution!

■ The protective covers mounted on the two sensor flanges (DN 50 to 300 / 2 to 12") are used to hold the lap joint flanges in place and to protect the PTFE liner during transportation. Consequently, do not remove these covers until immediately before the sensor is installed in the pipe.

- The covers must remain in place while the device is in storage.
- Make sure that the lining is not damaged or removed from the flanges.



Note

Bolts, nuts, seals, etc. are not included in the scope of supply and must be supplied by the customer.

The sensor is designed for installation between the two piping flanges.

- Observe in any case the necessary screw tightening torques on $\rightarrow \triangleq 30$
- If grounding disks are used, follow the mounting instructions which will be enclosed with the shipment
- To comply with the device specification, a concentrical installation in the measuring section is required




Fig. 21: Installing the Promag L sensor

Seals

Comply with the following instructions when installing seals:

- Hard rubber lining → additional seals are **always** necessary.
- Polyurethane lining \rightarrow **no** seals are required.
- PTFE lining \rightarrow **no** seals are required.
- For DIN flanges, use only seals according to EN 1514-1.
- Make sure that the seals do not protrude into the piping cross-section.



Caution!

Risk of short circuit!

Do not use electrically conductive sealing compounds such as graphite! An electrically conductive layer could form on the inside of the measuring tube and short-circuit the measuring signal.

Ground cable

- Information on potential equalization and detailed mounting instructions for the use of ground cables can be found on $\rightarrow \blacksquare$ 57.

Screw tightening torques (Promag L)

Please note the following:

- The tightening torques listed below are for lubricated threads only.
- Always tighten the screws uniformly and in diagonally opposite sequence.
- Overtightening the screws will deform the sealing faces or damage the seals.
- The tightening torques listed below apply only to pipes not subjected to tensile stress.

Promag L tightening torques for EN (DIN)

Nominal diameter	EN (DIN)		Max. tightening torque			
			Hard rubber	Polyurethane	PTFE	
[mm]	Pressure rating	Threaded fas-	[Nm]	[Nm]	[Nm]	
	[bar]	teners				
50	PN 10/16	4 × M 16	-	15	40	
65*	PN 10/16	8 × M 16	-	10	22	
80	PN 10/16	8 × M 16	-	15	30	
100	PN 10/16	8 × M 16	-	20	42	
125	PN 10/16	8 × M 16	-	30	55	
150	PN 10/16	8 × M 20	-	50	90	
200	PN 10	8 × M 20	-	65	130	
250	PN 10	12 × M 20	-	50	90	
300	PN 10	12 × M 20	-	55	100	
350	PN 6	12 × M 20	111	120	-	
350	PN 10	16 × M 20	112	118	-	
400	PN 6	16 × M 20	90	98	-	
400	PN 10	16 × M 24	151	167	-	
450	PN 6	16 × M 20	112	126	-	
450	PN 10	20 × M 24	153	133	-	
500	PN 6	20 × M 20	119	123	-	
500	PN 10	20 × M 24	155	171	-	
600	PN 6	20 × M 24	139	147	-	
600	PN 10	20 × M 27	206	219	-	
700	PN 6	24 × M 24	148	139	-	
700	PN 10	24 × M 27	246	246	-	
800	PN 6	24 × M 27	206	182	-	
800	PN 10	24 × M 30	331	316	-	
900	PN 6	24 × M 27	230	637	-	
900	PN 10	28 × M 30	316	307	-	
1000	PN 6	28 × M 27	218	208	-	
1000	PN 10	28 × M 33	402	405	-	
1200	PN 6	32 × M 30	319	299	-	
1200	PN 10	32 × M 36	564	568	-	
* Designed acc. to EN 3	1092-1 (not to DIN 2	2501)				

Promag L tightening torques for ASME

Nominal diame- ter		ASME	Threaded fasteners	Max. tightening torque					
		Pressure rating		Hard rubber Polyt		Polyur	ethane	PTFE	
[mm]	[inch]	[lbs]		[Nm]	[lbf·ft]	[Nm]	[lbf·ft]	[Nm]	[lbf·ft]
50	2"	Class 150	4 × 5/8"	-	-	15	11	40	29
80	3"	Class 150	4 × 5/8"	-	-	25	18	65	48
100	4"	Class 150	8 × 5/8"	-	-	20	15	44	32
150	6"	Class 150	8 × ¾,"	-	-	45	33	90	66
200	8"	Class 150	8 × ¾,"	-	-	65	48	125	92
250	10"	Class 150	12 × 7/8"	-	-	55	41	100	74
300	12"	Class 150	12 × 7/8"	-	-	68	56	115	85
350	14"	Class 150	12 × 1"	135	100	158	117	-	-
400	16"	Class 150	16 × 1"	128	94	150	111	-	-

Nomina te	l diame- er	ASME	Threaded fasteners	Max. tightening torque					
		Pressure rating		Hard 1	rubber	Polyur	ethane	PT	FE
[mm]	[inch]	[lbs]		[Nm]	[lbf·ft]	[Nm]	[lbf·ft]	[Nm]	$[lbf \cdot ft]$
450	18"	Class 150	16 × 1 1/8"	204	150	234	173	-	-
500	20"	Class 150	20 × 1 1/8"	183	135	217	160	-	-
600	24"	Class 150	20 × 1 ¼"	268	198	307	226	-	-

${\it Promag L tightening torques for AWWA}$

Nominal diameter		AWWA	Threaded fasteners	Max. tightening torque					
		Pressure rating		Hartgummi		Polyurethane		PTFE	
[mm]	[inch]			[Nm]	[lbf·ft]	[Nm]	[lbf·ft]	[Nm]	[lbf·ft]
700	28"	Class D	28 × 1 ¼"	247	182	292	215	-	-
750	30"	Class D	28 × 1 ¼"	287	212	302	223	-	-
800	32"	Class D	28 × 1 ½"	394	291	422	311	-	-
900	36"	Class D	32 × 1 ½"	419	309	430	317	-	-
1000	40"	Class D	36 × 1 ½"	420	310	477	352	-	-
1050	42"	Class D	36 × 1 ½"	528	389	518	382	-	-
1200	48"	Class D	44 × 1 ½"	552	407	531	392	ı	-

Promag L tightening torques for AS 2129

Nominal dia- meter	AS 2129	Threaded fasteners	Max. tightening torque				
	Pressure rating		Hard rubber Polyurethane		PTFE		
[mm]			[Nm]	[Nm]	[Nm]		
350	Table E	12 × M 24	203	-	-		
400	Table E	12 × M 24	226	-	-		
450	Table E	16 × M 24	226	-	-		
500	Table E	16 × M 24	271	-	-		
600	Table E	16 × M 30	439	-	-		
700	Table E	20 × M 30	355	-	-		
750	Table E	20 × M 30	559	-	-		
800	Table E	20 × M 30	631	-	-		
900	Table E	24 × M 30	627	-	-		
1000	Table E	24 × M 30	634	-	-		
1200	Table E	32 × M 30	727	-	-		

Promag L tightening torques for AS 4087

Nominal dia- meter	AS 4087	Threaded fasteners	Max. tightening torque				
	Pressure rating		Hard rubber	Polyurethane	PTFE		
[mm]			[Nm]	[Nm]	[Nm]		
350	PN 16	12 × M 24	203	-	-		
375	PN 16	12 × M 24	137	-	-		
400	PN 16	12 × M 24	226	-	-		
450	PN 16	12 × M 24	301	-	-		
500	PN 16	16 × M 24	271	-	-		
600	PN 16	16 × M 27	393	-	-		
700	PN 16	20 × M 27	330	-	-		
750	PN 16	20 × M 30	529	-	-		
800	PN 16	20 × M 33	631	-	-		
900	PN 16	24 × M 33	627	-	-		
1000	PN 16	24 × M 33	595	-	-		
1200	PN 16	32 × M 33	703	-	-		

Installation Promag 50

3.3.5 Installing the Promag P sensor



Caution!

- The protective covers mounted on the two sensor flanges guard the PTFE, which is turned over the flanges. Consequently, do not remove these covers until **immediately before** the sensor is installed in the pipe.
- The covers must remain in place while the device is in storage.
- Make sure that the lining is not damaged or removed from the flanges.



Note

Bolts, nuts, seals, etc. are not included in the scope of supply and must be supplied by the customer.

The sensor is designed for installation between the two piping flanges.

- Observe in any case the necessary screw tightening torques on $\rightarrow \triangleq 33$
- If grounding disks are used, follow the mounting instructions which will be enclosed with the shipment




Fig. 22: Installing the Promag P sensor

Seals

Comply with the following instructions when installing seals:

- PFA or PTFE lining → No seals are required!
- For DIN flanges, use only seals according to EN 1514-1.
- Make sure that the seals do not protrude into the piping cross-section.



Caution!

Risk of short circuit! Do not use electrically conductive sealing compounds such as graphite! An electrically conductive layer could form on the inside of the measuring tube and short-circuit the measuring signal.

Ground cable

- Information on potential equalization and detailed mounting instructions for the use of ground cables can be found on \rightarrow $\stackrel{\triangle}{=}$ 55

Promag 50 Installation

Installing the high-temperature version (with PFA lining)

The high-temperature version has a housing support for the thermal separation of sensor and transmitter. The high-temperature version is always used for applications in which high ambient temperatures are encountered **in conjunction with** high fluid temperatures. The high-temperature version is obligatory if the fluid temperature exceeds $+150\,^{\circ}$ C.



Note

You will find information on permissible temperature ranges on $\rightarrow \triangleq 103$

Insulation

Pipes generally have to be insulated if they carry very hot fluids, in order to avoid energy losses and to prevent accidental contact with pipes at temperatures that could cause injury. Guidelines regulating the insulation of pipes have to be taken into account.



Caution!

Risk of measuring electronics overheating. The housing support dissipates heat and its entire surface area must remain uncovered. Make sure that the sensor insulation does not extend past the top of the two sensor shells.




Fig. 23: Promag P (high-temperature version): Insulating the pipe

Tightening torques for threaded fasteners (Promag P)

Please note the following:

- The tightening torques listed below are for lubricated threads only.
- Always tighten the screws uniformly and in diagonally opposite sequence.
- Overtightening the screws will deform the sealing faces or damage the seals.
- The tightening torques listed below apply only to pipes not subjected to tensile stress.

Tightening torques for:

- EN (DIN) → 🖺 34
- ASME → 🗎 34
- JIS → 🗎 35
- AS 2129 → 🖺 35
- AS 4087 → 🖺 35

Installation Promag 50

Promag P tightening torques for EN (DIN)

Nominal diameter	EN (DIN)	Threaded	Max. tightening torque [Nm]		
[mm]	Pressure rating [bar]	fasteners	PTFE	PFA	
15	PN 40	4 × M 12	11	-	
25	PN 40	4 × M 12	26	20	
32	PN 40	4 × M 16	41	35	
40	PN 40	4 × M 16	52	47	
50	PN 40	4 × M 16	65	59	
65 *	PN 16	8 × M 16	43	40	
65	PN 40	8 × M 16	43	40	
80	PN 16	8 × M 16	53	48	
80	PN 40	8 × M 16	53	48	
100	PN 16	8 × M 16	57	51	
100	PN 40	8 × M 20	78	70	
125	PN 16	8 × M 16	75	67	
125	PN 40	8 × M 24	111	99	
150	PN 16	8 × M 20	99	85	
150	PN 40	8 × M 24	136	120	
200	PN 10	8 × M 20	141	101	
200	PN 16	12 × M 20	94	67	
200	PN 25	12 × M 24	138	105	
250	PN 10	12 × M 20	110	_	
250	PN 16	12 × M 24	131	_	
250	PN 25	12 × M 27	200	_	
300	PN 10	12 × M 20	125	_	
300	PN 16	12 × M 24	179	_	
300	PN 25	16 × M 27	204	_	
350	PN 10	16 × M 20	188	_	
350	PN 16	16 × M 24	254	_	
350	PN 25	16 × M 30	380	_	
400	PN 10	16 × M 24	260	_	
400	PN 16	16 × M 27	330	_	
400	PN 25	16 × M 33	488	_	
450	PN 10	20 × M 24	235	_	
450	PN 16	20 × M 27	300	_	
450	PN 25	20 × M 33	385	_	
500	PN 10	20 × M 24	265	_	
500	PN 16	20 × M 30	448	_	
500	PN 25	20 × M 33	533	_	
600	PN 10	20 × M 27	345	_	
600 *	PN 16	20 × M 33	658	_	
600	PN 25	20 × M 36	731	_	
* Designed acc. to EN	1092-1 (not to DIN 2501)		I		

Promag P tightening torques for ASME

Nominal	diameter	ASME			Max. tightening torque			
		Pressure	Threaded	PT	'FE	PI	PFA	
[mm]	[inch]	rating [lbs]	fasteners	[Nm]	[lbf⋅ft]	[Nm]	[lbf·ft]	
15	1/2"	Class 150	4 × ½"	6	4	-	-	
15	1/2"	Class 300	4 × ½"	6	4	-	-	
25	1"	Class 150	4 × ½"	11	8	10	7	
25	1"	Class 300	4 × 5/8"	14	10	12	9	
40	1 ½"	Class 150	4 × ½"	24	18	21	15	
40	1 ½"	Class 300	4 × 3/4"	34	25	31	23	
50	2"	Class 150	4 × 5/8"	47	35	44	32	
50	2"	Class 300	8 × 5/8"	23	17	22	16	
80	3"	Class 150	4 × 5/8"	79	58	67	49	

Promag 50 Installation

Nominal diameter		ASME			Max. tighte	ning torque	:
		Pressure	Threaded	PT	FE	PFA	
[mm]	[inch]	rating [lbs]	fasteners	[Nm]	[lbf · ft]	[Nm]	[lbf·ft]
80	3"	Class 300	8 × ¾"	47	35	42	31
100	4"	Class 150	8 × 5/8"	56	41	50	37
100	4"	Class 300	8 × ¾,"	67	49	59	44
150	6"	Class 150	8 × ¾,"	106	78	86	63
150	6"	Class 300	12 × ¾"	73	54	67	49
200	8"	Class 150	8 × ¾,"	143	105	109	80
250	10"	Class 150	12 × 7/8"	135	100	-	-
300	12"	Class 150	12 × 7/8"	178	131	-	-
350	14"	Class 150	12 × 1"	260	192	-	-
400	16"	Class 150	16 × 1"	246	181	-	-
450	18"	Class 150	16 × 1 1/8"	371	274	-	-
500	20"	Class 150	20 × 1 1/8"	341	252	-	-
600	24"	Class 150	20 × 1 ¼"	477	352	ı	_

Promag P tightening torques for JIS

Nominal diameter	JIS		Max. tightenii	ng torque [Nm]
[mm]	Pressure rating	Threaded fasteners	PTFE	PFA
25	10K	4 × M 16	32	27
25	20K	4 × M 16	32	27
32	10K	4 × M 16	38	-
32	20K	4 × M 16	38	_
40	10K	4 × M 16	41	37
40	20K	4 × M 16	41	37
50	10K	4 × M 16	54	46
50	20K	8 × M 16	27	23
65	10K	4 × M 16	74	63
65	20K	8 × M 16	37	31
80	10K	8 × M 16	38	32
80	20K	8 × M 20	57	46
100	10K	8 × M 16	47	38
100	20K	8 × M 20	75	58
125	10K	8 × M 20	80	66
125	20K	8 × M 22	121	103
150	10K	8 × M 20	99	81
150	20K	12 × M 22	108	72
200	10K	12 × M 20	82	54
200	20K	12 × M 22	121	88
250	10K	12 × M 22	133	_
250	20K	12 × M 24	212	_
300	10K	16 × M 22	99	-
300	20K	16 × M 24	183	_

Promag P tightening torques for AS 2129

Nominal diameter [mm]	AS 2129 Pressure rating	Threaded fasteners	Max. tightening torque [Nm] PTFE
25	Table E	4 × M 12	21
50	Table E	4 × M 16	42

Promag P tightening torques for AS 4087

Nominal diameter	AS 4087	Threaded fasteners	Max. tightening torque [Nm]
[mm]	Pressure rating		PTFE
50	PN 16	4 × M 16	42

Installation Promag 50

3.3.6 Installing the Promag W sensor



Note!

Bolts, nuts, seals, etc. are not included in the scope of supply and must be supplied by the customer.

The sensor is designed for installation between the two piping flanges.

- Observe in any case the necessary screw tightening torques on $\rightarrow \triangleq 36$
- If grounding disks are used, follow the mounting instructions which will be enclosed with the shipment




Fig. 24: Installing the Promag W sensor

Seals

Comply with the following instructions when installing seals:

- Hard rubber lining → additional seals are **always** necessary.
- Polyurethane lining \rightarrow **no** seals are required.
- For DIN flanges, use only seals according to EN 1514-1.
- Make sure that the seals do not protrude into the piping cross-section.



Caution!

Risk of short circuit!

Do not use electrically conductive sealing compounds such as graphite! An electrically conductive layer could form on the inside of the measuring tube and short-circuit the measuring signal.

Ground cable

- Information on potential equalization and detailed mounting instructions for the use of ground cables can be found on \rightarrow \cong 57

Screw tightening torques (Promag W)

Please note the following:

- The tightening torques listed below are for lubricated threads only.
- $\ \ \, \blacksquare$ Always tighten the screws uniformly and in diagonally opposite sequence.
- Overtightening the screws will deform the sealing faces or damage the seals.
- The tightening torques listed below apply only to pipes not subjected to tensile stress.

Promag 50 Installation

Tightening torques for:

- EN (DIN) → 🖹 37
- JIS→ 🖺 39
- ASME → 🖺 38
- AWWA → 🗎 39
- AS 2129 → 🗎 40
- AS 4087 → 🖺 40

Promag W tightening torques for EN (DIN)

Nominal diameter	EN (DIN)	Threaded	Max. tightening torque [Nm]		
[mm]	Pressure rating [bar]	fasteners	Hard rubber	Polyurethane	
25	PN 40	4 × M 12	-	15	
32	PN 40	4 × M 16	-	24	
40	PN 40	4 × M 16	-	31	
50	PN 40	4 × M 16	48	40	
65*	PN 16	8 × M 16	32	27	
65	PN 40	8 × M 16	32	27	
80	PN 16	8 × M 16	40	34	
80	PN 40	8 × M 16	40	34	
100	PN 16	8 × M 16	43	36	
100	PN 40	8 × M 20	59	50	
125	PN 16	8 × M 16	56	48	
125	PN 40	8 × M 24	83	71	
150	PN 16	8 × M 20	74	63	
150	PN 40	8 × M 24	104	88	
200	PN 10	8 × M 20	106	91	
200	PN 16	12 × M 20	70	61	
200	PN 25	12 × M 24	104	92	
250	PN 10	12 × M 20	82	71	
250	PN 16	12 × M 24	98	85	
250	PN 25	12 × M 27	150	134	
300	PN 10	12 × M 20	94	81	
300	PN 16	12 × M 24	134	118	
300	PN 25	16 × M 27	153	138	
350	PN 6	12 × M 20	111	120	
350	PN 10	16 × M 20	112	118	
350	PN 16	16 × M 24	152	165	
350	PN 25	16 × M 30	227	252	
400	PN 6	16 × M 20	90	98	
400	PN 10	16 × M 24	151	167	
400	PN 16	16 × M 27	193	215	
400	PN 25	16 × M 33	289	326	
450	PN 6	16 × M 20	112	126	
450	PN 10	20 × M 24	153	133	
450	PN 16	20 × M 27	198	196	
450	PN 25	20 × M 33	256	253	
500	PN 6	20 × M 20	119	123	
500	PN 10	20 × M 24	155	171	
500	PN 16	20 × M 30	275	300	
500	PN 25	20 × M 33	317	360	
600	PN 6	20 × M 24	139	147	
600	PN 10	20 × M 27	206	219	
600 *	PN 16	20 × M 33	415	443	
600	PN 25	20 × M 36	431	516	
700	PN 6	24 × M 24	148	139	
700	PN 10	24 × M 27	246	246	
700	PN 16	24 × M 33	278	318	

Installation Promag 50

Nominal	EN (DIN)		Max. tightening torque [Nr	
diameter [mm]	Pressure rating [bar]	Threaded fasteners	Hard rubber	Polyurethane
700	PN 25	24 × M 39	449	507
800	PN 6	24 × M 27	206	182
800	PN 0	24 × M 30	331	316
800	PN 16	24 × M 36	369	385
800	PN 25	24 × M 45	664	721
900	PN 6	24 × M 27	230	637
900	PN 10	28 × M 30	316	307
900	PN 16	28 × M 36	353	398
900	PN 25	28 × M 45	690	716
1000	PN 6	28 × M 27	218	208
1000	PN 10	$28 \times M33$	402	405
1000	PN 16	28 × M 39	502	518
1000	PN 25	28 × M 52	970	971
1200	PN 6	32 × M 30	319	299
1200	PN 10	32 × M 36	564	568
1200	PN 16	32 × M 45	701	753
1400	PN 6	36 × M 33	430	398
1400	PN 10	36 × M 39	654	618
1400	PN 16	36 × M 45	729	762
1600	PN 6	40 × M 33	440	417
1600	PN 10	40 × M 45	946	893
1600	PN 16	40 × M 52	1007	1100
1800	PN 6	44 × M 36	547	521
1800	PN 10	44 × M 45	961	895
1800	PN 16	44 × M 52	1108	1003
2000	PN 6	48 × M 39	629	605
2000	PN 10	48 × M 45	1047	1092
2000	PN 16	48 × M 56	1324	1261
* Designed acc. to I	EN 1092-1 (not to DIN 2501))		

Promag W tightening torques for ASME

Nominal		ASME		Max. tightening torque			
dian	neter	Pressure rating	Threaded	Hard rubber		Polyurethane	
[mm]	[inch]	[lbs]	fasteners	[Nm]	[lbf · ft]	[Nm]	[lbf·ft]
25	1"	Class 150	4 × ½"	-	-	7	5
25	1"	Class 300	4 × 5/8"	-	-	8	6
40	1 1/2"	Class 150	4 × ½"	-	-	10	7
40	1 1/2"	Class 300	4 × 3/4"	-	-	15	11
50	2"	Class 150	4 × 5/8"	35	26	22	16
50	2"	Class 300	8 × 5/8"	18	13	11	8
80	3"	Class 150	4 × 5/8"	60	44	43	32
80	3"	Class 300	8 × ¾"	38	28	26	19
100	4"	Class 150	8 × 5/8"	42	31	31	23
100	4"	Class 300	8 × ¾"	58	43	40	30
150	6"	Class 150	8 × ¾"	79	58	59	44
150	6"	Class 300	12 × ¾"	70	52	51	38
200	8"	Class 150	8 × ¾"	107	79	80	59
250	10"	Class 150	12 × 7/8"	101	74	75	55
300	12"	Class 150	12 × 7/8"	133	98	103	76
350	14"	Class 150	12 × 1"	135	100	158	117
400	16"	Class 150	16 × 1"	128	94	150	111
450	18"	Class 150	16 × 1 1/8"	204	150	234	173
500	20"	Class 150	20 × 1 1/8"	183	135	217	160
600	24"	Class 150	20 × 1 1/4"	268	198	307	226

Promag 50 Installation

Promag W tightening torques for JIS

Nominal diameter	JIS	Threaded	Max. tighteni	ng torque [Nm]
[mm]	Pressure rating	fasteners	Hard rubber	Polyurethane
25	10K	4 × M 16	-	19
25	20K	4 × M 16	-	19
32	10K	4 × M 16	-	22
32	20K	4 × M 16	-	22
40	10K	4 × M 16	-	24
40	20K	4 × M 16	-	24
50	10K	4 × M 16	40	33
50	20K	8 × M 16	20	17
65	10K	4 × M 16	55	45
65	20K	8 × M 16	28	23
80	10K	8 × M 16	29	23
80	20K	8 × M 20	42	35
100	10K	8 × M 16	35	29
100	20K	8 × M 20	56	48
125	10K	8 × M 20	60	51
125	20K	8 × M 22	91	79
150	10K	8 × M 20	75	63
150	20K	12 × M 22	81	72
200	10K	12 × M 20	61	52
200	20K	12 × M 22	91	80
250	10K	12 × M 22	100	87
250	20K	12 × M 24	159	144
300	10K	16 × M 22	74	63
300	20K	16 × M 24	138	124

Promag W tightening torques for AWWA

Nominal	diameter	AWWA		Max. tightening torque			
		Pressure	Threaded	Hard	rubber	Polyur	ethane
[mm]	[inch]	rating	fasteners	[Nm]	[lbf⋅ft]	[Nm]	[lbf·ft]
700	28"	Class D	28 × 1 1/4"	247	182	292	215
750	30"	Class D	28 × 1 1/4"	287	212	302	223
800	32"	Class D	28 × 1 ½"	394	291	422	311
900	36"	Class D	32 × 1 ½"	419	309	430	317
1000	40"	Class D	36 × 1 ½"	420	310	477	352
1050	42"	Class D	36 × 1 ½"	528	389	518	382
1200	48"	Class D	44 × 1 ½"	552	407	531	392
1350	54"	Class D	44 × 1 ¾"	730	538	633	467
1500	60"	Class D	52 × 1 ¾"	758	559	832	614
1650	66"	Class D	52 × 1 ¾"	946	698	955	704
1800	72"	Class D	60 × 1 ¾"	975	719	1087	802
2000	78"	Class D	64 × 2"	853	629	786	580

Installation Promag 50

Promag W tightening torques for AS 2129

Nominal diameter [mm]	AS 2129 Pressure rating	Threaded fasteners	Max. tightening torque [Nm] Hard rubber
50	Table E	4 × M 16	32
80	Table E	4 × M 16	49
100	Table E	8 × M 16	38
150	Table E	8 × M 20	64
200	Table E	8 × M 20	96
250	Table E	12 × M 20	98
300	Table E	12 × M 24	123
350	Table E	12 × M 24	203
400	Table E	12 × M 24	226
450	Table E	16 × M 24	226
500	Table E	16 × M 24	271
600	Table E	16 × M 30	439
700	Table E	20 × M 30	355
750	Table E	20 × M 30	559
800	Table E	20 × M 30	631
900	Table E	24 × M 30	627
1000	Table E	24 × M 30	634
1200	Table E	32 × M 30	727

Promag W tightening torques for AS 4087

Nominal diameter [mm]	AS 4087 Pressure rating	Threaded fasteners	Max. tightening torque [Nm] Hard rubber
50	Table E	4 × M 16	32
80	PN 16	4 × M 16	49
100	PN 16	4 × M 16	76
150	PN 16	8 × M 20	52
200	PN 16	8 × M 20	77
250	PN 16	8 × M 20	147
300	PN 16	12 × M 24	103
350	PN 16	12 × M 24	203
375	PN 16	12 × M 24	137
400	PN 16	12 × M 24	226
450	PN 16	12 × M 24	301
500	PN 16	16 × M 24	271
600	PN 16	16 × M 27	393
700	PN 16	20 × M 27	330
750	PN 16	20 × M 30	529
800	PN 16	20 × M 33	631
900	PN 16	24 × M 33	627
1000	PN 16	24 × M 33	595
1200	PN 16	32 × M 33	703

Promag 50 Installation

3.3.7 Turning the transmitter housing

Turning the aluminum field housing



Warning!

The turning mechanism in devices with Ex d/de or FM/CSA Cl. I Div. 1 classification is not the same as that described here. The procedure for turning these housings is described in the Ex-specific documentation.

- 1. Loosen the two securing screws.
- 2. Turn the bayonet catch as far as it will go.
- 3. Carefully lift the transmitter housing:
 - Promag D: approx. 10 mm (0.39 inch) above the securing screws
 - Promag E/H/L/P/W: to the stop
- 4. Turn the transmitter housing to the desired position:
 - Promag D: max. 180° clockwise or max. 180° counterclockwise
 - Promag E/H/L/P/W: max. 280° clockwise or max. 20° counterclockwise
- 5. Lower the housing into position and re-engage the bayonet catch.
- 6. Retighten the two securing screws.




Fig. 25: Turning the transmitter housing (aluminum field housing)

Turning the stainless-steel field housing

- 1. Loosen the two securing screws.
- 2. Carefully lift the transmitter housing as far as it will go.
- 3. Turn the transmitter housing to the desired position (max. $2 \times 90^{\circ}$ in either direction).
- 4. Lower the housing into position.
- 5. Retighten the two securing screws.




Fig. 26: Turning the transmitter housing (stainless-steel field housing)

Endress+Hauser 41

0004302

Installation Promag 50

3.3.8 Turning the onsite display

- 1. Unscrew the cover of the electronics compartment from the transmitter housing.
- 2. Press the side latches on the display module and remove it from the electronics compartment cover plate.
- 3. Turn the display to the desired position (max. $4 \times 45^{\circ}$ in both directions) and reset it onto the cover plate of the electronics compartment.
- 4. Screw the cover of the electronics compartment firmly back onto the transmitter housing.




Fig. 27: Turning the local display (field housing)

Promag 50 Installation

3.3.9 Installing the wall-mount housing

There are various ways of installing the wall-mount transmitter housing:

- Direct wall mounting
- Installation in control panel (with separate mounting kit, accessories) → 🗎 44



Caution

- Make sure that the ambient temperature does not exceed the permissible range at the mounting location, -20 to +60 °C (-4 to +140 °F), optional -40 to +60 °C (-40 to +140 °F). Install the device at a shady location. Avoid direct sunlight.
- Always install the wall-mount housing in such a way that the cable entries are pointing down.

Direct wall mounting

- 1. Drill the holes as illustrated in the graphic.
- 2. Remove the cover of the connection compartment (a).
- 3. Push the two securing screws (b) through the appropriate bores (c) in the housing.
 - Securing screws (M6): max. Ø 6.5 mm (0.26")
 - Screw head: max. Ø 10.5 mm (0.41")
- 4. Secure the transmitter housing to the wall as indicated.
- 5. Screw the cover of the connection compartment (a) firmly onto the housing.




Fig. 28: Mounted directly on the wall

Installation Promag 50

Panel-mounted installation

- 1. Prepare the opening in the panel as illustrated in the graphic.
- 2. Slide the housing into the opening in the panel from the front.
- 3. Screw the fasteners onto the wall-mount housing.
- 4. Place the threaded rods in the fasteners and screw them down until the housing is seated tightly against the panel. Afterwards, tighten the locking nuts. Additional support is not necessary.




Fig. 29: Panel installation (wall-mount housing)

Pipe mounting

The assembly should be performed by following the instructions in the graphic.



Caution!

If the device is mounted to a warm pipe, make certain that the housing temperature does not exceed +60 $^{\circ}$ C (+140 $^{\circ}$ F), which is the maximum permissible temperature.




Fig. 30: Pipe mounting (wall-mount housing)

Promag 50 Installation

3.4 Post-installation check

Perform the following checks after installing the measuring device in the pipe:

Device condition and specifications	Notes
Is the device damaged (visual inspection)?	-
Does the device correspond to specifications at the measuring point, including process temperature and pressure, ambient temperature, minimum fluid conductivity, measuring range, etc.?	→ 🖺 103
Installation	Notes
Does the arrow on the sensor nameplate match the actual direction of flow through the pipe?	-
Is the position of the measuring electrode plane correct?	→ 🗎 14
Is the position of the empty pipe detection electrode correct?	→ 🖺 14
Were all screws tightened to the specified torques when the sensor was installed?	Promag D $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ $
Were the correct seals used (type, material, installation)?	Promag D → $\stackrel{\square}{=}$ 20 Promag E → $\stackrel{\square}{=}$ 23 Promag H → $\stackrel{\square}{=}$ 26 Promag L → $\stackrel{\square}{=}$ 29 Promag P → $\stackrel{\square}{=}$ 32 Promag W → $\stackrel{\square}{=}$ 36
Are the measuring point number and labeling correct (visual inspection)?	-
Process environment / process conditions	Notes
Were the inlet and outlet runs respected?	Inlet run $\geq 5 \times DN$ Outlet run $\geq 2 \times DN$
Is the measuring device protected against moisture and direct sunlight?	-
Is the sensor adequately protected against vibration (attachment, support)?	Acceleration up to 2 g by analogy with IEC 600 68-2-8

Wiring Promag 50

4 Wiring



Warning!

When connecting Ex-certified devices, see the notes and diagrams in the Ex-specific supplement to these Operating Instructions.

Please do not hesitate to contact your Endress+Hauser representative if you have any questions.



Note!

The device does not have an internal circuit breaker. For this reason, assign the device a switch or power-breaker switch capable of disconnecting the power supply line from the mains.

4.1 Connecting the remote version

4.1.1 Connecting Promag D/E/H/L/P/W



Warning!

- Risk of electric shock! Switch off the power supply before opening the device. Do **not** install
 or wire the device while it is connected to the power supply. Failure to comply with this
 precaution can result in irreparable damage to the electronics.
- Risk of electric shock! Connect the protective conductor to the ground terminal on the housing before the power supply is applied.



Caution!

- Only sensors and transmitters with the same serial number can be connected to one another. Communication problems can occur if the devices are not connected in this way.
- Risk of damaging the coil driver. Always switch off the power supply before connecting or disconnecting the coil cable.

Procedure

- 1. Transmitter: Remove the cover from the connection compartment (a).
- 2. Sensor: Remove the cover from the connection housing (b).
- 3. Feed the signal cable (c) and the coil cable (d) through the appropriate cable entries.
 - d Caution!

Route the connecting cables securely (see "Connecting cable length" $\rightarrow \triangleq 19$).

4. Terminate the signal and coil current cable as indicated in the table:

Promag D/E/L/P/W \rightarrow Refer to the table $\rightarrow \triangleq 49$

Promag H \rightarrow Refer to the "Cable termination" table $\rightarrow \triangleq 50$

5. Establish the wiring between the sensor and the transmitter.

The electrical wiring diagram that applies to your device can be found:

- ► In the corresponding graphic:
 - \rightarrow 31 (Promag D) \rightarrow 32 (Promag E/L/P/W); \rightarrow 33 (Promag H)
- ▶ In the cover of the sensor and transmitter



The cable shields of the Promag H sensor are grounded by means of the strain relief terminals (see also the "Cable termination" table $\rightarrow \triangleq 50$)

് Caution!

Insulate the shields of cables that are not connected to eliminate the risk of short-circuits with neighboring cable shields inside the connection housing.

- 6. Transmitter: Screw the cover on the connection compartment (a).
- 7. Sensor: Secure the cover on the connection housing (b).

Promag 50 Wiring

Promag D




Fig. 31: Connecting the remote version of Promag D

- Wall-mount housing connection compartment Cover of the sensor connection housing Signal cable

- Coil current cable
- Not connected, insulated cable shields

Wire colors/Terminal No.:

5/6 = braun, 7/8 = white, 4 = green, 37/36 = yellow

Promag E/L/P/W




Fig. 32: Connecting the remote version of Promag E/L/P/W

- Wall-mount housing connection compartment
- Cover of the sensor connection housing
- Signal cable c d
- Coil current cable
- Not connected, insulated cable shields

Wire colors/Terminal No.:

5/6 = braun, 7/8 = white, 4 = green, 37/36 = yellow

Wiring Promag 50

Promag H




Fig. 33: Connecting the remote version of Promag \boldsymbol{H}

- Wall-mount housing connection compartment Cover of the sensor connection housing Signal cable Coil current cable а
- b
- c d
- Not connected, insulated cable shields n.c.

Wire colors/Terminal No.: 5/6 = braun, 7/8 = white, 4 = green, 37/36 = yellow

Promag 50 Wiring

Cable termination for the remote version Promag D/E/L/P/W

Terminate the signal and coil current cables as shown in the figure below (Detail A).


Ferrules must be provided on the fine-wire cores (Detail B: \odot = red ferrules, \varnothing 1.0 mm; \circledcirc = white ferrules, \varnothing 0.5 mm).


* Stripping only for reinforced cables



- Caution!
 When fitting the connectors, pay attention to the following points: • $Signal\ cable \rightarrow Make$ sure that the ferrules do not touch the wire shield on the sensor side. Minimum distance = 1 mm (exception "GND" = green cable)
- *Coil current cable* → Insulate one core of the three-core wire at the level of the core reinforcement; you only require two cores for the connection.







Wiring Promag 50

Cable termination for the remote version Promag H

Terminate the signal and coil current cables as shown in the figure below (Detail A).


Ferrules must be provided on the fine-wire cores (Detail B: \odot = red ferrules, \varnothing 1.0 mm; \varnothing = white ferrules, \varnothing 0.5 mm).




When fitting the connectors, pay attention to the following points:

- Signal cable → Make sure that the ferrules do not touch the wire shield on the sensor side.
 Minimum distance = 1 mm (exception "GND" = green cable).
- *Coil current cable* → Insulate one core of the three-core wire at the level of the core reinforcement; you only require two cores for the connection.
- On the sensor side, reverse both cable shields approx. 15 mm over the outer jacket. The strain relief ensures an electrical connection with the connection housing.

TRANSMITTER



SENSOR



Promag 50 Wiring

4.1.2 Cable specifications


Signal cable

• $3 \times 0.38 \text{ mm}^2$ PVC cable with common, braided copper shield ($\emptyset \sim 7 \text{ mm}$) and individually shielded cores

- With Empty Pipe Detection (EPD): 4 × 0.38 mm² PVC cable with common, braided copper shield ($\emptyset \sim 7$ mm) and individually shielded cores
- Conductor resistance: \leq 50 Ω/km
- Capacitance: core/shield: ≤ 420 pF/m
- Permanent operating temperature: -20 to +80 °C
- Cable cross-section: max. 2.5 mm²

Coil cable

- 2 × 0.75 mm² PVC cable with common, braided copper shield ($\varnothing \sim 7$ mm)
- Conductor resistance: \leq 37 Ω/km
- Capacitance: core/core, shield grounded: ≤ 120 pF/m
- Operating temperature: -20 to +80 °C
- Cable cross-section: max. 2.5 mm²
- Test voltage for cable insulation: ≥1433 V AC r.m.s. 50/60 Hz or ≥2026 V DC



Fia. 34: Cable cross-section

- Signal cable
- Coil current cable
- Core
- Core insulation
- Core shield
- Core jacket
- Core reinforcement
- Cable shield
- Outer jacket

Reinforced connecting cables

As an option, Endress+Hauser can also deliver reinforced connecting cables with an additional, reinforcing metal braid. Reinforced connecting cables should be used when laying the cable directly in the ground, if there is a risk of damage from rodents or if using the measuring device below IP 68 degree of protection.

Operation in zones of severe electrical interference:

The measuring device complies with the general safety requirements in accordance with EN 61010 and the EMC requirements of IEC/EN 61326.



Caution!

Grounding is by means of the ground terminals provided for the purpose inside the connection housing. Ensure that the stripped and twisted lengths of cable shield to the ground terminal are as short as possible.

Wiring Promag 50

4.2 Connecting the measuring unit

4.2.1 Connecting the transmitter



Warning!

- Risk of electric shock! Switch off the power supply before opening the device. Do not install
 or wire the device while it is energized. Failure to comply with this precaution can result in
 irreparable damage to the electronics.
- Risk of electric shock! Connect the protective conductor to the ground terminal on the housing before the power supply is applied (not necessary if the power supply is galvanically isolated).
- Compare the specifications on the nameplate with the local voltage supply and frequency. Also comply with national regulations governing the installation of electrical equipment.
- 1. Remove the cover of the connection compartment (f) from the transmitter housing.
- 2. Feed the power supply cable (a) and the signal cable (b) through the appropriate cable entries.
- 3. Perform the wiring:
 - Wiring diagram (aluminum housing) \rightarrow **2** 35
 - Wiring diagram (stainless steel housing) → 36
 - Wiring diagram (wall-mount housing) \rightarrow 37
 - Terminal assignment → 🖺 54
- 4. Screw the cover of the connection compartment (f) firmly onto the transmitter housing.




Fig. 35: Connecting the transmitter (aluminum field housing). Cable cross-section: max. 2.5 mm²

- a Cable for power supply: 85 to 260 V AC, 20 to 55 V AC, 16 to 62 V DC
 - Terminal **No. 1**: L1 for AC, L+ for DC
- Terminal No. 2: N for AC, L- for DC b Signal cable: Terminals Nos. $20-27 \rightarrow \triangle 54$
- c Ground terminal for protective ground
- d Ground terminal for signal cable shield
- Service connector for connecting service interface FXA193 (Fieldcheck, FieldCare)
- f Cover of the connection compartment
- g Securing clamp

Promag 50 Wiring




Fig. 36: Connecting the transmitter (stainless steel field housing); cable cross-section: max. 2.5 mm²

- Cable for power supply: 85 to 260 V AC, 20 to 55 V AC, 16 to 62 V DC Terminal No. 1: L1 for AC, L+ for DC Terminal No. 2: N for AC, L- for DC Signal cable: Terminals Nos. 20–27 \Rightarrow \triangleq 54
- b
- Ground terminal for protective ground Ground terminal for signal cable shield
- Service connector for connecting service interface FXA193 (Fieldcheck, FieldCare)
- Cover of the connection compartment




Fig. 37: Connecting the transmitter (wall-mount housing); cable cross-section: max. 2.5 mm²

- Cable for power supply: 85 to 260 V AC, 20 to 55 V AC, 16 to 62 V DC Terminal **No.** 1: L1 for AC, L+ for DC Terminal **No.** 2: N for AC, L- for DC Signal cable: Terminals **Nos.** 20–27 \Rightarrow \cong 54
- h
- Ground terminal for protective ground
- Ground terminal for signal cable shield
- Service connector for connecting service interface FXA193 (Fieldcheck, FieldCare)
- Cover of the connection compartment

Wiring Promag 50

4.2.2 Terminal assignment

	Terminal No. (inputs / outputs)			
Order version	20 (+) / 21 (-)	22 (+) / 23 (-)	24 (+) / 25 (-)	26 (+) / 27 (-)
50***-********W	-	-	-	Current output HART
50***-********A	-	-	Frequency output	Current output HART
50***-********D	Status input	Status output	Frequency output	Current output HART
50***-********	-	-	Frequency output Ex i	Current output, Ex i, active, HART
50***-********T	-	-	Frequency output Ex i	Current output, Ex i, passive, HART



Functional values of the inputs and outputs $\rightarrow \triangleq 98$

4.2.3 **HART** connection

Users have the following connection options at their disposal:

- Direct connection to transmitter by means of terminals 26(+) and 27 (-)
- Connection by means of the 4 to 20 mA circuit.



- The measuring loop's minimum load must be at least 250 Ω .
- After commissioning, make the following settings:
- CURRENT SPAN function \rightarrow "4-20 mA HART"
- Switch HART write protection on or off $\rightarrow \triangleq 65$

Connection of the HART handheld communicator

See also the documentation issued by the HART Communication Foundation, and in particular HCF LIT 20: "HART, a technical summary".




Fig. 38: Electrical connection of HART handheld Field Xpert SFX100

- HART handheld Field Xpert SFX100
- Auxiliary energy Shielding
- Other devices or PLC with passive input

Promag 50 Wiring

Connection of a PC with an operating software

In order to connect a PC with operating software (e.g. "FieldCare"), a HART modem (e.g. "Commubox FXA195") is needed.




Fig. 39: Electrical connection of a PC with operating software

- 1 PC with operating software
- 2 Auxiliary energy
- 3 Shielding
- 4 Other devices or PLC with passive input
- HART modem, e.g. Commubox FXA 195

4.3 Potential equalization



Warning!

The measuring system must be included in the potential equalization.

Perfect measurement is only ensured when the fluid and the sensor have the same electrical potential. This is ensured by the reference electrode integrated in the sensor as standard.

The following should also be taken into consideration for potential equalization:

- Internal grounding concepts in the company
- Operating conditions, such as the material/grounding of the pipes (see Table)

4.3.1 Potential equalization for Promag D

- No reference electrode is integrated!
 For the two ground disks of the sensor an electrical connection to the fluid is always ensured.
- Exampels for connections \rightarrow 🗎 56

4.3.2 Potential equalization for Promag E/L/P/W

- Reference electrode integrated in the sensor as standard
- Exampels for connections → 🗎 57

4.3.3 Potential equalization for Promag H

No reference electrode is integrated!

For the metal process connections of the sensor an electrical connection to the fluid is always ensured.



Caution

If using process connections made of a synthetic material, ground rings have to be used to ensure that potential is equalized ($\rightarrow \boxminus 27$). The necessary ground rings can be ordered separately from Endress+Hauser as accessories ($\rightarrow \boxminus 78$).

Wiring Promag 50

4.3.4 Exampels for potential equalization connections for Promag D

Standard case

Operating conditions Potential equalization When using the measuring device in a: • Metal, grounded pipe • Plastic pipe • Pipe with insulating lining Potential equalization takes place via the ground terminal of the transmitter (standard situation). Note! When installing in metal pipes, we recommend you connect the ground terminal of the transmitter housing with the piping. Fig. 40: Via the ground terminal of the transmitter

Special cases

Operating conditions Potential equalization When using the measuring device in a: Metal pipe that is not grounded This connection method also applies in situations where: Customary potential equalization cannot be ensured • Excessively high equalizing currents can be expected Potential equalization takes place via the ground terminal of the transmitter and the two pipe flanges. Here, the ground cable (copper wire, $6 \text{ mm}^2 / 0.0093 \text{ in}^2$) is mounted directly on the conductive flange coating with flange screws. Fig. 41: Via the ground terminal of the transmitter and the flanges of the pipe When using the measuring device in a: • Pipe with a cathodic protection unit The device is installed potential-free in the pipe. Only the two flanges of the pipe are connected with a ground cable (copper wire, 6 mm² (0.0093 in²)). Here, the ground cable is mounted directly on the conductive flange coating with flange screws. Note the following when installing: • The applicable regulations regarding potential-free installation must be observed. • There should be **no** electrically conductive connection a00012174 Potential equalization and cathodic between the pipe and the device. Fig. 42: protection • The mounting material must withstand the applicable torques. Power supply isolation transformer 2 Electrically isolated

Promag 50 Wiring

4.3.5 Exampels for potential equalization connections for Promag E/L/P/W

Standard case

Special cases

Operating conditions Potential equalization When using the measuring device in a: • Metal pipe that is not grounded This connection method also applies in situations where: • Customary potential equalization cannot be ensured • Excessively high equalizing currents can be expected Both sensor flanges are connected to the pipe flange by means of a ground cable (copper wire, 6 mm² / 0.0093 in²) and grounded. Connect the transmitter or sensor connection housing, as applicable, to ground potential by means of the ground terminal provided for the purpose. $DN \leq 300$ DN ≥ 350 Ground cable installation depends on the nominal diameter: • DN \leq 300 (12"): The ground cable is mounted directly on the conductive flange coating with the flange screws. $\bullet~$ DN $\geq~350$ (14"): The ground cable is mounted directly on the metal transport bracket. The ground cable for flange-to-flange connections can be ordered separately as an accessory from Endress+Hauser. Via the ground terminal of the transmitter Fig. 44: and the flanges of the pipe When using the measuring device in a: Plastic pipe Pipe with insulating lining This connection method also applies in situations where: • Customary potential equalization cannot be ensured • Excessively high equalizing currents can be expected Potential equalization takes place using additional ground disks, which are connected to the ground terminal via a ground cable (copper wire, min. 6 mm² / 0.0093 in²). When installing the ground disks, please comply with the enclosed Installation Instructions. Via the ground terminal of the transmitter Fig. 45:

Wiring Promag 50

Operating conditions Potential equalization When using the measuring device in a: Pipe with a cathodic protection unit The device is installed potential-free in the pipe. Only the two flanges of the pipe are connected with a ground cable (copper wire, 6 mm² / 0.0093 in²). Here, the ground cable is mounted directly on the conductive flange coating with flange screws. Note the following when installing: • The applicable regulations regarding potential-free installation must be observed. • There should be **no** electrically conductive connection Potential equalization and cathodic Fig. 46: between the pipe and the device. protection • The mounting material must withstand the applicable Power supply isolation transformer Electrically isolated torques.

4.4 Degree of protection

The devices meet all the requirements of IP 67 degree of protection.

Compliance with the following points is mandatory following installation in the field or servicing in order to ensure that IP 67 protection is maintained:

- The housing seals must be clean and undamaged when inserted into their grooves. The seals must be dried, cleaned or replaced if necessary.
- All threaded fasteners and screw covers must be firmly tightened.
- The cables used for connection must be of the specified outside diameter $\rightarrow \triangleq 51$.
- Firmly tighten the cable entries.
- The cables must loop down before they enter the cable entries ("water trap"). This arrangement prevents moisture penetrating the entry. Always install the measuring device in such a way that the cable entries do not point up.
- Remove all unused cable entries and insert plugs instead.
- Do not remove the grommet from the cable entry.




Fig. 47: Installation instructions, cable entries



Caution!

Do not loosen the threaded fasteners of the sensor housing, as otherwise the degree of protection quaranteed by Endress+Hauser no longer applies.



Note!

The Promag E/L/P/W sensors can be supplied with IP 68 rating (permanent immersion in water to a depth of 3 meters (10 ft)). In this case the transmitter must be installed remote from the sensor.

The Promag L sensors with IP 68 rating are only available with stainless steel flanges.

Promag 50 Wiring

4.5 Post-connection check

Perform the following checks after completing electrical installation of the measuring device:

Device condition and specifications	Notes
Are cables or the device damaged (visual inspection)?	-
Electrical connection	Notes
Does the supply voltage match the specifications on the nameplate?	 85 to 250 V AC (50 to 60 Hz) 20 to 28 V AC (50 to 60 Hz) 11 to 40 V DC
Do the cables used comply with the necessary specifications?	→ 🖺 51
Do the cables have adequate strain relief?	-
Is the cable type route completely isolated? Without loops and crossovers?	-
Are the power-supply and signal cables correctly connected?	See the wiring diagram inside the cover of the terminal compartment
Only remote version: Is the flow sensor connected to the matching transmitter electronics?	Check serial number on nameplates of sensor and connected transmitter.
Only remote version: Is the connecting cable between sensor and transmitter connected correctly?	→ 🖺 46
Are all screw terminals firmly tightened?	-
Have the measures for grounding/potential equalization been correctly implemented?	→ 🖺 55
Are all cable entries installed, firmly tightened and correctly sealed? Cables looped as "water traps"?	→ 🖺 58
Are all housing covers installed and firmly tightened?	-

Operation Promag 50

Operation 5

5.1 Display and operating elements

The local display enables you to read all important parameters directly at the measuring point and configure the device.

The display area consists of two lines; this is where measured values are displayed, and/or status variables (direction of flow, partially filled pipe, bar graph, etc.). You can change the assignment of display lines to variables at will in order to customize the display to suit your needs and preferences (\rightarrow "Description of Device Functions" manual).




Fig. 48: Display and operating elements

Liquid crystal display

The two-line liquid-crystal display shows measured values, dialog texts, error messages and information messages. The

- display as it appears when normal measuring is in progress is known as the HOME position (operating mode).

 Upper display line: Shows primary measured values, e.g. volume flow in [ml/min] or in [%].

 Lower display line: Shows supplementary measured variables and status variables, e.g. totalizer reading in [m3], bar graph, measuring point designation
- 2 Plus/minus keys
 - Enter numerical values, select parameters
 - Select different function groups within the function matrix

Press the +/- keys simultaneously to trigger the following functions:

- Exit the function matrix step by step → HOME position
- Press and hold down +/- keys for longer than 3 seconds \rightarrow Return directly to HOME position
- Cancel data entry
- Enter kev
 - HOME position → Entry into the function matrix
 - Save the numerical values you input or settings you change

Promag 50 Operation

5.2 Brief operating instructions on the function matrix




Note!

- See the general notes on $\rightarrow \triangle$ 62.
- ullet Detailed description of all the functions o "Description of Device Functions" manual

The function matrix comprises two levels, namely the function groups and the functions of the function groups.

The groups are the highest-level grouping of the control options for the device. A number of functions is assigned to each group. You select a group in order to access the individual functions for operating and configuring the device.

- HOME position $\rightarrow \blacksquare \rightarrow$ Enter the function matrix
- Select a function group (e.g. OPERATION)
- Select a function (e.g. LANGUAGE) Change parameter/enter numerical values: $\stackrel{\mathbb{H}}{\rightarrow}$ select or enter enable code, parameters, numerical values \blacksquare \rightarrow save your entries
- Exit the function matrix:
 - Press and hold down Esc key (\square) for longer than 3 seconds \rightarrow HOME position
 - Repeatedly press Esc key (\Box) \rightarrow return step by step to HOME position



Selecting functions and configuring parameters (function matrix)

Operation Promag 50

5.2.1 General notes

The Quick Setup menu ($\rightarrow \cong 72$) is adequate for commissioning in most instances. Complex measuring operations on the other hand necessitate additional functions that you can configure as necessary and customize to suit your process parameters. The function matrix, therefore, comprises a multiplicity of additional functions which, for the sake of clarity, are arranged in a number of function groups.

Comply with the following instructions when configuring functions:

- You select functions as described on $\rightarrow \triangleq 61$.
- You can switch off certain functions (OFF). If you do so, related functions in other function groups will no longer be displayed.
- Certain functions prompt you to confirm your data entries.

 Press 🕆 to select "SURE [YES]" and press 🗉 again to confirm. This saves your setting or starts a function, as applicable.
- Return to the HOME position is automatic if no key is pressed for 5 minutes.



Note!

- The transmitter continues to measure while data entry is in progress, i.e. the current measured values are output via the signal outputs in the normal way.
- If the power supply fails, all preset and configured values remain safely stored in the EEPROM.



Caution!

All functions are described in detail, including the function matrix itself, in the "Description of Device Functions" manual, which is a separate part of these Operating Instructions.

5.2.2 Enabling the programming mode

The function matrix can be disabled. Disabling the function matrix rules out the possibility of inadvertent changes to device functions, numerical values or factory settings. A numerical code (factory setting = 50) has to be entered before settings can be changed.

If you use a code number of your choice, you exclude the possibility of unauthorized persons accessing data (\rightarrow see the "Description of Device Functions" manual).

Comply with the following instructions when entering codes:

- If programming is disabled and the ⊕ operating elements are pressed in any function, a prompt for the code automatically appears on the display.
- If "0" is specified as the customer's code, programming is always enabled.
- The Endress+Hauser service organization can be of assistance if you mislay your personal code.



Caution!

Changing certain parameters such as all sensor characteristics, for example, influences numerous functions of the entire measuring system, particularly measuring accuracy. There is no need to change these parameters under normal circumstances and consequently, they are protected by a special code known only to the Endress+Hauser service organization. Please contact Endress+Hauser if you have any questions.

5.2.3 Disabling the programming mode

Programming is disabled if you do not press the operating elements within 60 seconds following automatic return to the HOME position.

You can also disable programming in the "ACCESS CODE" function by entering any number (other than the customer's code).

Promag 50 Operation

5.3 Displaying error messages

5.3.1 Type of error

Errors which occur during commissioning or measuring operation are displayed immediately. If two or more system or process errors occur, the error with the highest priority is the one shown on the display.

The measuring system distinguishes between two types of error:

- System errors \rightarrow 🗎 82:
 - This group comprises all device errors, e.g. communication errors, hardware faults, etc.




Fig. 50: Error messages on the display (example)

- 1 Error type:
 - P = process error
 - S = system error
 - Error message type:
 /= fault message
 - -! = notice message
- Error designation: e.g. EMPTY PIPE = measuring tube is only partly filled or completely empty
- 4 Error number: e.g. #401
- 5 Duration of most recent error occurrence (in hours, minutes and seconds)

5.3.2 Error message types

Users have the option of weighting certain errors differently, in other words having them classed as "Fault messages" or "Notice messages". You can define messages in this way with the aid of the function matrix (\rightarrow "Description of Device Functions" manual). Serious system errors, e.g. module defects, are always identified and classed as "fault messages" by the measuring device.

Notice message (!)

- Displayed as \rightarrow Exclamation mark (!), error type (S: system error, P: process error)
- The error in question has no effect on the outputs of the measuring device.

Fault message (*)

- Displayed as \rightarrow Lightning flash ($\frac{1}{2}$), error type (S: system error, P: process error).
- The error in question has a direct effect on the outputs.
 The response of the individual outputs (failsafe mode) can be defined in the function matrix using the "FAILSAFE MODE" function (→ "Description of Device Functions" manual).



Note!

For security reasons, error messages should be output via the status output.

Operation Promag 50

5.4 Communication

The HART protocol allows the transfer of measuring and device data between the HART master and the field devices for configuration and diagnostics purposes.

The HART master, e.g. a handheld terminal or PC-based operating programs (such as FieldCare), require device description (DD) files which are used to access all the information in a HART device. Information is exclusively transferred using so-called "commands". There are three different command classes:

• Universal commands:

All HART device support and use universal commands.

The following functionalities are linked to them:

- Identify HART devices
- Reading digital measured values (volume flow, totalizer, etc.)
- Common practice commands:

Common practice commands offer functions which are supported and can be executed by most but not all field devices.

Device-specific commands:

These commands allow access to device-specific functions which are not HART standard. Such commands access individual field device information, amongst other things, such as empty/full pipe calibration values, low flow cutoff settings, etc.



Note

5.4.1 Operating options

For the complete operation of the measuring device, including device-specific commands, there are DD files available to the user to provide the following operating aids and programs:

Field Xpert HART Communicator

Selecting device functions with a HART Communicator is a process involving a number of menu levels and a special HART function matrix.

The HART manual in the carrying case of the HART Communicator contains more detailed information on the device.

Operating program "FieldCare"

FieldCare is Endress+Hauser's FDT-based plant Asset Management Tool and allows the configuration and diagnosis of intelligent field devices. By using status information, you also have a simple but effective tool for monitoring devices. The Proline flow measuring devices are accessed via a service interface or via the service interface FXA193.

Operating program "SIMATIC PDM" (Siemens)

SIMATIC PDM is a standardized, manufacturer-independent tool for the operation, configuration,

maintenance and diagnosis of intelligent field devices.

Operating program "AMS" (Emerson Process Management)

AMS (Asset Management Solutions): program for operating and configuring devices.

Promag 50 Operation

5.4.2 Current device description files

The following table illustrates the suitable device description file for the operating tool in question and then indicates where these can be obtained.

HART protocol:

TIAKT Protocol.			
Valid for device software:	2.04.XX	\rightarrow Function DEVICE SOFTWARE	
Device data HART Manufacturer ID: Device ID:	11 _{hex} (ENDRESS+HAUSER) 41 _{hex}	\rightarrow Function MANUFACTURER ID \rightarrow Function DEVICE ID	
HART version data:	Device Revision 6/ DD Revision 1		
Software release:	01.2011		
Operating program:	Sources for obtaining device descriptions:		
Handheld Field Xpert SFX100	Use update function of handheld terminal		
FieldCare / DTM	 www.endress.com → Download CD-ROM (Endress+Hauser order number 56004088) DVD (Endress+Hauser order number 70100690) 		
	www.endress.com \rightarrow Download		
AMS	www.endress.com \rightarrow Download		

Tester/simulator:	Sources for obtaining device descriptions:	
Fieldcheck	Update by means of FieldCare with the flow device FXA193/291 DTM in the Fieldflash module	



Note!

The "Fieldcheck" tester/simulator is used for testing flowmeters in the field. When used in conjunction with the "FieldCare" software package, test results can be imported into a database, printed out and used for official certification. Contact your Endress+Hauser representative for more information.

5.4.3 Device variables

The following device variables are available using the HART protocol:

Code (decimal)	Device variable
0	OFF (not assigned)
1	Volume flow
250	Totalizer 1
251	Totalizer 2

At the factory, the process variables are assigned to the following device variables:

- Primary process variable (PV) \rightarrow Volume flow
- Second process variable (SV) \rightarrow Totalizer 1
- Third process variable (TV) \rightarrow not assigned
- Fourth process variable (FV) \rightarrow not assigned



Note

You can set or change the assignment of device variables to process variables using Command 51.

5.4.4 Switching HART write protection on/off

The HART write protection can be switched on and off using the HART WRITE PROTECT device function (\rightarrow "Description of Device Functions" manual).

Operation Promag 50

5.4.5 Universal and common practice HART commands

The following table contains all the universal commands supported by the device.

Command No. HART command / Access type Command data (numeric data in decimal form		Command data (numeric data in decimal form)	Response data (numeric data in decimal form)		
	Universal commands				
0	Read unique device identifier Access type = read	none	Device identification delivers information on the device and the manufacturer. It cannot be changed.		
			The response consists of a 12 byte device ID: - Byte 0: fixed value 254 - Byte 1: Manufacturer ID, 17 = E+H - Byte 2: Device type ID, 65 = Promag 50 - Byte 3: Number of preambles - Byte 4: Universal commands rev. no. - Byte 5: Device-specific commands rev. no. - Byte 6: Software revision - Byte 7: Hardware revision - Byte 8: Additional device information - Bytes 9-11: Device identification		
1	Read primary process variable Access type = read	none	 Byte 0: HART unit code of the primary process variable Bytes 1-4: Primary process variable 		
			Factory setting: Primary process variable = Volume flow		
			 Note! Manufacturer-specific units are represented using the HART unit code "240". You can change the assignment of device variables to process variables using Command 51. 		
2	Read the primary process variable as current in mA and percentage of the set measuring	none	 Bytes 0-3: actual current of the primary process variable in mA Bytes 4-7: % value of the set measuring range 		
	range Access type = read		Factory setting: Primary process variable = Volume flow		
			Note! You can change the assignment of device variables to process variables using Command 51.		
3	Read the primary process variable as current in mA and four dynamic process variables Access type = read	none	 24 bytes are sent as a response: Bytes 0-3: primary process variable current in mA Byte 4: HART unit code of the primary process variable Bytes 5-8: Primary process variable Byte 9: HART unit code of the second process variable Bytes 10-13: Second process variable Byte 14: HART unit code of the third process variable Bytes 15-18: Third process variable Byte 19: HART unit code of the fourth process variable Bytes 20-23: Fourth process variable 		
			Factory setting: Primary process variable = Volume flow Second process variable = Totalizer 1 Third process variable = OFF (not assigned) Fourth process variable = OFF (not assigned)		
			 Note! Manufacturer-specific units are represented using the HART unit code "240". You can change the assignment of device variables to process variables using Command 51. 		
6	Set HART shortform address Access type = write	Byte 0: desired address (0 to 15) Factory setting: 0 Note! With an address >0 (multidrop mode), the current output of the primary process variable is set to 4 mA.	Byte 0: active address		

Promag 50 Operation

		Command data	Response data	
HART	command / Access type	(numeric data in decimal form)	(numeric data in decimal form)	
11	Read unique device identification using the TAG	Bytes 0-5: TAG	Device identification delivers information on the device and the manufacturer. It cannot be changed.	
	(measuring point designation) Access type = read		The response consists of a 12 byte device ID if the given TAG agrees with the one saved in the device: - Byte 0: fixed value 254 - Byte 1: Manufacturer ID, 17 = E+H - Byte 2: Device type ID, 65 = Promag 50 - Byte 3: Number of preambles - Byte 4: Universal commands rev. no. - Byte 5: Device-specific commands rev. no. - Byte 6: Software revision - Byte 7: Hardware revision - Byte 8: Additional device information - Bytes 9-11: Device identification	
12	Read user message Access type = read	none	Bytes 0-24: User message Note! You can write the user message using Command 17.	
13	Read TAG, descriptor and date Access type = read	none	- Bytes 0-5: TAG - Bytes 6-17: descriptor	
			- Bytes 18-20: Date Note! You can write the TAG, descriptor and date using Command 18.	
14	Read sensor information on primary process variable	none	 Bytes 0-2: Sensor serial number Byte 3: HART unit code of sensor limits and measuring range of the primary process variable Bytes 4-7: Upper sensor limit Bytes 8-11: Lower sensor limit Bytes 12-15: Minimum span 	
			 Note! The data relate to the primary process variable (= volume flow). Manufacturer-specific units are represented using the HART unit code "240". 	
15	Read output information of primary process variable Access type = read	none	 Byte 0: Alarm selection ID Byte 1: Transfer function ID Byte 2: HART unit code for the set measuring range of the primary process variable Bytes 3-6: upper range, value for 20 mA Bytes 7-10: lower range, value for 4 mA Bytes 11-14: Damping constant in [s] Byte 15: Write protection ID Byte 16: OEM dealer ID, 17 = E+H 	
			Factory setting: Primary process variable = Volume flow Note! Manufacturer-specific units are represented using the HART unit code "240". You can change the assignment of device variables to process variables using Command 51.	
16	Read the device production number Access type = read	none	Bytes 0-2: Production number	
17	Write user message Access = write	You can save any 32-character long text in the device under this parameter: Bytes 0-23: Desired user message	Displays the current user message in the device: Bytes 0-23: Current user message in the device	
18	Write TAG, descriptor and date Access = write	With this parameter, you can store an 8 character TAG, a 16 character descriptor and a date: - Bytes 0-5: TAG - Bytes 6-17: descriptor - Bytes 18-20: Date	Displays the current information in the device: - Bytes 0-5: TAG - Bytes 6-17: descriptor - Bytes 18-20: Date	
19	Write the device production number Access = write	Bytes 0-2: Production number	Bytes 0-2: Production number	

Operation Promag 50

The following table contains all the common practice commands supported by the device.

Command No. HART command / Access type		Command data Response data (numeric data in decimal form) Response data (numeric data in decimal form)	
Comm	on practice commands		
34	Write damping value for primary process variable Access = write	Bytes 0-3: Damping value of the primary process variable "volume flow" in seconds Factory setting: Primary process variable = Current output damping	Displays the current damping value in the device: Bytes 0-3: Damping value in seconds
35	Write measuring range of primary process variable Access = write	Write the desired measuring range: - Byte 0: HART unit code of the primary process variable - Bytes 1-4: upper range, value for 20 mA - Bytes 5-8: lower range, value for 4 mA Factory setting: Primary process variable = Volume flow Note! The start of the measuring range (4 mA) must correspond to the zero flow. If the HART unit code is not the correct one for the process variable, the device will continue with the last valid unit.	The currently set measuring range is displayed as a response: - Byte 0: HART unit code for the set measuring range of the primary process variable - Bytes 1-4: upper range, value for 20 mA - Bytes 5-8: lower range, value for 4 mA Note! Manufacturer-specific units are represented using the HART unit code "240". You can change the assignment of device variables to process variables using Command 51.
38	Device status reset (configuration changed) Access = write	none	none Note! It is also possible to execute this HART command when write protection is activated (= ON)!
40	Simulate input current of primary process variable Access = write	Simulation of the desired output current of the primary process variable. An entry value of 0 exits the simulation mode: Bytes 0-3: Output current in mA Factory setting: Primary process variable = Volume flow Note! You can set the assignment of device variables to process variables using Command 51.	The momentary output current of the primary process variable is displayed as a response: Bytes 0-3: Output current in mA
42	Perform master reset Access = write	none	none
44	Write unit of primary process variable Access = write	Set unit of primary process variable. Only units which are suitable for the process variable are transferred to the device: Byte 0: HART unit code Factory setting: Primary process variable = Volume flow Note! If the written HART unit code is not the correct one for the process variable, the device will continue with the last valid unit. If you change the unit of the primary process variable, this has a direct impact on the system units.	The current unit code of the primary process variable is displayed as a response: Byte 0: HART unit code Note! Manufacturer-specific units are represented using the HART unit code "240".
48	Read additional device status Access = read	none	The device status is displayed in extended form as the response: Coding: see table $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $

Promag 50 Operation

Command No. HART command / Access type		Command data (numeric data in decimal form)	Response data (numeric data in decimal form)	
50	Read assignment of the device variables to the four process variables Access = read	none	Display of the current variable assignment of the process variables: - Byte 0: Device variable code to the primary process variable - Byte 1: Device variable code to the second process variable - Byte 2: Device variable code to the third process variable - Byte 3: Device variable code to the fourth process variable - Factory setting:	
			 Primary process variable: Code 1 for volume flow Second process variable: Code 250 for totalizer Third process variable: Code 0 for OFF (not assigned) Fourth process variable: Code 0 for OFF (not assigned) 	
51	Write assignment of the device variables to the four process variables Access = write	Setting of the device variables to the four process variables: - Byte 0: Device variable code to the primary process variable - Byte 1: Device variable code to the second process variable - Byte 2: Device variable code to the third process variable - Byte 3: Device variable code to the fourth process variable - Byte 3: Device variable code to the fourth process variable - Factory setting: - Primary process variable: Volume flow - Second process variable: Totalizer 1 - Third process variable: OFF (not assigned)	The variable assignment of the process variables is displayed as a response: - Byte 0: Device variable code to the primary process variable - Byte 1: Device variable code to the second process variable - Byte 2: Device variable code to the third process variable - Byte 3: Device variable code to the fourth process variable	
53	Write device variable unit Access = write	Fourth process variable: OFF (not assigned) This command sets the unit of the given device variables. Only those units which suit the device variable are transferred: Byte 0: Device variable code Byte 1: HART unit code Code of the supported device variables: See information → ■ 65 Note! If the written unit is not the correct one for the device variable, the device will continue with the last valid unit. If you change the unit of the device variable, this has a direct impact on the system units.	The current unit of the device variables is displayed in the device as a response: - Byte 0: Device variable code - Byte 1: HART unit code Note! Manufacturer-specific units are represented using the HART unit code "240".	
59	Write number of preambles in response message Access = write	This parameter sets the number of preambles which are inserted in the response messages: Byte 0: Number of preambles (4 to 20)	The current number of preambles is displayed in the response telegram: Byte 0: Number of preambles	

Operation Promag 50

5.4.6 Device status and error messages

You can read the extended device status, in this case, current error messages, via Command "48". The command delivers information which is partly coded in bits (see table below).



Notel

- \blacksquare You can find a detailed explanation of the device status and error messages and their elimination on $\to riangleq 70$
- Bits and bytes not listed are not assigned.

Byte	Bit	Error No.	Short error description
	0	001	Serious device error
0	1	011	Measuring amplifier has faulty EEPROM
	2	012	Error when accessing data of the measuring amplifier EEPROM
	1	031	S-DAT: defective or missing
1	2	032	S-DAT: Error accessing saved values
	5	051	I/O and the amplifier are not compatible.
3	3	111	Totalizer checksum error
	4	121	I/O board and amplifier not compatible.
4	3	251	Internal communication fault on the amplifier board.
	4	261	No data reception between amplifier and I/O board
-	0	321	Coil current of the sensor is outside the tolerance.
5	7	339	Flow buffer:
	0	340	The temporarily buffered flow portions (measuring mode for pulsating flow) could not be cleared or output within 60 seconds.
	1	341	
	2	342	
	3	343	Frequency buffer:
6	4	344	The temporarily buffered flow portions (measuring mode for pulsating flow) could not be cleared or output within 60 seconds.
	5	345	
	6	346	
	7	347	Pulse buffer:
	0	348	The temporarily buffered flow portions (measuring mode for pulsating flow) could not be cleared or output within 60 seconds.
	1	349	
	2	350	
_	3	351	Current output:
7	4	352	Flow is out of range.
	5	353	
	6	354	
	7	355	Frequency output:
	0	356	Flow is out of range.
8	1	357	
	2	358	

Promag 50 Operation

Byte	Bit	Error No.	Short error description
	3	359	Pulse output:
8	4	360	Flow is out of range.
	5	361	
	6	362	
10	7	401	Measuring tube partially filled or empty
11	2	461	EPD calibration not possible because the fluid's conductivity is either too low or too high.
11	4	463	The EPD calibration values for empty pipe and full pipe are identical, and therefore incorrect.
12	1	474	Maximum flow value entered is overshot
	7	501	Amplifier software version is loaded. Currently no other commands are possible.
13	0	502	Upload/download of device files. Currently no other commands are possible.
14	3	601	Positive zero return active
14	7	611	Simulation current output active
	0	612	
	1	613	
	2	614	
15	3	621	Simulation frequency output active
1)	4	622	
	5	623	
	6	624	
	7	631	Simulation pulse output active
	0	632	
	1	633	
	2	634	
16	3	641	Simulation status output active
	4	642	
	5	643	
	6	644	
17	7	671	Simulation of the status input active
	0	672	
	1	673	
18	2	674	
	3	691	Simulation of response to error (outputs) active
	4	692	Simulation of volume flow active

Commissioning Promag 50

6 Commissioning


6.1 Function check

Make sure that all final checks have been completed before you start up your measuring point:

- Checklist for "Post-connection check" → 🖺 59

6.2 Switching on the measuring device

Once the connection checks have been successfully completed, it is time to switch on the power supply. The device is now operational. The measuring device performs a number of post switch-on self-tests. As this procedure progresses the following sequence of messages appears on the local display:



Normal measuring mode commences as soon as start-up completes. Various measured-value and/or status variables (HOME position) appear on the display.



Note!

If start-up fails, an error message indicating the cause is displayed.

Promag 50 Commissioning


6.3 Quick Setup

In the case of measuring devices without a local display, the individual parameters and functions must be configured via the operating program, e.g. FieldCare.

If the measuring device is equipped with a local display, all the important device parameters for standard operation, as well as additional functions, can be configured quickly and easily by means of the following Quick Setup menu.

6.3.1 "Commissioning" Quick Setup menu

This Quick Setup menu guides you systematically through the setup procedure for all the major device functions that have to be configured for standard measuring operation.



A0005413-EN

Fig. 51: "QUICK SETUP COMMISSIONING" menu for the rapid configuration of important device functions

Commissioning Promag 50

6.4 Configuration

6.4.1 Current output: active/passive

The current output is configured as "active" or "passive" by means of various jumpers on the I/O board.



Warning!

Risk of electric shock! Exposed components carry dangerous voltages. Make sure that the power supply is switched off before you remove the cover of the electronics compartment.

- 1. Switch off power supply.
- 2. Remove the I/O board $\rightarrow \blacksquare$ 89
- 3. Position the jumper $\rightarrow \blacksquare$ 52
 - 🖒 Caution!

Risk of destroying the measuring device. Set the jumpers exactly as shown in the graphic. Pay strict attention to the position of the jumpers as indicated in the graphic.

4. Installation of the I/O board is the reverse of the removal procedure.




Fig. 52: Configuring current outputs using jumpers (I/O board)

Active current output (factory setting)

2 Passive current output

Promag 50 Commissioning

6.5 Adjustment

6.5.1 Empty-pipe/full-pipe adjustment

Flow cannot be measured correctly unless the measuring tube is completely full. This status can be permanently monitored using the Empty Pipe Detection:

- EPD = Empty Pipe Detection (with the help of an EPD electrode)
- OED = Open Electrode Detection (Empty Pipe Detection with the help of the measuring electrodes, if the sensor is not equipped with an EPD electrode or the orientation is not suitable for using EPD).



Caution!

Detailed information on the empty-pipe/full-pipe adjustment procedure can be found in the "Description of Device Functions" manual:

- EPD/OED ADJUSTMENT (carrying out the adjustment).
- EPD (switching on and off EPD/OED).
- EPD RESPONSE TIME (input of the response time for EPD/OED).



Note!

- The EPD function is not available unless the sensor is fitted with an EPD electrode.
- The devices are already calibrated at the factory with water (approx. $500 \,\mu\text{S/cm}$). If the fluid conductivity differs from this reference, empty-pipe/full-pipe adjustment has to be performed again on site.
- The default setting for EPD when the devices are delivered is OFF; the function has to be activated if required.
- The EPD process error can be output by means of the configurable relay output.

Performing empty-pipe and full-pipe adjustment (EPD)

- 1. Select the appropriate function in the function matrix: $HOME \rightarrow \blacksquare \rightarrow \pm \rightarrow PROCESS\ PARAMETER \rightarrow \blacksquare \rightarrow \pm \rightarrow EPD\ ADJUSTMENT$
- 2. Empty the piping:
 - The wall of the measuring tube should still be wet with fluid during EPD empty pipe adjustment
 - The wall of the measuring tube/the measuring electrodes should **no longer** be wet with fluid during OED empty pipe adjustment
- 3. Start empty-pipe adjustment: Select "EMPTY PIPE ADJUST" or "OED EMPTY ADJUST" and press \blacksquare to confirm.
- 4. After empty-pipe adjustment, fill the piping with fluid.
- 5. Start full-pipe adjustment: Select "FULL PIPE ADJUST" or "OED FULL ADJUST" and press © to confirm.
- 6. Having completed the adjustment, select the setting "OFF" and exit the function by pressing \blacksquare .
- 7. Switch on empty pipe detection in the EPD function:

 - OED empty pipe adjustment: Select OED and confirm with \blacksquare .
 - Caution

The adjustment coefficients must be valid before you can activate the EPD function. If adjustment is incorrect the following messages might appear on the display:

- FULL = EMPTY
 - The adjustment values for empty pipe and full pipe are identical. In cases of this nature you must repeat empty-pipe or full-pipe adjustment!
- ADJUSTMENT NOT OK
 Adjustment is not possible because the fluid's conductivity is out of range.

Commissioning Promag 50

6.6 Data storage device (HistoROM)

At Endress+Hauser, the term HistoROM refers to various types of data storage modules on which process and measuring device data are stored. It is possible to plug these modules into other devices to copy device configurations from one device to another, for example.

6.6.1 HistoROM/S-DAT (sensor-DAT)

The S-DAT is an exchangeable data storage device in which all sensor relevant parameters are stored, i.e., diameter, serial number, calibration factor, zero point.

Promag 50 Maintenance

7 Maintenance

No special maintenance work is required.

7.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing and the seals.

7.2 Seals

The seals of the Promag H sensor must be replaced periodically, particularly in the case of gasket seals (aseptic version).

The period between changes depends on the frequency of cleaning cycles, the cleaning temperature and the fluid temperature.

Replacement seals (accessories) $\rightarrow \blacksquare$ 78.

Accessories Promag 50

8 Accessories

Various accessories, which can be ordered separately from Endress+Hauser, are available for the transmitter and the sensor. Your Endress+Hauser service organization can provide detailed information on the specific order codes on request.

8.1 Device-specific accessories

Accessory	Description	Order code
Proline Promag 50 transmitter	Transmitter for replacement or storage. Use the order code to define the following specifications:	50XXX - XXXXX*****
	 Approvals Degree of protection/version Cable for remote version Cable entry Display/power supply/operation Software Outputs/inputs 	

8.2 Measuring principle-specific accessories

Accessory	Description	Order code
Mounting set for Promag 50 transmitter	Mounting set for the transmitter (remote version). Suitable for Wall mounting Pipe mounting Panel-mounted installation	DK5WM - *
	Mounting set for aluminum field housing. Suitable for: • Pipe mounting	
Wall-mounting kit for Promag H	Wall-mounting kit for the Promag H sensor.	DK5HM - **
Cable for remote version	Coil and signal cables, various lengths.	DK5CA - **
Mounting kit for Promag D, wafer version	 Mounting bolts Nuts incl. washers Flange seals Centering sleeves (if required for the flange) 	DKD** - **
Set of seals for Promag D	Set of seals consisting of two flange seals.	DK5DD - ***
Mounting kit for Promag H	2 process connectionsThreaded fastenersSeals	DKH** - ****
Set of seals for Promag H	For regular replacement of the seals of the Promag H sensor.	DK5HS - ***
Welding jig for Promag H	Weld nipple as process connection: welding jig for installation in pipe.	DK5HW - ***
Adapter connection for Promag A, H	Adapter connections for installing a Promag 10 H instead of a Promag 30/33 A or Promag 30/33 H DN 25.	DK5HA - ****
Ground rings for Promag H	Ground rings for potential equalization.	DK5HR - ***
Ground cable for Promag E/L/P/W	Ground cable for potential equalization.	DK5GC - ***
Ground disk for Promag E/L/P/W	Ground disk for potential equalization.	DK5GD - * * ***
Process display RIA45	Multifunctional 1-channel display unit: Universal input Transmitter power supply Limit relay Analog output	RIA45 – *****

Promag 50 Accessories

Accessory	Description	Order code
Process display RIA251	Digital display device for looping into the 4 to 20 mA current loop.	RIA251 - **
Field display unit RIA16	Digital field display device for looping into the 4 to 20 mA current loop.	RIA16 - ***
Application Manager RMM621	Electronic recording, display, balancing, control, saving and event and alarm monitoring of analog and digital input signals. Values and conditions determined are output by means of analog and digital output signals. Remote transmission of alarms, input values and calculated values using a PSTN or GSM modem.	RMM621 - *******

8.3 Communication-specific accessories

Accessory	Description	Order code
HART Communicator Field Xpert SFX 100	Handheld terminal for remote configuration and for obtaining measured values via the HART current output (4 to 20 mA) and FOUNDATION Fieldbus. Contact your Endress+Hauser representative for more information.	SFX100 - ******
Fieldgate FXA320	Gateway for remote interrogation of HART sensors and actuators via Web browser: 2-channel analog input (4 to 20 mA) 4 binary inputs with event counter function and frequency measurement Communication via modem, Ethernet or GSM Visualization via Internet/Intranet in Web browser and/or WAP cellular phone Limit value monitoring with alarm by e-mail or SMS Synchronized time stamping of all measured values.	FXA320 - ****
Fieldgate FXA520	Gateway for remote interrogation of HART sensors and actuators via Web browser: Web server for remote monitoring of up to 30 measuring points Intrinsically safe version [EEx ia]IIC for applications in hazardous areas Communication via modem, Ethernet or GSM Visualization via Internet/Intranet in Web browser and/or WAP cellular phone Limit value monitoring with alarm by e-mail or SMS Synchronized time stamping of all measured values Remote diagnosis and remote configuration of connected HART devices	FXA520 - ****
FXA195	The Commubox FXA195 connects intrinsically safe Smart transmitters with HART protocol to the USB port of a personal computer. This makes the remote operation of the transmitters possible with the aid of configuration programs (e.g. FieldCare). Power is supplied to the Commubox by means of the USB port	FXA195 - *

Accessories Promag 50

8.4 Service-specific accessories

Accessory	Description	Order code
Applicator	Software for selecting and planning flowmeters. The Applicator software can be downloaded from the Internet or ordered on CD-ROM for installation on a local PC. Contact your Endress+Hauser representative for more information.	DXA80 - *
Fieldcheck	Tester/simulator for testing flowmeters in the field. When used in conjunction with the "FieldCare" software package, test results can be imported into a database, printed out and used for official certification. Contact your Endress+Hauser representative for more information.	50098801
FieldCare	FieldCare is Endress+Hauser's FDT-based asset management tool. It can configure all intelligent field units in your system and helps you manage them. By using status information, it is also a simple but effective way of checking their status and condition.	See the product page on the Endress+Hauser Web site: www.endress.com
Memograph M graphic display recorder	The Memograph M graphic display recorder provides information on all the relevant process variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a DSD card or USB stick. Memograph M boasts a modular design, intuitive operation and a comprehensive security concept. The ReadWin® 2000 PC software is part of the standard package and is used for configuring, visualizing and archiving the data captured. The mathematics channels which are optionally available enable continuous monitoring of specific power consumption, boiler efficiency and other parameters which are important for efficient energy management.	
FXA193	Service interface from the device to the PC for operation via FieldCare.	FXA193 - *

9 Troubleshooting

9.1 Troubleshooting instructions

Always start troubleshooting with the checklist below if faults occur after start-up or during operation. The routine takes you directly to the cause of the problem and the appropriate remedial measures.

Check the display				
No display visible and no	1. Check the supply voltage \rightarrow terminals 1, 2			
output signals present.	2. Check the power line fuse $\rightarrow riangleq 93$ 85 to 260 V AC: 0.8 A slow-blow / 250 V 20 to 55 V AC / 16 to 62 V DC: 2 A slow-blow / 250 V			
	3. Measuring electronics defective \rightarrow order spare parts \rightarrow $\stackrel{\triangle}{=}$ 88			
No display visible, but output signals are present.	1. Check whether the ribbon-cable connector of the display module is correctly plugged into the amplifier board \Rightarrow \cong 89			
	2. Display module defective → order spare parts \rightarrow 🖺 88			
	3. Measuring electronics defective \rightarrow order spare parts \rightarrow $\stackrel{\triangle}{=}$ 88			
Display texts are in a foreign language.	Switch off power supply. Press and hold down both the OS buttons and switch on the measuring device. The display text will appear in English (default) and is displayed at maximum contrast.			
Measured value indicated, but no signal at the current or pulse output.	,			
\				
Error messages on display	Error messages on display			
Errors which occur during commissioning or measuring operation are displayed immediately. Error messages consist of a variety of icons: the meanings of these icons are as follows (example):				
 Error type: S = system error, P = process error Error message type: f = fault message, ! = notice message EMPTY PIPE = Type of error, e.g. measuring tube is only partly filled or completely empty 				

- **03:00:05** = duration of error occurrence (in hours, minutes and seconds)
- #401 = error number
- Caution!
- See the information on \rightarrow $\stackrel{\triangle}{=}$ 63!
- The measuring system interprets simulations and positive zero return as system errors, but displays them as notice message only.

Error number: No. 001 – 399 No. 501 – 699	System error (device error) has occurred $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $
Error number: No. 401 - 499	Process error (application error) has occurred $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $
1	

Other error (without error message) Some other error has occurred. Diagnosis and rectification → ■ 85

Troubleshooting Promag 50

9.2 System error messages

Serious system errors are **always** recognized by the device as "Fault message", and are shown as a lightning flash (*) on the display. Fault messages immediately affect the outputs.



Caution!



Notel

Also observe the information on $\rightarrow \triangleq 63$.

No.	Error message / Type	Cause	Remedy (spare part → 🖺 88)
ع = Fau	stem error alt message (with an effect tice message (without an e		
No. #	0xx → Hardware error		
001	S: CRITICAL FAILURE \$: # 001	Serious device error	Replace the amplifier board.
011	S: AMP HW EEPROM \$: # 011	Amplifier: Defective EEPROM	Replace the amplifier board.
012	S: AMP SW EEPROM \$: # 012	Amplifier: Error accessing EEPROM data	The EEPROM data blocks in which an error has occurred are displayed in the TROUBLESHOOTING function. Press Enter to acknowledge the errors in question; default values are automatically inserted instead of the errored parameter values. Note!
			The measuring device has to be restarted if an error has occurred in a totalizer block (see error No. 111 / CHECKSUM TOTAL).
031	S: SENSOR HW DAT \$: # 031	S-DAT is not plugged into the amplifier board correctly (or is missing).	Check whether the S-DAT is correctly plugged into the amplifier board.
		2. S-DAT is defective.	 Replace the S-DAT if it is defective. Check that the new replacement DAT is compatible with the measuring electronics.
032	S: SENSOR SW DAT \$: # 032		Check the: - Spare part set number - Hardware revision code
			3. Replace measuring electronics boards if necessary.
			4. Plug the S-DAT into the amplifier board.
No. #	1xx → Software error		
101	S: GAIN ERROR AMP \$: # 101	Gain deviation compared to reference gain > 25%.	Replace the amplifier board.
111	S: CHECKSUM TOTAL	Totalizer checksum error.	Restart the measuring device.
	\$: # 111		2. Replace the amplifier board if necessary.
121	S: A / C COMPATIB. !: # 121	Due to different software versions, I/O board and amplifier board are only partially compatible (possibly restricted functionality). Note! This message is only listed in the error history. Nothing is shown on the display.	Module with lower software version has either to be updated by FieldCare with the required software version or the module has to be replaced.

No.	Error message / Type	Cause	Remedy (spare part → 🖺 88)			
No. #	$2xx \rightarrow Error in DAT / no contract \rightarrow Error in DAT / no contract $	ommunication				
251	S: COMMUNICATION I/O \$: # 251	Internal communication fault on the amplifier board.	Replace the amplifier board.			
261	S: COMMUNICATION I/O \$: # 261	No data reception between amplifier and I/O board or faulty internal data transfer.	Check the BUS contacts.			
No. #	No. # 3xx → System limits exceeded					
321	S: TOL. COIL CURR. \$: # 321	Sensor: Coil current is out of tolerance.	Warning! Switch off power supply before manipulating the coil current cable, coil current cable connector or measuring electronics boards!			
			Remote version:			
			1. Check wiring of terminals $41/42 \rightarrow \triangle 46$			
			2. Check coil current cable connector.			
			Compact and remote version: Replace measuring electronics boards if necessary			
339	S: STACK CUR OUT n	The temporarily buffered flow portions (measuring	1. Change the upper or lower limit setting, as applicable.			
to 342	!: # 339 to 342	mode for pulsating flow) could not be cleared or	2. Increase or reduce flow, as applicable.			
	C. CTACK EDEO OUT	output within 60 seconds.	Recommendations in the event of fault category = FAULT			
343 to	S: STACK FREQ. OUT n !: # 343 to 346		MESSAGE (\$)			
346			Configure the fault response of the output to "ACTUAL VALUE" so that the temporary buffer can be cleared.			
			 Clear the temporary buffer by the measures described under 			
			Item 1.			
347	S: STACK PULSE OUT n	The temporarily buffered flow portions (measuring	1. Increase the setting for pulse weighting			
to 350	!: # 343 to 346	mode for pulsating flow) could not be cleared or output within 60 seconds.	2. Increase the max. pulse frequency if the totalizer can handle a higher number of pulses.			
			3. Increase or reduce flow, as applicable.			
			Recommendations in the event of fault category = FAULT MESSAGE (\$)			
			 Configure the fault response of the output to "ACTUAL VALUE" so that the temporary buffer can be cleared. Clear the temporary buffer by the measures described under 			
			Item 1.			
351	S: CURRENT RANGE n	Current output:	1. Change the upper or lower limit setting, as applicable.			
to 354	!: # 351 to 354	flow is out of range.	2. Increase or reduce flow, as applicable.			
355	S: FREQ. RANGE n	Frequency output:	1. Change the upper or lower limit setting, as applicable.			
to 358	!: # 355 to 358	flow is out of range.	2. Increase or reduce flow, as applicable.			
359	S: PULSE RANGE	Pulse output:	Increase the setting for pulse weighting			
to 362	!: # 359 to 362	the pulse output frequency is out of range.	 2. When selecting the pulse width, choose a value that can still be processed by a connected counter (e.g. mechanical counter, PLC etc.). Determine the pulse width: - Variant 1: Enter the minimum duration that a pulse must be present at the connected counter to ensure its registration. - Variant 2: Enter the maximum (pulse) frequency as the half "reciprocal value" that a pulse must be present at the connected counter to ensure its registration. 			
			Example: The maximum input frequency of the connected counter is 10 Hz. The pulse width to be entered is: $\frac{1}{2 \cdot 10 \text{ Hz}} = 50 \text{ ms}$			
			3. Reduce flow.			

Troubleshooting Promag 50

No.	Error message / Type	Cause	Remedy (spare part → 🖺 88)		
No. # !	No. # $5xx \rightarrow Application error$				
501	S: SWUPDATE ACT. !: # 501	New amplifier or communication (I/O module) software version is loaded. Currently no other functions are possible.	Wait until the procedure is finished. The device will restart automatically.		
502	S: UP-/DOWNLOAD ACT !: # 502	Uploading or downloading the device data via operating program. Currently no other functions are possible.	Wait until the procedure is finished.		
No. # 6	oxx → Simulation mode ac	tive			
601	S: POS. ZERO-RETURN !: # 601	Positive zero return active Caution! This message has the highest display priority!	Switch off positive zero return		
611 to 614	S: SIM. CURR. OUT. n !: # 611 to 614	Simulation current output active			
621 to 624	S: SIM. FREQ. OUT. n !: # 621 to 624	Simulation frequency output active	Switch off simulation		
631 to 634	S: SIM. PULSE n !: # 631 to 634	Simulation pulse output active	Switch off simulation		
641 to 644	S: SIM. STAT. OUT n !: # 641 to 644	Simulation status output active	Switch off simulation		
671 to 674	S: SIM. STATUS IN n !: # 671 to 674	Simulation status input active	Switch off simulation		
691	S: SIM. FAILSAFE !: # 691	Simulation of response to error (outputs) active	Switch off simulation		
692	S: SIM. MEASURAND !: # 692	Simulation of a measured variable active (e.g. mass flow).	Switch off simulation		
698	S: DEV. TEST ACT. !: # 698	The measuring device is being checked on site via the test and simulation device.	-		

9.3 Process error messages



Note!

Also observe the information on $\rightarrow \triangleq 63$.

No.	Error message / Type	Cause	Remedy (spare part → 🖺 88)
P = Process error \$ = Fault message (with an effect on the outputs) ! = Notice message (without an effect on the outputs)			
401	EMPTY PIPE \$: # 401	Measuring tube partially filled or empty	 Check the process conditions of the plant Fill the measuring tube
461	ADJ. NOT OK !: # 461	EPD calibration not possible because the fluid's conductivity is either too low or too high.	The EPD function cannot be used with fluids of this nature.
463	FULL = EMPTY \$: # 463	The EPD calibration values for empty pipe and full pipe are identical, therefore incorrect.	Repeat calibration, making sure procedure is correct $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $

9.4 Process errors without messages

Symptoms	Rectification		
Remark: You may have to change or c	orrect certain settings in functions in the function matrix in order to rectify the fault.		
Flow values are negative, even though the fluid is flowing forwards through the pipe.	 Remote version: Switch off the power supply and check the wiring →		
Measured-value reading fluctuates even though flow is steady.	 Check grounding and potential equalization →		
Measured-value reading shown on display, even though the fluid is at a standstill and the measuring tube is full.	 Check grounding and potential equalization → \$\bigsim 55\$ Check the fluid for presence of gas bubbles. Activate the "LOW FLOW CUTOFF" function, i.e. enter or increase the value for the switching point. 		
Measured-value reading on display, even though measuring tube is empty.	 Perform empty-pipe/full-pipe adjustment and then switch on Empty Pipe detection → \$\begin{align*} \Pi \ 75 \end{align*} Remote version: Check the terminals of the EPD cable → \$\begin{align*} \Pi \ 46 \end{align*} Fill the measuring tube. 		
The current output signal is always 4 mA, irrespective of the flow signal at any given time.	 Select the "BUS ADDRESS" function and change the setting to "0". Value for creepage too high. Reduce the value in the "LOW FLOW CUTOFF" function. 		
The fault cannot be rectified or some other fault not described above has arisen. In these instances, please contact your Endress+Hauser service organization.	The following options are available for tackling problems of this nature: Request the services of an Endress+Hauser service technician If you contact our service organization to have a service technician sent out, please be ready to quote the following information: Brief description of the fault Nameplate specifications (→ 6): order code, serial number Returning devices to Endress+Hauser The necessary procedures (→ 5) must be carried out before you return a flowmeter requiring repair or calibration to Endress+Hauser. Always enclose a duly completed "Declaration of Conformity" form with the flowmeter. You will find a master copy of this form at the back of this manual. Replace transmitter electronics		
	Components in the measuring electronics defective \rightarrow order spare parts $\rightarrow \stackrel{\triangle}{=} 88$		

Troubleshooting Promag 50

9.5 Response of outputs to errors



Note!

The failsafe mode of totalizers, current, pulse and frequency outputs can be customized by means of various functions in the function matrix. You will find detailed information on these procedures in the "Description of Device Functions" manual.

You can use positive zero return to set the signals of the current, pulse and status outputs to their fallback value, for example when measuring has to be interrupted while a pipe is being cleaned. This function takes priority over all other device functions: simulations, for example, are suppressed.

Failsafe mode	of outputs and totalizers	
	Process/system error is current	Positive zero return is activated
Caution System or proce the information	ess errors defined as "Notice messages" have no effect whatsoeve	er on the inputs and outputs. See
Current output	MINIMUM VALUE $0-20 \text{ mA} \rightarrow 0 \text{ mA}$ $4-20 \text{ mA} \rightarrow 2 \text{ mA}$ $4-20 \text{ mA} \text{ HART} \rightarrow 2 \text{ mA}$ $4-20 \text{ mA} \text{ NAMUR} \rightarrow 3.5 \text{ mA}$ $4-20 \text{ mA} \text{ HART} \text{ NAMUR} \rightarrow 3.5 \text{ mA}$ $4-20 \text{ mA} \text{ US} \rightarrow 3.75 \text{ mA}$ $4-20 \text{ mA} \text{ HART} \text{ US} \rightarrow 3.75 \text{ mA}$ $4-20 \text{ mA} \text{ HART} \text{ US} \rightarrow 3.75 \text{ mA}$ $0-20 \text{ mA} (25 \text{ mA}) \rightarrow 0 \text{ mA}$ $4-20 \text{ mA} (25 \text{ mA}) \rightarrow 2 \text{ mA}$ $4-20 \text{ mA} (25 \text{ mA}) \text{ HART} \rightarrow 2 \text{ mA}$	Output signal corresponds to "zero flow"
	MAXIMUM VALUE $0-20 \text{ mA} \rightarrow 22 \text{ mA}$ $4-20 \text{ mA} \rightarrow 22 \text{ mA}$ $4-20 \text{ mA} \rightarrow 22 \text{ mA}$ $4-20 \text{ mA} \text{ HART} \rightarrow 22 \text{ mA}$ $4-20 \text{ mA} \text{ NAMUR} \rightarrow 22.6 \text{ mA}$ $4-20 \text{ mA} \text{ HART NAMUR} \rightarrow 22.6 \text{ mA}$ $4-20 \text{ mA} \text{ US} \rightarrow 22.6 \text{ mA}$ $4-20 \text{ mA} \text{ HART US} \rightarrow 22.6 \text{ mA}$ $4-20 \text{ mA} \text{ HART US} \rightarrow 22.6 \text{ mA}$ $0-20 \text{ mA} (25 \text{ mA}) \rightarrow 25 \text{ mA}$ $0-20 \text{ mA} (25 \text{ mA}) \rightarrow 25 \text{ mA}$ $0-20 \text{ mA} (25 \text{ mA}) \rightarrow 25 \text{ mA}$ $0-20 \text{ mA} (25 \text{ mA}) \rightarrow 25 \text{ mA}$ $0-20 \text{ mA} (25 \text{ mA}) \rightarrow 25 \text{ mA}$ $0-20 \text{ mA} (25 \text{ mA}) \rightarrow 25 \text{ mA}$	
	HOLD VALUE Last valid value (preceding occurrence of the fault) is output. ACTUAL VALUE	
	Measured value display on the basis of the current flow measurement. The fault is ignored.	
Pulse output	MIN/MAX VALUE \rightarrow FALLBACK VALUE Signal output \rightarrow no pulses HOLD VALUE	Output signal corresponds to "zero flow"
	Last valid value (preceding occurrence of the fault) is output. ACTUAL VALUE Fault is ignored, i.e. normal measured-value output on the basis of ongoing flow measurement.	
Frequency output	FALLBACK VALUE Signal output → 0 Hz	Output signal corresponds to "zero flow"
	FAILSAFE LEVEL Output of the frequency specified in the FALÌLSAFE VALUE function.	
	HOLD VALUE Measured value display on the basis of the last saved value preceding occurrence of the fault.	
	ACTUAL VALUE Measured value display on the basis of the current flow measurement. The fault is ignored.	

Failsafe mode of outputs and totalizers				
	Process/system error is current	Positive zero return is activated		
Totalizer	STOP The totalizers are paused until the error is rectified.	Totalizer stops		
	ACTUAL VALUE The fault is ignored. The totalizer continues to count in accordance with the current flow value.			
	HOLD VALUE The totalizer continues to count the flow in accordance with the last valid flow value (before the error occurred).			
Status output	In the event of a fault or power supply failure: Status output → non-conductive	No effect on status output		

Troubleshooting Promag 50

9.6 Spare parts

Detailed troubleshooting instructions are provided in the previous sections $\rightarrow \triangleq 81$ The measuring device, moreover, provides additional support in the form of continuous selfdiagnosis and error messages.

Fault rectification can entail replacing defective components with tested spare parts. The illustration below shows the available scope of spare parts.



Note!

You can order spare parts directly from your Endress+Hauser service organization by providing the serial number printed on the transmitter's nameplate $\rightarrow \stackrel{\triangle}{=} 6$

Spare parts are shipped as sets comprising the following parts:

- Spare part
- Additional parts, small items (threaded fasteners, etc.)
- Mounting instructions
- Packaging




Fig. 53: Spare parts for Promag 50 transmitter (field and wall-mounted housings)

- Power unit board (85 to 260 V AC, 20 to 55 V AC, 16 to 62 V DC)
- Amplifier board
- 3
- I/O board (COM module) HistoROM / S-DAT (sensor data memory)

Display module

9.6.1 Removing and installing printed circuit boards



Field housing: removing and installing printed circuit boards $\rightarrow \blacksquare 54$

Warning!

- Risk of electric shock!
 - Exposed components carry dangerous voltages. Make sure that the power supply is switched off before you remove the cover of the electronics compartment.
- Risk of damaging electronic components (ESD protection). Static electricity can damage electronic components or impair their operability. Use a workplace with a grounded working surface purpose-built for electrostatically sensitive devices!
- If you cannot guarantee that the dielectric strength of the device is maintained in the following steps, then an appropriate inspection must be carried out in accordance with the manufacturer's specifications.
- When connecting Ex-certified devices, see the notes and diagrams in the Ex-specific supplement to these Operating Instructions.



Caution!

Use only original Endress+Hauser parts.

- 1. Switch off power supply.
- 2. Unscrew cover of the electronics compartment from the transmitter housing.
- 3. Remove the local display (1) as follows:
 - Press in the latches (1.1) at the side and remove the display module.
 - Disconnect the ribbon cable (1.2) of the display module from the amplifier board.
- 4. Remove the screws and remove the cover (2) from the electronics compartment.
- 5. Remove the boards (4, 6): Insert a suitable tool into the hole (3) provided for the purpose and pull the board clear of its holder.
- 6. Remove amplifier board (5):
 - Disconnect the plug of the electrode signal cable (5.1) including S-DAT (5.3) from the board.
 - Loosen the plug locking of the coil current cable (5.2) and gently disconnect the plug from the board, i.e. without moving it to and fro.
 - Insert a thin pin into the hole (3) provided for the purpose and pull the board clear of its holder.
- 7. Installation is the reverse of the removal procedure.

Troubleshooting Promag 50




Fig. 54: Field housing: removing and installing printed circuit boards

- Local display
- 1.1 1.2 2 3

- 4 5 5.1 5.2 5.3 6

- Local display
 Latch
 Ribbon cable (display module)
 Screws of electronics compartment cover
 Aperture for installing/removing boards
 Power supply board
 Amplifier board
 Electrode signal cable (sensor)
 Coil current cable (sensor)
 Histo-ROM / S-DAT (sensor data memory)
 I/O board

Wall-mount housing: removing and installing printed circuit boards $\rightarrow \blacksquare$ 55



Warning!

- Risk of electric shock!
 Exposed components carry dangerous voltages. Make sure that the power supply is switched off before you remove the cover of the electronics compartment.
- Risk of damaging electronic components (ESD protection). Static electricity can damage electronic components or impair their operability. Use a workplace with a grounded working surface purpose-built for electrostatically sensitive devices!
- If you cannot guarantee that the dielectric strength of the device is maintained in the following steps, then an appropriate inspection must be carried out in accordance with the manufacturer's specifications.
- When connecting Ex-certified devices, see the notes and diagrams in the Ex-specific supplement to these Operating Instructions.



Caution!

Use only original Endress+Hauser parts.

- 1. Switch off power supply.
- 2. Remove the screws and open the hinged cover (1) of the housing. Remove screws of the electronics module (2).
- 3. Then push up electronics module and pull it as far as possible out of the wall-mounted housing.
- 4. Disconnect the following cable plugs from amplifier board (7):
 - Electrode signal cable plug (7.1) including S-DAT (7.3).
 - Plug of coil current cable (7.2). To do so, loosen the plug locking of the coil current cable and gently disconnect the plug from the board, i.e. without moving it to and fro.
 - Ribbon cable plug (3) of the display module.
- 5. Remove the screws and remove the cover (4) from the electronics compartment.
- 6. Remove the boards (6, 7, 8): Insert a suitable tool into the hole (5) provided for the purpose and pull the board clear of its holder.
- 7. Installation is the reverse of the removal procedure.

Troubleshooting Promag 50




Fig. 55: Wall-mount housing: removing and installing printed circuit boards

- Housing cover
- Electronics module
- Electronics module
 Ribbon cable (display module)
 Cover of electronics compartment (3 screws)
 Aperture for installing/removing boards
 Power supply board
 Amplifier board
 Electrode signal cable (sensor)
 Coil current cable (sensor)
 Histo-ROM / S-DAT (sensor data memory)
 I/O board

9.6.2 Replacing the device fuse



Warning!

Risk of electric shock! Exposed components carry dangerous voltages. Make sure that the power supply is switched off before you remove the cover of the electronics compartment.

The main fuse is on the power supply board ($\rightarrow \blacksquare$ 56).

The procedure for replacing the fuse is as follows:

- 1. Switch off power supply.
- 3. Remove cap (1) and replace the device fuse (2). Use only fuses of the following type:
 - Power supply 20 to 55 V AC / 16 to 62 V DC \rightarrow 2.0 A slow-blow / 250 V; 5.2 × 20 mm
 - Power supply 85 to 260 V AC $\,
 ightarrow\,$ 0.8 A slow-blow / 250 V; 5.2 × 20 mm
 - Ex-rated devices \rightarrow see the Ex documentation.
- 4. Installation is the reverse of the removal procedure.



Caution!

Use only original Endress+Hauser parts.




Fig. 56: Replacing the device fuse on the power supply board


1 Protective cap

2 Device fuse

Troubleshooting Promag 50

Replacing the exchangeable electrode 9.6.3

The Promag W sensor (DN 350 to 2000 / 14 to 78") is available with exchangeable measuring electrodes as an option. This design permits the measuring electrodes to be replaced or cleaned under process conditions.



Apparatus for replacing exchangeable measuring electrodes

View A = DN 1200 to 2000 (48 to 78")

View B = DN 350 to 1050 (14 to 42")

- Allen screw
- Handle
- Electrode cable
- Knurled nut (locknut)
- Measuring electrode Stop cock (ball valve)
- Retaining cylinder
- Locking pin (for handle)
- Ball-valve housing
 Seal (retaining cylinder)
- 10 11

Coil spring

Removing the electrode		Installing the electrode	
1	Loosen Allen screw (1) and remove the cover.	1	Insert new electrode (5) into retaining cylinder (7) from below. Make sure that the seals at the tip of the electrode are clean.
2	Remove electrode cable (3) secured to handle (2).	2	Mount handle (2) on the electrode and insert locking pin (8) to secure it in position. Caution! Make sure that coil spring (11) is inserted. This is essential to ensure correct electrical contact and correct measuring signals.
3	Loosen knurled nut (4) by hand. This knurled nut acts as a locknut.	3	Pull the electrode back until the tip of the electrode no longer protrudes from retaining cylinder (7).
4	Remove electrode (5) by turning handle (2). The electrode can now be pulled out of retaining cylinder (7) as far as a defined stop. Marning! Risk of injury. Under process conditions (pressure in the piping system) the electrode can recoil suddenly against its stop. Apply counter-pressure while releasing the electrode.	4	Screw the retaining cylinder (7) onto ball-valve housing (9) and tighten it by hand. Seal (10) on the cylinder must be correctly seated and clean. Note! Make sure that the rubber hoses on retaining cylinder (7) and stop cock (6) are of the same color (red or blue).
5	Close stop cock (6) after pulling out the electrode as far as it will go. Marning! Do not subsequently open the stop cock, in order to prevent fluid escaping.	5	Open stop cock (6) and turn handle (2) to screw the electrode all the way into the retaining cylinder.
6	Remove the electrode complete with retaining cylinder (7).	6	Screw knurled nut (4) onto the retaining cylinder. This firmly locates the electrode in position.
7	Remove handle (2) from electrode (5) by pressing out locking pin (8). Take care not to lose coil spring (11).	7	Use the Allen screw to secure electrode cable (3) to handle (2). Caution! Make sure that the machine screw securing the electrode cable is firmly tightened. This is essential to ensure correct electrical contact and correct measuring signals.
8	Remove the old electrode and insert the new electrode. Replacement electrodes can be ordered separately from Endress+Hauser.	8	Reinstall the cover and tighten Allen screw (a).

Troubleshooting Promag 50

9.7 Return



Caution!

Do not return a measuring device if you are not absolutely certain that all traces of hazardous substances have been removed, e.g. substances which have penetrated crevices or diffused through plastic.

Costs incurred for waste disposal and injury (burns, etc.) due to inadequate cleaning will be charged to the owner-operator.

The following steps must be taken before returning a flow measuring device to Endress+Hauser, e.g. for repair or calibration:

- Always enclose a duly completed "Declaration of contamination" form. Only then can Endress+Hauser transport, examine and repair a returned device.
- Enclose special handling instructions if necessary, for example a safety data sheet as per EC REACH Regulation No. 1907/2006.
- Remove all residues. Pay special attention to the grooves for seals and crevices which could contain residues. This is particularly important if the substance is hazardous to health, e.g. flammable, toxic, caustic, carcinogenic, etc.



Motal

You will find a preprinted "Declaration of contamination" form at the back of these Operating Instructions.

9.8 Disposal

Observe the regulations applicable in your country!

9.9 Software history

Date	Software version	Changes to software	Operating Instructions
01.2011	Amplifier: V 2.04.XX	Introduction of new nominal diameters; calf values to 2.5	71249447 / 15.14
11.2009	Amplifier: V 2.03.XX	Introduction of Calf history	71106181 / 12.09 71105332 / 11.09
06.2009	Amplifier: V 2.02.XX	Introduction of Promag L	71095684 / 06.09
03.2009	Amplifier: V 2.02.XX	Introduction of Promag D Introduction of new nominal diameter	71088677 / 03.09
11.2004	Amplifier: 1.06.01 Communication module: 1.04.00	Software update relevant only for production	50097089 / 10.03
10.2003 Amplifier: 1.06.00 Communication module: 1.03.00		Software expASMEon: Language groups Flow direction pulse output selectable New functionalities: Second Totalizer Adjustable backlight (display) Operation hours counter Simulation function for pulse output Counter for access code Reset function (fault history) Up-/download with FieldTool	50097089 / 10.03

Date	Software version	Changes to software	Operating Instructions
08.2003	Communication module: 1.02.01	Software expASMEon: New / revised functionalities	50097089 / 08.03
		New functionalities: Current span NAMUR NE 43 Failsafe mode function Troubleshooting function System and process error messages Response of status output	
08.2002	Amplifier: 1.04.00	Software expASMEon: New / revised functionalities	50097089 / 08.02
		New functionalities: Current span NAMUR NE 43 EPD (new mode) Failsafe mode function Acknowledge fault function Troubleshooting function System and process error messages Response of status output	
03.2002	Amplifier: 1.03.00	Software expASMEon: Suitability for custody transfer measurement Promag 50/51	none
06.2001	Amplifier: 1.02.00 Communication module: 1.02.00	Software expASMEon: New functionalities: New functionalities: General device functions "OED" software function "Pulse width" software function	50097089 / 06.01
09.2000	Amplifier: 1.01.01 Communication module: 1.01.00	Software expASMEon: • Functional adaptations	none
08.2000	Amplifier: 1.01.00	Software expASMEon: • Functional adaptations	none
04.2000	Amplifier: 1.00.00 Communication module: 1.00.00	Original software Compatible with: FieldTool Commuwin II (version 2.05.03 and higher) HART Communicator DXR 275 (from OS 4.6) with Rev. 1, DD1	50097089 / 04.00



Note

Uploads or downloads between the individual software versions are only possible with a special service software.

Technical data Promag 50

10 Technical data

10.1 Technical data at a glance

10.1.1 Application

 $\rightarrow \blacksquare 4$

10.1.2 Function and system design

Measuring principle

Electromagnetic flow measurement on the basis of Faraday's Law.

Measuring system

 $\rightarrow \blacksquare 6$

10.1.3 Input

Measured variable

Flow velocity (proportional to induced voltage)

Measuring range

Typically v = 0.01 to 10 m/s (0.033 to 33 ft/s) with the specified accuracy

Operable flow range

Over 1000:1

Input signal

Status input (auxiliary input)

- Galvanically isolated
- U = 3 to 30 V DC
- $Ri = 5 k\Omega$
- Can be configured for: totalizer reset, positive zero return, error message reset.

10.1.4 Output

Output signal

Current output

- Galvanically isolated
- Active/passive can be selected:
 - Active: 0/4 to 20 mA, R_L < 700 Ω (HART: $R_L \ge 250~\Omega)$
 - Passive: 4 to 20 mA, supply voltage V_S 18 to 30 V DC, R_i ≥150 Ω)
- Time constant can be selected (0.01 to 100s)
- Full scale value adjustable
- Temperature coefficient: typ. 0.005% o.f.s./°C, resolution: 0.5 µA

o.f.s. = of full scale value

Promag 50 Technical data

Pulse/frequency output

- Galvanically isolated
- Passive: 30 V DC / 250 mA
- Open collector
- Can be configured as:
 - Pulse output

Pulse value and pulse polarity can be selected, max. pulse width adjustable (0.5 to 2000 ms)

- Frequency output

Full scale frequency 2 to 1000 Hz (f_{max} = 1.25 Hz), on/off ratio 1:1, pulse width max. 10 s

Signal on alarm

Current output

Failsafe mode can be selected (e.g. in accordance with NAMUR Recommendation NE 43)

Pulse/frequency output

Failsafe mode can be selected

Status output

"Not conductive" in the event of fault or power supply failure

Load

See "Output signal"

Switching output

Status output

- Galvanically isolated
- Max. 30 V DC/250 mA
- Open collector
- Can be configured for: error messages, empty pipe detection (EPD), flow direction, limit values

Low flow cut off

Low flow cut off, switch-on point can be selected as required

Galvanic isolation

All circuits for inputs, outputs, and power supply are galvanically isolated from each other.

10.1.5 Power supply

Electrical connections

→ 🖺 46

Supply voltage (power supply)

- 20 to 55 V AC, 45 to 65 Hz
- 85 to 260 V AC, 45 to 65 Hz
- 16 to 62 V DC

Technical data Promag 50

Cable entry

Power supply and signal cables (inputs/outputs):

- Cable entry M20 × 1.5 (8 to 12 mm/0.31 to 0.47 inch)
- Sensor cable entry for armored cables M20 × 1.5 (9.5 to 16 mm / 0.37 to 0.63 inch)
- Threads for cable entries ½" NPT, G ½"

Connecting cable for remote version:

- Cable entry M20 × 1.5 (8 to 12 mm/0.31 to 0.47 inch)
- Sensor cable entry for armored cables M20 × 1.5 (9.5 to 16 mm / 0.37 to 0.63 inch)
- Threads for cable entries ½" NPT. G ½"

Cable specifications

→ 🖺 51

Power consumption

Power consumption

- AC: <15 VA (incl. sensor)
- DC: <15 W (incl. sensor)

Switch-on current

- max. 3 A (<5 ms) for 24 V DC
- max. 8.5 A (<5 ms) for 260 V AC

Power supply failure

- Lasting min. 1 cycle frequency:
- EEPROM saves measuring system data
- S-DAT: exchangeable data storage chip which stores the data of the sensor (nominal diameter, serial number, calibration factor, zero point etc.)

Potential equalization

→ 🖺 55

10.1.6 Performance characteristics

Reference operating conditions

To DIN EN 29104 and VDI/VDE 2641:

- Fluid temperature: +28 °C ± 2 K
- Ambient temperature: +22 °C ± 2 K
- Warm-up period: 30 minutes

Installation:

- Inlet run >10 × DN
- Outlet run > 5 × DN
- Sensor and transmitter grounded.
- The sensor is centered in the pipe.

Promag 50 Technical data

Maximum measured error

- Current output: plus typically ± 5 µA
- Pulse output: ± 0.5% o.r. ± 1 mm/s
 Option: ± 0.2% o.r. ± 2 mm/s (o.r. = of reading)

Fluctuations in the supply voltage do not have any effect within the specified range.




Fig. 58: Max. measured error in % of reading

Repeatability

Max. \pm 0.1% o.r. \pm 0.5 mm/s (o.r. = of reading)

10.1.7 Installation

Installation instructions

Any orientation (vertical, horizontal), restrictions and installation instructions $\rightarrow \blacksquare 12$

Inlet and outlet run

- Inlet run: ≥ 5 × DNOutlet run: ≥ 2 × DN
- **Adapters**

→ 🖺 16

Length of connecting cable

→ 🖺 19

10.1.8 Environment

Ambient temperature range

■ Transmitter: -20 to +60 °C (-4 to +140 °F)

Note

At ambient temperatures below $-20 (-4 \,^{\circ}\text{F})$ the readability of the display may be impaired.

Sensor (Flange material carbon steel): −10 to +60 °C (+14 to +140 °F)

Technical data Promag 50



Caution!

- The permitted temperature range of the measuring tube lining may not be undershot or overshot (→ "Operating conditions: Process" → "Medium temperature range").
- Install the device in a shady location. Avoid direct sunlight, particularly in warm climatic regions.
- The transmitter must be mounted separate from the sensor if both the ambient and fluid temperatures are high.

Storage temperature

The storage temperature corresponds to the operating temperature range of the measuring transmitter and the appropriate measuring sensors.



Caution!

- The measuring device must be protected against direct sunlight during storage in order to avoid unacceptably high surface temperatures.
- A storage location must be selected where moisture does not collect in the measuring device. This will help prevent fungus and bacteria infestation which can damage the liner.

Degree of protection

- Standard: IP 67 (NEMA 4X) for transmitter and sensor
- Optional: IP 68 (NEMA 6P) for remote version of Promag E/L/P/W sensor. Promag L only with stainless steel flanges.

Shock and vibration resistance

Acceleration up to 2 g following IEC 60068-2-6 (high-temperature version: no data available)

CIP cleaning



Caution!

The maximum fluid temperature permitted for the device may not be exceeded.

CIP cleaning is possible:

Promag E (100 °C / 212 °F), Promag H/P

CIP cleaning is not possible:

Promag D/L/W

SIP cleaning



Caution!

The maximum fluid temperature permitted for the device may not be exceeded.

SIP cleaning is possible:

Promag H

SIP cleaning is not possible:

Promag D/E/L/P/W

Electromagnetic compatibility (EMC)

- As per IEC/EN 61326 and NAMUR Recommendation NE 21
- Emission: to limit value for industry EN 55011

Promag 50 Technical data

10.1.9 Process

Medium temperature range

The permissible temperature depends on the lining of the measuring tube

Promag D

0 to +60 °C (+32 to +140 °F) for polyamide

Promag E

-10 to +110 °C (+14 to +230 °F) for PTFE, Restrictions → see the following diagram




Fig. 59: Compact and remote version Promag E (TA = ambient temperature; TF = fluid temperature)

Promag H

Sensor:

- DN 2 to 25: -20 to +150 °C (-4 to +302 °F)
- DN 40 to 100: -20 to +150 °C (-4 to +302 °F)

Seals:

- EPDM: -20 to +150 °C (-4 to +302 °F)
- Silicone: -20 to +150 °C (-4 to +302 °F)
- Viton: -20 to +150 °C (-4 to +302 °F)
- Kalrez: -20 to +150 °C (-4 to +302 °F)

Promag L

- 0 to +80 °C (+32 to +176 °F) for hard rubber (DN 350 to 1200)
- -20 to +50 °C (-4 to +122 °F) for polyurethane (DN 50 to 1200)
- -20 to +90 °C (-4 to +194 °F) for PTFE (DN 50 to 300)

Promag P

Standard

- -40 to +130 °C (-40 to +266 °F) for PTFE (DN 15 to 600 / 1/2 to 24"), Restrictions \rightarrow see the following diagrams
- -20 to +130 °C (-4 to +266 °F) for PFA/HE (DN 25 to 200 / 1 to 8"), Restrictions \rightarrow see the following diagrams
- -20 to +150 °C (-4 to +302 °F) for PFA (DN 25 to 200 / 1 to 8"), Restrictions \rightarrow see the following diagrams

Optional High-temperature version (HT): –20 to +180 $^{\circ}\text{C}$ (–4 to +356 $^{\circ}\text{F}) for PFA (DN 25 to 200 / 1$




Abb. 60: Compact version Promag P (with PFA- or PTFE-lining)

TA = ambient temperature; TF = fluid temperature; HT = high-temperature version with insulation m = light gray area \rightarrow temperature range from -10 to -40 °C (-14 to -40 °F) is valid for stainless steel version only n = diagonal hatched area \rightarrow foam lining (HE) and degree of protection IP 68 = fluid temperature max. 130°C / 266 °F




Abb. 61: Remote version Promag P (with PFA- or PTFE-lining)

TA = ambient temperature; TF = fluid temperature; HT = high-temperature version with insulation m = light gray area \rightarrow temperature range from -10 to -40 °C (-14 to -40 °F) is valid for stainless steel version only n = diagonal hatched area \rightarrow foam lining (HE) and degree of protection IP68 = fluid temperature max. 130°C / 266 °F

Promag W

- 0 to +80 °C (+32 to +176 °F) for hard rubber (DN 50 to 2000)
- -20 to +50 °C (-4 to +122 °F) for polyurethane (DN 25 to 1200)

Conductivity

The minimum conductivity is $\geq 5 \mu \text{S/cm}$ ($\geq 20 \mu \text{S/cm}$ for demineralized water)



Note

Note that in the case of the remote version, the requisite minimum conductivity is also influenced by the length of the connecting cable $\rightarrow \blacksquare 19$

Medium pressure range (nominal pressure)

Promag D

- EN 1092-1 (DIN 2501)
 - PN 16
- ASME B 16.5
 - Class 150
- JIS B2220
 - 10K

Promag E

- EN 1092-1 (DIN 2501)
 - PN 10 (DN 200 to 600 / 8 to 24")
 - PN 16 (DN 65 to 600 / 3 to 24")
 - PN 40 (DN 15 to 150 / ½ to 2")
- ASME B 16.5
 - Class 150 (½ to 24")
- JIS B2220
 - 10K (DN 50 to 300 / 2 to 12")
 - 20K (DN 15 to 40 / ½ to 1½")

Promag H

The permissible nominal pressure depends on the process connection and the seal:

- 40 bar \rightarrow flange, weld nipple (with O-ring seal)
- 16 bar → all other process connections

Promag L

- EN 1092-1 (DIN 2501)
 - PN 6 (DN 350 to 1200 / 14 to 48")
 - PN 10 (DN 50 to 1200 / 2 to 48")
 - PN 16 (DN 50 to 150 / 2 to 6")
- EN 1092-1, lap joint flange, stampel plate
 - PN 10 (DN 50 to 300 / 2 to 12")
- ASME B 16.5
 - Class 150 (2 to 24")
- AWWA
 - Class D (28 to 48")
- AS2129
 - Table E (DN 350 to 1200 / 14 to 48")
- AS4087
 - PN 16 (DN 350 to 1200 / 14 to 48")

Promag P

- EN 1092-1 (DIN 2501)
 - PN 10 (DN 200 to 600 / 8 to 24")
 - PN 16 (DN 65 to 600 / 3 to 24")
 - PN 25 (DN 200 to 600 / 8 to 24")
 - PN 40 (DN 25 to 150 / 1 to 6")

- ASME B 16.5
 - Class 150 (1 to 24")
 - Class 300 (1 to 6")
- JIS B2220
 - 10K (DN 50 to 300 / 2 to 12")
 - 20K (DN 25 to 300 / 1 to 12")
- AS 2129
 - Table E (DN 25 / 1"), 50 / 2")
- AS 4087
 - PN 16 (DN 50 / 2")

Promag W

- EN 1092-1 (DIN 2501)
 - PN 6 (DN 350 to 2000 / 14 to 84")
 - PN 10 (DN 200 to 2000 / 8 to 84")
 - PN 16 (DN 65 to 2000 / 3 to 84")
 - PN 25 (DN 200 to 1000 / 8 to 40")
 - PN 40 (DN 25 to 150 / 1 to 6")
- ASME B 16.5
 - Class 150 (1 to 24")
 - Class 300 (1 to 6")
- AWWA
 - Class D (28 to 78")
- JIS B2220
 - 10K (DN 50 to 300 / 2 to 12")
 - 20K (DN 25 to 300 / 1 to 12")
- AS 2129
 - Table E (DN 80 / 3", 100 / 4", 150 to 1200 / 6 to 48")
- AS 4087
 - PN 16 (DN 80 / 3", 100 / 4", 150 to 1200 / 6 to 48")

Pressure tightness

Promag D

Measuring tube: 0 mbar abs (0 psi abs) with a fluid temperature of \leq 60 °C (140 °F)

Promag E (Measuring tube lining: PTFE)

Nominal o	liameter	Resistance of measuring tube lining to partial vacuum Limit values for abs. pressure [mbar] ([psi]) at various fluid temperatures									
		25 °C		80	80 °C		100 °C		110 ℃		
		77	°F	170	5°F	212	2 °F	230) °F		
[mm]	[inch]	[mbar]	[psi]			[mbar]	[psi]	[mbar]	[psi]		
15	1/2"	0	0	0	0	0	0	100	1.45		
25	1"	0	0	0	0	0	0	100	1.45		
32	-	0	0	0	0	0	0	100	1.45		
40	1 ½"	0	0	0	0	0	0	100	1.45		
50	2"	0	0	0	0	0	0	100	1.45		
65	-	0	0	*	*	40	0.58	130	1.89		
80	3"	0	0	*	*	40	0.58	130	1.89		
100	4"	0	0	*	*	135	1.96	170	2.47		
125	-	135	1.96	*	*	240	3.48	385	5.58		
150	6"	135	1.96	*	*	240	3.48	385	5.58		
200	8"	200	2.90	*	*	290	4.21	410	5.95		
250	10"	330	4.79	*	*	400	5.80	530	7.69		

Nominal o	liameter		Resistance of measuring tube lining to partial vacuum Limit values for abs. pressure [mbar] ([psi]) at various fluid temperatures									
		25	°C	80) °C	100)°C	110 °C				
		77	°F	17	6 °F	212	2 °F	230) °F			
[mm]	[inch]	[mbar]	[psi]			[mbar]	[psi]	[mbar]	[psi]			
300	12"	400	5.80	*	*	500	7.25	630	9.14			
350	14"	470	6.82	*	*	600	8.70	730	10.59			
400	16"	540	7.83	*	*	670	9.72	800	11.60			
450	18"			Part	ial vacuum i	s impermiss	ible!					
500	20"											
600	24"											
* No value	* No value can be quoted.											

Promag H (Measuring tube lining: PFA)

Nominal diameter Resistance of measuring tube lining to partial vacuum Limit values for abs. pressure [mbar] ([psi]) at various fluid temperatur							ratures			
		25 ℃	25 °C 80 °C 100 °C 130 °C 150 °C 180 °C							
[mm]	[inch]	77 °F	77 °F 176 °F 212 °F 266 °F 302 °F 356 °F							
2 to 100	1/12 to 4"	0	0 0 0 0 0							

Promag L (Measuring tube lining: Polyurethane, Hard rubber)

Nominal diar	neter	Measuring tube lining	Resistance of measuring tube lining to partial vacuum Limit values for abs. pressure [mbar] ([psi]) at various fluid temperatures					
			25 °C 50 °C 80 °C					
[mm]	[inch]		77 °F 122 °F 176 °F					
50 to 1200	2 to 48"	Polyurethane	0 0 -					
350 to 1200	14 to 48"	Hard rubber	0	0	0			

Promag L (Measuring tube lining: PTFE)

Nominal d	iameter	Resistance of measuring tube lining to partial vacuum Limit values for abs. pressure [mbar] ([psi]) at various fluid temperatures							
		25	°C	90	°C				
		77	°F	194	4 °F				
[mm]	[inch]	[mbar]	[psi]	[mbar]	[psi]				
50	2"	0	0	0	0				
65	-	0	0	40	0.58				
80	3"	0	0	40	0.58				
100	4"	0	0	135	1.96				
125	-	135	1.96	240	3.48				
150	6"	135	1.96	240	3.48				
200	8"	200	2.90	290	4.21				
250	10"	330	4.79	400	5.80				
300	12"	400	5.80	500	7.25				

Promag P (Measuring tube lining: PFA)

Promag P Nominal dia	meter	Resistance of measuring tube lining to partial vacuum Limit values for abs. pressure [mbar] ([psi]) at various fluid temperatures							
		25 °C	80° C	100 °C	130 ℃	150 ℃	180 °C		
[mm]	[inch]	77 °F	176° F	212 °F	266 °F	302 °F	356 °F		
25	1"	0	0	0	0	0	0		
32	-	0	0	0	0	0	0		
40	1 ½"	0	0	0	0	0	0		
50	2"	0	0	0	0	0	0		
65	-	0	*	0	0	0	0		
80	3"	0	*	0	0	0	0		
100	4"	0	*	0	0	0	0		
125	-	0	*	0	0	0	0		
150	6"	0	*	0	0	0	0		
200	8"	0	*	0	0	0	0		
* No value ca	an be quoted.	•							

Promag P (Measuring tube lining: PTFE)

Nominal diameter						ng to parti ar] ([psi]			emperat	ures	
		25	°C	80)°C	100 ℃		130 ℃		150 ℃	180 °C
		77	°F	170	6 °F	212	2°F	266	i °F	302 °F	356 °F
[mm]	[inch]	[mbar]	[psi]			[mbar]	[psi]	[mbar]	[psi]		
25	1"	0	0	0	0	0	0	100	1.45	_	-
32	_	0	0	0	0	0	0	100	1.45	-	-
40	1 ½"	0	0	0	0	0	0	100	1.45	-	-
50	2"	0	0	0	0	0	0	100	1.45	-	-
65	_	0	0	*	*	40	0.58	130	1.89	-	-
80	3"	0	0	*	*	40	0.58	130	1.89	-	-
100	4"	0	0	*	*	135	1.96	170	2.47	-	-
125	_	135	1.96	*	*	240	3.48	385	5.58	-	-
150	6"	135	1.96	*	*	240	3.48	385	5.58	-	-
200	8"	200	2.90	*	*	290	4.21	410	5.95	-	1
250	10"	330	4.79	*	*	400	5.80	530	7.69	-	-
300	12"	400	5.80	*	*	500	7.25	630	9.14	-	-
350	14"	470	6.82	*	*	600	8.70	730	10.59	-	1
400	16"	540	7.83	*	*	670	9.72	800	11.60	-	_
450	18"		Partial vacuum is impermissible!								
500	20"	1									
600	24"										
* No value	can be qu	oted.									

Promag W

Nominal diameter Measuring tube lining			Resistance of measuring tube lining to partial vacuum Limit values for abs. pressure [mbar] ([psi]) at various fluid temperatures						
			25 °C 50 °C 80 °C 100 °C 130 °C 150 °C 1					180 °C	
[mm]	[inch]		77 °F	122 °F	176 °F	212 °F	266 °F	302 °F	356 °F
25 to 1200	1 to 40"	Polyurethane	0	0	-	-	-	-	-
50 to 2000	2 to 78"	Hard rubber	0	0	0	-	-	ı	-

Limiting flow

→ 🖺 17

Pressure loss

 No pressure loss if the sensor is installed in a pipe of the same nominal diameter (Promag H: only DN 8 and larger).

■ Pressure losses for configurations incorporating adapters according to DIN EN 545 (see "Adapters" \rightarrow 🗎 16)

10.1.10 Mechanical construction

Design, dimensions

Weight (SI units)

Promag D

Weight data in kg										
Nominal	diameter	Compact version	Remote version	(without cable)						
[mm]	[inch]		Sensor	Transmitter						
25	1"	4.5	2.5	6.0						
40	1 1/2"	5.1	3.1	6.0						
50	2"	5.9	3.9	6.0						
65	2 1/2"	6.7	4.7	6.0						
80	3"	7.7	5.7	6.0						
100 4" 10.4 8.4 6.0										
Transmitter Promag (compact version): 3.4 kg (Weight data valid without packaging material)										

Promag E

Weight	Weight data in kg										
	ninal			Compact	t version						
dian	neter		EN (DIN)		ASME	JIS				
[mm]	[inch]	PN 6	PN 10	N 10 PN 16 PN 40		Class 150	10K				
15	1/2"	_	_	_	6.5	6.5	6.5				
25	1"	_	-	_	7.3	7.3	7.3				
32	-	_	-	_	8.0	-	7.3				
40	1½"	-	-	-	9.4	9.4	8.3				
50	2"	-	-	-	10.6	10.6	9.3				
65	-	-	-	12.0	_	-	11.1				
80	3"	-	-	14.0	_	14.0	12.5				
100	4"	-	-	16.0	_	16.0	14.7				
125	-	-	-	21.5	_	-	21.0				
150	6"	-	-	25.5	_	25.5	24.5				
200	8"	-	45.0	46.0	_	45.0	41.9				
250	10"	-	65.0	70.0	_	75.0	69.4				
300	12"	-	70.0	81.0	_	110.0	72.3				
350	14"	77.4	88.4	99.4	_	137.4	-				
400	16"	89.4	104.4	120.4	_	168.4	-				
450	18"	99.4	112.4	133.4	_	191.4	_				
500	20"	114.4	132.4	182.4	_	228.4	_				
600	24"	155.4	162.4	260.4	-	302.4	-				

- Transmitter (compact version): 1.8 kg
 Weight data without packaging material

Weight	data in	kg						
	ninal			Reme	ote version	(without cab	le)	
dian	neter			Ser	sor			Transmitter
			EN (DIN)		ASME	JIS	
[mm]	[inch]	PN 6	PN 10	PN 16	PN 40	Class 150	10K	Wall-mount housing
15	1/2"	-	-	-	4.5	4.5	4.5	
25	1"	-	-	-	5.3	5.3	5.3	-
32	-	-	-	-	6.0	-	5.3	-
40	1½"	-	-	-	7.4	7.4	6.3	-
50	2"	-	-	-	8.6	8.6	7.3	=
65	-	-	-	10.0	-	-	9.1	-
80	3"	-	-	12.0	-	12.0	10.5	-
100	4"	-	-	14.0	-	14.0	12.7	=
125	-	-	-	19.5	-	-	19.0	6.0
150	6"	_	-	23.5	-	23.5	22.5	0.0
200	8"	-	43.0	44.0	-	43.0	39.9	=
250	10"	-	63.0	68.0	-	73.0	67.4	-
300	12"	-	68.0	79.0	-	108.0	70.3	-
350	14"	73.1	84.1	95.1	-	133.1		=
400	16"	85.1	100.1	116.1	-	164.1		
450	18"	95.1	108.1	129.1	-	187.1		
500	20"	110.1	128.1	178.1	-	224.1		
600	24"	158.1	158.1	256.1	-	298.1		

- Transmitter (remote version): 3.1 kgWeight data without packaging material

Promag H

Weight dat	Weight data in kg									
Nominal	diameter	Compact version	Remote version (without cable)							
[mm]	[inch]	DIN	Sensor	Transmitter						
2	1/12"	5.2	2	6.0						
4	5/32"	5.2	2	6.0						
8	5/16"	5.3	2	6.0						
15	1/2"	5.4	1.9	6.0						
25	1"	5.5	2.8	6.0						
40	1 ½"	6.5	4.5	6.0						
50	2"	9.0	7.0	6.0						
65	2 1/2"	9.5	7.5	6.0						
80	3"	19.0	17.0	6.0						
100	4"	18.5	16.5	6.0						

 $Transmitter\ Promag\ (compact\ version) \hbox{:}\ 3.4\ kg$

(Weight data valid for standard pressure ratings and without packaging material)

Promag L compact version (lap joint flanges / welded flanges DN > 350)

Weight da	ta in kg									
Nominal	diameter	Compact version								
					(including t	ransmi	tter)			
[mm]	[inch]	E	N (DIN)	E	N (DIN)	ASM	ASME / AWWA		AS	
50	2"		10.6		-		10.6		-	
65	2 1/2"		12.0		-		-		-	
80	3"	PN 16	14.0		-		14.0		-	
100	4"	PN	16.0		-		16.0		-	
125	5"		21.5		-		-		-	
150	6"		25.5		-	.50	25.5		-	
200	8"		45		-	ASME / Class 150	45		-	
250	10"		65		-	/ Cla	65		-	
300	12"		70		-	ME,	70		-	
350	14"		90		79	ASI	139	PN 16. Tabelle E	101	
375	15"		-	91	-		-	abe	107	
400	16"		106	PN	91		170	-6. T	122	
450	18"		114		101		193	NG 1	135/145*	
500	20"	PN 10	134		116		230		184	
600	24"	PN	157		157		304		262	
700	28"		248		200		277		354	
750	30"		-		-	O,	329		441	
800	32"		322		248	Class	396		501	
900	36"		402		316	A / C	482		698	
1000	40"		475		366	AWWA / Class D	601		769	
	42"		-		-	AV	684		-	
1200	48"		724		537		914		1227	

Transmitter Promag (compact version): 3,4 kg (Weight data valid without packaging material)
* DN 450 AS Tab E

Promag L remote version (lap joint flanges / welded flanges DN > 350)

Weight da	ta in kg								
Nominal	diameter				Remote	version	L		
				(sensor	plus sensor h	ousing v	without cable)	
[mm]	[inch]	E	EN (DIN)	E	N (DIN)	ASM	E / AWWA	AS	
50	2"		8.6		-		8.6		-
65	2 1/2"		10.0		-		_		-
80	3"	16	12.0		-		12.0		-
100	4"	PN 16	14.0		-		14.0		-
125	5"		19.5		-		-		-
150	6"		23.5		-	50	23.5		-
200	8"		43		-	ASME / Class 150	43		-
250	10"		63		-	, Cla	63		-
300	12"		68		-	ME ,	108		-
350	14"		87		76	ASI	136	lle E	98
375	15"		-	9	-		-	Tabelle	104
400	16"		103	PN	88		167	.6, T	119
450	18"		111		98		190	PN 16, '	132/142*
500	20"	10	131		113		227		181
600	24"	PN 10	154		154		301		259
700	28"		-		198		275		352
750	30"		-		-	D s	327		439
800	32"		320		246	Jass	394		499
900	36"		400		314	4 / C	480		696
1000	40"		473		364	AWWA / Class D	599		767
	42"		-		-	ΑW	682		-
1200	48"		722		535		912		1225
Transmitte	r Promag (r	emote v	rersion): 6 kg						

Transmitter Promag (remote version): 6 kg (Weight data valid without packaging material) *DN 450 AS Tab E

Promag L (lap joint flanges, stamped plate)

Weight da	ta in kg							
Nominal	Nominal diameter Co		pact version	Remote version (without cable)				
[mm]	[inch]	1	EN (DIN)	Sens	sor EN (DIN)	Transmitter		
50	2"		7.2		5.2	6.0		
65	2 1/2"		8.0		6.0	6.0		
80	3"		9.0		7.0	6.0		
100	4"	0	11.5	0	9.5	6.0		
125	5"	PN 10	15.0	PN 10	13.0	6.0		
150	6"	Ъ	19.0	ď	17.0	6.0		
200	8"		37.5		35.5	6.0		
250	10"		56.0		54.0	6.0		
300	12"		57.0		55.0	6.0		
Transmitto	r Promaa (co	nmnact versi	on): 3 /1 ka					

 $Transmitter\ Promag\ (compact\ version): 3.4\ kg\ (Weight\ data\ valid\ for\ standard\ pressure\ ratings\ and\ without\ packaging\ material)$

Promag P

Weight	Weight data in kg														
	ninal neter		Compact version						Remote version (without cable)						
										S	ensor			Trans-	
[mm]	[inch]		(DIN) / AS*		JIS		SME/ WWA		EN (DIN) / AS*		JIS		SME/ WWA	mitter	
15	1/2"		6.5		6.5		6.5		4.5		4.5		4.5	6.0	
25	1"	0	7.3		7.3		7.3	0	5.3		5.3		5.3	6.0	
32	1 1/4"	PN 40	8.0		7.3		-	PN 40	6.0		5.3		-	6.0	
40	1 ½"	Щ	9.4		8.3		9.4	ц	7.4		6.3		7.4	6.0	
50	2"		10.6		9.3		10.6		8.6		7.3		8.6	6.0	
65	2 ½"		12.0		11.1		-		10.0		9.1		-	6.0	
80	3"	9	14.0	10K	12.5		14.0	9	12.0	10K	10.5		12.0	6.0	
100	4"	PN 16	14.4		14.7	0	16.0	PN 16	14.0		12.7	C	14.0	6.0	
125	5"	ц	16.0		21.0	150	-	Н	19.5		19.0	150	-	6.0	
150	6"		21.5		24.5	Class	25.5		23.5		22.5	Class	23.5	6.0	
200	8"		45		41.9		45		43		39.9		43	6.0	
250	10"		65		69.4		75		63		67.4		73	6.0	
300	12"		70		72.3		110		68		70.3		108	6.0	
350	14"	10	115				175	10	113				173	6.0	
400	16"	PN	135				205	PN	133				203	6.0	
450	18"		175				255		173				253	6.0	
500	20"		175				285		173				283	6.0	
600	24"		235				405		233				403	6.0	

Transmitter Promag (compact version): 3.4 kg
High-temperature version: + 1.5 kg
(Weight data valid for standard pressure ratings and without packaging material)
* Flanges according to AS are only available for DN 25 and 50.

Promag W

Nom	data in inal ieter	kg	kg Compact version					Remote version (without cable))	
[mm]	[inch]		(DIN) / AS*		JIS		SME/ WWA		(DIN) / AS*	Se	nsor JIS		ME/ WWA	Trans- mitter
25	1"		7.3		7.3		7.3		5.3		5.3		5.3	6.0
32	1 1/4"	40	8.0		7.3		-	40	6.0		5.3		-	6.0
40	1 1/2"	PN	9.4		8.3		9.4	PN	7.4		6.3		7.4	6.0
50	2"		10.6		9.3		10.6		8.6		7.3		8.6	6.0
65	2 1/2"		12.0		11.1		-		10.0		9.1		-	6.0
80	3")	14.0	X	12.5		14.0	,,	12.0	云	10.5		12.0	6.0
100	4"	PN 16	16.0	10K	14.7		16.0	PN 16	14.0	10K	12.7		14.0	6.0
125	5"	[d	21.5		21.0	20	-	Ы	19.5		19.0	20	-	6.0
150	6"		25.5		24.5	Class 150	25.5		23.5		22.5	Class 150	23.5	6.0
200	8"		45		41.9	Cla	45		43		39.9	Cla	43	6.0
250	10"		65		69.4		65		63		67.4		73	6.0
300	12"		70		72.3		110		68		70.3		108	6.0
350	14"		115				175		113				173	6.0
400	16"		135				205		133				203	6.0
450	18"	(175				255		173				253	6.0
500	20"	PN 10	175				285	PN 10	173				283	6.0
600	24"	ΡΙ	235				405	PI	233				403	6.0
700	28"		355				400		353				398	6.0
-	30"		-				460		_				458	6.0
800	32"		435				550		433				548	6.0
900	36"		575				800		573				798	6.0
1000	40"		700				900		698				898	6.0
-	42"		-				1100		-				1098	6.0
1200	48"		850				1400		848				1398	6.0
-	54"		-			Class D	2200		-			Class D	2198	6.0
1400	_		1300	1		Ü	_		1298			C	-	6.0
-	60"	9	-	1			2700	9	-				2698	6.0
1600	_	PN	1700	1			_	PN	1698				-	6.0
-	66"		_	1			3700		_				3698	6.0
1800	72"		2200	1			4100		2198				4098	6.0
-	78"		-	1			4600		-				4598	6.0
2000	_		2800	1			_		2798				-	6.0

Transmitter Promag (compact version): 3.4 kg (Weight data valid for standard pressure ratings and without packaging material) *Flanges according to AS are only available for DN 80, 100, 150 to 400, 500 and 600

Weight (US units)

Promag D

Weight data in lbs								
Nominal	diameter	Compact version	Remote version (without cable)					
[mm]	[inch]		Sensor	Transmitter				
25	1"	10	6	13				
40	1 1/2"	11	7	13				
50	2"	13	9	13				
80 3" 17 13 13								
100 4" 23 19 13								
Transmitter	Promag (comp	oact version): 7.5 lbs (Weight d	ata valid without packaging m	aterial)				

Promag E (ASME)

Weight	data in	lbs		
	ninal	Compact version	Remote version	(without cable)
dian	ieter		Sensor	Transmitter
		ASME	ASME	
[mm]	[inch]	Class 150	Class 150	Wall-mount housing
15	1/2"	14.3	9.92	
25	1"	16.1	11.7	
40	11/2"	20.7	16.3	
50	2"	23.4	19.0	
80	3"	30.9	26.5	
100	4"	35.3	30.9	
150	6"	56.2	51.8	
200	8"	99.2	94.8	13.2
250	10"	165.4	161.0	
300	12"	242.6	238.1	
350	14"	303.0	293.5	
400	16"	371.3	361.8	
450	18"	422.0	412.6	
500	20"	503.6	494.1	
600	24"	666.8	657.3	

[■] Transmitter: 4.0 lbs (compact version); 6.8 lbs (remote version)

Promag H

Weight dat	a in lbs						
Nominal	diameter	Compact version	Remote version (without cable)				
[mm]	[inch]		Sensor	Transmitter			
2	1/12"	11	4	13			
4	5/32"	11	4	13			
8	5/16"	12	4	13			
15	1/2"	12	4	13			
25	1"	12	6	13			
40	1 ½"	14	10	13			
50	2"	20	15	13			
65	2 1/2"	21	17	13			
80	3"	42	37	13			
100	4"	41	36	13			
Tuenemitter	D	anast manaism), 7 F lbs					

Transmitter Promag (compact version): 7.5 lbs

Weight data without packaging material

⁽Weight data valid for standard pressure ratings and without packaging material)

 $Promag\ L\ (ASME\ /\ AWWA:\ lap\ joint\ flanges\ /\ welded\ flanges\ DN > 700)$

Weight data in	lbs				
Nominal	diameter	Co	mpact version	Remote ve	ersion (without cable)
[mm]	[inch]	ASME / AWWA		ASME / AWWA	
50	2"		23		19
65	2 ½"		-		-
80	3"	50	31	.50	26
100	4"	ASME / Class 150	35	ASME / Class 150	31
125	5"	, Cla	-	′ Cla	-
150	6"	ME /	56	ME /	52
200	8"	ASI	99	ASI	95
250	10"		143		139
300	12"		243		238
350	14"		-		-
400	16"		-		-
450	18"		-		-
500	20"		-		-
600	24"		-		-
700	28"		611		606
750	30"	Q	725	O :	721
800	32"	Slass	873	Class	869
900	36"	0/4	1063)/{	1058
1000	40"	AWWA / Class D	1324	AWWA / Class D	1320
	42"	AV	1508	ΑV	1504
1200	48"		2015		2011

Transmitter Promag (compact version): 7,5 lbs Transmitter Promag (remote version): 13 lbs (Weight data valid without packaging material)

Promag P (ASME/AWWA)

Weight data in	lbs						
Nominal	diameter	Com	pact version	Remote version (without cable)			
[mm]	[inch]				Sensor	Transmitter	
15	1/2"		14		10	13	
25	1"		16		12	13	
40	1 ½"		21		16	13	
50	2"		23		19	13	
80	3"		31		26	13	
100	4"		35		31	13	
150	6"	20	56	20	52	13	
200	8"	Class 150	99	Class 150	95	13	
250	10"	Cla	165	Cla	161	13	
300	12"		243		238	13	
350	14"		386		381	13	
400	16"		452		448	13	
450	18"		562		558	13	
500	20"		628		624	13	
600	24"		893		889	13	

 $Transmitter\ Promag\ (compact\ version);\ 7.5\ lbs$

High-temperature version: 3.3 lbs

(Weight data valid for standard pressure ratings and without packaging material)

Promag W (ASME/AWWA)

Weight data in	lbs					
Nominal	diameter	Com	pact version	Rei	mote version (v	without cable)
[mm]	[inch]			S	ensor	Transmitter
25	1"		16		12	13
40	1 1/2"		21		16	13
50	2"		23		19	13
80	3"		31		26	13
100	4"		35		31	13
150	6"		56		52	13
200	8"	Class 150	99	Class 150	95	13
250	10"	Class	143	lass	161	13
300	12"		243		238	13
350	14"		386		381	13
400	16"		452		448	13
450	18"		562		558	13
500	20"		628		624	13
600	24"		893		889	13
700	28"		882		878	13
_	30"		1014		1010	13
800	32"		1213		1208	13
900	36"		1764		1760	13
1000	40"		1985		1980	13
_	42"	Class D	2426	Class D	2421	13
1200	48"	Clas	3087	Clas	3083	13
_	54"		4851		4847	13
-	60"		5954		5949	13
_	66"		8159		8154	13
1800	72"		9041		9036	13
_	78"		10143		10139	13

Transmitter Promag (compact version): 7.5 lbs (Weight data valid for standard pressure ratings and without packaging material)

Material

Promag D

■ Transmitter housing: powder-coated die-cast aluminum

■ Sensor housing: powder-coated die-cast aluminum

Measuring tube: polyamide, O-rings EPDM (Drinking water approvals: WRAS BS 6920, ACS, NSF 61, KTW/W270)

■ Electrodes: 1.4435 (316, 316L)

• Ground disks: 1.4301 (304)

Promag E

- Transmitter housing
 - Compact housing: powder-coated die-cast aluminum
 - Wall-mount housing: powder-coated die-cast aluminum
- Sensor housing
 - DN 25 to 300 (1 to 12"): powder-coated die-cast aluminum
 - DN 350 to 600 (14 to 24"): with protective lacquering
- Measuring tube
 - DN ≤ 300 (12"): stainless steel 1.4301 (304) or 1.4306 (304L) (with Al/Zn protective coating)
 - DN \geq 350 (14"): stainless steel 1.4301 (304) or 1.4306 (304L) (with protective lacquering)
- Electrodes: 1.4435 (316, 316L), Alloy C22, Tantalum
- Flanges (with protective lacquering)
 - EN 1092-1 (DIN2501): RSt37-2 (S235JRG2); Alloy C22; Fe 410W B
 - ANSI: A105
 - JIS: RSt37-2 (S235JRG2); HII
- Seals: to DIN EN 1514-1
- Ground disks: 1.4435 (316, 316L) or Alloy C22

Promag H

- Transmitter housing:
 - Compact housing: powder-coated die-cast aluminum or stainless steel field housing (1.4301 (316L))
 - Wall-mounted housing: powder-coated die-cast aluminum
 - Window material: glas or polycarbonate
- Sensor housing: stainless steel 1.4301 (304)
- Wall mounting kit: stainless steel 1.4301 (304)
- Measuring tube: stainless steel 1.4301 (304)
- Liner: PFA (USP class VI; FDA 21 CFR 177.1550: 3A)
- Electrodes:
 - Standard: 1.4435 (316, 316L)
 - Option: Alloy C22, Tantalum, Platinum
- Flange:
 - All connections stainless-steel 1.4404 (316L)
 - EN (DIN), ASME, JIS made of PVDF
 - Adhesive fitting made of PVC
- Seals
 - DN 2 to 25 (1/12 to 1"): O-ring (EPDM, Viton, Kalrez), gasket seal (EPDM*, Viton, Silicone*)
 - DN 40 to 100 ($1\frac{1}{2}$ to 4"): gasket seal (EPDM*, Silicone*)
 - * = USP class VI; FDA 21 CFR 177.2600: 3A
- Ground rings: 1.4435 (316, 316L) (optional: Tantalum, Alloy C22)

Promag L

- Transmitter housing:
 - Compact housing: powder-coated die-cast aluminum
 - Wall-mounted housing: powder-coated die-cast aluminum
- Sensor housing
 - DN 50 to 300 (2 to 12"): powder-coated die-cast aluminum
 - DN 350 to 1200 (14 to 84"): with protective lacquering

- Measuring tube:
 - $-DN \le 300 (12")$: stainless steel 1.4301 (304) or 1.4306 (304L)
 - DN \ge 350 (14"): stainless steel 202 or 304
- Electrodes: 1.4435 (316, 316L), Alloy C22
- Flange
 - EN 1092-1 (DIN 2501): DN ≤ 300: 1.4306; 1.4307; 1.4301 (304); 1.0038 (\$235]RG2)
 - EN 1092-1 (DIN 2501): DN ≥ 350: A105; 1.0038 (S235JRG2)
 - AWWA: A181/A105; 1.0425 (316L) (P265GH); 1.0044 (S275JR)
 - AS 2129: A105; 1.0345 (P235GH); 1.0425 (316L) (P265GH); 1.0038 (S235JRG2); FE 410 WB
 - AS 4087: A105; 1.0425 (316L) (P265GH); 1.0044 (S275JR)
- Seals: to DIN EN 1514-1
- Ground disks: 1.4435 (316, 316L) or Alloy C22

Promag P

- Transmitter housing:
 - Compact housing: powder-coated die-cast aluminum
 - Wall-mounted housing: powder-coated die-cast aluminum
- Sensor housing
 - DN 15 to 300 ($\frac{1}{2}$ to 12"): powder-coated die-cast aluminum
 - DN 350 to 2000 (14 to 84"): with protective lacquering
- Measuring tube
 - DN ≤ 300 (12"): stainless steel 1.4301 (304) or 1.4306 (304L); for flanges made of carbon steel with Al/Zn protective coating
 - DN \geq 350 (14"): stainless steel 1.4301 (304) or 1.4306 (304L); for flanges made of carbon steel with Al/Zn protective coating
- Electrodes: 1.4435 (316, 316L), Platinum, Alloy C22, Tantalum, Titanium
- Flange
 - EN 1092-1 (DIN2501): 1.4571 (316L); RSt37-2 (S235JRG2); Alloy C22; FE 410W B (DN \leq 300 (12") with Al/Zn protective coating; DN \geq 350 (14") with protective lacquering)
 - ASME: A105; F316L
 - (DN \leq 300 (12") with Al/Zn protective coating; DN \geq 350 (14") with protective lacquering)
 - AWWA: 1.0425
 - JIS: RSt37-2 (S235JRG2); HII; 1.0425 (316L) (DN \leq 300 (12") with Al/Zn protective coating; DN \geq 350 (14") with protective lacquering)
 - AS 2129
 - DN 25 (1"): A105 or RSt37-2 (S235JRG2)
 - DN 40 (1½"): A105 or St44-2 (S275JR)
 - AS 4087: A105 or St44-2 (S275JR)
- Seals: to DIN EN 1514-1
- Ground disks: 1.4435 (316, 316L) or Alloy C22

Promag W

- Transmitter housing:
 - Compact housing: powder-coated die-cast aluminum
 - Wall-mounted housing: powder-coated die-cast aluminum
- Sensor housing
 - DN 25 to 300 (1 to 12"): powder-coated die-cast aluminum
 - DN 350 to 2000 (14 to 84"): with protective lacquering

- Measuring tube
 - DN ≤ 300 (12"): stainless steel 1.4301 (304) or 1.4306 (304L) (for flanges made of carbon steel with Al/Zn protective coating)
 - DN \geq 350 (14"): stainless steel 1.4301 (304) or 1.4306 (304) (for flanges made of carbon steel with protective lacquering)
- Electrodes: 1.4435 (316, 316L) or Alloy C22, Tantalum
- Flange
 - EN 1092-1 (DIN2501): 1.4571 (316L); RSt37-2 (S235JRG2); Alloy C22; FE 410 WB (DN \leq 300 (12") with Al/Zn protective coating; DN \geq 350 (14") with protective lacquering)
 - ASME: A105; F316L (DN \leq 300 (12") with Al/Zn protective coating; DN \geq 350 (14") with protective lacquering)
 - AWWA: 1.0425
 - JIS: RSt37-2 (S235JRG2); HII; 1.0425 (316L) (DN \leq 300 (12") with Al/Zn protective coating; DN \geq 350 (14") with protective lacquering)
 - AS 2129
 - DN 150 to 300 (6 to 12"), DN 600 (24"): A105 or RSt37-2 (S235JRG2)
 - DN 80 to 100 (3 to 4"), 350 to 500 (14 to 20"): A105 or St44-2 (S275JR)
 - AS 4087: A105 or St44-2 (S275JR)
- Seals: to DIN EN 1514-1
- Ground disks: 1.4435 (316, 316L), Alloy C22, Titanium, Tantalum

Pressure-temperature ratings

The material load diagrams (pressure-temperature graphs) for the process connections are to be found in the "Technical Information" documents of the device in question: List of supplementary documentation $\Rightarrow \triangleq 124$.

Fitted electrodes

Promag D

• 2 measuring electrodes for signal detection

Promag E/L/P/W

- 2 measuring electrodes for signal detection
- 1 EPD electrode for empty pipe detection
- 1 reference electrode for potential equalization

Promag H

- 2 measuring electrodes for signal detection
- 1 EPD electrode for empty pipe detection (apart from DN 2 to 15)

Process connections

Promag D

Wafer version \rightarrow without process connections

Promag E

Flange connections:

- EN 1092-1 (DIN 2501)
 - $-DN \le 300 (12") = form A$
 - DN ≥ 350 (14") = flat face
 - DN 65 PN 16 and DN 600 PN 16 only as per EN 1092-1
- ASME
- JIS

Promag H

With O-ring:

- Weld nipple DIN (EN), ISO 1127, ODT/SMS
- Flange EN (DIN), ASME, JIS
- Flange made of PVDF EN (DIN), ASME, JIS
- External thread
- Internal thread
- Hose connection
- PVC adhesive fitting

With gasket seal:

- Weld nipple DIN 11850, ODT/SMS
- Clamp ISO 2852, DIN 32676, L14 AM7
- Threaded joint DIN 11851, DIN 11864-1, ISO 2853, SMS 1145
- Flange DIN 11864-2

Promag L

Flange connections:

- EN 1092-1 (DIN 2501)
 - $-DN \le 300 = Form A$
 - DN ≥ 350 = Form B
- ASME
- AWWA
- AS

Promag P/W

Flange connections:

- EN 1092-1 (DIN 2501)
 - $-DN \le 300 = form A$
 - DN ≥ 350 = flat face
 - DN 65 PN 16 and DN 600 PN 16 only as per EN 1092-1
- ASME
- AWWA (only Promag W)
- JIS
- AS

Surface roughness

All data relate to parts in contact with fluid.

- Liner \rightarrow PFA: \leq 0.4 μ m (15 μ in)
- Electrodes: 0.3 to 0.5 μm (12 to 20 μin)
- Process connection made of stainless-steel (Promag H): \leq 0.8 µm (31 µin)

10.1.11 Human interface

Display elements

- Liquid crystal display: illuminated, two-line, 16 characters per line
- Custom configurations for presenting different measured-value and status variables
- 2 totalizers



Note!

At ambient temperatures below -20 (-4 °F) the readability of the display may be impaired.

Operating elements

- Local operation with three keys (□ ± €)
- "Quick Setup" menus for straightforward commissioning

Language groups

Language groups available for operation in different countries:

- Western Europe and America (WEA):
 English, German, Spanish, Italian, French, Dutch and Portuguese
- Eastern Europe/Scandinavia (EES):
 English, Russian, Polish, Norwegian, Finnish, Swedish and Czech
- Southeast Asia (SEA):
 English, Japanese, Indonesian



Vote!

You can change the language group via the operating program "FieldCare".

Remote operation

Operation via HART protocol and Fieldtool

10.1.12 Certificates and approvals

CE mark

The measuring system is in conformity with the statutory requirements of the EC Directives. Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.

C-tick mark

The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".

Ex approval

Information about currently available Ex versions (ATEX, FM, CSA, IECEx, NEPSI etc.) can be supplied by your Endress+Hauser Sales Center on request. All explosion protection data are given in a separate documentation which is available upon request.

Sanitary compatibility

Promag D/E/L/P/W

No applicable approvals or certification

Promag H

- 3A authorization and EHEDG-tested
- Seals: in conformity with FDA (except Kalrez seals)

Drinking water approval

Promag D/L/W

- WRAS BS 6920
- ACS
- NSF 61
- KTW/W270

Promag E/H/P

No drinking water approval

Pressure Equipment Directive

Promag D/L

No pressure measuring device approval

Promag E/H/P/W

The devices can be ordered with or without a PED approval. If a device with a PED approval is required, this must be explicitly stated in the order. For devices with nominal diameters less than or equal to DN 25 (1"), this is neither possible nor necessary.

- With the PED/G1/x (x = category) marking on the sensor nameplate, Endress+Hauser confirms compliance with the "Essential Safety Requirements" specified in Annex I of the Pressure Equipment Directive 97/23/EC.
- Devices bearing this marking (PED) are suitable for the following types of medium:
 Media in Group 1 and 2 with a vapor pressure greater than, or smaller and equal to 0.5 bar (7.3 psi)
- Devices not bearing this marking (PED) are designed and manufactured according to good engineering practice. They meet the requirements of Art.3 Section 3 of the Pressure Equipment Directive 97/23/EC. The range of application is indicated in tables 6 to 9 in Annex II of the Pressure Equipment Directive.

Other standards and guidelines

■ EN 60529

Degrees of protection by housing (IP code).

■ EN 61010-1

Safety requirements for electrical equipment for measurement, control and laboratory use

■ IEC/EN 61326

Electromagnetic compatibility (EMC requirements)

■ ASME/ISA-S82.01

Safety Standard for Electrical and Electronic Test, Measuring, Controlling and related Equipment - General Requirements. Pollution degree 2, Installation Category II.

 CAN/CSA-C22.2 (No. 1010.1-92)
 Safety requirements for Electrical Equipment for Measurement and Control and Laboratory Use. Pollution degree 2, Installation Category I.

■ NAMUR NE 21

Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment.

NAMUR NE 43

Standardization of the signal level for the breakdown information of digital transmitters with analog output signal.

10.1.13 Ordering information

Detailed ordering information is available from the following sources:

- In the Product Configurator on the Endress+Hauser website: www.endress.com → Select country → Instruments → Select device → Product page function: Configure this product
- From your Endress+Hauser Sales Center: www.endress.com/worldwide



Note

Product Configurator - the tool for individual product configuration

- Up-to-the-minute configuration data
- Depending on the device: Direct input of measuring point-specific information such as measuring range or operating language
- Automatic verification of exclusion criteria
- Automatic creation of the order code and its breakdown in PDF or Excel output format
- Ability to order directly in the Endress+Hauser Online Shop

10.1.14 Accessories

Various accessories, which can be ordered separately from Endress+Hauser, are available for the transmitter and the sensor $\rightarrow \blacksquare 78$.

Your Endress+Hauser service organization can provide detailed information on the specific order codes on request.

10.1.15 Documentation

- Flow measuring technology (FA00005D/06)
- Technical Information Promag 50D (TI00082D/06)
- Technical Information Promag 50E (TIO1161D/06)
- Technical Information Promag 50L (TI00097D/06)
- Technical Information Promag 50/53H (TI00048D/06)
- Technical Information Promag 50/53P (TI00047D/06)
- Technical Information Promag 50/53W (TI00046D/06)
- Description of Device Functions Promag 50 HART (BA00049D/06)
- Supplementary documentation on Ex-ratings: ATEX, FM, CSA, etc.


Index

A	Environment 101
Accessories	Error message types63
Adapters	Error messages
Ambient temperature range	Process error (application error) 84
Applicator (selection and configuration software) 80	System errors (device errors)82
Approvals	Europäische Druckgeräterichtlinie
FF	Ex approval 122
С	Exterior cleaning
Cable entry	
Cable specifications	F
Calibration factor	Field Xpert SFX10054
CE mark	FieldCare 64, 80
CE mark (Declaration of Conformity) 8	Fieldcheck (tester and simulator) 80
Centering sleeve	Fitted electrodes 120
Promag D 21	Flow rate/limits17
Certificates	Function matrix
CIP cleaning	Brief operating instructions 61
Cleaning (exterior cleaning)	Fuse, replacing93
Code entry (function matrix) 62	FXA19380
Commissioning	FXA19579
General	
Two current outputs	G
Commissioning Quick Setup menu	Galvanic isolation
Commubox FXA 195 (electrical connection) 55, 79	Gewicht 115
Communication	Ground cable
Conductivity of fluid	Promag E
Connecting cable	Promag L
Connection	Promag P32
Check59	Promag W36
HART54	Grounding rings
Remote version	Promag H
C-tick mark	
Current output	Н
Configuration (active/passive)	HART
Comingulation (accire) passive, in the control of t	Command classes
D	Commands
Declaration of Conformity (CE mark) 8	Communicator DXR 37564
Degree of protection	Device description files
Design	Device status / Error messages 70
Device description files 65	Write protection
Device variable via HART protocol	Hazardous substances96
Display	High-temperature version
Elements	HOME position (operating mode)60
Turning the display 42	T
Documentation	I
Drinking water approval	Incoming acceptance
Druckgerätezulassung	Inlet/outlet run
5	Installation
E	Promag D
Electrical connection	Promag E
Commubox FXA 191 55	Promag H
HART handheld terminal	Promag L
Electrical connections	Promag P
Electrodes	Promag W
EPD electrode	Installation conditions
EMC (electromagnetic compatibility) 51, 102	Adapters
Empty-pipe/full-pipe adjustment	Dimensions12
•	

Down pipe 13 EPD electrode 14	Pig (cleaning)	
Foundations, supports	Check	
Inlet/outlet run	Potential equalization	
Installation of pumps	Power consumption	
Mounting location	Power supply	
Orientation14	Power supply failure	
Partially filled pipes	Pressure Equipment Directive	123
Vibrations	Pressure loss	
Installing the wall-mount housing 43	Adapters (reducers, expanders)	
•	Pressure tightness	
L 122	Pressure-temperature ratings	
Language groups	Process	
Load	Process connections	
Local display	Process error messages	
See Display	Process errors (definition)	. 63
Low flow cut off	Programming mode	
M	Disable	
Maintenance	Enable	. 62
	Promag D	
Material	Centering sleeve	
Maximum measured error	Installation	
Measured variable	Mounting bolts	
Measuring principle	Seals	
Measuring range	Tightening torques	
Measuring system	Promag D mounting kit	. 20
Mechanical construction	Promag E	
Medium pressure range	Ground cable	
Medium temperature range	Installation	
Mounting bolts	Seals	
Promag D	Tightening torques	. 24
Mounting the sensor	Promag H	
See Installing the sensor	Cleaning with pigs	. 28
N	Grounding ring (DN 2 to 25, 1/12" to 1")	
Nameplate specifications	Installation	
Connections	Seals	
Sensor	Weld nipple	. 28
Transmitter 6	Promag L	
Nominal diameter and flow rate	Ground cable	
Promag W	Installation	
110mag vv	Seals	
0	Tightening torques	. 30
Operable flow range98	Promag P	
Operating elements 60, 122	Ground cable	
Operation	High-temperature version	
Device description files	Installation	
FieldCare	Seals	
Operating programs	Tightening torques	. 33
Operational safety 4	Promag W	
Order code	Ground cable	
Accessories	Installation	
Sensor8	Seals	
Ordering code	Tightening torques	. 36
Sensor	0	
Transmitter 6	Q	70
Output98	Quick Setup	. 73
Output	R	
P		100
Performance characteristics	Reference operating conditions	TOO

Repeatability	
F	86 96
S	
Safety icons	5
Safety instructions	
Sanitary compatibility	
	 76
	77
	20
	23
Promag H	26
Promag L	29
Promag P	32
9	36
Serial number	
Sensor	
Transmitter	
Service interface FXA 193	
Shock resistance	
g	99 02
SIP cleaning	UΔ
	72
	, <u>2</u> 88
Standards, guidelines	
	02
5 1	99
Surface roughness	21
Switching on (measuring device)	72
	82
System errors (definition)	63
Т	
	98
Temperature	70
<u> </u>	01
	03
	02
Tightening torques	
5 5 1	22
	24
Promag L	30
5	33
5	36
Transmitter	
	52
· · · · · · · · · · · · · · · · ·	43 1
,	41 41
	41 81
110401001110011119	-1

Гуреs of error (system and process errors)	63
V Vibration resistance	
W	
Wall-mount housing, installing	09
























Description of Device Functions

Proline Promag 50

Electromagnetic Flow Measuring System







Contents

I	Function matrix Promag 50
1.1 1.2	The function matrix: layout and use
2	Group MEASURING VALUES 7
3	Group SYSTEM UNITS 8
4	Group QUICK SETUP10
5	Group OPERATION11
6	Group USER INTERFACE13
7	Group TOTALIZER 1/216
8	Group HANDLING TOTALIZER18
9	Group CURRENT OUTPUT19
10	Group PULSE/FREQUENCY OUTPUT 23
11	Group STATUS OUTPUT34
11 11.1 11.2	Group STATUS OUTPUT
11.1	Information on the response of the status output 37
11.1 11.2	Information on the response of the status output 37 Switching response of the status output
11.1 11.2 12	Information on the response of the status output 37 Switching response of the status output
11.1 11.2 12	Information on the response of the status output 37 Switching response of the status output
11.1 11.2 12 13	Information on the response of the status output 37 Switching response of the status output
11.1 11.2 12 13 14 15	Information on the response of the status output 37 Switching response of the status output
11.1 11.2 12 13 14 15	Information on the response of the status output 37 Switching response of the status output
11.1 11.2 12 13 14 15 16	Information on the response of the status output

Z I	Factory settings 58
	SI units (not for USA and Canada)
22	Index of key words 62

Registered trademarks

HART®

Registered trademark of the HART Communication Foundation, Austin, USA

 $HistoROM^{TM},$ S-DAT $^{\circledR},$ FieldCare $^{\circledR}$ Registered trademarks of Endress+Hauser Flowtec AG, Reinach, CH

 $Endress\!+\!Hauser$

1 Function matrix Promag 50

1.1 The function matrix: layout and use

The function matrix is a two-level construct: the groups form one level and the groups' functions the other.

The groups are the highest-level grouping of the operating options for the measuring device. A number of functions is assigned to each group.

You select a group in order to access the individual functions for operating and parameterizing the measuring device.


An overview of all the groups available is provided in the table of contents on Page 3 and in the graphical representation of the function matrix on Page 6.

An overview of all the functions available is provided on Page 6, complete with page references to the detailed function descriptions.

The descriptions of the individual functions start on Page 7.

Example of how to parameterize a function (in this case changing the language for the UI):

- 1. Enter into the function matrix (E-key).
- 2. Select the OPERATION group.
- 3. Select the LANGUAGE function, change the setting from ENGLISH to DEUTSCH with = and save with = (all text on the display now appears in German).
- 4. Exit the function matrix (ESC > 3 seconds).



A0001142

Function groups \blacktriangleright Functions \rightarrow

1.2 Illustration of the function matrix

								SIMUL. FREO. (P. 28)					ECC CLEAN. CYCL. (P. 48)						
								ACTUAL FREO. (P. 27)					ECC RECOVERY TIME (P. 48)			OPERAT. HRS. (P. 55)			
				DISPLAY TEST (P. 15)			VALUE SIM. CURRENT (P. 22)	FAILSAFE VALUE (P. 27)	VALUE SIM. PULSE (P. 33)				ECC DURATION (P. 47)		POLARITY ECC (P. 53)	SYSTEM RESET (P. 55)			
				BACKLIGHT (P. 15)			SIMUL. CURRENT (P. 22)	FAILSAFE MODE (P. 27)	SIMULATION PULSE (P. 32)	VAL. SIM. SWIT. PT. (P. 36)		DEVICE REVISION (P. 42)	ECC (P. 47)		EPD ELECTRODE (P. 53)	ALARM DELAY (P. 55)			
				CONTRAST LCD (P. 14)	RESET TOTALIZ. (P. 17)		ACTUAL CURRENT (P. 21)	TIME CONSTANT (P. 27)	FAILSAFE MODE (P. 32)	SIM. SWITCH POINT (P. 35)		DEVICE ID (P. 42)	EPD/OED RES.TIME (P. 47)		OVERVLTG TIME (P. 53)	ERROR CATEG. (P. 55)			
			ACCESS CODE COUNTER (P. 12)	DISPL. DAMPING (P. 14)	TOTALIZER MODE (P. 17)		FAILSAFE MODE (P. 21)	OUTPUT SIGNAL (P. 25)	OUTPUT SIGNAL (P. 30)	ACTUAL STATUS (P. 35)	VALUE SIM. STATUS (P. 41)	MANUFACT. ID (P. 42)	EPD/OED ADJ. (P. 46)	INTEGRAT. TIME (P. 51)	MEAS. PERIOD (P. 53)	ASSIGN PROC. ERR. (P. 54)			SW REV. L/O MOD. (P. 57)
	FORMAT DATE/TIME (P. 9)		STATUS ACCESS (P. 12)	FORMAT (P. 14)	UNIT TOTALIZER (P. 16)		TIME CONSTANT (P. 21)	VALUE-f HIGH (P. 24)	PULSE WIDTH (P. 29)	TIME CONSTANT (P. 35)	SIM. STATUS INP. (P. 40)	HART PROTOCOL (P. 42)	EMPTY PIPE DET. (P. 44)	SYSTEM DAMPING (P. 51)	NOM. DIAMETER (P. 52)	ERROR CATEG. (P. 54)		SW REV. NO. S-DAT (P. 57)	I/O MODULE TYPE (P. 57)
	UNIT LENGTH (P. 9)		PRIVATE CODE (P. 12)	100% VALUE (P. 13)	OVERFLOW (P. 16)		VALUE 20 mA (P. 21)	END VALUE FREO. (P. 23)	PULSE VALUE (P. 29)	OFF-VALUE (P. 35)	MIN. PULSE WIDTH (P. 40)	BUS ADDRESS (P. 42)	OFF-VALUE (P. 43)	POS. ZERO RETURN (P. 50)	ZERO POINT (P. 52)	ASSIGN SYS. ERR. (P. 54)	VAL.SIM.MEAS.VAR. (P. 56)	HW REV. SENS. (P. 57)	LANGUAGE GROUP (P. 57)
	UNIT VOLUME (P. 8)		ACCESS CODE (P. 12)	ASSIGN LINE 2 (P. 13)	SUM (P. 16)	FAILSAFE MODE (P. 18)	CURRENT SPAN (P. 20)	ASSIGN FREO. (P. 23)	ASSIGN PULSE (P. 28)	ON-VALUE (P. 34)	ACTIVE LEVEL (P. 40)	TAG DESCR. (P. 42)	ON-VALUE (P. 43)	MEASURING MODE (P. 49)	K-FACTOR (P. 52)	PREV. SYS. COND. (P. 54)	SIM. MEAS. VARIAB. (P. 56)	SENSOR TYPE (P. 57)	SW REV. AMPL. (P. 57)
VOLUME FLOW (P. 7)	UNIT VOL. FLOW (P. 8)	QUICK SETUP COMMISSION (P. 10)	LANGUAGE (P. 11)	ASSIGN LINE 1 (P. 13)	ASSIGN TOTALIZER (P. 16)	RESET ALL TOTAL. (P. 18)	ASSIGN CURRENT OUTP. (P. 19)	OPERATION MODE (P. 23)	VALUE SIM. FREQ. (P. 28)	ASSIGN STATUS (P. 34)	ASSIGN STATUS (P. 40)	TAG NAME (P. 42)	ASSIGN LF CUT OFF (P. 43)	INSTALL. DIRECT. (P. 49)	CALIBRATION DATE (P. 52)	CURR. SYS. COND. (P. 54)	SIM. FAILS. MODE (P. 56)	SERIAL NUMBER (P. 57)	DEVICE SOFTWARE (P. 57)
MEASURING VALUES (P. 7)	SYSTEM UNITS (P. 8)	QUICK SETUP (P. 10)	OPERATION (P. 11)	USER INTERFACE (P. 13)	TOTALIZER 1/2 (P. 16)	HANDLING TOTALIZ. (P. 18)	CURRENT OUTPUT (P. 19)	PULSE/FREO. OUTP. (P. 23)		STATUS OUTPUT (P. 34)	STATUS INPUT (P. 40)	COMMUNICATION (P. 42)	PROCESS PARAM. (P. 43)	SYSTEM PARAM. (P. 49)	SENSOR DATA (P. 52)	SUPERVISION (P. 54)	SIMULAT. SYSTEM (P. 56)	SENSOR VERSION (P. 57)	AMPLIFIER VERS. (P. 57)

2 Group MEASURING VALUES

Function description MEASURING VALUES Note! • The engineering unit of the measured variable displayed here can be set in the SYSTEM UNITS group, (see Page 8). ■ If the fluid in the pipe flows backwards, a negative sign prefixes the flow reading on the display. **VOLUME FLOW** The volume flow currently measured appears on the display. User interface: 5-digit floating-point number, including unit and sign (e.g. $5.5445 \text{ dm}^3/\text{min}$; $1.4359 \text{ m}^3/\text{h}$; -731.63 gal/d; etc.)

3 Group SYSTEM UNITS

Function description SYSTEM UNITS

Use this function group to select the unit for the measured variable.

UNIT VOLUME FLOW

Use this function to select the unit for displaying the volume flow.

The unit you select here is also valid for:

- Current output
- Frequency output
- Switch points (limit value for volume flow, flow direction)
- Low flow

Options:

Metric:

Cubic centimeter \rightarrow cm³/s; cm³/min; cm³/h; cm³/day Cubic decimeter \rightarrow dm³/s; dm³/min; dm³/h; dm³/day Cubic meter \rightarrow m³/s; m³/min; m³/h; m³/day Milliliter \rightarrow ml/s; ml/min; ml/h; ml/day Liter \rightarrow l/s; l/min; l/h; l/day Hectoliter \rightarrow hl/s; hl/min; hl/h; hl/day Megaliter \rightarrow Ml/s; Ml/min; Ml/h; Ml/day

Cubic centimeter \rightarrow cc/s; cc/min; cc/h; cc/day

115.

Acre foot \rightarrow af/s; af/min; af/h; af/day Cubic foot \rightarrow ft³/s; ft³/min; ft³/h; ft³/day Fluid ounce \rightarrow oz f/s; oz f/min; oz f/h; oz f/day Gallon \rightarrow gal/s; gal/min; gal/h; gal/day Kilo gallon \rightarrow Kgal/s; Kgal/min; Kgal/h; Kgal/day Million gallon \rightarrow Mgal/s; Mgal/min; Mgal/h; Mgal/day Barrel (normal fluids: 31.5 gal/bbl) \rightarrow bbl/s; bbl/min; bbl/h; bbl/day Barrel (beer: 31.0 gal/bbl) \rightarrow bbl/s; bbl/min; bbl/h; bbl/day Barrel (petrochemicals: 42.0 gal/bbl) \rightarrow bbl/s; bbl/min; bbl/h; bbl/day Barrel (filling tanks: 55.0 gal/bbl) \rightarrow bbl/s; bbl/min; bbl/h; bbl/day

Imperial:

Gallon \rightarrow gal/s; gal/min; gal/h; gal/day Mega gallon \rightarrow Mgal/s; Mgal/min; Mgal/h; Mgal/day Barrel (beer: 36.0 gal/bbl) \rightarrow bbl/s; bbl/min; bbl/h; bbl/day Barrel (petrochemicals: 34.97 gal/bbl) \rightarrow bbl/s; bbl/min; bbl/h; bbl/day

Factory setting:

Depends on nominal diameter and country (see Page 58 ff.).

UNIT VOLUME

Use this function to select the unit for displaying the volume.

The unit you select here is also valid for:

■ Pulse weighting (e.g. m³/p)

Options:

Metric \rightarrow cm³; dm³; m³; ml; l; hl; Ml Mega US \rightarrow cc; af; ft³; oz f; gal; Kgal; Mgal; bbl (normal fluids); bbl (beer); bbl (petrochemicals) \rightarrow bbl (filling tanks) Imperial \rightarrow gal; Mgal; bbl (beer); bbl (petrochemicals)

Factory setting:

Depends on nominal diameter and country (see Page 58 ff.).



The unit of the totalizers is independent of your choice here. The unit for each totalizer is selected separately for the totalizer in question.

Function description SYSTEM UNITS					
UNIT LENGTH	Use this function to select the unit for displaying the length of the nominal diameter.				
	The unit you select here is also valid for: Nominal diameter of sensor (see function NOMINAL DIAMETER on Page 48)				
	Options: MILLIMETER INCH				
	Factory setting: MILLIMETER (SI units: not for USA and Canada) INCH (US units: only for USA and Canada)				
FORMAT DATE/TIME	Use this function to select the format for the date and the time.				
	The unit you select here is also valid for: Displaying the current calibration date (function CALIBRATION DATE on Seite 52)				
	Options: DD.MM.YY 24H MM/DD/YY 12H A/P DD.MM.YY 12H A/P MM/DD/YY 24H				
	Factory setting: DD.MM.YY 24H (SI units) MM/DD/YY 12H A/P (US units)				


4 Group QUICK SETUP

Function description QUICK SETUP					
QUICK SETUP COMMISSION	Use this function to start the Quick Setup menu for commissioning.				
	Options: YES				
	NO				
	Factory setting:				
	NO				



Note!

The display returns to the QUICK SETUP COMMISSION cell if you press the ESC key combination during interrogation.



a0005413-en

10

5 Group OPERATION

Function description OPERATION LANGUAGE Use this function to select the language for all texts, parameters and messages shown on the local display. Note! The displayed options depend on the available language group shown in the LANGUAGE GROUP function. Options: Language group WEST EU / USA: **ENGLISH DEUTSCH FRANCAIS ESPANOL** ITALIANO **NEDERLANDS PORTUGUESE** Language group EAST EU / SCAND: **ENGLISH** NORSK SVENSKA SUOMI POLISH RUSSIAN CZECH Language group ASIA: **ENGLISH** BAHASA INDONESIA JAPANESE (Silbenschrift) Factory setting: Country-dependent (see Page 58 ff.) Note! ■ If you press the 🕒 keys simultaneously at startup, the language defaults to $\,\blacksquare\,$ You can change the language group via the configuration program FieldCare. Please do not hesitate to contact your Endress+Hauser sales office if you have any questions.

Function description OPERATION		
ACCESS CODE	All data of the measuring system are protected against inadvertent change. Programming is disabled and the settings cannot be changed until a code is entered in this function. If you press the 🔭 keys in any function, the measuring system automatically goes to this function and the prompt to enter the code appears on the display (when programming is disabled).	
	You can enable programming by entering your personal code, (factory setting = 50, see function PRIVATE CODE on Page 12)	
	User input: max. 4-digit number: 09999	
	 Note! The programming levels are disabled if you do not press a key within 60 seconds following automatic return to the HOME position. You can also disable programming in this function by entering any number (other than the defined private code). The Endress-Hauser service organization can be of assistance if you mislay your personal code. 	
PRIVATE CODE	Use this function to enter a personal code number for enabling programming.	
	User input: 09999 (max. 4-digit number)	
	Factory setting: 50	
	 Note! Programming is always enabled with the code "0". Programming has to be enabled before this code can be changed. When programming is disabled this function is not available, thus preventing others from accessing your personal code. 	
STATUS ACCESS	Use this function to check the access status for the function matrix.	
	User interface: ACCESS CUSTOMER (parameterization possible) LOCKED (parameterization disabled)	
ACCESS CODE COUNTER	Displays how often the customer code, service code or the digit "0" (code-free) has been entered to gain access to the function matrix.	
	Display: max. 7-digit number: 09999999	
	Factory setting:	

6 Group USER INTERFACE

Function description USER INTERFACE		
ASSIGN LINE 1	Use this function to define which display value is assigned to the main line (top line of the local display) for display during normal measuring operation. Options: OFF VOLUME FLOW VOLUME FLOW IN % TOTALIZER 1	
	TOTALIZER 2 Factory setting: VOLUME FLOW	
ASSIGN LINE 2	Use this function to define which display value is assigned to the additional line (bottom line of the local display) for display during normal measuring operation. Options: OFF VOLUME FLOW VOLUME FLOW IN % VOLUME FLOW BARGRAPH IN % TOTALIZER 1 TAG NAME OPERATING/SYSTEM CONDITION FLOW DIRECTION TOTALIZER 2 Factory setting: TOTALIZER 1	
100% VALUE	This function is only available if VOLUME FLOW IN % or VOLUME FLOW BARGRAPH IN % was selected in the function ASSIGN LINE 1 or ASSIGN LINE 2. Use this function to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: Depends on nominal diameter and country (see Page 58 ff.).	

	Function description USER INTERFACE		
FORMAT	Use this function to define the maximum number of places after the decimal point displayed for the reading in the main line.		
	Options: XXXXX. – XXXX.X – XXX.XX – XX.XXX		
	Factory setting: X.XXXX		
	 Note! Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → 1/h), indicating that the measuring system is computing with more decimal places than can be shown on the display. 		
DISPLAY DAMPING	Use this function to enter a time constant defining how the display reacts to severely fluctuating flow variables, either very quickly (enter a low time constant) or with damping (enter a high time constant).		
	User input: 0100 seconds		
	Factory setting: 3 s		
	Note! Setting the time constant to zero seconds switches off damping.		
CONTRAST LCD	Use this function to optimize display contrast to suit local operating conditions.		
	User input: 10100%		
	Factory setting: 50%		

	Function description USER INTERFACE
BACKLIGHT	Use this function to optimize the backlight to suit local operating conditions.
	User input: 0100%
	Note! Entering the value "0" means that the backlight is "switched off". The display then no longer emits any light, i.e. the display texts can no longer be read in the dark.
	Factory setting: 50%
DISPLAY TEST	Use this function to test the operability of the local display and its pixels.
	Options: OFF ON
	Factory setting:
	OFF
	Test sequence: 1. Start the test by selecting ON.
	2. All pixels of the main line and additional line are darkened for at least 0.75 seconds.
	3. The main line and additional line show an "8" in each field for at least 0.75 seconds.
	4. The main line and additional line show a "0" in each field for at least 0.75 seconds.
	5. The main line and additional line show nothing (blank display) for at least 0.75 seconds.
	When the test completes the local display returns to its initial state and the setting changes to OFF.

7 Group TOTALIZER 1/2

Function description TOTALIZER 1/2			
ASSIGN TOTALIZER	Use this function to assign a measured variable (volume flow) to the totalizer.		
	Options: OFF VOLUME FLOW Factory setting: VOLUME FLOW Note! The totalizer is reset to "0" as soon as the selection is changed.		
SUM	Use this function to view the total for the totalizer measured variable aggregated since measuring commenced. The value can be positive or negative.		
	User interface: max. 7-digit floating-point number, including sign and unit (e.g. 896,845.7 dm ³) Note! The totalizer response to faults is defined in the FAILSAFE MODE function (see Page 18).		
OVERFLOW	Use this function to view the overflow for the totalizer aggregated since measuring commenced.		
	Total flow quantity is represented by a floating decimal point number consisting of max. 7 digits. You can use this function to view higher numerical values (>9 999 999) as overflows. The effective quantity is thus the total of OVERFLOW plus the value returned by the SUM function.		
	Example: Reading for 2 overflows: 2 E7 kg (= $2~000~000~dm^3$) The value returned by the SUM function = $896,845.7~dm^3$ Effective total quantity = $2,896,845.7~dm^3$		
	Display shows: Integer with exponent, including sign and unit, e.g. 2 E7 dm ³		
UNIT TOTALIZER	Use this function to define the unit for the totalizer.		
	Options: Metric \rightarrow cm ³ ; dm ³ ; ml; l; hl; Ml Mega		
	US \rightarrow cc; af; ft ³ ; oz f; gal; Kgal; Mgal; bbl (normal fluids); bbl (beer); bbl (petrochemicals); bbl (filling tanks)		
	Imperial \rightarrow gal; Mgal; bbl (beer); bbl (petrochemicals)		
	Factory setting: Depends on nominal diameter and country (see Page 58 ff.).		

16

Use this function to define how the flow components are to be totalized. Options: BALANCE Positive and negative flow components. The positive and negative flow components are balanced. In other words, net flow in the flow direction is registered. FORWARD Positive flow components only REVERSE Negative flow components only Factory setting: Totalizer I = BALANCE Totalizer 2 = FORWARD RESET TOTALIZER Use this function to reset the sum and the overflow of the totalizer to "zero" (= RESET). Options: NO YES Factory setting: NO Note! If the device is equipped with a status input and if it is appropriately configured, totalizer resetting can also be triggered by a pulse.		Function description TOTALIZER 1/2
Positive and negative flow components. The positive and negative flow components are balanced. In other words, net flow in the flow direction is registered. FORWARD Positive flow components only REVERSE Negative flow components only Factory setting: Totalizer 1 = BALANCE Totalizer 2 = FORWARD Use this function to reset the sum and the overflow of the totalizer to "zero" (= RESET). Options: NO YES Factory setting: NO YES Note! If the device is equipped with a status input and if it is appropriately configured, totalizer	TOTALIZER MODE	Options:
Positive flow components only REVERSE Negative flow components only Factory setting: Totalizer 1 = BALANCE Totalizer 2 = FORWARD Use this function to reset the sum and the overflow of the totalizer to "zero" (= RESET). Options: NO YES Factory setting: NO Note! If the device is equipped with a status input and if it is appropriately configured, totalizer		Positive and negative flow components. The positive and negative flow components are
RESET TOTALIZER Use this function to reset the sum and the overflow of the totalizer to "zero" (= RESET). Options: NO YES Factory setting: NO Note! If the device is equipped with a status input and if it is appropriately configured, totalizer		Positive flow components only
Totalizer 1 = BALANCE Totalizer 2 = FORWARD Use this function to reset the sum and the overflow of the totalizer to "zero" (= RESET). Options: NO YES Factory setting: NO Note! If the device is equipped with a status input and if it is appropriately configured, totalizer		Negative flow components only
Options: NO YES Factory setting: NO Note! If the device is equipped with a status input and if it is appropriately configured, totalizer		Totalizer 1 = BALANCE
NO YES Factory setting: NO Note! If the device is equipped with a status input and if it is appropriately configured, totalizer	RESET TOTALIZER	Use this function to reset the sum and the overflow of the totalizer to "zero" (= RESET).
NO Note! If the device is equipped with a status input and if it is appropriately configured, totalizer		NO
If the device is equipped with a status input and if it is appropriately configured, totalizer		
		If the device is equipped with a status input and if it is appropriately configured, totalizer

8 Group HANDLING TOTALIZER

	Function description HANDLING TOTALIZER
RESET ALL TOTALIZERS	Use this function to reset the totals (including all overflows) of the totalizers (12) to "zero". Options: NO YES Factory setting: NO Note! If the device has a status input and if it is appropriately configured, a reset for the totaliz (12) can also be triggered by a pulse (see the ASSIGN STATUS INPUT function on Page 31).
FAILSAFE MODE	Use this function to define the totalizer response in case of fault. Options: STOP The totalizer is paused until the fault is rectified. ACTUAL VALUE The totalizer continues to count on the basis of the current flow measuring value. The fault is ignored. HOLD VALUE The totalizer continues to count the flow that is based on the last valid flow measuring value (before the fault occurred). Factory setting: STOP

9 Group CURRENT OUTPUT

	Function description CURRENT OUTPUT
ASSIGN CURRENT OUT- PUT	Use this function to assign a measured variable to the current output.
roi	Options: OFF
	VOLUME FLOW
	Factory setting: VOLUME FLOW
	Note! If you select OFF, the only function shown in this group is the function (ASSIGN CURRENT OUTPUT).

Function description CURRENT OUTPUT

CURRENT SPAN

Use this function to define the current span. The selection specifies the operational range and the lower and upper signal on alarm. For the current output the option HART can be defined additionally.


Options:

- 0-20 mA
- 4-20 mA
- 4-20 mA HART
- 4-20 mA NAMUR
- 4-20 mA HART NAMUR
- 4-20 mA US
- 4-20 mA HART US
- 0-20 mA (25 mA)
- 4-20 mA (25 mA)
- 4-20 mA (25 mA) HART

Factory setting:

4-20 mA HART NAMUR

Current span, operational range and signal on alarm level



а	1	2	3
0-20 mA	0 - 20.5 mA	0	22
4-20 mA	4 - 20.5 mA	2	22
4-20 mA HART	4 - 20.5 mA	2	22
4-20 mA NAMUR	3.8 - 20.5 mA	3.5	22.6
4-20 mA HART NAMUR	3.8 - 20.5 mA	3.5	22.6
4-20 mA US	3.9 - 20.8 mA	3.75	22.6
4-20 mA HART US	3.9 - 20.8 mA	3.75	22.6
0-20 mA (25 mA)	0 - 24 mA	0	25
4-20 mA (25 mA)	4 - 24 mA	2	25
4-20 mA (25 mA) HART	4 - 24 mA	2	25

A0001222

- a = Current span
- 1 = Operational range (measuring information)
- 2 = Lower signal on alarm level
- 3 = Upper signal on alarm level



Note!

- When switching the hardware from an active (factory setting) to a passive output signal select a current span of 4-20 mA.
- $\,\blacksquare\,$ If the measured value exceeds the measuring range a notice message is generated (#351...354, current span).
- In case of a fault the behaviour of the current output is according to the selected option in the function FAILSAFE MODE (see Page 21). Change the error category in the function ASSIGN SYSTEM ERROR (see Page 54) to generate a fault message instead of a notice message.

20

	Function description CURRENT OUTPUT
VALUE 20 mA	Use this function to assign the 20 mA current a full scale value. Positive and negative values are permissible. The required measuring range is defined by defining the VALUE 20 mA. In the SYMMETRY measuring mode, (see Page 45), the value assigned applies to both flow directions; in the STANDARD measuring mode it applies only to the flow direction selected.
	User input: 5-digit floating-point number, with sign Factory setting:
	Depends on nominal diameter and country (see Page 58 ff.).
	 Note! The appropriate unit is taken from the group SYSTEM UNITS, (see Page 8). The value for 0 or 4 mA always corresponds to the zero flow (0 [unit]). This value is fixed and cannot be edited.
TIME CONSTANT	Use this function to enter a time constant defining how the current output signal reacts to severely fluctuating measured variables, either very quickly (enter a low time constant) or with damping (enter a high time constant).
	User input: fixed-point number 0.01100.00 s
	Factory setting: 3.00 s
FAILSAFE MODE	For safety reasons it is advisable to ensure that the current output assumes a predefined state in the event of a fault. The setting you select here affects only the current output. The failsafe mode of other outputs and the totalizers is defined in the corresponding function groups.
	Options: MIN. CURRENT The current output adopts the value of the lower signal on alarm level (as defined in the function CURRENT SPAN).
	MAX. CURRENT The current output adopts the value of the upper signal on alarm level (as defined in the function CURRENT SPAN).
	HOLD VALUE (not recommended) Measuring value output is based on the last measuring value saved before the error occurred .
	ACTUAL VALUE Measured value output is based on the current flow measurement. The fault is ignored.
	Factory setting: MIN. CURRENT
ACTUAL CURRENT	Use this function to view the computed actual value of the output current.
	User interface: 0.0025.00 mA

Function description CURRENT OUTPUT SIMULATION CURRENT Use this function to activate simulation of the current output. Options: OFF ON Factory setting: OFF Note! ■ The "SIMULATION CURRENT OUTPUT" notice message indicates that simulation is ■ The measuring device continues to measure while simulation is in progress, i.e. the current measuring values are output correctly via the other outputs. Caution! The setting is not saved if the power supply fails. **VALUE SIMULATION** Note! **CURRENT** This function is not available unless the function SIMULATION CURRENT is active (= ON). Use this function to define a selectable value (e.g. 12 mA) to be output at the current output. This value is used to test downstream devices and the measuring device itself. User input: Floating-point number: 0.00...25.00 mA Factory setting: 0.00 mA Caution! The setting is not saved if the power supply fails.

10 Group PULSE/FREQUENCY OUTPUT

Function description PULSE/FREQUENCY OUTPUT		
This group is not available unless the measuring device is equipped with a pulse/frequency output.		
OPERATION MODE	Use this function to configure the output as a pulse output or frequency output. The functions available in this function group vary, depending on which option you select here. Options: PULSE FREQUENCY Factory setting: PULSE	
ASSIGN FREQUENCY	Note! This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE. Use this function to assign a measured variable to the frequency output. Options: OFF VOLUME FLOW Factory setting: VOLUME FLOW Note! If you select OFF, the only functions shown in this function group are the functions ASSIGN FREQUENCY and OPERATION MODE.	
END VALUE FREQ.	Note! This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE. Use this function to define a full scale frequency for the frequency output. You define the associated measured value of the measuring range in the function VALUE-f HIGH on Page 24. User input: 4-digit fixed-point number 21250 Hz Factory setting: 1000 Hz Example: VALUE-f HIGH = 1000 l/h, end frequency = 1000 Hz: i.e. at a flow of 1000 l/h, a frequency of 1000 Hz is output. VALUE-f HIGH = 3600 l/h, end frequency = 1000 Hz: i.e. at a flow of 3600 l/h, a frequency of 1000 Hz is output. Note! In the FREQUENCY operating mode the output signal is symmetrical (on/off ratio = 1:1). At low frequencies the pulse duration is limited to a maximum of 2 seconds, i.e. the on/off ratio is no longer symmetrical. The initial frequency is always 0 Hz. This value is fixed and cannot be edited.	

VALUE-f HIGH



This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE.

Use this function to assign a value to the end value frequency.


Positive and negative values are permissible. The required measuring range is defined by defining the VALUE-f HIGH. In the SYMMETRY measuring mode, (see Page 45), the value assigned applies to both flow directions; in the STANDARD measuring mode it applies only to the flow direction selected.

User input:

5-digit floating-point number

Factory setting:

Depends on nominal diameter and country, [value] / [dm³...m³ or US-gal...US-Mgal] corresponds to the factory setting for the final value (see Page $58\ \text{ff.}$)



A0001279

1 = Value-f min.

2 = Value-f high



- \blacksquare The appropriate unit is taken from the group SYSTEM UNITS, (see Page 8).
- The value-f min. for the initial frequency always corresponds to the zero flow (0 [unit]). This value is fixed and cannot be edited.

OUTPUT SIGNAL



Function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function.

For selecting the output configuration of the frequency output.

Options:

PASSIVE - POSITIVE PASSIVE - NEGATIVE

Factory setting: PASSIVE - POSITIVE

Explanation

■ PASSIVE = power is supplied to the frequency output by means of an external power supply.

Configuring the output signal level (POSITIVE or NEGATIVE) determines the quiescent behaviour (at zero flow) of the frequency output.

The internal transistor is activated as follows:

- If POSITIVE is selected, the internal transistor is activated with a **positive** signal level.
- If NEGATIVE is selected, the internal transistor is activated with a **negative** signal level (0 V).




Note!

With the passive output configuration, the output signal levels of the frequency output depend on the external circuit (see examples).

Example for passive output circuit (PASSIVE)

If PASSIVE is selected, the frequency output is configured as an open collector.



A0001225

- ① = Open collector
- ② = External power supply




Note!

For continuous currents up to 25 mA (I_{max} = 250 mA / 20 ms).

Example for output configuration PASSIVE-POSITIVE:

Output configuration with an external pull-up resistance.


In the quiescent state (at zero flow), the output signal level at the terminals is 0 V.



A0004687

- ① = Open collector
- 2 = Pull-up resistance
- ③ = Transistor activation in "POSITIVE" quiescent state (at zero flow)
- (4) = Output signal level in quiescent state (at zero flow)

In the operating status (flow present), the output signal level changes from 0 V to a positive voltage level.



A0001975

(continued on next page)


OUTPUT SIGNAL

(continued)

Example for output configuration PASSIVE-POSITIVE:

Output configuration with an external pull-down resistance.

In the quiescent state (at zero flow), a positive voltage level is measured via the $\operatorname{pull-down}$ resistance.



① = Open collector

A0004689

- ② = Pull-down resistance
- ③ = Transistor activation in "POSITIVE" quiescent state (at zero flow)
- (at zero flow)

In the operating status (flow present), the output signal level changes from a positive voltage level to 0 $\mbox{V}.$




A0001981

Example for output configuration PASSIVE-NEGATIVE:

Output configuration with an external pull-up resistance.


In the quiescent state (at zero flow), the output signal level at the terminals is at a positive voltage level.



A0004690

- ① = Open collector
- ② = Pull-up resistance
- @= Transistor activation in "NEGATIVE" quiescent state (at zero flow)
- 4 = Output signal level in quiescent state (at zero flow)

In the operating status (flow present), the output signal level changes from a positive voltage level to 0 $\ensuremath{\text{V}}.$



A0001981

Func	tion description PULSE/FREQUENCY OUTPUT
TIME CONSTANT	Note! This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE.
	Use this function to enter a time constant defining how the frequency output signal reacts to severely fluctuating measured variables, either very quickly (enter a low time constant) or with damping (enter a high time constant).
	User input: Floating-point number 0.00100.00 s
	Factory setting: 0.00 s
FAILSAFE MODE	Note! This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE.
	For safety reasons it is advisable to ensure that the frequency output assumes a predefined state in the event of a fault. Use this function to define this state. The setting you select here affects only the frequency output. It has no effect on other outputs and the display (e.g. totalizers).
	Options: FALLBACK VALUE Output is 0 Hz.
	FAILSAFE LEVEL Output is the frequency specified in the FAILSAFE VALUE function.
	HOLD VALUE Measuring value output is based on the last measuring value saved before the error occurred.
	ACTUAL VALUE Measuring value output is based on the current flow measurement. The fault is ignored.
	Factory setting: FALLBACK VALUE
FAILSAFE VALUE	Note! This function is not available unless FREQUENCY was selected in the OPERATION MODE function and FAILSAFE LEVEL was selected in the function FAILSAFE MODE.
	Use this function to define the frequency that the measuring device should output in the event of a fault.
	User input: max. 4-digit number: 01250 Hz
	Factory setting: 1250 Hz
ACTUAL FREQUENCY	Note! This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE.
	Use this function to view the computed value of the output frequency.
	User interface: 01250 Hz

Function description PULSE/FREQUENCY OUTPUT **SIMULATION FREQUENCY** This function is not available unless the FREQUENCY setting was selected in the function OPERATION MODE. Use this function to activate simulation of the frequency output. Options: OFF ON Factory setting: OFF Note! ■ The "SIMULATION FREQUENCY OUTPUT" notice message indicates that simulation $\,\blacksquare\,$ The measuring device continues to measure while simulation is in progress, i.e. the current measuring values are output correctly via the other outputs. Caution! The setting is not saved if the power supply fails. **VALUE SIMULATION** Note! **FREQUENCY** This function is not available unless FREQUENCY was selected in the OPERATION MODE function and the function VALUE SIMULATION FREQUENCY is active (= ON). Use this function to define a selectable frequency value (e.g. 500 Hz) to be output at the frequency output. This value is used to test downstream devices and the measuring device itself. User input: 0...1250 Hz Factory setting: 0 Hz Caution! The setting is not saved if the power supply fails. **ASSIGN PULSE** Note! This function is not available unless the PULSE setting was selected in the OPERATION MODE function. Use this function to assign a measured variable to the pulse output. **Options:** OFF VOLUME FLOW Factory setting: VOLUME FLOW Note! If you select OFF, the only functions shown in this function group are the functions ASSIGN PULSE and OPERATION MODE.

PULSE VALUE



This function is not available unless the PULSE setting was selected in the OPERATION MODE function.

Use this function to define the flow at which a pulse is triggered.

These pulses can be totalled by an external totalizer and in this way the total flow since measuring commenced can be registered.

User input:

5-digit floating-point number, [unit]

Factory setting:

Depends on nominal diameter and country (see Page 58 ff.).



Note!

The appropriate unit is taken from the group SYSTEM UNITS (see Page 8).

PULSE WIDTH



Note!

This function is not available unless the PULSE setting was selected in the $\ensuremath{\mathsf{OPERATION}}$ MODE function.

Use this function to enter the maximum pulse width of the output pulses.


User input:


0.5...2000 ms

Factory setting:

100 ms

Pulse output is **always** with the pulse width (B) entered in this function. The intervals (P) between the individual pulses are automatically configured. However, they must at least correspond to the pulse width (B = P).





B = Pulse width entered (the illustration applies to positive pulses) P= Intervals between the individual pulses



Note!

When entering the pulse width, select a value that can still be processed by an external totalizer (e.g. mechanical totalizer, PLC, etc.).



Caution!

If the pulse number or frequency resulting from the pulse value entered, (see function PULSE VALUE on Page 27), and from the current flowis too large to maintain the pulse width selected (interval P is smaller than the pulse width B entered), a system error message (pulse memory) is generated after buffering/balancing time.

OUTPUT SIGNAL



Function is not available unless the PULSE setting was selected in the OPERATION MODE function.

For selecting the output configuration of the pulse output.

PASSIVE - POSITIVE PASSIVE - NEGATIVE

Factory setting: PASSIVE - POSITIVE

Explanation

■ PASSIVE = power is supplied to the pulse output by means of an external power supply.

Configuring the output signal level (POSITIVE or NEGATIVE) determines the quiescent behaviour (at zero flow) of the pulse output.

The internal transistor is activated as follows:


- If POSITIVE is selected, the internal transistor is activated with a **positive** signal level.
- If NEGATIVE is selected, the internal transistor is activated with a **negative** signal level (0 V).



With the passive output configuration, the output signal levels of the pulse output $\[$ depend on the external circuit (see examples).

Example for passive output circuit (PASSIVE)

If PASSIVE is selected, the pulse output is configured as an open collector.



A0001225

1 = Open Collector

② = External power supply




Note!

For continuous currents up to 25 mA ($I_{max} = 250 \text{ mA} / 20 \text{ ms}$).

Example for output configuration PASSIVE-POSITIVE:

Output configuration with an external pull-up resistance.

In the quiescent state (at zero flow), the output signal level at the terminals is 0 V.



1 = Open Collector

② = Pull-Up-Resistance

③ = Transistor activation in "POSITIVE" quiescent state (at zero flow)

④ = Output signal level in quiescent state (at zero flow)

In the operating status (flow present), the output signal level changes from 0 V to a positive voltage level.




A0001975

(continued on next page)

OUTPUT SIGNAL (continued)

Example for output configuration PASSIVE-POSITIVE:

Output configuration with an external pull-down resistance. In the quiescent state (at zero flow), a positive voltage level is measured via the pull-down resistance.




① = Open Collector

② = Pull-Down-Resistance

③ = Transistor activation in "POSITIVE" quiescent state (at zero flow)

(at zero flow)

In the operating status (flow present), the output signal level changes from a positive voltage level to 0 $\ensuremath{\mathrm{V}}.$




A0001981

A0004689

Example for output configuration PASSIVE-NEGATIVE:

Output configuration with an external pull-up resistance. In the quiescent state (at zero flow), the output signal level at the terminals is at a positive voltage level.



A0004690

① = Open Collector

2 = Pull-Up-Resistance

③ = Transistor activation in "NEGATIVE" quiescent state (at zero flow)

④ = Output signal level in quiescent state (at zero flow)

In the operating status (flow present), the output signal level changes from a positive voltage level to 0 $\ensuremath{\text{V}}.$



A0001981

FAILSAFE MODE



This function is not available unless the PULSE setting was selected in the function OPERATION MODE.

For safety reasons it is advisable to ensure that the pulse output assumes a predefined state in the event of a fault. Use this function to define this state. The setting you select here affects only the pulse output. It has no effect on other outputs and the display (e.g. totalizers).

Options:

FALLBACK VALUE

Output is 0 pulse.

ACTUAL VALUE

Measuring value output is based on the current flow measurement. The fault is ignored.

Factory setting:

FALLBACK VALUE

SIMULATION PULSE



This function is not available unless the PULSE option was selected in the OPERATION MODE function.

Use this function to activate simulation of the pulse output.

Options:

OFF

COUNTDOWN

The pulses specified in the VALUE SIMULATION PULSE function are output.

CONTINUOUSLY

Pulses are continuously output with the pulse width specified in the PULSE WIDTH function. Simulation is started once the CONTINUOUSLY option is confirmed with the E key.



Note!

Simulation is started by confirming the CONTINUOUSLY option with the 🗉 key. The simulation can be switched off again via the SIMULATION PULSE function.

Factory setting:

OFF



- Note!
- The notice message #631 "SIM. PULSE" indicates that simulation is active.
- The on/off ratio is 1:1 for both types of simulation.
- The measuring device continues to measure while simulation is in progress, i.e. the current measured values are output correctly via the other outputs.



Caution!

The setting is not saved if the power supply fails.

VALUE SIMULATION PULSE



This function is not available unless the COUNTDOWN option was selected in the SIMULATION PULSE function.

Use this function to specify the number of pulses (e.g. 50) which are output during the simulation. This value is used to test downstream devices and the measuring device itself. The pulses are output with the pulse width specified in the PULSE WIDTH function. The on/off ratio is 1:1.

Simulation is started once the specified value is confirmed with the E key. The display remains at "0" if the specified pulses have been output.

User input:

0...10000

Factory setting:



Note!

Simulation is started by confirming the simulation value with the 🗉 key. The simulation can be switched off again via the SIMULATION PULSE function.



Caution!

The setting is not saved if the power supply fails.

11 **Group STATUS OUTPUT**

Function description STATUS OUTPUT

This group is not available unless the measuring device is equipped with a status output.

ASSIGN STATUS OUTPUT

Use this function to assign a switching function to the status output.

Options:

OFF

ON (operation) FAULT MESSAGE

NOTICE MESSAGE

FAULT MESSAGE or NOTICE MESSAGE

EPD or OED (Empty Pipe Detection / Open Electrode Detection, only if active)

FLOW DIRECTION

VOLUME FLOW LIMIT VALUE

Factory setting:

FAULT MESSAGE



Note!

- The behaviour of the status output is a normally closed behaviour, in other words the output is closed (transistor conductive) when normal, error-free measuring is in progress.
- It is very important to read and comply with the information on the switching characteristics of the status output, (see Page 34).
- If you select OFF, the only function shown in this function group is the function ASSIGN STATUS OUTPUT.

ON-VALUE



Note!

This function is not available unless LIMIT VALUE or FLOW DIRECTION was selected in the function ASSIGN STATUS OUTPUT.

Use this function to assign a value to the switch-on point (status output pulls up). The value can be equal to, greater than or less than the switch-off point. Positive and negative values are permissible.

User input:

5-digit floating-point number, [unit]

Factory setting:

0 [unit]



Note!

- \blacksquare The appropriate unit is taken from the group SYSTEM UNITS, (see Page 8).
- Only the switch-on point is available for flow direction output (no switch-off point). If you enter a value not equal to the zero flow (e.g. 5), the difference between the zero flow and the value entered corresponds to half the switchover hysteresis.

Function description STATUS OUTPUT		
	•	
OFF-VALUE	Note! This function is not available unless LIMIT VALUE was selected in the function ASSIGN STATUS OUTPUT.	
	Use this function to assign a value to the switch-off point (status output drops out). The value can be equal to, greater than or less than the switch-on point. Positive and negative values are permissible.	
	User input: 5-digit floating-point number, [unit]	
	Factory setting: 0 [unit]	
	 Note! The appropriate unit is taken from the group SYSTEM UNITS, (see Page 8). If SYMMETRY is selected in the function MEASURING MODE (Page 45) and values with different signs are entered for the switch-on and switch-off points, the notice message "INPUT RANGE EXCEEDED" appears. 	
TIME CONSTANT	Use this function to enter a time constant defining how the measuring signal reacts to severely fluctuating measured variables, either very quickly (enter a low time constant) or with damping (enter a high time constant). The purpose of damping, therefore, is to prevent the status output changing state continuously in response to fluctuations in flow.	
	User input: fixed-point number 0.00100.00 s	
	Factory setting: 0.00 s	
ACTUAL STATUS OUTPUT	Use this function to check the current status of the status output.	
	User interface: NOT CONDUCTIVE CONDUCTIVE	
SIMULATION SWITCH POINT	Use this function to activate simulation of the status output.	
TORVI	Options: OFF ON	
	Factory setting: OFF	
	Note! The "SIMULATION STATUS OUTPUT" message indicates that simulation is active. The measuring device continues to measure while simulation is in progress, i.e. the current measuring values are output correctly via the other outputs.	
	Caution! The setting is not saved if the power supply fails.	

Function description STATUS OUTPUT VALUE SIMULATION Note! **SWITCH POINT** This function is not available unless the function SIMULATION SWITCH POINT is active (= ON). Use this function to define the switching response of the status output during the simulation. This value is used to test downstream devices and the measuring device itself. Options: NOT CONDUCTIVE CONDUCTIVE Factory setting: NOT CONDUCTIVE Caution! The setting is not saved if the power supply fails.


11.1 Information on the response of the status output

General

If you have configured the status output for "LIMIT VALUE" or "FLOW DIRECTION", you can configure the requisite switch points in the functions ON-VALUE and OFF-VALUE. When the measured variable in question reaches these predefined values, the status output switches as shown in the illustrations below.

Status output configured for limit value

The status output switches as soon as the measured variable undershoots or overshoots a defined switch point. Application: Monitoring flow or process-related boundary conditions.





A0001235

- $A = Maximum safety \rightarrow ① SWITCH-OFF POINT > ② SWITCH-ON POINT$
- $B = Maximum safety \rightarrow ① SWITCH-OFF POINT < ② SWITCH-ON POINT$
- $C = Maximum safety \rightarrow \textcircled{1} SWITCH-OFF POINT = \textcircled{2} SWITCH-ON POINT (this configuration is to avoid)$
- ③ = Status output switched off (not conductive)

Status output configured for flow direction

The value entered in the function SWITCH–ON POINT defines the switch point for the positive and negative directions of flow. If, for example, the switch point entered is = $1 \text{ m}^3/\text{h}$, the status output switches off at $-1 \text{ m}^3/\text{h}$ (not conductive) and switches on again at $+1 \text{ m}^3/\text{h}$ (conductive). Set the switch point to 0 if your process calls for direct switchover (no switching hysteresis). If low flow cut off is used, it is advisable to set hysteresis to a value greater than or equal to the low flow rate.





A0001236

- a = Status output conductive
- b = Status output not conductive

11.2 Switching response of the status output

Function	Status			lector response ansistor)
ON (operation)	System in measuring mode	XXX.XXX.XX A0001052	conduc- tive	A0001237
	System not in measuring mode (power supply failed)	XXX XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX	not conduc- tive	A0001238
Fault message	System OK	XXX.XXX.XX Esc A0001052	conduc- tive	A0001237
	(System or process error) Fault → Error response of outputs/Inputs and totalizer	XXX.XXXX A0001291	not conduc- tive	A0001238
Notice message	System OK	XXX.XXX.XX Esc A0001052	conduc- tive	A0001237
	(System or process error) Fault → Continuation of measuring	XXX.X.K.XX A0001291	not conduc- tive	A0001238
Fault message or notice message	System OK	XXX.XXX.XX A0001052	conduc- tive	A0001237
	(System or process error) Fault → Response to error or Note → Continuation of measuring	XXX.XXXXX A0001291	not conduc- tive	A0001238
Empty pipe detection (EPD) / Open electrode detection (OED)	Measuring tube full	A0001292	conduc- tive	A0001237
	Measuring tube partially filled / empty measuring tube	A0001293	not conduc- tive	A0001238

Function	Status			llector response ransistor)
Flow direction	Forward	A0001241	conduc- tive	A0001237
	Reverse	A0001242	not conduc- tive	A0001238
Limit value Volume flow	Limit value not overshot or undershot	A0001243	conduc- tive	A0001237
	Limit value overshot or undershot	A0001244	not conduc- tive	A0001238

12 Group STATUS INPUT

Function description STATUS INPUT		
This group is not available unless the measuring device is equipped with a status input.		
ASSIGN STATUS INPUT	Use this function to assign a switching function to the status input. Options: OFF RESET TOTALIZER 1 POSITIVE ZERO RETURN RESET TOTALIZER 2 RESET ALL TOTALIZERS Factory setting: OFF Note! Positive zero return is active as long as the active level is available at the status input (continuous signal). All other assignments react to a change in level (pulse) at the status input.	
ACTIVE LEVEL	Use this function to define whether the assigned switch function, (see function ASSIGN STATUS INPUT) is released or sustained when the level is present (HIGH) or not present (LOW). Options: HIGH LOW Factory setting: HIGH	
MINIMUM PULSE WIDTH	Use this function to define a minimum pulse width which the input pulse must achieve in order to trigger the selected switching function. User input: 20100 ms Factory setting: 50 ms	
SIMULATION STATUS INPUT	Use this function to activate simulation of the status input, i.e. to trigger the function assigned to the status input, (see function ASSIGN STATUS INPUT on Page 31). Options: OFF ON Factory setting: OFF Note! The "SIMULATION STATUS INPUT" notice message indicates that simulation is active. The measuring device continues to measure while simulation is in progress, i.e. the current measuring values are output correctly via the outputs. Caution! The setting is not saved if the power supply fails.	

13 Group COMMUNICATION

	Function description COMMUNICATION
TAG NAME	Use this function to enter a tag name for the measuring device. You can edit and read this tag name at the local display or via the HART protocol.
	User input: max. 8-character text, permitted characters are: A–Z, 0–9, +, –, punctuation marks
	Factory setting: "" (no text)
TAG DESCRIPTION	Use this function to enter a tag description for the measuring device. You can edit and read this tag description at the local display or via the HART protocol.
	User input: max. 16-character text, permitted characters are: A–Z, 0–9, +, –, punctuation marks
	Factory setting: "" (No text)
BUS ADDRESS	Use this function to define the address for the exchange of data with the HART protocol.
	User input: 015
	Factory setting:
	Note! Addresses 115: a constant 4 mA current is applied.
HART PROTOCOL	Use this function to display if the HART protocol is active.
	User interface: OFF = HART protocol not active ON = HART protocol active
	Note! The HART protocol is activated by selecting 4–20 mA HART or 4–20 mA (25 mA) HART in the function CURRENT SPAN (see Page 20).
MANUFACTURER ID	Use this function to view the manufacturer.
	User interface: - Endress+Hauser - 17 (≅ 11 hex) for Endress+Hauser
DEVICE ID	Use this function to view the device ID in hexadecimal numerical format.
	User interface: 41 (≅ 65 dez) for Promag 50
DEVICE REVISION	Use this function to view the device–specific revision of the HART command interface.
	User interface: E.g.: 5

14 Group PROCESS PARAMETER

F	Function description PROCESS PARAMETER
ASSIGN LOW FLOW CUT	Use this function to assign the switch point for low flow cut off.
	Options:
	OFF VOLUME FLOW
	Factory setting: VOLUME FLOW
ON-VALUE LOW FLOW CUT OFF	Use this function to enter the switch-on point for low flow cut off.
001 011	Low flow cut off is active if the value entered is not equal to 0. The sign of the flow value is highlighted on the display to indicate that low flow cut off is active.
	User input: 5-digit floating-point number, [unit]
	Factory setting: Depends on nominal diameter and country (see Page 58 ff.).
	Note! The appropriate unit is taken from the group SYSTEM UNITS (see Page 8).
OFF-VALUE LOW FLOW CUT OFF	Use this function to enter the switch-off point for low flow cut off. Enter the switch-off point as a positive hysteresis value from the switch-on point.
	User input: Integer 0100%
	Factory setting: 50%
	Q ① = switch-on point, ② = switch-off point $a = Low flow cut off is switched on$ $b = Low flow cut off is switched off (a + a \cdot H)$ $H = Hysteresis value: 0 to 100%$ ■ = Low flow cut off active $Q = Flow$

Function description PROCESS PARAMETER

EMPTY PIPE DETECTION (EPD)

Flow cannot be measured correctly unless the measuring tube is full. This status can be monitored at all times with the Empty Pipe Detection function. Use this function to activate Empty Pipe Detection (EPD) or Open Electrode Detection (OED).

- EPD = Empty Pipe Detection (with the help of an EPD electrode)
- OED = Open Electrode Detection (empty pipe detection with the help of the measuring electrodes, if the sensor is not equipped with an EPD electrode or the orientation is not suitable for using EPD).

Options:

OFF - ON SPECIAL - OED - ON STANDARD

OFF (neither EPD nor OED are active)

ON SPECIAL (only for DN <400):

Switching on the Empty Pipe Detection (EPD) for devices in remote version (transmitter and sensor are installed separately).

OED:

Switching on the Open Electrode Detection (OED).

ON STANDARD:

Switching on the Empty Pipe Detection (EPD) for:

- Devices in compact version (transmitter and sensor form a single mechanical unit).
- Applications where a facing and coating of the fluid on the measuring tube line and measuring electrode accrues.

Factory setting:

OFF



- The options ON STANDARD and ON SPECIAL are not available unless the sensor is equipped with an EPD electrode.
- The default setting for the EPD/OED functions when the device is delivered is OFF. The functions must be activated as required.
- \blacksquare The devices are calibrated at the factory with water (approx. 500 $\mu\text{S/cm}$). If the conductivity of certain fluids deviates from this reference, empty pipe/full pipe adjustment must be performed again on site (see function EPD/OED ADJUSTMENT on page 46).
- The adjustment coefficients must be valid before you can switch on the EPD or OED. If these coefficients are not available, the function EPD/OED ADJUSTMENT is displayed (see Page 44).
- If there are problems with the adjustment, the following error messages appear on the
 - ADJUSTMENT FULL = EMPTY:

The adjustment values for empty pipe and full pipe are identical. In such instances, empty pipe adjustment/full pipe adjustment must be carried out again.

ADJUSTMENT NOT OK:

Adjustment is not possible as the fluid conductivity values are outside the permitted

(continued on next page)

Function description PROCESS PARAMETER

EMPTY PIPE DETECTION (EPD) (continued)

Notes on empty pipe detection (EPD and OED)

- Flow cannot be measured correctly unless the measuring pipe is completely full. This status can be monitored at all times by means of the EPD/OED.
- An empty or partially filled pipe is a process error. A default factory setting defines that
 a fault message is issued and that this process error has an effect on the outputs.
- The EPD/OED process error can be output via the configurable status output.
- Use the function ASSIGN PROCESS ERROR to define whether a notice or fault message should be triggered (see Page 54).
- A plausibility check of the adjustment values will only be executed by activating the empty pipe detection. If an empty or full pipe adjustment is performed during the empty pipe detection is active, the empty pipe detection has to be de- and again activated, after finishing the adjustment, to start the plausibility check.

Response to partially filled pipes

If the EPD/OED is switched on and responds to a partially filled or empty pipe, the fault message "EMPTY PIPE" appears on the display. If the pipe is partially empty and the EPD/OED is ${\bf not}$ switched on, the response can vary in identically configured systems:

- Flow reading fluctuates
- Zero flow
- Excessively high flow values

Notes on Open Electrode Detection (OED)

Open Electrode Detection (OED) functions like the Empty Pipe Detection (EPD). In contrast to the EPD where the measuring device must be equipped with a separate (optional) electrode, the OED detects partial filling by means of the two measuring electrodes which are present as standard (fluid no longer covers the measuring electrodes).

Open electrode detection can also be used if:

- the sensor is not installed in the optimal position for using EPD (optimal = installed horizontally).
- the sensor is not equipped with an additional (optional) EPD electrode.



■ Cable connection length:

When mounting a remote version, please observe the maximum permissible cable length of 15 metres in order to keep the OED function.

■ OED empty pipe adjustment:

To achieve the best results for the open electrode detection, it is important to have the electrodes surface as dry as possible (no liquid film) while the empty-pipe adjustment is being made.

Even during normal operation, the OED function is only secured if there is no longer any liquid film present on the electrodes when the measuring pipe is empty.

Function description PROCESS PARAMETER

EPD/OED ADJUSTMENT

Use this function to activate the $\ensuremath{\mathsf{EPD/OED}}$ adjustment for an empty or full measuring tube.



Note!

A detailed description and other helpful hints for the empty-pipe/full-pipe adjustment procedure can be found on Page 44.

Options:

OFF FULL PIPE ADJUST EMPTY PIPE ADJUST OED FULL ADJUST OED EMPTY ADJUST

Factory setting:

OFF

Procedure for EPD or OED empty-pipe / full-pipe adjustment

- Empty the piping. In case of an EPD adjustment, the wall of the measuring tube should be wetted with fluid for the adjustment procedure but this is not the case with an OED adjustment!
- 2. Start empty-pipe adjustment: Select "EMPTY PIPE ADJUST" or "OED EMPTY ADJUST" and press to confirm.
- 3. After empty-pipe adjustment, fill the piping with fluid.
- 4. Start full-pipe adjustment: Select "FULL PIPE ADJUST" or "OED FULL ADJUST" and press ₤ to confirm.
- 5. Having completed the adjustment, select the setting "OFF" and exit the function by pressing $\[\]$
- 6. Now select the "EMPTY PIPE DETECTION" function. Switch on Empty Pipe Detection by selecting the following settings:
 - EPD \rightarrow Select ON STANDARD or ON SPECIAL and press $^{\blacksquare}$ to confirm.
 - OED ightarrow Select OED and confirm with ${\ensuremath{\,^{ar{ar{ar}}}}}$.



Caution!

The adjustment coefficients must be valid before you can activate the EPD/OED function. If adjustment is incorrect the following messages might appear on the display:

– FULL = EMPTY

The adjustment values for empty pipe and full pipe are identical. In cases of this nature you **must** repeat empty-pipe or full-pipe adjustment **again!**

- ADJUSTMENT NOT OK

Adjustment is not possible because the fluid's conductivity is out of range.

Function description PROCESS PARAMETER This function is not available unless ON STANDARD, ON SPECIAL or OED was selected in the EMPTY PIPE DETECTION function. Use this function to enter the time span for which the criteria for an "empty" pipe have to be satisfied without interruption before a notice message or fault message is generated. The setting defined here is used by the active empty pipe detection (EPD) or open electrode detection (OED).

User input:

fixed-point number 1.0...100 s

Factory setting:

1.0 s



Note!

OED detection time:

The recognition of open electrodes is, in contrast to the empty pipe detection (EPD), very slow reacting (delay at least 25 seconds) and is only activated after an aditional delay from the programmed response time!

We recommend in most applications to use the empty pipe detection (EPD) which is an optimal solution for detecting partly filled measuring tubes.

ECC

EPD/OED RESPONSE

TIME



This function is not available unless the measuring device is equipped with the optional electrode cleaning function (ECC).

Use this function to activate cyclical electrode cleaning.

Options:

OFF ON

Factory setting:

ON (only if the optional electrode cleaning function ECC is available)

Notes on electrode cleaning (ECC)

Conductive deposits on the electrodes and on the walls of the measuring tube (e.g. magnetite) can falsify measurement values. The Electrode Cleaning Circuitry (ECC) was developed to prevent such conductive deposits accreting in the vicinity of the electrodes. ECC functions as described above for all available electrode materials except tantalum. If tantalum is used as the electrode material, the ECC protects the electrode surface only against oxidation.



Caution!

If the ECC is switched off for a prolonged period in applications with conductive deposits, a layer forms inside the measuring tube and this can falsify measurement values. If the layer is allowed to accrete beyond a certain level, it might no longer be possible to remove it by switching on the ECC. If this happens the measuring tube must be cleaned and the layer removed.

ECC DURATION



Note!

This function is not available unless the measuring device is equipped with the optional electrode cleaning function (ECC).

Use this function to specify the electrode cleaning duration.

User input:

fixed-point number 0.01...30.0 s

Factory setting:

 $2.0 \, s$

Function description PROCESS PARAMETER

ECC RECOVERY TIME



This function is not available unless the measuring device is equipped with the optional electrode cleaning function (ECC).

Use this function to specify the recovery time for which the last flow value measured prior to cleaning is retained. A recovery time is necessary as the signal outputs can fluctuate after electrode cleaning on account of electrochemical interference voltages.

User input:

max. 3-digit number: 1... 600 s

Factory setting:



Caution!

The last value measured prior to cleaning is output for the duration of the recovery time (max. 600 s). This in turn means that the measuring system does not register changes in flow, e.g. stoppage, during this time span.

ECC CLEANING CYCLE



This function is not available unless the measuring device is equipped with the optional electrode cleaning function (ECC).

Use this function to specify the cleaning cycle for electrode cleaning.

User input:

Integer: 30...10080 min

Factory setting:

40 min

15 Group SYSTEM PARAMETERS

Function description SYSTEM PARAMETERS

INSTALLATION DIRECTION SENSOR

Use this function to reverse the sign of the flow quantity, if necessary.

Options:

NORMAL (flow as indicated by the arrow)

INVERSE (flow opposite to direction indicated by the arrow)

Factory setting:

NORMAL



Ascertain the actual direction of fluid flow with reference to the direction indicated by the arrow on the sensor (nameplate).

MEASURING MODE

Use this function to select the measuring mode for all outputs.

Options:

STANDARD SYMMETRY

Factory setting:

STANDARD


The responses of the individual outputs in each of the measuring modes are described in detail on the following pages:

Current output and frequency output

STANDARD

Only the flow components for the selected flow direction are totalled, (positive or negative full scale value @= flow direction). Flow components in the opposite direction are not taken into account (suppression).

Example for current output:



A0001248


SYMMETRY

The output signals of the current and frequency outputs are independent of the direction of flow (absolute amount of the measured variable).

The "VALUE 20 mA" or "VALUE-f HIGH" \cite{Migma} (e.g. backflow) corresponds to the mirrored VALUE 20 mA or VALUE-f HIGH \cite{Migma} (e.g. flow).

Positive and negative flow components are taken into account.

Example for current output:



A0001249



Note

The direction of flow can be output via the configurable status output.

(continued on next page)

Function description SYSTEM PARAMETERS

MEASURING MODE

(continued)

Pulse output

STANDARD

Only positive flow components are totalled. Negative components are not taken into account.

SYMMETRY

Positive and negative flow components are taken into account.



Note!

The direction of flow can be output via the configurable status output.

Status output



The information is only applicable if LIMIT VALUE was selected in the function ASSIGN STATUS OUTPUT.

STANDARD

The status output signal switches at the defined switch points.


The status output signal switches at the defined switch points, irrespective of the sign. In other words, if you define a switch point with a positive sign, the status output signal switches as soon as the value is reached in the negative direction (negative sign), (see illustration).

Example for the SYMMETRY measuring mode:

Switch-on point: Q = 4Switch-off point: Q = 10

① = Status output switched on (conductive)

2 = Status output switched off (not conductive)



A0001247

POSITIVE ZERO RETURN

Use this function to interrupt evaluation of measured variables.

This is necessary when a piping system is being cleaned, for example.

This setting acts on all function and outputs of the measuring device.

Options:

 $ON \longrightarrow Signal$ output is set to the "ZERO FLOW" value.

Factory setting:

OFF

50

Function description SYSTEM PARAMETERS SYSTEM DAMPING Use this function to set the filter depth of the digital filter. This reduces the sensitivity of the measuring signal to interference peaks (e.g. high solids content, gas bubbles in the fluid, etc.). The system reaction time decreases with an increasing filter setting. User input: 0...15 Factory setting: Note! The system damping acts on all functions and outputs of the measuring device. INTEGRATION TIME Use this function to set the integration time. Under normal circumstances it is not necessary to change the factory settings. User input: 3.3...65 ms Factory setting: 20 ms at 50 Hz \rightarrow mains frequency (e.g. Europe) 16.7 ms at 60 Hz \rightarrow mains frequency (e.g. USA) Caution! The integration time must not be selected with a greater value than the measuring period (see Page 53). Note! The integration time defines the duration of internal totaling of the induced voltage in the fluid (measured by the measuring electrode), i.e. the time in which the measuring device records the true flow (afterwards the magnetic field for the next integration is created from the opposite pole).

16 Group SENSOR DATA

Function description SENSOR DATA

All sensor data (calibration factors, zero point and nominal diameter etc.) are set at the factory and saved on the S-DAT sensor memory chip.



Caution!

Under normal circumstances you should not change the following parameter settings, because changes affect numerous functions of the entire measuring facility in general and the accuracy of the measuring system in particular. For this reason, the functions described below cannot be changed even when you enter your personal code.

Contact the Endress+Hauser service organization if you have any questions about these functions.

CALIBRATION DATE	Use this function to view the current calibration date and time for the sensor.
	User interface: Calibration date and time
	Factory setting: Calibration date and time of the current calibration.
	$\ \ \ \ $ Note! The calibration date and time format is defined in the FORMAT DATE TIME function, \rightarrow Page 9.
K-FACTOR	Use this function to display the current calibration factor for the sensor. The calibration factor is determined and set at the factory.
	User interface: 5-digit fixed-point number: 0.50002.0000
	Factory setting: Depends on nominal diameter and calibration
	Note! This value is also provided on the sensor nameplate.
ZERO POINT	This function shows the current zero-point correction value for the sensor. Zero-point correction is determined and set at the factory.
	User interface: max. 4-digit number: -1000+1000
	Factory setting: Depends on nominal diameter and calibration
	Note! This value is also provided on the sensor nameplate.
NOMINAL DIAMETER	This function shows the nominal diameter for the sensor. The nominal diameter depends on the size of the sensor and is set at the factory.
	User interface: 22000 mm or 1/1278"
	Factory setting: Depends on the size of the sensor
	Note! This value is also provided on the sensor nameplate.

	Function description SENSOR DATA
MEASURING PERIOD	Use this function to set the time for a full measuring period. The duration of the measuring period is calculated from the rise time of the magnetic field, the brief recovery time, the integration time (which can be set) and the empty pipe detection time. User input: 0.01000 ms Factory setting: Depends on nominal diameter
	Note! The system checks the time entered and sets the measuring period which is actually used internally to a plausible value. If you enter 0 ms, the system automatically computes the shortest time.
OVERVOLTAGE TIME	Use this function to specify the time in which overvoltage is applied to the coil circuit in order to build up the magnetic field as fast as possible. The overvoltage time is adjusted automatically while measuring is in progress. The overvoltage time depends on the sensor type and the nominal diameter and is set at the factory. User interface: 4-digit floating-point number: 0.0100.0 ms Factory setting: Depends on nominal diameter
EPD ELECTRODE	Use this function to check whether the sensor is equipped with an EPD electrode. User interface: YES NO Factory setting: YES → Electrode fitted as standard
POLARITY ECC	Use this function to display the actual current polarity for optional electrode cleaning (ECC). Electrode cleaning uses either a positive or negative current, depending on the electrode material. The measuring device automatically selects the correct polarity on the basis of the electrode-material data stored in the S-DAT. User interface: POSITIVE → for electrodes made of: 1.4435, Hastelloy C, platinum, titanium NEGATIVE → for electrodes made of: tantalum Caution! If the incorrect current is applied to the electrodes, the electrode material is destroyed.

17 Group SUPERVISION

	Function description SUPERVISION					
CURRENT SYSTEM	Use this function to check the present system status.					
CONDITION	User interface: "SYSTEM OK" or the fault / notice message with the highest priority.					
PREVIOUS SYSTEM CONDITIONS	Use this function to view the fifteen most recent fault and notice messages since measuring last started.					
	User interface: The last 15 fault/notice messages appear on the display					
ASSIGN SYSTEM ERROR	Use this function to view all system errors and the associated error categories (fault message or notice message). By selecting a certain system error, its error category can be changed in the subsequent function ERROR CATEGORY.					
	Options: CANCEL List of system errors					
	Note! You can exit this function as follows: select "CANCEL" and confirm with A list of possible system errors is provided in the Operating Instructions Promag 50, BA 046D/06/en					
ERROR CATEGORY	Note! This function is only available if a system error has been selected in the function ASSIGN SYSTEM ERROR.					
	Use this function to define whether a system error triggers a notice message or a fault message. If you select FAULT MESSAGES, all outputs respond to an error in accordance with their defined error response patterns.					
	Options: NOTICE MESSAGES (display only) FAULT MESSAGES (outputs and display)					
	Note! Press the $\[\]$ key twice to call up the ASSIGN SYSTEM ERROR function.					
ASSIGN PROCESS ERROR	Use this function to view all process errors and the associated error categories (fault message or notice message). By selecting an individual process error, its error category can be changed in the subsequent function ERROR CATEGORY.					
	Options: CANCEL List of process errors					
	Note! You can exit this function as follows: select "CANCEL" and confirm with A list of possible process errors is provided in the Operating Instructions Promag 50, BA 046D/06/en					

Function description SUPERVISION					
ERROR CATEGORY	Note! This function is only available if a process error has been selected in the function ASSIGN PROCESS ERROR. Use this function to define whether a process error triggers a notice message or a fault message. If you select FAULT MESSAGES, all outputs respond to an error in accordance				
	with their defined error response patterns. Options: NOTICE MESSAGES (display only) FAULT MESSAGES (outputs and display) Note! Press the E key twice to call up the ASSIGN PROCESS ERROR function.				
ALARM DELAY	Use this function to define a time span in which the criteria for an error have to be satisfied without interruption before an error or notice message is generated. Depending on the setting and the type of error, this suppression acts on: Display Status output Current output				
	User input: 0100 s (in steps of one second) Factory setting: 0 s				
	If this function is activated error and notice messages are delayed by the time corresponding to the setting before being forwarded to the higher-order controller (process controller, etc.). It is therefore imperative to check in advance in order to make sure whether a delay of this nature could affect the safety requirements of the process. If error and notice messages cannot be suppressed, a value of 0 seconds must be entered here.				
SYSTEM RESET	Use this function to perform a reset of the measuring system. Options: NO				
	RESTART SYSTEM (restart without interrupting power supply) Factory setting: NO				
OPERATION HOURS	The hours of operation of the device appear on the display. Display: Depends on the number of hours of operation elapsed: Hours of operation < 10 hours → display format = 0:00:00 (hr:min:sec) Hours of operation 1010,000 hours → display format = 0000:00 (hr:min) Hours of operation > 10,000 hours → display format = 000000 (hr)				
PERMANENT STORAGE	This function indicates whether permanent storage of all parameters in the EEPROM has been switched on or off.				
	Factory setting: ON				

18 Group SIMULATION SYSTEM

,	Powert on the solution CIMILI ATION OVETEM					
	Function description SIMULATION SYSTEM					
SIMULATION FAILSAFE MODE	Use this function to set all inputs, outputs and the totalizer to their defined failsafe modes, in order to check whether they respond correctly. During this time, the words "SIMULATION FAILSAFE MODE" appear on the display.					
	Options: ON OFF					
	Factory setting: OFF					
SIMULATION MEASURED VARIABLE	Use this function to set all inputs, outputs and the totalizer to their defined flow-response modes, in order to check whether they respond correctly. During this time, the words "SIMULATION MEASURAND" appear on the display.					
	Options: OFF VOLUME FLOW					
	Factory setting: OFF					
	Caution! The measuring device cannot be used for measuring while this simulation is in progress. The setting is not saved if the power supply fails.					
VALUE SIMULATION MEASURED VARIABLE	Note! This function is not available unless the SIMULATION MEASURED VARIABLE function is active (= VOLUME FLOW).					
	Use this function to specify a selectable value (e.g. $12~\mathrm{m}^3/\mathrm{s}$). This value is used to test downstream devices and the measuring device itself.					
	User input: 5-digit floating-point number, [unit]					
	Factory setting: 0 [unit]					
	Caution! The setting is not saved if the power supply fails.					
	Note! The appropriate unit is taken from the group SYSTEM UNITS, (see Page 8)					

19 Group SENSOR VERSION

	Function description SENSOR VERSION
SERIAL NUMBER	Use this function to view the serial number of the sensor.
SENSOR TYPE	Use this function to view the sensor type.
HARDWARE REVISION NUMBER SENSOR	Use this function to view the hardware revision number of the sensor.
SOFTWARE REVISION NUMBER S-DAT	Use this function to view the software revision number of the software used to create the content of the S-DAT

20 Group AMPLIFIER VERSION

Function description AMPLIFIER VERSION						
DEVICE SOFTWARE	Displays the current device software version.					
SOFTWARE REVISION NUMBER AMPLIFIER	Use this function to view the software revision number of the amplifier.					
LANGUAGE GROUP	Use this function to view the language group. The following language groups can be ordered: WEST EU / USA, EAST EU / SCAND., ASIA. Display: available language group Note! The language options of the available language group are displayed in the LANGUAGE function. You can change the language group via the configuration software FieldCare. Please do not hesitate to contact your Endress+Hauser sales office if you have any questions.					
I/O MODULE TYPE	Use this function to view the configuration of the I/O module complete with terminal numbers.					
SOFTWARE REVISION NUMBER I/O MODULE	Use this function to view the software revision number of the I/O module.					

21 Factory settings

21.1 SI units (not for USA and Canada)

Low flow, full scale value, pulse value, totalizer

Nominal diameter		Low flow		Full sca	Full scale value		value	Totalizer
[mm]	[inch]	(approx. v	= 0.04 m/s)	(approx. $v = 2.5 \text{ m/s}$)		(approx. 2 pulses/s at v = 2.5 m/s)		
2	1/12"	0.01	dm ³ /min	0.5	dm ³ /min	0.005	dm ³	dm ³
4	5/32"	0.05	dm ³ /min	2	dm ³ /min	0.025	dm^3	dm ³
8	⁵ / ₁₆ "	0.1	dm ³ /min	8	dm ³ /min	0.10	dm^3	dm^3
15	1/2"	0.5	dm ³ /min	25	dm ³ /min	0.20	dm^3	dm^3
25	1"	1	dm ³ /min	75	dm ³ /min	0.50	dm^3	dm^3
32	1 1/4"	2	dm ³ /min	125	dm ³ /min	1.00	dm^3	dm^3
40	1 1/2"	3	dm ³ /min	200	dm ³ /min	1.50	dm^3	dm ³
50	2"	5	dm ³ /min	300	dm ³ /min	2.50	dm^3	dm^3
65	2 1/2"	8	dm ³ /min	500	dm ³ /min	5.00	dm^3	dm^3
80	3"	12	dm ³ /min	750	dm ³ /min	5.00	dm^3	dm^3
100	4"	20	dm ³ /min	1200	dm ³ /min	10.00	dm^3	dm ³
125	5"	30	dm ³ /min	1850	dm ³ /min	15.00	dm^3	dm ³
150	6"	2.5	m ³ /h	150	m ³ /h	0.025	m^3	m^3
200	8"	5.0	m ³ /h	300	m ³ /h	0.05	m^3	m^3
250	10"	7.5	m ³ /h	500	m ³ /h	0.05	m ³	m^3
300	12"	10	m ³ /h	750	m ³ /h	0.10	m^3	m^3
350	14"	15	m ³ /h	1000	m ³ /h	0.10	m^3	m^3
400	16"	20	m ³ /h	1200	m ³ /h	0.15	m^3	m^3
450	18"	25	m ³ /h	1500	m ³ /h	0.25	m^3	m^3
500	20"	30	m ³ /h	2000	m ³ /h	0.25	m^3	m^3
600	24"	40	m ³ /h	2500	m ³ /h	0.30	m^3	m^3
700	28"	50	m ³ /h	3500	m ³ /h	0.50	m^3	m^3
-	30"	60	m ³ /h	4000	m ³ /h	0.50	m^3	m^3
800	32"	75	m ³ /h	4500	m ³ /h	0.75	m^3	m^3
900	36"	100	m ³ /h	6000	m ³ /h	0.75	m^3	m^3
1000	40"	125	m ³ /h	7000	m ³ /h	1.00	m^3	m^3
-	42"	125	m ³ /h	8000	m ³ /h	1.00	m^3	m^3
1200	48"	150	m ³ /h	10000	m ³ /h	1.50	m^3	m^3
-	54"	200	m ³ /h	13000	m ³ /h	1.50	m^3	m^3
1400	_	225	m ³ /h	14000	m ³ /h	2.00	m ³	m^3
-	60"	250	m ³ /h	16000	m ³ /h	2.00	m ³	m^3
1600	-	300	m ³ /h	18000	m ³ /h	2.50	m^3	m^3
-	66"	325	m ³ /h	20500	m ³ /h	2.50	m ³	m^3
1800	72"	350	m ³ /h	23000	m ³ /h	3.00	m ³	m^3
-	78"	450	m ³ /h	28500	m ³ /h	3.50	m ³	m^3
2000	_	450	m ³ /h	28500	m ³ /h	3.50	m ³	m^3

Language

Country	Language
Australia	English
Austria	Deutsch
Belgium	English
Czech Republic	Czech
Denmark	English
England	English
Finland	Suomi
France	Français
Germany	Deutsch
Hong Kong	English
Hungary	English
India	English
Indonesia	Bahasa Indonesia
Instruments International	English
Italy	Italiano
Japan	Japanese
Malaysia	English
Netherlands	Nederlands
Norway	Norsk
Poland	Polish
Portugal	Portuguese
Russia	Russian
Singapore	English
South Africa	English
Spain	Espanol
Sweden	Svenska
Switzerland	Deutsch
Thailand	English

Length

	Unit
Length	mm

21.2 US units (only for USA and Canada)

Low flow, full scale value, pulse value, totalizer

Nominal	diameter Low flow Full scale value		Pulse value		Totalizer			
[inch]	[mm]	(approx. v	= 0.04 m/s)	(approx. $v = 2.5 \text{ m/s}$)		(approx. 2 pulses/s at $v = 2.5 \text{ m/s}$)		
1/12"	2	0.002	gal/min	0.1	gal/min	0.001	gal	gal
5/32"	4	0.008	gal/min	0.5	gal/min	0.005	gal	gal
5/16"	8	0.025	gal/min	2	gal/min	0.02	gal	gal
1/2"	15	0.10	gal/min	6	gal/min	0.05	gal	gal
1"	25	0.25	gal/min	18	gal/min	0.20	gal	gal
1 1/4"	32	0.50	gal/min	30	gal/min	0.20	gal	gal
1 1/2"	40	0.75	gal/min	50	gal/min	0.50	gal	gal
2"	50	1.25	gal/min	75	gal/min	0.50	gal	gal
2 1/2"	65	2.0	gal/min	130	gal/min	1	gal	gal
3"	80	2.5	gal/min	200	gal/min	2	gal	gal
4"	100	4.0	gal/min	300	gal/min	2	gal	gal
5"	125	7.0	gal/min	450	gal/min	5	gal	gal
6"	150	12	gal/min	600	gal/min	5	gal	gal
8"	200	15	gal/min	1200	gal/min	10	gal	gal
10"	250	30	gal/min	1500	gal/min	15	gal	gal
12"	300	45	gal/min	2400	gal/min	25	gal	gal
14"	350	60	gal/min	3600	gal/min	30	gal	gal
16"	400	60	gal/min	4800	gal/min	50	gal	gal
18"	450	90	gal/min	6000	gal/min	50	gal	gal
20"	500	120	gal/min	7500	gal/min	75	gal	gal
24"	600	180	gal/min	10500	gal/min	100	gal	gal
28"	700	210	gal/min	13500	gal/min	125	gal	gal
30"	_	270	gal/min	16500	gal/min	150	gal	gal
32"	800	300	gal/min	19500	gal/min	200	gal	gal
36"	900	360	gal/min	24000	gal/min	225	gal	gal
40"	1000	480	gal/min	30000	gal/min	250	gal	gal
42"	_	600	gal/min	33000	gal/min	250	gal	gal
48"	1200	600	gal/min	42000	gal/min	400	gal	gal
54"	_	1.3	Mgal/d	75	Mgal/d	0.0005	Mgal	Mgal
_	1400	1.3	Mgal/d	85	Mgal/d	0.0005	Mgal	Mgal
60"	_	1.3	Mgal/d	95	Mgal/d	0.0005	Mgal	Mgal
_	1600	1.7	Mgal/d	110	Mgal/d	0.0008	Mgal	Mgal
66"	_	2.2	Mgal/d	120	Mgal/d	0.0008	Mgal	Mgal
72"	1800	2.6	Mgal/d	140	Mgal/d	0.0008	Mgal	Mgal
78"	_	3.0	Mgal/d	175	Mgal/d	0.001	Mgal	Mgal
_	2000	3.0	Mgal/d	175	Mgal/d	0.001	Mgal	Mgal

Language, length

	Unit
Language	English
Length	inch

22	Index of key words	Response time
		End value frequency
Nume	rics	Error category
100% V	alue	Process error
_		System error
Α		F
	code	
	evel (status input)	Factory settings
Actual	21	Current output
	rent	Frequency output
-	uency	Pulse output
	elay (notice or fault messages)	Totalizer
Assign	ciay (nouce of fault incoolages)	Flow damping (system damping) 51
0	rent output	Format (display)
	lay line 1	Frequency (High value)
_	lay line 2	Function matrix
_	uency	Layout and use
Low	flow cut off	Overview
	ess error	G
	e	
	as input	Group Amplifier version
	is output	Communication
	em error	Current output
Lota	lizer	Handling totalizer
В		Measuring values
	ress	Operation
Dab aaa		Process parameter
C		Pulse/frequency output
Code		Quick Setup
	ess code	Sensor data
	nter (Unlocking)	Sensor version
	ate code	Simulation system
	sioning Quick Setup	Status input
	t LCD	Status output
Current	Spail 20	System parameters
D		System units
Device 1	D	Totalizer
	Revision	User interface
Device s	software 57	
Display		H
	dight	Hardware revision number (sensor)
	trast LCD	HART Protocol
	ping	I
	nat	I/O module type (input/output type)
Test		Installation direction sensor
Е		Integration time
	ectrode cleaning)	
,	ning cycle	K
	ation	K-Factor
	rity	T
Reco	very time	L
	Pipe Detection (EPD/OED)	Language
	electrode	Factory settings
	/OED adjustment	Language group (display)
Gen	eral information	Selection

Low flow cut off	1	Measured variable	56
Off value	43	Pulses	32
On value	43	Status input	40
		Switch point	35
M		Software revision number	
Manufacturer ID		Amplifier	
Measuring mode		Device Software	
Measuring period		I/O Module	
Minimum pulse width	40	S-DAT	
N		Status access	12
Nominal diameter	52	Status output	0.5
Nonliniai diameter	<i>J</i> Z	Flow direction	
0		General	
OED (Open electrode detection)		Limit value	
see Empty Pipe Detection	44	Storage	JC
Off value		permanent	55
Low flow cut off	43	Sum (totalizer)	
Status output	35	System	10
On value		Current conditions	54
Low flow cut off	43	Damping (flow damping)	
Status output		Operation hours	
Operation hours		Previous conditions	
Operation mode (pulse/frequency output)	23	Reset	
Output signal	0.4		
Frequency output		T	
Pulse		Tag	
Overflow (totalizer)		Description	
Overvoltage time	33	Name	
P		Test display	15
Permanent storage	55	Time constant	0.1
Polarity ECC		Current output	
Positive zero return		Frequency output	
Previous system conditions		Status output	
Pulse value		Totalizer Assign	
Pulse width		Failsafe mode	
		Mode	
Q		Overflow	
Quick Setup commissioning	10	Reset	
R		Reset all totalizers	
		Unit selection	
Reset All totalizers	1 Ω		
System		U	
Totalizer		Unit	
Totalizor	•	Length	
S		Totalizer	
Sensor		Volume	
Installation direction	49	Volume flow	. ბ
K-Factor	52	V	
Measuring period	53	Value	
Overvoltage time		20 mA	21
Sensor type		f high	
Serial number		Failsafe level	
Zero point	52	Value simulation	
Simulation		Current	22
Current		Frequency	
Failsafe mode		Measured variable	
Frequency	ZÖ	Pulse	

Status input	41
Switch point	36
Volume flow (display)	. 7
Z	
Zero point	52

www.endress.com/worldwide



People for Process Automation



















Technical Information

Proline Promag 50P, 53P

Electromagnetic Flow Measuring System Flow measurement of liquids in chemical or process applications





Application

Electromagnetic flowmeter for bidirectional measurement of liquids with a minimum conductivity of $\geq 5~\mu S/cm$:

- Acid, alkalis
- Paints
- Pastes
- Water, wastewater etc.
- Flow measurement up to 9600 m³/h (42268 gal/min)
- Fluid temperature up to +180 °C (356 °F)
- Process pressures up to 40 bar (580 psi)
- Lengths in accordance with DVGW/ISO

Application-specific lining materials:

- PTFE
- PFA

Approvals for hazardous area:

- ATEX
- IECEx
- FM
- CSA
- NEPSI
- TIIS

Connection to process control system:

- HART
- PROFIBUS DP/PA
- FOUNDATION Fieldbus
- MODBUS RS485

Your benefits

Promag measuring devices offer you cost-effective flow measurement with a high degree of accuracy for a wide range of process conditions.

The uniform Proline transmitter concept comprises:

- Modular device and operating concept resulting in a higher degree of efficiency
- Software options for batching, electrode cleaning and for measuring pulsating flow
- High degree of reliability and measuring stability
- Uniform operating concept

The tried-and-tested Promag sensors offer:

- No pressure loss
- Not sensitive to vibrations
- Simple installation and commissioning



Table of contents

Function and system design
Measuring principle
Measuring system
Input
Measured variable
Measuring ranges
Operable flow range
Input signal
input signal4
Output
Output signal
Signal on alarm
Load6
Low flow cutoff
Galvanic isolation
Switching output
Power supply
Electrical connection, measuring unit
Electrical connection, terminal assignment
Electrical connection, remote version
Supply voltage (power supply)
Cable entry
Remote version cable specifications
Power consumption
Power supply failure
Potential equalization
Performance characteristics13
Reference operating conditions
Maximum measured error
Repeatability
Operating conditions: Installations
Installation instructions
Installation instructions
Adapters
Length of connecting capie
Operating conditions: Environment20
Ambient temperature range
Storage temperature
Degree of protection
Shock and vibration resistance
Electromagnetic compatibility (EMC)20
Operating conditions: Process
Medium temperature range
Conductivity
Medium pressure range monunal pressurer
Medium pressure range (nominal pressure)
Pressure tightness
Pressure tightness


Mechanical construction	25
Design, dimensions	. 25
Weight	
Measuring tube specifications	
Material	
Material load diagram	
Fitted electrodes	
Process connections	
Surface roughness	. 40
Human interface	41
Display elements	. 41
Operating elements	
Language groups	. 41
Remote operation	. 41
Certificates and approvals	42
CE mark	
C-tick mark	
Pressure measuring device approval	
Ex approval	
Other standards and guidelines	
FOUNDATION Fieldbus certification	
MODBUS RS485 certification	
PROFIBUS DP/PA certification	. 42
Ordering information	43
Accessories	43
Documentation	43
Registered trademarks	43

Function and system design

Measuring principle

Following Faraday's law of magnetic induction, a voltage is induced in a conductor moving through a magnetic field.

In the electromagnetic measuring principle, the flowing medium is the moving conductor. The voltage induced is proportional to the flow velocity and is supplied to the amplifier by means of two measuring electrodes. The flow volume is calculated by means of the pipe cross-sectional area. The DC magnetic field is created through a switched direct current of alternating polarity.



 $Ue = B \cdot L \cdot v$ $Q = A \cdot v$

Ue Induced voltage

B Magnetic induction (magnetic field)

L Electrode spacing
v Flow velocity
Q Volume flow
A Pipe cross-section
I Current strength

Measuring system

The measuring system consists of a transmitter and a sensor.

Two versions are available:

- Compact version: Transmitter and sensor form a mechanical unit.

Transmitter:

- Promag 50 (user interface with push buttons for operation, two-line display, illuminated)
- Promag 53 ("Touch Control" without opening the housing, four-line display, unilluminated)

Sensor

■ Promag P (DN 15 to 600 / ½ to 24")

Input

Measured variable	Flow velocity (proportional to induced voltage)	ow velocity (proportional to induced voltage)			
Measuring ranges	Measuring ranges for liquids Typically $v=0.01$ to $10~\text{m/s}$ (0.03 to 33 ft/s) with the specified accuracy				
Operable flow range	Over 1000 : 1				
Input signal	Status input (auxiliary input) $U = 3 \text{ to } 30 \text{ V DC}, R_i = 5 \text{ k}\Omega$, galvanically isolated Configurable for: totalizer(s) reset, measured value suppression, error-message reset				
	Status input (auxiliary input) with PROFIBUS DP and MODBUS RS485 • $U = 3$ to 30 V DC, $R_i = 3$ k Ω , galvanically isolated				

- Switching level: 3 to 30 V DC, independent of polarity
- Configurable for: totalizer(s) reset, measured value suppression, error-message reset, batching start/stop (optional), batch totalizer reset (optional)

Current input (only Promag 53)

- active/passive selectable, galvanically isolated, full scale value selectable, resolution: 3 μA, temperature coefficient: typ. 0.005% o.r./°C (o.r. = of reading)
- active: 4 to 20 mA, $R_i \le 150 \Omega$, max. 24 V DC, short-circuit-proof
- passive: 0/4 to 20 mA, $R_i < 150 \Omega$, max. 30 V DC

Output

Output signal

Promag 50

Current output

active/passive selectable, galvanically isolated, time constant selectable (0.01 to 100 s),

full scale value selectable, temperature coefficient: typ. 0.005% o.r./°C (o.r. = of reading), resolution: 0.5 μA

- active: 0/4 to 20 mA, $R_L < 700 \Omega$ (HART: $R_L \ge 250 \Omega$)
- passive: 4 to 20 mA, operating voltage V_s : 18 to 30 V DC, $R_i \ge 150 \Omega$

Pulse/frequency output

passive, open collector, 30 V DC, 250 mA, galvanically isolated

- Frequency output: full scale frequency 2 to 1000 Hz (f_{max} = 1250 Hz), on/off ratio 1:1, pulse width max. 10s
- Pulse output: pulse value and pulse polarity selectable, max. pulse width configurable (0.5 to 2000 ms)

PROFIBUS DP interface

- Transmission technology (Physical Layer): RS485 in accordance with ANSI/TIA/EIA-485-A: 1998, galvanically isolated
- Profil version 3.0
- Data transmission rate: 9,6 kBaud to 12 MBaud
- Automatic data transmission rate recognition
- Function blocks: 1 × analog Input, 1 × totalizer
- Output data: volume flow, totalizer
- Input data: positive zero return (ON/OFF), totalizer control, value for local display
- Cyclic data transmission compatible with previous model Promag 33
- Bus address adjustable via miniature switches or local display (optional) at the measuring device

PROFIBUS PA interface

- Transmission technology (Physical Layer): IEC 61158-2 (MBP), galvanically isolated
- Profil version 3.0
- Current consumption: 11 mA
- Permissible supply voltage: 9 to 32 V
- Bus connection with integrated reverse polarity protection
- Error current FDE (Fault Disconnection Electronic): 0 mA
- Function blocks: 1 × analog input, 2 × totalizer
- Output data: volume flow, totalizer
- Input data: positive zero return (ON/OFF), control totalizer, value for local display
- Cyclic data transmission compatible with previous model Promag 33
- Bus address adjustable via miniature switches or local display (optional) at the measuring device

Promag 53

Current output

active/passive selectable, galvanically isolated, time constant selectable (0.01 to 100 s),

full scale value selectable, temperature coefficient: typ. 0.005% o.r./°C (o.r. = of reading), resolution: 0.5 μA

- active: 0/4 to 20 mA, $R_I < 700 \Omega$ (HART: $R_I \ge 250 \Omega$)
- \blacksquare passive: 4 to 20 mA, operating voltage V_S : 18 to 30 V DC, $R_i \geq$ 150 Ω

Pulse/frequency output

active/passive selectable, galvanically isolated (Ex i version: only passive)

- active: 24 V DC, 25 mA (max. 250 mA during 20 ms), $R_L > 100 \Omega$
- passive: open collector, 30 V DC, 250 mA
- Frequency output: full scale frequency 2 to 10000 Hz ($f_{max} = 12500 \text{ Hz}$), EEx-ia: 2 to 5000 Hz; on/off ratio 1:1, pulse width max. 10 s
- Pulse output: pulse value and pulse polarity selectable, max. pulse width configurable (0.05 to 2000 ms)

PROFIBUS DP interface

- Transmission technology (Physical Layer): RS485 in accordance with ANSI/TIA/EIA-485-A: 1998, galvanically isolated
- Profil version 3.0
- Data transmission rate: 9,6 kBaud to 12 MBaud
- Automatic data transmission rate recognition
- Function blocks: 2 × analog Input, 3 × totalizer
- Output data: volume flow, calculated mass flow, totalizer 1 to 3
- Input data: positive zero return (ON/OFF), totalizer control, value for local display
- Cyclic data transmission compatible with previous model Promag 33
- Bus address adjustable via miniature switches or local display (optional) at the measuring device
- Available output combination \rightarrow $\stackrel{\triangle}{=}$ 8

PROFIBUS PA interface

- Transmission technology (Physical Layer): IEC 61158-2 (MBP), galvanically isolated
- Profil version 3.0
- Current consumption: 11 mA
- Permissible supply voltage: 9 to 32 V
- \blacksquare Bus connection with integrated reverse polarity protection
- Error current FDE (Fault Disconnection Electronic): 0 mA
- Function blocks: 2 × analog input, 3 × totalizer
- Output data: volume flow, calculated mass flow, totalizer 1 to 3
- Input data: positive zero return (ON/OFF), totalizer control, value for local display
- \blacksquare Cyclic data transmission compatible with previous model Promag 33
- Bus address adjustable via miniature switches or local display (optional) at the measuring device

MODBUS RS485 interface

- Transmission technology (Physical Layer): RS485 in accordance with ANSI/TIA/EIA-485-A: 1998, galvanically isolated
- MODBUS device type: Slave
- Adress range: 1 to 247
- Bus address adjustable via miniature switches or local display (optional) at the measuring device
- Supported MODBUS function codes: 03, 04, 06, 08, 16, 23
- Broadcast: supported with the function codes 06, 16, 23
- Übertragungsmodus: RTU oder ASCII
- Supported baudrate: 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200 Baud
- Response time:
 - Direct data access = typically 25 to 50 ms
 - Auto-scan buffer (data range) = typically 3 to 5 ms
- Available output combination \rightarrow $\stackrel{\triangle}{=}$ 8

FOUNDATION Fieldbus interface

- FOUNDATION Fieldbus H1
- Transmission technology (Physical Layer): IEC 61158-2 (MBP), galvanically isolated
- ITK version 5.01
- Current consumption: 12 mA
- Error current FDE (Fault Disconnection Electronic): 0 mA
- Bus connection with integrated reverse polarity protection
- Function blocks:
 - $-5 \times$ Analog Input (execution time: 18 ms each)
 - $-1 \times PID (25 \text{ ms})$
 - 1 × Digital Output (18 ms)
 - 1 × Signal Characterizer (20 ms)
 - $-1 \times \text{Input Selector}$ (20 ms)
 - $-1 \times Arithmetic (20 ms)$
 - $-1 \times Integrator (18 ms)$
- Output data: volume flow, calculated mass flow, temperature, totalizer 1 to 3
- Input data: positive zero return (ON/OFF), reset totalizer
- Link Master (LM) functionality is supported

Signal on alarm

- Current output → failure response selectable (e.g. in accordance with NAMUR recommendation NE 43)
- Pulse/frequency output → failure response selectable
- Status output (Promag 50) → non-conductive by fault or power supply failure
- Relay output (Promag 53) \rightarrow de-energized by fault or power supply failure

Load

see "Output signal"

Low flow cutoff

Switch points for low flow cutoff are selectable.

Galvanic isolation

All circuits for inputs, outputs and power supply are galvanically isolated from each other.

Switching output

Status output (Promag 50, Promag 53)

Open collector, max. 30 V DC / 250 mA, galvanically isolated.


Configurable for: error messages, Empty Pipe Detection (EPD), flow direction, limit values.

Relay outputs (Promag 53)

Normally closed (NC or break) or normally open (NO or make) contacts available (default: relay 1 = NO, relay 2 = NC), max. 30 V / 0,5 A AC; 60 V / 0,1 A DC, galvanically isolated. Configurable for: error messages, Empty Pipe Detection (EPD), flow direction, limit values, batching contacts.

Power supply

Electrical connection, measuring unit



Connecting the transmitter, cable cross-section max. 2.5 mm² (14 AWG)

- A View A (field housing)
- B View B (stainless steel field housing)
- C View C (wall-mount housing)
- *) fixed communication boards
- **) flexible communication boards
- a Connection compartment cover
- Cable for power supply: 85 to 260 V AC / 20 to 55 V AC / 16 to 62 V DC
 - Terminal No. 1: L1 for AC, L+ for DC
 - Terminal No. 2: N for AC, L- for DC
- c Ground terminal for protective conductor
- d Signal cable: see "Electrical connection, terminal assignment" $\rightarrow \triangle$ 8 Fieldbus cable:
 - Terminal No. 26: DP (B) / PA + / FF + / MODBUS RS485 (B) / (PA, FF: with polarity protection)
 - Terminal No. 27: DP (A) / PA / FF / MODBUS RS485 (A) / (PA, FF: with polarity protection)
- e Ground terminal for signal cable shield / Fieldbus cable / RS485 line
- f Service adapter for connecting service interface FXA193 (Fieldcheck, FieldCare)
- g Signal cable: see "Electrical connection, terminal assignment" → 🖹 8 Cable for external termination (only for PROFIBUS DP with fixed assignment communication board):
 - Terminal No. 24: +5 V
 - Terminal No. 25: DGND

Electrical connection, terminal assignment

Terminal assignment, Promag 50

Order variant	Terminal No. (inputs/outputs)				
	20 (+) / 21 (-)	22 (+) / 23 (-)	24 (+) / 25 (-)	26 (+) / 27 (-)	
50***_*******	-	_	_	Current output HART	
50***-********A	_	_	Frequency output	Current output HART	
50***-********D	Status input	Status output	Frequency output	Current output HART	
50***-*********	-	_	-	PROFIBUS PA	
50***_**********J	-	-	+5 V (external termination)	PROFIBUS DP	
50***_******	-	-	Frequency output, Ex i, passive	Current output, Ex i, passive, HART	
50***_*********T	-	-	Frequency output, Ex i, passive	Current output, Ex i, passive, HART	

Ground terminal $\rightarrow 17$


Terminal assignment, Promag 53

The inputs and outputs on the communication board can be either permanently assigned or variable, depending on the version ordered (see table). Replacements for modules which are defective or which have to be replaced can be ordered as accessories.

Order variant	Terminal No. (inputs/outputs)				
	20 (+) / 21 (-)	22 (+) / 23 (-)	24 (+) / 25 (-)	26 (+) / 27 (-)	
Fixed communication boards (fixed assignment)					
53***-********A	_	-	Frequency output	Current output HART	
53***-*******B	Relay output 2	Relay output 1	Frequency output	Current output HART	
53***-*********F	_	-	_	PROFIBUS PA, Ex i	
53***-*********G	_	-	_	FOUNDATION Fieldbus, Ex i	
53***-*********	_	-	_	PROFIBUS PA	
53***-*********J	_	-	_	PROFIBUS DP	
53***-*******	_	-	_	FOUNDATION Fieldbus	
53***-********	_	-	Status input	MODBUS RS485	
53***_******	-	-	Frequency output, Ex i	Current output, Ex i, passive, HART	
53***_*******	_	-	Frequency output, Ex i	Current output, Ex i, passive, HART	
Flexible communication b	boards				
53***-*********C	Relay output 2	Relay output 1	Frequency output	Current output HART	
53***-********D	Status input	Relay output	Frequency output	Current output HART	
53***-*********L	Status input	Relay output 2	Relay output 1	Current output HART	
53***-********M	Status input	Frequency output	Frequency output	Current output HART	
53***-********N	Current output	Frequency output	Status input	MODBUS RS485	
53***-********P	Current output	Frequency output	Status input	PROFIBUS DP	
53***-********V	Relay output 2	Relay output 1	Status input	PROFIBUS DP	
53***-*********2	Relay output	Current output	Frequency output	Current output HART	
53***-********4	Current input	Relay output	Frequency output	Current output HART	
53***-********	Status input	Current input	Frequency output	Current output HART	
53***_*********	Relay output 2	Relay output 1	Status input	MODBUS RS485	

Ground terminal \rightarrow $\stackrel{\triangle}{=}$ 7

Electrical connection, remote version



Connecting the remote version

- a Wall-mount housing connection compartment
- b Sensor connection housing cover
- c Signal cable
- d Coil current cable
- n.c. Not connected, insulated cable shields

Terminal no. and cable colors: 6/5 = brown; 7/8 = white; 4 = green; 36/37 = yellow

Supply voltage (power supply)

- 85 to 260 V AC, 45 to 65 Hz
- 20 to 55 V AC, 45 to 65 Hz
- 16 to 62 V DC

PROFIBUS PA and FOUNDATION Fieldbus

- Non-Ex: 9 to 32 V DC
- Ex i: 9 to 24 V DC
- Ex d: 9 to 32 V DC

Cable entry

Power supply and signal cables (inputs/outputs):

- Cable entry M20 \times 1.5 (8 to 12 mm / 0.31 to 0.47")
- Sensor cable entry for armoured cables $M20 \times 1.5$ (9.5 to 16 mm / 0.37 to 0.63")
- Thread for cable entries, ½" NPT, G ½"

Connecting cable for remote version:

- Cable entry M20 × 1.5 (8 to 12 mm / 0.31 to 0.47")
- Sensor cable entry for armoured cables $M20 \times 1.5$ (9.5 to 16 mm / 0.37 to 0.63")
- Thread for cable entries, ½" NPT, G ½"


Remote version cable specifications

Coil cable

- $2 \times 0.75 \text{ mm}^2$ (18 AWG) PVC cable with common, braided copper shield ($\varnothing \sim 7 \text{ mm} / 0.28$ ")
- Conductor resistance: $\leq 37 \Omega/\text{km} (\leq 0.011 \Omega/\text{ft})$
- Capacitance core/core, shield grounded: ≤ 120 pF/m (≤ 37 pF/ft)
- Operating temperature: -20 to +80 °C (-68 to +176 °F)
- Cable cross-section: max. 2.5 mm² (14 AWG)
- Test voltage for cable insulation: ≤ 1433 AC r.m.s. 50/60 Hz or ≥ 2026 V DC

Signal cable

- $3 \times 0.38 \text{ mm}^2$ (20 AWG) PVC cable with common, braided copper shield ($\varnothing \sim 7 \text{ mm} / 0.28$ ") and individual shielded cores
- With empty pipe detection (EPD): $4 \times 0.38 \text{ mm}^2$ (20 AWG) PVC cable with common, braided copper shield ($\varnothing \sim 7 \text{ mm} / 0.28$ ") and individual shielded cores
- Conductor resistance: $\leq 50 \Omega/\text{km} (\leq 0.015 \Omega/\text{ft})$
- Capacitance core/shield: ≤ 420 pF/m (≤ 128 pF/ft)
- Operating temperature: -20 to +80 °C (-68 to +176 °F)
- Cable cross-section: max. 2.5 mm² (14 AWG)



- a Signal cable
- b Coil current cable
- 1 Core
- 2 Core insulation
- 3 Core shield
- 4 Core jacket
- 5 Core reinforcement
- 6 Cable shield
- 7 Outer jacket

Operation in zones of severe electrical interference

The measuring device complies with the general safety requirements in accordance with EN 61010 and the EMC requirements of IEC/EN 61326 and NAMUR recommendation NE 21.



Caution!

Grounding is by means of the ground terminals provided for the purpose inside the connection housing. Ensure that the stripped and twisted lengths of cable shield to the ground terminal are as short as possible.

Power consumption

- AC: < 15 VA (incl. sensor)
- \blacksquare DC: < 15 W (incl. sensor)

Switch-on current:

- Max. 3 A (< 5 ms) for 260 V AC
- Max. 13.5 A (< 50 ms) for 24 V DC

Power supply failure

Lasting min. $\frac{1}{2}$ cycle frequency: EEPROM saves measuring system data

- EEPROM or T-DAT (Promag 53 only) retain the measuring system data in the event of a power supply failure
- S-DAT: exchangeable data storage chip which stores the data of the sensor (nominal diameter, serial number, calibration factor, zero point etc.)

Potential equalization



Warning!

The measuring system must be included in the potential equalization.

Perfect measurement is only ensured when the fluid and the sensor have the same electrical potential. This is ensured by the reference electrode integrated in the sensor as standard.

The following should also be taken into consideration for potential equalization:

- Internal grounding concepts in the company
- Operating conditions, such as the material/ grounding of the pipes (see table)

Standard situation

Operating conditions Potential equalization When using the measuring device in a: ■ Metal, grounded pipe Potential equalization takes place via the ground terminal of the transmitter. Note! When installing in metal pipes, we recommend you connect the ground terminal of the transmitter housing with the piping. Via the ground terminal of the transmitter

Special situations

Operating conditions

When using the measuring device in a:

■ Metal pipe that is not grounded

This connection method also applies in situations where:

- Customary potential equalization cannot be ensured.
- Excessively high equalizing currents can be expected.

Both sensor flanges are connected to the pipe flange by means of a ground cable (copper wire, at least 6 $\mbox{mm}^2 \, / \, 0.0093 \ \mbox{in}^2)$ and grounded. Connect the transmitter or sensor connection housing, as applicable, to ground potential by means of the ground terminal provided for the purpose.


- DN \leq 300 (12"): the ground cable is mounted directly on the conductive flange coating with the flange screws.
- DN \geq 350 (14"): the ground cable is mounted directly on the transportation metal support.



Note!

The ground cable for flange-to-flange connections can be ordered separately as an accessory from Endress+Hauser.

Potential equalization



Via the ground terminal of the transmitter and the flanges of the pipe


When using the measuring device in a:

- Plastic pipe
- Pipe with insulating lining

This connection method also applies in situations where:

- Customary potential equalization cannot be ensured.
- Excessively high equalizing currents can be expected.

Potential equalization takes place using additional ground disks, which are connected to the ground terminal via a ground cable (copper wire, at least 6 mm² / 0.0093 in²). When installing the ground disks, please comply with the enclosed Installation Instructions.



Via the ground terminal of the transmitter and the optionally available ground disks

Operating conditions

When using the measuring device in a:


■ Pipe with a cathodic protection unit

The device is installed potential-free in the pipe. Only the two flanges of the pipe are connected with a ground cable (copper wire, at least 6 $\,\mathrm{mm^2}$ / 0.0093 in²). Here, the ground cable is mounted directly on the conductive flange coating with flange screws.

Note the following when installing:

- The applicable regulations regarding potential-free installation must be observed.
- There should be **no** electrically conductive connection between the pipe and the device.
- The mounting material must withstand the applicable torques.

Potential equalization



Potential equalization and cathodic protection

- Power supply isolation transformer
- P. Electrically isolated

12

Performance characteristics

Reference operating conditions

As per DIN EN 29104 and VDI/VDE 2641:

- Fluid temperature: +28 °C \pm 2 K (+82 °F \pm 2 K)
- Ambient temperature: +22 °C ± 2 K (+72 °F ± 2 K)
- Warm-up period: 30 minutes

Installation conditions:

- Inlet run $> 10 \times DN$
- Outlet run $> 5 \times DN$
- Sensor and transmitter grounded.
- The sensor is centered in the pipe.

Maximum measured error


Promag 50:

- Current output: also typically \pm 5 μA
- Pulse output: $\pm 0.5\%$ o.r. ± 1 mm/s ($\pm 0.5\%$ o.r. ± 0.04 in/s) optional: $\pm 0.2\%$ o.r. ± 2 mm/s ($\pm 0.2\%$ o.r. ± 0.08 in/s) (o.r. = of reading)

Promag 53:

- Current output: also typically \pm 5 μ A
- Pulse output: $\pm 0.2\%$ o.r. ± 2 mm/s ($\pm 0.2\%$ o.r. ± 0.08 in/s) (o.r. = of reading)

Fluctuations in the supply voltage do not have any effect within the specified range.



Max. measured error in % of reading

Repeatability

Max. $\pm 0.1\%$ o.r. ± 0.5 mm/s ($\pm 0.1\%$ o.r. ± 0.02 in/s) (o.r. = of reading)


Operating conditions: Installations

Installation instructions

Mounting location

Entrained air or gas bubble formation in the measuring tube can result in an increase in measuring errors. **Avoid** the following installation locations in the pipe:


- Highest point of a pipeline. Risk of air accumulating!
- Directly upstream from a free pipe outlet in a vertical pipeline.



Mounting location

Installation of pumps

Sensors may not be installed on the pump suction side. This precaution is to avoid low pressure and the consequent risk of damage to the lining of the measuring tube. Information on the pressure tightness of the measuring tube lining $\rightarrow \stackrel{\text{\tiny lin}}{=} 22$, Section "Pressure tightness".



Installation of pumps

Partially filled pipes


Partially filled pipes with gradients necessitate a drain-type configuration.

The empty pipe detection function (EPD) provides additional security in detecting empty or partially filled pipes.



Caution!


Risk of solids accumulating. Do not install the sensor at the lowest point in the drain. It is advisable to install a cleaning valve.



Installation with partially filled pipes

Down pipes

Install a siphon or a vent valve downstream of the sensor in down pipes $h \ge 5$ m (16.4 ft). This precaution is to avoid low pressure and the consequent risk of damage to the lining of the measuring tube. This measure also prevents the liquid current stopping in the pipe which could cause air locks. Information on the pressure tightness of the measuring tube lining $\rightarrow \stackrel{\triangle}{=} 22$, Section "Pressure tightness".



A00119

Installation measures for vertical pipes


- 1 Vent valve
- 2 Pipe siphon
- h Length of the down pipe

Orientation

An optimum orientation helps avoid gas and air accumulations and deposits in the measuring tube. However, the measuring device also offers the additional function of empty pipe detection (EPD) for detecting partially filled measuring tubes or if outgassing fluids or fluctuating operating pressures are present.

Vertical orientation

This is the ideal orientation for self-emptying piping systems and for use in conjunction with empty pipe detection.



Vertical orientation


Horizontal orientation

The measuring electrode axis should be horizontal. This prevents brief insulation of the two measuring electrodes by entrained air bubbles.



Caution

Empty pipe detection only works correctly with horizontal orientation if the transmitter housing is facing upwards. Otherwise there is no guarantee that empty pipe detection will respond if the measuring tube is only partially filled or empty.



Horizontal orientation

- 1 EPD electrode for empty pipe detection
- 2 Measuring electrodes for signal detection
- 3 Reference electrode for potential equalization

16


Vibrations

Secure the piping and the sensor if vibration is severe.



Caution!

If vibrations are too severe, we recommend the sensor and transmitter be mounted separately. Information on the permitted shock and vibration resistance $\rightarrow \stackrel{\text{\tiny le}}{=} 20$, Section "Shock and vibration resistance".



Measures to prevent vibration of the measuring device

L > 10 m (33 ft)


Foundations, supports

If the nominal diameter is DN \geq 350, mount the transmitter on a foundation of adequate load-bearing strength.



Caution

Do not allow the casing to take the weight of the sensor. This would buckle the casing and damage the internal magnetic coils.




Inlet and outlet run

If possible, install the sensor well clear of assemblies such as valves, T-pieces, elbows etc.

Note the following inlet and outlet runs to comply with measuring accuracy specifications:

Inlet run: ≥ 5 × DNOutlet run: ≥ 2 × DN



Inlet and outlet run

Adapters


Suitable adapters to DIN EN 545 (double-flange reducers) can be used to install the sensor in larger-diameter pipes. The resultant increase in the rate of flow improves measuring accuracy with very slow-moving fluids. The nomogram shown here can be used to calculate the pressure loss caused by reducers and expanders.



Note!

The nomogram only applies to liquids of viscosity similar to water.

- 1. Calculate the ratio of the diameters d/D.
- 2. From the nomogram read off the pressure loss as a function of flow velocity (downstream from the reduction) and the d/D ratio.




Pressure loss due to adapters

18

Length of connecting cable

When mounting the remote version, please note the following to achieve correct measuring results:

- Fix cable run or lay in armored conduit. Cable movements can falsify the measuring signal especially in the case of low fluid conductivities.
- Route the cable well clear of electrical machines and switching elements.
- If necessary, ensure potential equalization between sensor and transmitter.
- The permitted cable length L_{max} is determined by the fluid conductivity. A minimum conductivity of 20 μ S/cm is required for measuring demineralized water.
- When the empty pipe detection function is switched on (EPD), the maximum connecting cable length is 10 m (33 ft).



Permitted length of connecting cable for remote version Area marked in gray = permitted range; L_{max} = length of connecting cable in [m] ([ft]); fluid conductivity in [μ S/cm]

Operating conditions: Environment

Ambient temperature range

Transmitter

- Standard: -20 to +60 °C (-4 to +140 °F)
- Optional: -40 to +60 °C (-40 to +140 °F)



Note

At ambient temperatures below -20 °C (-4 °F)the readability of the display may be impaired.

Sensor

- Flange material carbon steel: -10 to +60 °C (+14 to +140 °F)
- Flange material stainless steel: -40 to +60 °C (-40 to +140 °F)



Caution!

The permitted temperature range of the measuring tube lining may not be undershot or overshot $\rightarrow \stackrel{\triangle}{=} 21$, Section "Medium temperature range".

Please note the following points:

- Install the device in a shady location. Avoid direct sunlight, particularly in warm climatic regions.
- The transmitter must be mounted separate from the sensor if both the ambient and fluid temperatures are high.

Storage temperature

The storage temperature corresponds to the operating temperature range of the measuring transmitter and the appropriate measuring sensors.



Caution!

- The measuring device must be protected against direct sunlight during storage in order to avoid unacceptably high surface temperatures.
- A storage location must be selected where moisture does not collect in the measuring device. This will help prevent fungus and bacteria infestation which can damage the liner.
- Do not remove the protective plates or caps on the process connections until the device is ready to install.

Degree of protection

- Standard: IP 67 (NEMA 4X) for transmitter and sensor.
- \blacksquare Optional: IP 68 (NEMA 6P) for sensor for remote version.
- For information regarding applications where the device is buried directly in the soil or is installed in a flooded wastewater basin please contact your local Endress+Hauser Sales Center.

Shock and vibration resistance

Acceleration up to 2 g following IEC 600 68-2-6

Electromagnetic compatibility (EMC)


■ As per IEC/EN 61326 and NAMUR recommendation NE 21.

Operating conditions: Process

Medium temperature range

The permitted temperature depends on the lining of the measuring tube:

- PTFE: -40 to +130 °C (-40 to +266 °F) (DN 15 to 600 / ½ to 24"), restrictions \rightarrow see diagrams
- PFA: -20 to +180 °C (-4 to +356 °F) (DN 25 to 200 / 1 to 8"), restrictions \rightarrow see diagrams




Compact version (with PFA or PTFE lining)

 T_A = Ambient temperature, T_F = Fluid temperature, HT = High temperature version with insulatio

① Gray shaded area \rightarrow temperature range from -10 to -40 °C (-14 to -40 °F) applies only to stainless steel flanges

② HE + IP 68 to 130 °C (266 °F) only



Remote version (with PFA or PTFE lining)

 $T_A = Ambient$ temperature, $T_F = Fluid$ temperature, HT = High temperature version with insulation

① Gray shaded area \rightarrow temperature range from -10 to -40 °C (-14 to -40 °F) applies only to stainless steel flanges

② HE + IP 68 to 130 °C (266 °F) only

Conductivity

The minimum conductivity is:

- $\geq 5 \mu S/cm$ for fluids generally
- \geq 20 µS/cm for demineralized water



Notel

In the remote version, the necessary minimum conductivity also depends on the cable length ($\rightarrow \stackrel{\text{le}}{=} 19$, Section "Length of connecting cable").

Medium pressure range (nominal pressure)

- EN 1092-1 (DIN 2501)
 - PN 10 (DN 200 to 600 / 8 to 24")
 - PN 16 (DN 65 to 600 / 3 to 24")
 - $-\,$ PN 25 (DN 200 to 600 / 8 to 24")
 - PN 40 (DN 15 to 150 / ½ to 6")
- ANSI B 16.5
 - Class 150 (DN ½ to 24")
 - Class 300 (DN ½ to 6")
- JIS B2220
 - 10 K (DN 50 to 300 / 2 to 12")
 - 20 K (DN 15 to 300 / ½ to 12")
- AS 2129
 - Table E (DN 25, 50 / 1", 2")
- AS 4087
 - PN 16 (DN 50 / 2")

Pressure tightness

Measuring tube lining: PTFE

Nominal	diameter		Limit value	es for abs. p	ressure [m	bar] ([psi])	at fluid ter	nperatures:	
		25 °C	(77 °F)	80 °C (176 °F)	100 °C	(212 °F)	130 °C	(266 °F)
[mm]	[inch]	[mbar]	[psi]	[mbar]	[psi]	[mbar]	[psi]	[mbar]	[psi]
15	1/2"	0	0	0	0	0	0	100	1.45
25	1"	0	0	0	0	0	0	100	1.45
32	_	0	0	0	0	0	0	100	1.45
40	11/2"	0	0	0	0	0	0	100	1.45
50	2"	0	0	0	0	0	0	100	1.45
65	_	0	0	*	*	40	0.58	130	1.89
80	3"	0	0	*	*	40	0.58	130	1.89
100	4"	0	0	*	*	135	1.96	170	2.47
125	-	135	1.96	*	*	240	3.48	385	5.58
150	6"	135	1.96	*	*	240	3.48	385	5.58
200	8"	200	2.90	*	*	290	4.21	410	5.95
250	10"	330	4.79	*	*	400	5.80	530	7.69
300	12"	400	5.80	*	*	500	7.25	630	9.14
350	14"	470	6.82	*	*	600	8.70	730	10.6
400	16"	540	7.83	*	*	670	9.72	800	11.6
450	18"			•					
500	20"			Part	ial vacuum i	is impermissi	ble!		
600	24"								

^{*} No value can be specified.

22

Measuring tube lining: PFA

Nominal	diameter	Liı	mit values for	abs. pressure	[mbar] ([psi]) at fluid tempera	atures:
		25 °C	(77 °F)	80 °C (176 °F)	100 to 180 °C	(212 to 356 °F)
[mm]	[inch]	[mbar]	[psi]	[mbar]	[psi]	[mbar]	[psi]
25	1"	0	0	0	0	0	0
32	-	0	0	0	0	0	0
40	11/2"	0	0	0	0	0	0
50	2"	0	0	0	0	0	0
65	_	0	0	*	*	0	0
80	3"	0	0	*	*	0	0
100	4"	0	0	*	*	0	0
125	-	0	0	*	*	0	0
150	6"	0	0	*	*	0	0
200	8"	0 0		*	*	0	0

^{*} No value can be specified.

Limiting flow

The diameter of the pipe and the flow rate determine the nominal diameter of the sensor.

The optimum flow velocity is between 2 to 3 m/s (6.5 to 9.8 ft/s). The velocity of flow (v), moreover, has to be matched to the physical properties of the fluid:

- v < 2 m/s (6.5 ft/s): for abrasive fluids such as potter's clay, lime milk, ore slurry etc.
- v > 2 m/s (6.5 ft/s): for fluids causing build-up such as wastewater sludges etc.

Flow ch	naracteri	istic values (SI units)			
Diam	neter	Recommended flow rate	Fact	ory settings	
[mm]	[inch]	Min./max. full scale value (v ~ 0.3 or 10 m/s)	Full scale value, current output $(v \sim 2.5 \text{ m/s})$	Pulse value (~ 2 pulses/s)	Low flow cut off (v ~ 0.04 m/s)
15	1/2"	4 to 100 dm ³ /min	25 dm ³ /min	0.20 dm ³	0.50 dm ³ /min
25	1"	9 to 300 dm ³ /min	75 dm ³ /min	$0.50 dm^3$	1.00 dm ³ /min
32	-	15 to 500 dm ³ /min	125 dm ³ /min	1.00 dm ³	2.00 dm ³ /min
40	11/2"	25 to 700 dm ³ /min	200 dm ³ /min	1.50 dm ³	3.00 dm ³ /min
50	2"	35 to 1100 dm ³ /min	300 dm ³ /min	$2.50 dm^3$	5.00 dm ³ /min
65	_	60 to 2000 dm ³ /min	500 dm ³ /min	5.00 dm ³	8.00 dm ³ /min
80	3"	90 to 3000 dm ³ /min	750 dm ³ /min	5.00 dm ³	12.0 dm ³ /min
100	4"	145 to 4700 dm ³ /min	1200 dm ³ /min	10.0 dm ³	20.0 dm ³ /min
125	_	220 to 7500 dm ³ /min	1850 dm ³ /min	15.0 dm ³	30.0 dm ³ /min
150	6"	20 to 600 m ³ /h	150 m ³ /h	0.03 m ³	2.50 m ³ /h
200	8"	35 to 1100 m ³ /h	300 m ³ /h	0.05 m ³	5.00 m ³ /h
250	10"	55 to 1700 m ³ /h	500 m ³ /h	0.05 m ³	7.50 m ³ /h
300	12"	80 to 2400 m ³ /h	750 m ³ /h	0.10 m ³	10.0 m ³ /h
350	14"	110 to 3300 m ³ /h	1000 m ³ /h	0.10 m ³	15.0 m ³ /h
400	16"	140 to 4200 m ³ /h	1200 m ³ /h	0.15 m ³	20.0 m ³ /h
450	18"	180 to 5400 m ³ /h	1500 m ³ /h	0.25 m ³	25.0 m ³ /h
500	20"	220 to 6600 m ³ /h	2000 m ³ /h	0.25 m ³	30.0 m ³ /h
600	24"	310 to 9600 m ³ /h	2500 m ³ /h	0.30 m ³	40.0 m ³ /h


Flow ch	naracter	istic values (US units)			
Diam	neter	Recommended flow rate	Fact	tory settings	
[inch]	[mm]	Min./max. full scale value (v ~ 0.3 or 10 m/s)	Full scale value, current output $(v \sim 2.5 \text{ m/s})$	Pulse value (~ 2 pulses/s)	Low flow cut off (v ~ 0.04 m/s)
1/2"	25	1.0 to 26 gal/min	6 gal/min	0.10 gal	0.15 gal/min
1"	25	2.5 to 80 gal/min	18 gal/min	0.20 gal	0.25 gal/min
1½"	40	7 to 190 gal/min	50 gal/min	0.50 gal	0.75 gal/min
2"	50	10 to 300 gal/min	75 gal/min	0.50 gal	1.25 gal/min
3"	80	24 to 800 gal/min	200 gal/min	2.00 gal	2.50 gal/min
4"	100	40 to 1250 gal/min	300 gal/min	2.00 gal	4.00 gal/min
6"	150	90 to 2650 gal/min	600 gal/min	5.00 gal	12.0 gal/min
8"	200	155 to 4850 gal/min	1200 gal/min	10.0 gal	15.0 gal/min
10"	250	250 to 7500 gal/min	1500 gal/min	15.0 gal	30.0 gal/min
12"	300	350 to 10600 gal/min	2400 gal/min	25.0 gal	45.0 gal/min
14"	350	500 to 15000 gal/min	3600 gal/min	30.0 gal	60.0 gal/min
16"	400	600 to 19000 gal/min	4800 gal/min	50.0 gal	60.0 gal/min
18"	450	800 to 24000 gal/min	6000 gal/min	50.0 gal	90.0 gal/min
20"	500	1000 to 30000 gal/min	7500 gal/min	75.0 gal	120.0 gal/min
24"	600	1400 to 44000 gal/min	10500 gal/min	100.0 gal	180.0 gal/min

Pressure loss

Mechanical construction

Design, dimensions

Transmitter remote version, wall-mount housing (non Ex-zone and II3G/Zone 2)



Dimensions (SI units)

A	В	С	D	Е	F	G	Н	J
215	250	90.5	159.5	135	90	45	> 50	81
K	L	М	N	0	Р	α	R	S
53	95	53	102	81.5	11.5	192	8 × M5	20


All dimensions in [mm]

Dimensions (US units)

A	В	С	D	Е	F	G	Н	J
8.46	9.84	3.56	6.27	5.31	3.54	1.77	> 1.97	3.18
K	L	М	N	0	P	α	R	S
2.08	3.74	2.08	4.01	3.20	0.45	7.55	8 × M5	0.79

All dimensions in [inch]

Transmitter remote version, connection housing (II2GD/Zone 1)



A0002128

Dimensions (SI units)

А	A*	В	В*	С	D	Е	ØF	G	Н	J	K	L	М
265	242	240	217	206	186	178	8.6 (M8)	100	130	100	144	170	355

All dimensions in [mm]

Dimensions (US units)


Α	A*	В	В*	С	D	Е	ØF	G	Н	J	K	L	М
10.4	9.53	9.45	8.54	8.11	7.32	7.01	0.34 (M8)	3.94	5.12	3.94	5.67	6.69	14.0

All dimensions in [inch]


There is a separate mounting kit for the wall-mounted housing. It can be ordered from Endress+Hauser as an accessory. The following installation variants are possible:

- lacktriangle Panel-mounted installation
- Pipe mounting


Installation in control panel




Pipe mounting



$Compact\ version\ DN \leq 300\ (12")$



High temperature version DN \leq 300 (12")



Measurement D1, E1 = Measurement D, E of the standard compact version plus 110 mm (4.33")

Dimensions (SI units)

DN	L 1)	A	A*	В	С	D	Е	F	G	Н	K
EN (DIN) / JIS / AS ²⁾											
15	200						341	257	84	94	120
25	200						341	257	84	94	120
32	200						341	257	84	94	120
40	200						341	257	84	94	120
50	200						341	257	84	94	120
65	200						391	282	109	94	180
80	200	227	207	187	168	160	391	282	109	94	180
100	250						391	282	109	94	180
125	250						472	322	150	140	260
150	300						472	322	150	140	260
200	350						527	347	180	156	324
250	450						577	372	205	166	400
300	500						627	397	230	166	460


Dimensions (US units)

DN	L 1)	А	A*	В	С	D	Е	F	G	Н	K
ANSI											
1/2"	7.87						13.4	10.1	3.31	3.70	4.72
1"	7.87						13.4	10.1	3.31	3.70	4.72
11/2"	7.87						13.4	10.1	3.31	3.70	4.72
2"	7.87						13.4	10.1	3.31	3.70	4.72
3"	7.87	8.94	8.15	7.36	6.61	6.30	15.4	11.1	4.29	3.70	7.09
4"	9.84	0.94	0.13	7.30	0.01	0.30	15.4	11.1	4.29	3.70	7.09
6"	11.8						18.6	12.7	5.91	5.51	10.2
8"	13.8						20.8	13.7	7.09	6.14	12.8
10"	17.7						22.7	14.7	8.07	6.54	15.8
12"	19.7						24.7	15.6	9.06	6.54	18.1

 $^{^{1)}}$ The length is regardless of the pressure rating selected. Fitting length to DVGW. All dimensions in [inch]

¹⁾ The length is regardless of the pressure rating selected. Fitting length to DVGW.
²⁾ Only DN 25 and DN 50 are available for flanges according to AS.
All dimensions in [mm]

$Compact\ version\ DN \geq 350\ (14")$



A000542

Dimensions (SI units)

DN	L 1)	A	A*	В	С	D	Е	F	G	Н	J
EN (DIN)											
350	550						738.5	456.5	282.0	564	276
400	600						790.5	482.5	308.0	616	276
450	650	227	207	187	168	160	840.5	507.5	333.0	666	292
500	650						891.5	533.0	358.5	717	292
600	780						995.5	585.0	410.5	821	402

 $^{^{1)}\,\}mbox{The length}$ is regardless of the pressure rating selected. Fitting length to DVGW. All dimensions in [mm]


Dimensions (US units)

DN	L 1)	A	A*	В	С	D	Е	F	G	Н	J
ANSI											
14"	21.7						29.1	18.0	11.1	22.2	10.9
16"	23.6						31.1	19.0	12.1	24.3	10.9
18"	25.6	8.94	8.15	7.36	6.61	6.30	33.1	20.0	13.1	26.2	11.5
20"	25.6						35.1	21.0	14.1	28.2	11.5
24"	30.7						39.2	23.0	16.2	32.3	15.8


 $^{^{1)}}$ The length is regardless of the pressure rating selected. Fitting length to DVGW. All dimensions in [inch] $\,$

30

Sensor, remote version DN $\leq 300 \ (12")$



High temperature version $DN \le 300 (12")$



Measurement D1, E1 = Measurement D, E of the standard remote version plus 110 mm (4.33")

Dimensions (SI units)

DN	L 1)	А	В	С	D	Е	F	G	Н	J
EN (DIN) / JIS / AS ²⁾										
15	200					286	202	84	120	94
25	200					286	202	84	120	94
32	200					286	202	84	120	94
40	200					286	202	84	120	94
50	200					286	202	84	120	94
65	200					336	227	109	180	94
80	200	129	163	143	102	336	227	109	180	94
100	250					336	227	109	180	94
125	250					417	267	150	260	140
150	300					417	267	150	260	140
200	350					472	292	180	324	156
250	450					522	317	205	400	166
300	500					572	342	230	460	166


Dimensions (US units)

DN	L 1)	А	В	С	D	Е	F	G	Н	J
ANSI										
1/2"	7.87					11.3	7.95	3.31	4.72	3.70
1"	7.87					11.3	7.95	3.31	4.72	3.70
11/2"	7.87			5.63		11.3	7.95	3.31	4.72	3.70
2"	7.87		6.42			11.3	7.95	3.31	4.72	3.70
3"	7.87	E 00			4.02	13.2	8.94	4.29	7.09	3.70
4"	9.84	5.08			4.02	13.2	8.94	4.29	7.09	3.70
6"	11.8					16.4	10.5	5.91	10.2	5.51
8"	13.8					18.6	11.5	7.08	12.8	6.14
10"	17.7					20.6	12.5	8.07	15.8	6.54
12"	19.7					22.5	13.5	9.06	18.1	6.54

 $^{^{1)}}$ The length is regardless of the pressure rating selected. Fitting length to DVGW. All dimensions in [inch]

¹⁾ The length is regardless of the pressure rating selected. Fitting length to DVGW. ²⁾ Only DN 25 and DN 50 are available for flanges according to AS. All dimensions in [mm]

Sensor, remote version $DN \geq 350 \ (14")$



Dimensions (SI units)

DN	L 1)	А	В	С	D	Е	F	G	Н	J
EN (DIN)										
350	550					683.5	401.5	282.0	564	276
400	600					735.5	427.5	308.0	616	276
450	650	129	163	143	102	785.5	452.5	333.0	666	292
500	650					836.5	478.0	358.5	717	292
600	780					940.5	530.0	410.5	821	402


 $^{^{\}rm 1)}$ The length is regardless of the pressure rating selected. Fitting length to DVGW. All dimensions in [mm]

Dimensions (US units)

DN	L 1)	А	В	С	D	Е	F	G	Н	J
ANSI										
14"	21.7					26.9	15.8	11.1	22.2	10.9
16"	23.6					29.0	16.8	12.1	24.3	10.9
18"	25.6	5.08	6.42	5.63	4.02	30.9	17.8	13.1	26.2	11.5
20"	25.6					32.9	18.8	14.1	28.2	11.5
24"	30.7					37.0	20.9	16.2	32.3	15.8

 $^{^{\}rm 1)}$ The length is regardless of the pressure rating selected. Fitting length to DVGW. All dimensions in [inch]

Ground disk for flange connections



Dimensions (SI units)

DN 1)	A	В	С	D	Е	t
EN (DIN) / JIS / AS ²⁾	PTFE, PFA					
15	16	43	61.5	73		
25	26	62	77.5	87.5		
32	35	80	87.5	94.5		
40	41	82	101	103		
50	52	101	115.5	108		
65	68	121	131.5	118		
80	80	131	154.5	135	6 E	
100	104	156	186.5	153	6.5	
125	130	187	206.5	160		
150	158	217	256	184		2
200	206	267	288	205		
250	260	328	359	240		
3003)	312	375	413	273		
3004)	310	375	404	268		
350 ³⁾	343	433	479	365		
4003)	393	480	542	395		
450 ³⁾	439	538	583	417	9.0	
500 ³⁾	493	592	650	460		
6003)	593	693	766	522		

 $^{^{1)}}$ Ground disks at DN 15 to 250 (½ to 10") can be used for all flange standards/pressure ratings. $^{2)}$ Only DN 25 and DN 50 are available for flanges according to AS.

³⁾ PN 10/16 4) PN 25, JIS 10K/20K

All dimensions in [mm]

Dimensions (US units)

DN 1)	A	В	С	D	Е	t
ANSI	PTFE, PFA					
1/2"	0.63	1.69	2.42	2.87		
1"	1.02	2.44	3.05	3.44		
11/2"	1.61	3.23	3.98	4.06		
2"	2.05	3.98	4.55	4.25		
3"	3.15	5.16	6.08	5.31	0.26	
4"	4.09	6.14	7.34	6.02	0.20	
6"	6.22	8.54	10.08	7.24		
8"	8.11	10.5	11.3	8.07		0.08
10"	10.2	12.9	14.1	9.45		
12"	12.3	14.8	16.3	10.8		
14"	13.5	17.1	18.9	14.4		
16"	15.45	18.9	21.3	15.6		
18"	17.3	21.2	23.0	16.4	0.35	
20"	19.4	23.3	25.6	18.1		
24"	23.4	27.3	30.1	20.6		

¹⁾ Ground disks can be used for all flange standards/pressure ratings. All dimensions in [inch]

Weight Weight in SI units

Weigh	t data i	n kg													
	ninal		C	omp	act versi	on			Remote version (without cable)						
diam	neter							Sensor						Transmitter	
[mm]	[inch]		(DIN) / AS ¹⁾		JIS		ANSI		(DIN) / AS ¹⁾		JIS		ANSI	Wall-mount housing	
15	1/2"		6.5		6.5		6.5		4.5		4.5		4.5		
25	1"		7.3	_	7.3		7.3		5.3		5.3		5.3		
32	-	PN 40	8.0		7.3	-	PN 40	6.0		5.3		-			
40	11/2"	H	9.4	_			9.4	Щ.	7.4		6.3		7.4		
50	2"		10.6		9.3		10.6		8.6		7.3		8.6		
65	-		12.0		11.1		-		10.0		9.1				
80	3"		14.0	10K	12.5		14.0	PN 16	12.0	10K	10.5		12.0		
100	4"	PN 16	16.0		14.7		16.0		14.0		12.7		14.0		
125	-	Д	21.5		21.0	150	-			19.5		19.0	150	-	6.0
150	6"		25.5	_	24.5	Class 150	25.5		23.5		22.5	Class	23.5	0.0	
200	8"		45	_	41.9		45		43		39.9		43		
250	10"		65		69.4		75		63		67.4		73		
300	12"		70		72.3		110		68		70.3		108		
350	14"	10	115				175	10	113				173		
400	16"	PN	135				205	PN	133				203		
450	18"		175				255		173				253		
500	20"		175				285	173			283				
600	24"		235				405		233				403		

¹⁾ For flanges to AS, only DN 25 and 50 are available.

Transmitter (compact version): 3.4 kg, high temperature version: +1.5 kg
 Weight data valid for standard pressure ratings and without packaging material.

Weight in US units (only ANSI)

Weight data	a in lbs								
Nominal	diameter		Compact version	Remote version (without cable)					
					Sensor	Transmitter			
[mm]	[inch]		ANSI		ANSI	Wall-mount housing			
15	1/2"		14.3		9.92				
25	1"		16.1		11.7				
40	1½"		20.7		16.3				
50	2"		23.4		19.0				
80	3"		30.9		26.5				
100	4"		35.3		30.9				
150	6"	56.2	00	51.8					
200	8"	Class 150	99.2	Class 150	94.8	13.2			
250	10"	ਹੋ	165.4	ਹੋ	161.0				
300	12"		242.6		238.1				
350	14"		385.9		381.5				
400	16"		452.0		447.6				
450	18"		562.3		557.9				
500	20"		628.4		624.0				
600	24"		893.0		888.6				

- Transmitter (compact version): 7.50 lbs, high temperature version: +3.31 lbs
 Weight data valid for standard pressure ratings and without packaging material.

Measuring tube specifications

Dian	neter		P	ressure ratin	ıg]	Internal diameter				
		EN (DIN)	AS 2129	AS 4087	ANSI	JIS	Pl	FA	PT	'FE		
[mm]	[inch]	[bar]			[lbs]		[mm]	[inch]	[mm]	[inch]		
15	1/2"	PN 40	-	-	C1.150	20K	-	-	15	0.59		
25	1"	PN 40	Table E	-	Cl.150	20K	23	0.91	26	1.02		
32	_	PN 40	-	-	-	20K	32	1.26	35	1.38		
40	11/2"	PN 40	-	-	C1.150	20K	36	1.42	41	1.61		
50	2"	PN 40	Table E	PN 16	Cl.150	10K	48	1.89	52	2.05		
65	_	PN 16	-	-	-	10K	63	2.48	67	2.64		
80	3"	PN 16	-	-	Cl.150	10K	75	2.95	80	3.15		
100	4"	PN 16	_	-	Cl.150	10K	101	3.98	104	4.09		
125	-	PN 16	-	-	-	10K	126	4.96	129	5.08		
150	6"	PN 16	-	-	Cl.150	10K	154	6.06	156	6.14		
200	8"	PN 10	-	-	Cl.150	10K	201	7.91	202	7.95		
250	10"	PN 10	-	-	Cl.150	10K	-	-	256	10.1		
300	12"	PN 10	-	-	Cl.150	10K	-		306	12.0		
350	14"	PN 10	_	-	Cl.150	-	_	-	337	13.3		
400	16"	PN 10	-	-	Cl.150	-	-	-	387	15.2		
450	18"	PN 10	-	-	Cl.150	-			432	17.0		
500	20"	PN 10	-	-	Cl.150	-	-	-	487	19.2		
600	24"	PN 10	-	-	C1.150	-	-	23	593	23.3		

Material

- Transmitter housing
 - Compact housing: powder-coated die-cast aluminum
 - Wall-mount housing: powder-coated die-cast aluminum
- Sensor housing
 - DN 25 to 300 (1 to 12"): powder-coated die-cast aluminum
 - DN 350 to 600 (14 to 24"): with protective lacquering
- Measuring tube
 - DN \leq 300 (12"): stainless steel 1.4301 or 1.4306/304L; (for flanges made of carbon steel with Al/Zn protective coating)
 - DN \ge 350 (14"): stainless steel 1.4301 or 1.4306/304L; (for flanges made of carbon steel with protective lacquering)
- Electrodes: 1.4435, Platinum, Alloy C-22, Tantalum, Titanium
- Flanges
 - EN 1092-1 (DIN 2501): 1.4571/316L; RSt37-2 (S235JRG2); C22; FE 410W B (DN \leq 300 (12"): with Al/Zn protective coating; DN \geq 350 (14") with protective lacquering)
 - ANSI: A105; F316L
 - (DN \leq 300 (12"): with Al/Zn protective coating; DN \geq 350 (14") with protective lacquering)
 - AWWA: 1.0425
 - JIS: RSt37-2 (S235JRG2); HII; 1.0425/316L $(DN \le 300 (12^{\circ}))$; with Al/Zn protective coating; $DN \ge 350 (14^{\circ})$ with protective lacquering)
 - - DN 25 (1"): A105 or RSt37-2 (S235JRG2)
 - DN 40 (1 ½"): A105 or St44-2 (S275JR)
 - AS 4087: A105 or St44-2 (S275JR)
- Seals: to DIN EN 1514-1
- Ground disks: 1.4435/316L or Alloy C-22

Material load diagram




Caution!

The following diagrams contain material load diagrams (reference curves) for flange materials with regard to the medium temperature. However, the maximum medium temperatures permitted always depend on the lining material of the sensor and/or the sealing material ($\rightarrow \stackrel{\triangle}{=} 21$).


Flange connection to EN 1092-1 (DIN 2501)

Material: RSt37-2 (S235JRG2) / C22 / Fe 410W B




Flange connection to EN 1092-1 (DIN 2501)

Material: 316L / 1.4571




Flange connection to ANSI B16.5

Material: A 105



Flange connection to ANSI B16.5

Material: F316L




A0005

Endress+Hauser 39

A00032

Flange connection to JIS B2220


Material: RSt37-2 (S235JRG2) / HII / 1.0425 / 316L



A000322

Flange connection to AS 2129 Table E or AS 4087 PN 16

Material: A105 / RSt37-2 (S235JRG2) / St44-2 (S275JR)



A0005595

Fitted electrodes

Measuring electrodes, reference electrodes and empty pipe detection electrodes:

- Standard available with 1.4435, Alloy C-22, tantalum, platinum/rhodium 80/20, titanium
- Optional: measuring electrodes made of platinum/rhodium 80/20

Process connections

Flange connection:

- EN 1092-1 (DIN 2501), DN \leq 300 (12") form A, DN \geq 350 (14") form B (Dimensions to DIN 2501, DN 65 PN 16 and DN 600 (24") PN 16 exclusively to EN 1092-1)
- ANSI B16.5
- JIS B2220
- AS 2129 Table E
- AS 4087 PN 16

Surface roughness

- PFA liner: $\leq 0.4 \, \mu \text{m} \, (15.7 \, \mu \text{in})$
- Elektroden
 - 1.4435, Alloy C-22, titanium: \leq 0.3 to 0.5 μ m (\leq 11.8 to 19.7 μ in)
 - − Tantal, Platin/Rhodium: \leq 0.3 to 0.5 μm (\leq 11.8 to 19.7 μin)

(All data refer to parts in contact with medium)

Human interface

Display elements

- Liquid crystal display: backlit, two lines (Promag 50) or four lines (Promag 53) with 16 characters per line
- Custom configurations for presenting different measured-value and status variables
- Totalizer
 - Promag 50: 2 totalizers
 - Promag 53: 3 totalizers

Operating elements

Unified operation concept for both types of transmitter:

Promag 50:

- Local operation via three keys (□, ±, ₺)
- Quick Setup menus for straightforward commissioning

Promag 53:

- Local operation via three keys (□, ±, ₺)
- Application-specific Quick Setup menus for straightforward commissioning

Language groups

Language groups available for operation in different countries:

Promag 50, Promag 53:

- Western Europe and America (WEA):
 English, German, Spanish, Italian, French, Dutch, Portuguese
- Eastern Europe and Scandinavia (EES):
 English, Russian, Polish, Norwegian, Finnish, Swedish, Czech
- South and east Asia (SEA): English, Japanese, Indonesian

Promag 53:

■ China (CN): English, Chinese

You can change the language group via the operating program "FieldCare".

Remote operation

- Promag 50: Remote control via HART, PROFIBUS DP/PA
- Promag 53: Remote control via HART, PROFIBUS DP/PA, MODBUS RS485, FOUNDATION Fieldbus

Certificates and approvals

CE mark The measuring system is in conformity with the statutory requirements of the EC Directives. Endress+Hauser confirms successful testing of the device by affixing to it the CE mark. C-tick mark The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)". Pressure measuring device Measuring devices with a nominal diameter smaller than or equal to DN 25 correspond to Article 3(3) of the EC Directive 97/23/EC (Pressure Equipment Directive) and have been designed and manufactured approval according to good engineering practice. Where necessary (depending on the medium and process pressure), there are additional optional approvals to Category II/III for larger nominal diameters. Ex approval Information about currently available Ex versions (ATEX, IECEx, FM, CSA, NEPSI) can be supplied by your Endress+Hauser Sales Center on request. All explosion protection data are given in a separate documentation which is available upon request. Other standards and ■ EN 60529 guidelines Degrees of protection by housing (IP code) Protection Measures for Electrical Equipment for Measurement, Control, Regulation and Laboratory Procedures. ■ IEC/EN 61326 "Emission in accordance with requirements for Class A". Electromagnetic compatibility (EMC requirements) ■ NAMUR NE 21: Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment. ■ NAMUR NE 43: Standardization of the signal level for the breakdown information of digital transmitters with analog output signal. ■ NAMUR NE 53: Software of field devices and signal-processing devices with digital electronics. ■ ANSI/ISA-S82.01 Safety Standard for Electrical and Electronic Test, Measuring, Controlling and related Equipment - General Requirements Pollution degree 2, Installation Category II. ■ CAN/CSA-C22.2 No. 1010.1-92 Safety requirements for Electrical Equipment for Measurement and Control and Laboratory Use. Pollution degree 2, Installation Category II **FOUNDATION Fieldbus** The flow device has successfully passed all the test procedures carried out and is certified and registered by the certification Fieldbus Foundation. The device thus meets all the requirements of the following specifications: ■ Certified to FOUNDATION Fieldbus Specification ■ The device meets all the specifications of the FOUNDATION Fieldbus H1. ■ Interoperability Test Kit (ITK), revision status 5.01 (device certification number: on request) ■ The device can also be operated with certified devices of other manufacturers ■ Physical Layer Conformance Test of the Fieldbus Foundation The measuring device meets all the requirements of the MODBUS/TCP conformity test and has the "MOD-**MODBUS RS485 certification**

The measuring device meets all the requirements of the MODBUS/TCP conformity test and has the "MODBUS/TCP Conformance Test Policy, Version 2.0". The measuring device has successfully passed all the test procedures carried out and is certified by the "MODBUS/TCP Conformance Test Laboratory" of the University of Michigan.

PROFIBUS DP/PA certification

The flow device has successfully passed all the test procedures carried out and is certified and registered by the PNO (PROFIBUS User Organisation). The device thus meets all the requirements of the following specifications:

- Certified to PROFIBUS PA, profile version 3.0 (device certification number: on request)
- The device can also be operated with certified devices of other manufacturers (interoperability)

Ordering information

Your Endress+Hauser service organization can provide detailed ordering information and information on the order codes on request.

Accessories

Various accessories, which can be ordered separately from Endress+Hauser, are available for the transmitter and the sensor. Your Endress+Hauser service organization can provide detailed information on the order codes in question.

Documentation

- Flow Measurement (FA005D/06)
- Operating Instructions Promag Promag 50 (BA046D/06 and BA049D/06)
- Operating Instructions Promag Promag 50 PROFIBUS PA (BA055D/06 and BA056D/06)
- Operating Instructions Promag Promag 53 (BA047D/06 and BA048D/06)
- Operating Instructions Promag Promag 53 FOUNDATION Fieldbus (BA051D/06 and BA052D/06)
- Operating Instructions Promag Promag 53 MODBUS RS485 (BA117D/06 and BA118D/06)
- Operating Instructions Promag Promag 53 PROFIBUS DP/PA (BA053D/06 and BA054D/06)
- Supplementary documentation on Ex-ratings: ATEX, IECEx, FM, CSA, NEPSI

Registered trademarks

HART®

Registered trademark of the HART Communication Foundation, Austin, USA

PROFIBUS[®]

Registered trademark of the PROFIBUS Nutzerorganisation e.V., Karlsruhe, D

FOUNDATIONTM Fieldbus

Registered trademark of the Fieldbus Foundation, Austin, USA

MODBUS®

Registered trademark of the MODBUS Organisation

HistoROM[™], S-DAT[®], T-DAT[™], F-CHIP[®], FieldCare[®], FieldCheck[®], FieldXpert[™], Applicator[®] Registered or registration-pending trademarks of Endress+Hauser Flowtec AG, Reinach, CH

Instruments International

Endress+Hauser Instruments International AG Kaegenstrasse 2 4153 Reinach Switzerland

Tel. +41 61 715 81 00 Fax +41 61 715 25 00 www.endress.com info@ii.endress.com



People for Process Automation


Products


Valid as of version V 2.04.XX (device software)


Operating Instructions **Proline Promag 50 HART**

Electromagnetic flowmeter














Table of contents

1	Safety instructions 4
1.1 1.2 1.3 1.4 1.5	Designated use
2	Identification6
2.1 2.2 2.3	Device designation6Certificates and approvals8Registered trademarks9
3	Installation
3.1 3.2 3.3 3.4	Incoming acceptance, transport and storage10Installation conditions12Installation instructions20Post-installation check45
4	Wiring46
4.1 4.2 4.3 4.4 4.5	Connecting the remote version46Connecting the measuring unit52Potential equalization55Degree of protection58Post-connection check59
5	Operation60
5.1 5.2 5.3 5.4	Display and operating elements 60 Brief operating instructions on the function matrix 61 Displaying error messages 63 Communication 64
6	Commissioning72
6.1 6.2 6.3 6.4 6.5 6.6	Function check72Switching on the measuring device72Quick Setup73Configuration74Adjustment75Data storage device (HistoROM)76
7	Maintenance
7.1	
7.2	Exterior cleaning
7.2 8	

9	Troubleshooting	81
9.1	Troubleshooting instructions	. 81
9.2	System error messages	
9.3	Process error messages	
9.4	Process errors without messages	
9.5	Response of outputs to errors	. 86
9.6	Spare parts	
9.7	Return	. 96
9.8	Disposal	. 96
9.9	Software history	. 96
10	Technical data	98
10.1	Technical data at a glance	. 98
	J	
	Index	125

Safety instructions Promag 50

1 Safety instructions

1.1 Designated use

The measuring device described in this Operating Manual is to be used only for measuring the flow rate of conductive fluids in closed pipes.

A minimum conductivity of 20 μ S/cm is required for measuring demineralized water. Most liquids can be measured as of a minimum conductivity of 5 μ S/cm.

Examples:

- Acids, alkalis
- Drinking water, wastewater, sewage sludge
- Milk, beer, wine, mineral water, etc.

Resulting from incorrect use or from use other than that designated the operational safety of the measuring devices can be suspended. The manufacturer accepts no liability for damages being produced from this.

1.2 Installation, commissioning and operation

Please note the following:

- Installation, connection to the electricity supply, commissioning and maintenance of the device must be carried out by trained, qualified specialists authorized to perform such work by the facility's owner-operator. The specialist must have read and understood this Operating Manual and must follow the instructions it contains.
- The device must be operated by persons authorized and trained by the facility's owneroperator. Strict compliance with the instructions in the Operating Manual is mandatory.
- With regard to special fluids, including fluids used for cleaning, Endress+Hauser will be happy to assist in clarifying the corrosion-resistant properties of wetted materials. However, minor changes in temperature, concentration or in the degree of contamination in the process may result in variations in corrosion resistance. For this reason, Endress+Hauser does not accept any responsibility with regard to the corrosion resistance of wetted materials in a specific application.
 - The user is responsible for the choice of suitable wetted materials in the process.
- If welding work is performed on the piping system, do not ground the welding appliance through the Promag flowmeter.
- The installer must ensure that the measuring system is correctly wired in accordance with the wiring diagrams. The transmitter must be grounded apart from when special protective measures are taken (e.g. galvanically isolated SELV or PELV power supply)
- Invariably, local regulations governing the opening and repair of electrical devices apply.

1.3 Operational safety

Please note the following:

- Measuring systems for use in hazardous environments are accompanied by separate Ex documentation, which is an integral part of this Operating Manual. Strict compliance with the installation instructions and ratings as stated in this supplementary documentation is mandatory. The symbol on the front of this Ex documentation indicates the approval and the certification body (e.g. Éx Europe, Supplementary Canada).
- The measuring device complies with the general safety requirements in accordance with EN 61010-1, the EMC requirements of IEC/EN 61326 and NAMUR Recommendations NE 21 and NE 43.
- Depending on the application, the seals of the process connections of the Promag H sensor require periodic replacement.

Promag 50 Safety instructions

When hot fluid passes through the measuring tube, the surface temperature of the housing increases. In the case of the sensor, in particular, users should expect temperatures that can be close to the fluid temperature. If the temperature of the fluid is high, implement sufficient measures to prevent burning or scalding.

 The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser distributor will supply you with current information and updates to these Operating Instructions.

1.4 Return

- Do not return a measuring device if you are not absolutely certain that all traces of hazardous substances have been removed, e.g. substances which have penetrated crevices or diffused through plastic.
- Costs incurred for waste disposal and injury (burns, etc.) due to inadequate cleaning will be charged to the owner-operator.

1.5 Notes on safety conventions and icons

The devices are designed to meet state-of-the-art safety requirements, have been tested, and left the factory in a condition in which they are safe to operate. The devices comply with the applicable standards and regulations in accordance with EN 61010-1 "Safety requirements for electrical equipment for measurement, control and laboratory use". The devices can, however, be a source of danger if used incorrectly or for anything other than the designated use. Consequently, always pay particular attention to the safety instructions indicated in this Operating Manual by the following icons:



Warning!

"Warning" indicates an action or procedure which, if not performed correctly, can result in injury or a safety hazard. Comply strictly with the instructions and proceed with care.



Caution!

"Caution" indicates an action or procedure which, if not performed correctly, can result in incorrect operation or destruction of the device. Comply strictly with the instructions.



Note!

"Note" indicates an action or procedure which, if not performed correctly, can have an indirect effect on operation or trigger an unexpected response on the part of the device.

Identification Promag 50

Identification 2


2.1 **Device designation**

The flow measuring system consists of the following components:

- Promag 50 transmitter
- Promag D/E/H/L/P/W sensor

In the *compact version*, the transmitter and sensor form a single mechanical unit; in the remote version they are installed separately.

2.1.1 Nameplate of the transmitter



Nameplate specifications for the "Promag 50" transmitter (example) Fig. 1:

 ${\it Ordering\ code/serial\ number: See\ the\ specifications\ on\ the\ order\ confirmation\ for\ the\ meanings\ of\ the\ individual\ letters\ and\ order\ or$ 1 digits.
Power supply, frequency, power consumption

- Additional information:
 - EPD/MSÜ: with Empty Pipe Detection
- ECC: with electrode cleaning 4
- Outputs available:

 - I-OUT (HART): with current output (HART) f-OUT (HART): with frequency output STATUS-IN: with status input (power supply)
- Reserved for information on special products
- Observe device documentation
- Reserved for additional information on device version (approvals, certificates)
- 6 7 8 9 Permitted ambient temperature range
- Degree of protection

Promag 50 Identification

2.1.2 Nameplate of the sensor




Fig. 2: Nameplate specifications for the "Promag" sensor (example)

- 1 Ordering code/serial number: See the specifications on the order confirmation for the meanings of the individual letters and digits.
- Calibration factor with zero point
- Nominal diameter / Pressure rating
- Fluid temperature range 4 5 6 7
- Materials: lining/measuring electrodes
- Reserved for information on special products Permitted ambient temperature range Observe device documentation
- 8
- Reserved for additional information on device version (approvals, certificates)
- Calibration tolerance
- 11 Additional information (examples):
 - EPD/MSÜ: with Empty Pipe Detection electrode
 - R/B: with reference electrode
- Degree of protection Flow direction 12 13

Identification Promag 50

2.1.3 Nameplate, connections




Fig. 3: Nameplate specifications for transmitter (example)

- 1 Serial number
- 2 Possible configuration of current output
- 3 Possible configuration of relay contacts
- Terminal assignment, cable for power supply: 85 to 260 V AC, 20 to 55 V AC, 16 to 62 V DC Terminal No. 1: L1 for AC, L+ for DC Terminal No. 2: N for AC, L- for DC
- 5 Signals present at inputs and outputs, possible configuration and terminal assignment (20 to 27), see also "Electrical values of inputs/outputs"
- 6 Version of device software currently installed
- 7 Installed communication type, e.g.: HART, PROFIBUS PA, etc.
- 8 Information on current communication software (Device Revision and Device Description), e.g.:
 Dev. 01 / DD 01 for HART
- 9 Date of installation
- 10 Current updates to data specified in points 6 to 9

2.2 Certificates and approvals

The devices are designed to meet state-of-the-art safety requirements in accordance with sound engineering practice. They have been tested and left the factory in a condition in which they are safe to operate.

The devices comply with the applicable standards and regulations in accordance with EN 61010-1 "Safety requirements for electrical equipment for measurement, control and laboratory use" and with the EMC requirements of IEC/EN 61326/A1.

The measuring system described in this Operating Manual is therefore in conformity with the statutory requirements of the EC Directives. Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.

The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".

Promag 50 Identification

2.3 Registered trademarks

 $\text{KALREZ}^{\text{\tiny{\$}}}$ and $\text{VITON}^{\text{\tiny{\$}}}$

Registered trademarks of E.I. Du Pont de Nemours & Co., Wilmington, USA

TRI-CLAMP®

Registered trademark of Ladish & Co., Inc., Kenosha, USA

HART®

Registered trademark of the HART Communication Foundation, Austin, USA

HistoROM™, S-DAT®, Field Xpert™, FieldCare®, Fieldcheck®, Applicator®

Registered or registration-pending trademarks of Endress+Hauser Flowtec AG, Reinach, CH

3 Installation

3.1 Incoming acceptance, transport and storage

3.1.1 Incoming acceptance

On receipt of the goods, check the following:

- Check the packaging and the contents for damage.
- Check the shipment, make sure nothing is missing and that the scope of supply matches your order.

3.1.2 Transport

The following instructions apply to unpacking and to transporting the device to its final location:

- Transport the devices in the containers in which they are delivered.
- Do not remove the protective plates or caps on the process connections until you are ready to install the device. This is particularly important in the case of sensors with PTFE linings.

Special notes on flanged devices



Caution!

- The wooden covers mounted on the flanges from the factory protect the linings on the flanges during storage and transportation. In case of Promag L they are additionally used to hold the lap joint flanges in place. Do not remove these covers until **immediately before** the device in the pipe.
- Do not lift flanged devices by the transmitter housing, or the connection housing in the case of the remote version.

Transporting flanged devices DN \leq 300 (12")

Use webbing slings slung round the two process connections. Do not use chains, as they could damage the housing.



Warning!

Risk of injury if the measuring device slips. The center of gravity of the assembled measuring device might be higher than the points around which the slings are slung.

At all times, therefore, make sure that the device does not unexpectedly turn around its axis or slip.




Fig. 4: Transporting sensors with DN \leq 300 (12")

Transporting flangeddevices DN > 300 (12")

Use only the metal eyes on the flanges for transporting the device, lifting it and positioning the sensor in the piping.



Caution!

Do not attempt to lift the sensor with the tines of a fork-lift truck beneath the metal casing. This would buckle the casing and damage the internal magnetic coils.




Fig. 5: Transporting sensors with DN > 300 (12")

3.1.3 Storage

Please note the following:

- Pack the measuring device in such a way as to protect it reliably against impact for storage (and transportation). The original packaging provides optimum protection.
- The storage temperature corresponds to the operating temperature range of the measuring transmitter and the appropriate measuring sensors →
 □ 101.
- Do not remove the protective plates or caps on the process connections until you are ready to install the device. This is particularly important in the case of sensors with PTFE linings.
- The measuring device must be protected against direct sunlight during storage in order to avoid unacceptably high surface temperatures.
- Choose a storage location where moisture does not collect in the measuring device. This will help prevent fungus and bacteria infestation which can damage the liner.

3.2 Installation conditions

3.2.1 Dimensions

3.2.2 Mounting location

Entrained air or gas bubble formation in the measuring tube can result in an increase in measuring errors.

Avoid the following locations:

- Highest point of a pipeline. Risk of air accumulating!
- Directly upstream from a free pipe outlet in a vertical pipeline.




Fig. 6: Mounting location

Installation of pumps

Do **not** install the sensor on the intake side of a pump. This precaution is to avoid low pressure and the consequent risk of damage to the lining of the measuring tube. Information on the lining's resistance to partial vacuum can be found on $\rightarrow \blacksquare 106$.




Fig. 7: Installation of pumps

Partially filled pipes

Partially filled pipes with gradients necessitate a drain-type configuration.



Caution!

Risk of solids accumulating. Do not install the sensor at the lowest point in the drain. It is advisable to install a cleaning valve.




Fig. 8: Installation in a partially filled pipe

Down pipes

Install a siphon or a vent valve downstream of the sensor in down pipes whose length $h \ge 5$ m (16.4 ft). This precaution is to avoid low pressure and the consequent risk of damage to the lining of the measuring tube.

This measure also prevents the system losing prime, which could cause air pockets. Information on the lining's resistance to partial vacuum can be found on $\Rightarrow \triangleq 106$.




Fig. 9: Measures for installation in a down pipe

1 Vent valve

2 Pipe siphon

h Length of down pipe

3.2.3 Orientation

An optimum orientation position helps avoid gas and air accumulations and deposits in the measuring tube. However, Promag offers the additional Empty Pipe Detection (EPD) function to ensure the detection of partially filled measuring tubes, e.g. in the case of degassing fluids or varying process pressure:

- Electrode Cleaning Circuit (ECC) for applications with accretive fluids, e.g. electrically conductive deposits (\rightarrow "Description of Device Functions" manual).
- Empty Pipe Detection (EPD) ensures the detection of partially filled measuring tubes, e.g. in the case of degassing fluids ($\rightarrow \square$ 75)
- Exchangeable Measuring Electrodes for abrasive fluids (→ 🗎 94)

Vertical orientation

This is the ideal orientation for self-emptying piping systems and for use in conjunction with Empty Pipe Detection.




Fig. 10: Vertical orientation

Horizontal orientation

The measuring electrode plane should be horizontal. This prevents brief insulation of the two measuring electrodes by entrained air bubbles.



Caution!

Empty Pipe Detection functions correctly only when the measuring device is installed horizontally and the transmitter housing is facing upward ($\rightarrow \blacksquare 10$). Otherwise there is no quarantee that Empty Pipe Detection will respond if the measuring tube is only partially filled or empty.




Fig. 11: Horizontal orientation

- EPD electrode for the detection of empty pipes (not with Promag D and Promag H (DN 2 to 15 / 1/12 to $\frac{1}{2}$ "))
- Measuring electrodes for signal detection Reference electrode for the potential equalization (not with Promag D and H)

Inlet and outlet run

If possible, install the sensor upstream from fittings such as valves, T-pieces, elbows, etc. The following inlet and outlet runs must be observed in order to meet accuracy specifications:

Inlet run: ≥ 5 × DNOutlet run: ≥ 2 × DN




Fig. 12: Inlet and outlet runs

3.2.4 Vibrations

Secure the piping and the sensor if vibration is severe.



Caution!

If vibrations are too severe, we recommend the sensor and transmitter be mounted separately. Information on resistance to vibration and shock can be found on $\rightarrow \triangleq 102$.




Fig. 13: Measures to prevent vibration of the device (L > 10 m (32.8 ft))

3.2.5 Foundations, supports

If the nominal diameter is DN \geq 350 (14"), mount the sensor on a foundation of adequate load-bearing strength.



Caution!

Risk of damage.

Do not support the weight of the sensor on the metal casing: the casing would buckle and damage the internal magnetic coils.




Fig. 14: Correct support for large nominal diameters (DN \geq 350 / 14")

3.2.6 Adapters

Suitable adapters to DIN EN 545 (double-flange reducers) can be used to install the sensor in larger-diameter pipes.

The resultant increase in the rate of flow improves measuring accuracy with very slow-moving fluids. The nomogram shown here can be used to calculate the pressure loss caused by reducers and expanders.



Note

The nomogram only applies to liquids of viscosity similar to water.

- 1. Calculate the ratio of the diameters d/D.
- 2. From the nomogram read off the pressure loss as a function of flow velocity (*downstream* from the reduction) and the d/D ratio.




Fig. 15: Pressure loss due to adapters

3.2.7 Nominal diameter and flow rate

The diameter of the pipe and the flow rate determine the nominal diameter of the sensor. The optimum velocity of flow is between 2 and 3 m/s (6.5 to 9.8 ft/s).

The velocity of flow (v), moreover, has to be matched to the physical properties of the fluid:

- v < 2 m/s (v < 6.5 ft/s): for abrasive fluids
- v > 2 m/s (v > 6.5 ft/s): for fluids producing buildup



Note!

Recommended flow (SI units)

Nominal diameter	Promag D	Promag E/P	Promag H	Promag L	Promag W		
[mm]	1	Min./max. full sca	le value (v ≈ 0.3 o	r 10 m/s) in [dm ³ /	min]		
2	-	-	0.06 to 1.8	-	-		
4	_	-	0.25 to 7	_	-		
8	_	-	1 to 30	_	-		
15	-	4 to 100	4 to 100	-	-		
25	9 to 300	9 to 300	9 to 300	-	9 to 300		
32	_	15 to 500	_	_	15 to 500		
40	25 to 700	25 to 700	25 to 700	_	25 to 700		
50	35 to 1100	35 to 1100	35 to 1100	35 to 1100	35 to 1100		
65	60 to 2000	60 to 2000	60 to 2000	60 to 2000	60 to 2000		
80	90 to 3000	90 to 3000	90 to 3000	90 to 3000	90 to 3000		
100	145 to 4700	145 to 4700	145 to 4700	145 to 4700	145 to 4700		
125	-	220 to 7500	-	220 to 7500	220 to 7500		
[mm]		Min./max. full so	cale value (v ≈ 0.3	3 or 10 m/s) in [m³/h]			
150	-	20 to 600	-	20 to 600	20 to 600		
200	-	35 to 1100	-	35 to 1100	35 to 1100		
250	-	55 to 1700	-	55 to 1700	55 to 1700		
300	-	80 to 2400	-	80 to 2400	80 to 2400		
350	-	110 to 3300	-	110 to 3300	110 to 3300		
375	-	-	-	140 to 4200	140 to 4200		
400	-	140 to 4200	-	140 to 4200	140 to 4200		
450	-	180 to 5400	-	180 to 5400	180 to 5400		
500	-	220 to 6600	-	220 to 6600	220 to 6600		
600	-	310 to 9600	-	310 to 9600	310 to 9600		
700	_	-	_	420 to 13500	420 to 13500		
750	-	-	-	480 to 15200	480 to 15200		
800	-	-	-	550 to 18000	550 to 18000		
900	-	-	-	690 to 22500	690 to 22500		
1000	-	-	-	850 to 28000	850 to 28000		
1050	-	-	-	950 to 40000	950 to 40000		
1200	-	-	-	1250 to 40000	1250 to 40000		
1400	-	-	-	-	1700 to 55000		
1600	-	-	-	-	2200 to 70000		
1800	-	-	-	-	2800 to 90000		
2000	_	-	_	-	3400 to 110000		

Recommended flow (US units)

Nominal diameter	Promag D	Promag E/P	Promag H	Promag L	Promag W
[inch]		Min./max. full scal	 e value (v ≈ 0.3	or 10 m/s) in [gal/	min]
1 1/12"	-	_	0.015 to 0.5	-	-
5/32"	-	-	0.07 to 2	-	-
5/16"	-	_	0.25 to 8	-	-
1/2"	-	1.0 to 27	1.0 to 27	-	-
1"	2.5 to 80	2.5 to 80	2.5 to 80	-	2.5 to 80
1 1/4"	-	4 to 130	-	-	4 to 130
1 1/2"	7 to 190	7 to 190	7 to 190	7 to 190	7 to 190
2"	10 to 300	10 to 300	10 to 300	10 to 300	10 to 300
2 1/2"	16 to 500	16 to 500	16 to 500	16 to 500	16 to 500
3"	24 to 800	24 to 800	24 to 800	24 to 800	24 to 800
4"	40 to 1250	40 to 1250	40 to 1250	40 to 1250	40 to 1250
5"	-	60 to 1950	-	60 to 1950	60 to 1950
6"	-	90 to 2650	-	90 to 2650	90 to 2650
8"	-	155 to 4850	-	155 to 4850	155 to 4850
10"	-	250 to 7500	- 250 to 7500		250 to 7500
12"	-	350 to 10600	-	350 to 10600	350 to 10600
14"	-	500 to 15000	-	500 to 15000	500 to 15000
15"	-	-	_	600 to 19000	600 to 19000
16"	-	600 to 19000	-	600 to 19000	600 to 19000
18"	-	800 to 24000	-	800 to 24000	800 to 24000
20"	-	1000 to 30000	_	1000 to 30000	1000 to 30000
24"	-	1400 to 44000	-	1400 to 44000	1400 to 44000
28"	-	-	_	1900 to 60000	1900 to 60000
30"	-	_	-	2150 to 67000	2150 to 67000
32"	-	-	-	2450 to 80000	2450 to 80000
36"	-	-	_	3100 to 100000	3100 to 100000
40"	-	-	_	3800 to 125000	3800 to 125000
42"	-	-	-	4200 to 135000	4200 to 135000
48"	-	-	-	5500 to 175000	5500 to 175000
[inch]		Min./max. full scal	le value (v ≈ 0.3	or 10 m/s) in [Mga	al/d]
54"	-	-	_	-	9 to 300
60"	_	-	_	-	12 to 380
66"	_	-	-	-	14 to 500
72"	-	_	-	_	16 to 570
78"	-	-	_	-	18 to 650

3.2.8 Length of connecting cable

In order to ensure measuring accuracy, comply with the following instructions when installing the remote version:

- Fix cable run or lay in armored conduit. Cable movements can falsify the measuring signal especially in the case of low fluid conductivities.
- Route the cable well clear of electrical machines and switching elements.
- Ensure potential equalization between sensor and transmitter, if necessary.
- The permitted connecting cable length L_{max} is determined by the fluid conductivity (\rightarrow 🖸 16). A minimum conductivity of 20 μ S/cm is required for measuring demineralized water. Most liquids can be measured as of a minimum conductivity of 5 μ S/cm.
- The maximum connecting cable length is 10 m (32.8 ft) when empty pipe detection (EPD \rightarrow \trianglerighteq 75) is switched on.




Fig. 16: Permissible cable length for the remote version

Area shaded gray = permitted range Lmax = connecting cable length in [m] Fluid conductivity in [µS/cm]

3.3 Installation instructions

3.3.1 Installing the Promag D sensor

The sensor is installed between the pipe flanges with a mounting kit. The device is centered using recesses on the sensor ($\rightarrow \stackrel{\triangle}{=} 21$).



Note!

A mounting kit consisting of mounting bolts, seals, nuts and washers can be ordered separately ($\Rightarrow \stackrel{\triangle}{=} 78$). Centering sleeves are provided with the device if they are required for the installation.



Caution!

When installing the transmitter in the pipe, observe the necessary torques ($\Rightarrow \stackrel{\triangle}{=} 22$).




Fig. 17: Mounting the sensor

- 1 Nut
- 2 Washer
- 3 Mounting bolt
- 4 Centering sleeve
- 5 Seal

Seals

When installing the sensor, make sure that the seals used do not project into the pipe cross-section.



Caution!

Risk of short circuit! Do not use electrically conductive sealing compounds such as graphite! An electrically conductive layer could form on the inside of the measuring tube and short-circuit the measuring signal.



Note!

Use seals with a hardness rating of 70° Shore.

Arrangement of the mounting bolts and centering sleeves

The device is centered using recesses on the sensor. The arrangement of the mounting bolts and the use of the centering sleeves supplied depend on the nominal diameter, the flange standard und the pitch circle diameter.

		Process connection	
	EN (DIN)	ASME	JIS
DN 25 to 40 (1 to 1 ½")			
	A0010896	A0010824	A0010896
DN 50 (2")			
D27.65.(.)	A0010897	A0010825	A0010825
DN 65 (-)	3 2 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3		A0012171
DN 80 (3")	1 0 1 1 A0010898	A0010827	A0010826
DN 100 (4")	1 1 1 1 A0012168	1 1 1 A0012168	A0012169

- 1 = Mounting bolts with centering sleeves
- 2 = EN (DIN) flanges: 4-hole \rightarrow with centering sleeves
- 3 = EN (DIN) flanges: 8-hole \rightarrow without centering sleeves

Screw tightening torques (Promag D)

Please note the following:

- The tightening torques listed below are for lubricated threads only.
- Always tighten the screws uniformly and in diagonally opposite sequence.
- Overtightening the screws will deform the sealing faces or damage the seals.
- The tightening torques listed below apply only to pipes not subjected to tensile stress.

The tightening torques apply to situations where an EPDM soft material flat seal (e.g. 70 Shore) is used.

Tightening torques, mounting bolts and centering sleeves for EN (DIN) PN 16

Nominal diameter	Mounting bolts	Centering sleeve length	Tightening torque [Nm] with a process flange with a	
[mm]	[mm]	[mm]	smooth seal face	raised face
25	4 × M12 × 145	54	19	19
40	4 × M16 × 170	68	33	33
50	4 × M16 × 185	82	41	41
65 ¹⁾	4 × M16 × 200	92	44	44
65 ²⁾	8 × M16 × 200	_ 3)	29	29
80	8 × M16 × 225	116	36	36
100	8 × M16 × 260	147	40	40

¹⁾ EN (DIN) flanges: 4-hole \rightarrow with centering sleeves

Tightening torques, mounting bolts and centering sleeves for JIS 10K

Nominal diameter	Mounting bolts	Centering sleeve length	Tightening torque [Nm] with a process flange with a	
[mm]	[mm]	[mm]	smooth seal face	raised face
25	4 × M16 × 170	54	24	24
40	4 × M16 × 170	68	32	25
50	4 × M16 × 185	- *	38	30
65	4 × M16 × 200	- *	42	42
80	8 × M16 × 225	_ *	36	28
100	8 × M16 × 260	- *	39	37
* A centering sle	eeve is not required. The o	device is centered directly	via the sensor housing.	

Tightening torques, mounting bolts and centering sleeves for ASME Class 150

Nominal diameter	Mounting bolts	Centering sleeve length	Tightening torque [lbf · ft] with a process flange with a		
[inch]	[inch]	[inch]	smooth seal face raised fac		
1"	4 × UNC 1/2" × 5.70"	_ *	14	7	
1 1/2"	4 × UNC 1/2" × 6.50"	- *	21	14	
2"	4 × UNC 5/8" × 7.50"	_ *	30	27	
3"	4 × UNC 5/8" × 9.25"	- *	31	31	
4"	8 × UNC 5/8" × 10,4"	5,79	28	28	
* A centering sl	eeve is not required. The o	device is centered directly	via the sensor housing.	,	

 $^{^{2)}\,\}text{EN}$ (DIN) flanges: 8-hole \rightarrow without centering sleeves

³⁾ A centering sleeve is not required. The device is centered directly via the sensor housing.

3.3.2 Installing the Promag E sensor



Caution!

• The protective covers mounted on the two sensor flanges guard the PTFE, which is turned over the flanges. Consequently, do not remove these covers until **immediately before** the sensor is installed in the pipe.

- The covers must remain in place while the device is in storage.
- Make sure that the lining is not damaged or removed from the flanges.



Note:

Bolts, nuts, seals, etc. are not included in the scope of supply and must be supplied by the customer.

The sensor is designed for installation between the two piping flanges.

- Observe in any case the necessary screw tightening torques on $\rightarrow \triangleq 24$
- If grounding disks are used, follow the mounting instructions which will be enclosed with the shipment




Fig. 18: Installing the Promag E sensor

Seals

Comply with the following instructions when installing seals:

- PFA or PTFE lining → No seals are required!
- For DIN flanges, use only seals according to EN 1514-1.
- Make sure that the seals do not protrude into the piping cross-section.



Caution

Risk of short circuit! Do not use electrically conductive sealing compounds such as graphite! An electrically conductive layer could form on the inside of the measuring tube and short-circuit the measuring signal.

Ground cable

- If necessary, special ground cables for potential equalization can be ordered as an accessory ($\rightarrow \cong 78$).
- Information on potential equalization and detailed mounting instructions for the use of ground cables can be found on \rightarrow $\stackrel{ riangle}{=}$ 55

Tightening torques for threaded fasteners (Promag E)

Please note the following:

- The tightening torques listed below are for lubricated threads only.
- Always tighten the screws uniformly and in diagonally opposite sequence.
- Overtightening the screws will deform the sealing faces or damage the seals.
- The tightening torques listed below apply only to pipes not subjected to tensile stress.

Tightening torques for:

- EN (DIN) → 🖺 24
- ASME → 🖺 25
- JIS → 🖺 25

Promag E tightening torques for EN (DIN)

Nominal diameter [mm]	EN (DIN) Pressure rating [bar]	Threaded fasteners	Max. tightening torque [Nm]
15	PN 40	4 × M 12	11
25	PN 40	4 × M 12	26
32	PN 40	4 × M 16	41
40	PN 40	4 × M 16	52
50	PN 40	4 × M 16	65
65 *	PN 16	8 × M 16	43
80	PN 16	8 × M 16	53
100	PN 16	8 × M 16	57
125	PN 16	8 × M 16	75
150	PN 16	8 × M 20	99
200	PN 10	8 × M 20	141
200	PN 16	12 × M 20	94
250	PN 10	12 × M 20	110
250	PN 16	12 × M 24	131
300	PN 10	12 × M 20	125
300	PN 16	12 × M 24	179
350	PN 6	12 × M 20	200
350	PN 10	16 × M 20	188
350	PN 16	16 × M 24	254
400	PN 6	16 × M 20	166
400	PN 10	16 × M 24	260
400	PN 16	16 × M 27	330
450	PN 6	16 × M 20	202
450	PN 10	20 × M 24	235
450	PN 16	20 × M 27	300
500	PN 6	20 × M 20	176
500	PN 10	20 × M 24	265
500	PN 16	20 × M 30	448
600	PN 6	20 × M 24	242
600	PN 10	20 × M 27	345
600 *	PN 16	20 × M 33	658
* Designed acc. to EN 109	2-1 (not to DIN 2501)		

Promag E tightening torques for ASME

Nominal	diameter	ASME		Max. tighte	ning torque
		Pressure rating		PT	FE
[mm]	[inch]	[lbs]	Threaded fasteners	[Nm]	[lbf⋅ft]
15	1/2"	Class 150	4 × ½"	6	4
25	1"	Class 150	4 × ½"	11	8
40	1 ½"	Class 150	4 × ½"	24	18
50	2"	Class 150	4 × 5/8"	47	35
80	3"	Class 150	4 × 5/8"	79	58
100	4"	Class 150	8 × 5/8"	56	41
150	6"	Class 150	8 × ¾"	106	78
200	8"	Class 150	8 × ¾"	143	105
250	10"	Class 150	12 × 7/8"	135	100
300	12"	Class 150	12 × 7/8"	178	131
350	14"	Class 150	12 × 1"	260	192
400	16"	Class 150	16 × 1"	246	181
450	18"	Class 150	16 × 1 1/8"	371	274
500	20"	Class 150	20 × 1 1/8"	341	252
600	24"	Class 150	20 × 1 1/4"	477	352

Promag E tightening torques for JIS

Nominal diameter	JIS		Max. tightening torque [Nm]
[mm]	Pressure rating	Threaded fasteners	PTFE
15	20K	4 × M 12	16
25	20K	4 × M 16	32
32	20K	4 × M 16	38
40	20K	4 × M 16	41
50	10K	4 × M 16	54
65	10K	4 × M 16	74
80	10K	8 × M 16	38
100	10K	8 × M 16	47
125	10K	8 × M 20	80
150	10K	8 × M 20	99
200	10K	12 × M 20	82
250	10K	12 × M 22	133
300	10K	16 × M 22	99


3.3.3 Installing the Promag H sensor

The sensor is supplied to order, with or without pre-installed process connections. Preinstalled process connections are secured to the sensor with 4 or 6 hex-head threaded fasteners.



Caution!

The sensor might require support or additional attachments, depending on the application and the length of the piping run. When plastic process connections are used, the sensor must be additionally supported mechanically. A wall-mounting kit can be ordered separately from Endress+Hauser as an accessory ($\rightarrow \triangleq 78$).



Promag H process connections (DN 2 to 25 / 1/12 to 1", DN 40 to 100 / 1½ to 4") Abb. 19:

 $A = DN \ 2$ to $25 \ / \ 1/12$ to 1": process connections with O-ring

- welding flanges (DIN EN ISO 1127, ODT / SMS),
- flange (EN (DIN), ASME, JIS), flange PVDF (EN (DIN), ASME, JIS)
- external and internal thread, hose connection, PVC adhesive fitting

 $B = DN\ 2$ to 25 / 1/12 to 1": process connections with aseptic gasket vseal

- weld nipples (DIN 11850, ODT/SMS)
- Clamp (ISO 2852, DIN 32676, L14 AM7)
- coupling (DIN 11851, DIN 11864-1, SMS 1145)
- flange DIN 11864-2

C = DN 40 to 100 / $1\frac{1}{2}$ to 4": process connections with aseptic gasket seal – weld nipples (DIN 11850, ODT/SMS)

- Clamp (ISO 2852, DIN 32676, L14 AM7)
- coupling (DIN 11851, DIN 11864-1, ISO 2853, SMS 1145)
- flange DIN 11864-2

Seals

When installing the process connections, make sure that the seals are clean and correctly centered.



Caution!

- With metal process connections, you must fully tighten the screws. The process connection forms a metallic connection with the sensor, which ensures a defined compression of the seal.
- With plastic process connections, note the max. torques for lubricated threads (7 Nm / 5.2 lbf ft). With plastic flanges, always use seals between connection and counter flange.
- The seals must be replaced periodically, depending on the application, particularly in the case of gasket seals (aseptic version)!

The period between changes depends on the frequency of cleaning cycles, the cleaning temperature and the fluid temperature. Replacement seals can be ordered as accessories → 🖺 78.

Usage and assembly of ground rings (DN 2 to 25 / 1/12 to 1")

In case the process connections are made of plastic (e.g. flanges or adhesive fittings), the potential between the sensor and the fluid must be equalized using additional ground rings. If the ground rings are not installed this can affect the accuracy of the measurements or cause the destruction of the sensor through the electrochemical erosion of the electrodes.



Caution!

- Depending on the option ordered, plastic disks may be installed at the process connections instead of ground rings. These plastic disks serve only as spacers and have no potential equalization function. In addition, they provide a sealing function at the interface between the sensor and process connection. For this reason, with process connections without ground rings, these plastic disks/seals must not be removed, or must always be installed.
- Ground rings can be ordered separately from Endress+Hauser as accessories ($\rightarrow \boxminus 78$). When placing the order, make certain that the ground ring is compatible with the material used for the electrodes. Otherwise, there is a risk that the electrodes may be destroyed by electrochemical corrosion! Information about the materials can be found on $\rightarrow \boxminus 117$.
- Ground rings, including the seals, are mounted within the process connections. Therefore, the fitting length is not affected.
- 1. Loosen the four or six hexagonal headed bolts (1) and remove the process connection from the sensor (4).
- 2. Remove the plastic disk (3), including the two O-ring seals (2).
- 3. Place one seal (2) in the groove of the process connection.
- 4. Place the metal ground ring (3) on the process connection.
- 5. Now place the second seal (2) in the groove of the ground ring.
- Finally, mount the process connection on the sensor again.
 With plastic process connections, note the max. torques for lubricated threads (7 Nm / 5.2 lbf ft).




Fig. 20: Installing ground rings with Promag H (DN 2 to 25 / 1/12 to 1")

- 1 = Hexagonal-headed bolt (process connection)
- 2 = O-ring seals
- 3 = Ground ring or plastic disk (spacer)
- 4 = Sensor

Welding the transmitter into the piping (weld nipples)



Caution!

Risk of destroying the measuring electronics. Make sure that the welding machine is *not* grounded via the sensor or the transmitter.

- 1. Tack-weld the sensor into the pipe. A suitable welding jig can be ordered separately as an accessory ($\Rightarrow \triangleq 78$).
- 2. Loosen the screws on the process connection flange and remove the sensor, complete with the seal, from the pipe.
- 3. Weld the process connection to the pipe.
- 4. Reinstall the sensor in the pipe. Make sure that everything is clean and that the seal is correctly seated.



Note!

- If thin-walled foodstuffs pipes are not welded correctly, the heat could damage the installed seal. It is therefore advisable to remove the sensor and the seal prior to welding.
- The pipe has to be spread approximately 8 mm to permit disassembly.

Cleaning with pigs

If pigs are used for cleaning, it is essential to take the inside diameters of the measuring tube and process connection into account. All the dimensions and lengths of the sensor and transmitter are provided in the separate documentation "Technical Documentation" $\rightarrow \blacksquare$ 124.

3.3.4 Installing the Promag L sensor



Caution!

■ The protective covers mounted on the two sensor flanges (DN 50 to 300 / 2 to 12") are used to hold the lap joint flanges in place and to protect the PTFE liner during transportation. Consequently, do not remove these covers until immediately before the sensor is installed in the pipe.

- The covers must remain in place while the device is in storage.
- Make sure that the lining is not damaged or removed from the flanges.



Note

Bolts, nuts, seals, etc. are not included in the scope of supply and must be supplied by the customer.

The sensor is designed for installation between the two piping flanges.

- Observe in any case the necessary screw tightening torques on $\rightarrow \triangleq 30$
- If grounding disks are used, follow the mounting instructions which will be enclosed with the shipment
- To comply with the device specification, a concentrical installation in the measuring section is required




Fig. 21: Installing the Promag L sensor

Seals

Comply with the following instructions when installing seals:

- Hard rubber lining → additional seals are **always** necessary.
- Polyurethane lining \rightarrow **no** seals are required.
- PTFE lining \rightarrow **no** seals are required.
- For DIN flanges, use only seals according to EN 1514-1.
- Make sure that the seals do not protrude into the piping cross-section.



Caution!

Risk of short circuit!

Do not use electrically conductive sealing compounds such as graphite! An electrically conductive layer could form on the inside of the measuring tube and short-circuit the measuring signal.

Ground cable

- Information on potential equalization and detailed mounting instructions for the use of ground cables can be found on $\rightarrow \blacksquare$ 57.

Screw tightening torques (Promag L)

Please note the following:

- The tightening torques listed below are for lubricated threads only.
- Always tighten the screws uniformly and in diagonally opposite sequence.
- Overtightening the screws will deform the sealing faces or damage the seals.
- The tightening torques listed below apply only to pipes not subjected to tensile stress.

Promag L tightening torques for EN (DIN)

Nominal diameter	EN (DIN)		Max. tightening torque				
			Hard rubber	Polyurethane	PTFE		
[mm]	Pressure rating	Threaded fas-	[Nm]	[Nm]	[Nm]		
	[bar]	teners					
50	PN 10/16	4 × M 16	-	15	40		
65*	PN 10/16	8 × M 16	-	10	22		
80	PN 10/16	8 × M 16	-	15	30		
100	PN 10/16	8 × M 16	-	20	42		
125	PN 10/16	8 × M 16	-	30	55		
150	PN 10/16	8 × M 20	-	50	90		
200	PN 10	8 × M 20	-	65	130		
250	PN 10	12 × M 20	-	50	90		
300	PN 10	12 × M 20	-	55	100		
350	PN 6	12 × M 20	111	120	-		
350	PN 10	16 × M 20	112	118	-		
400	PN 6	16 × M 20	90	98	-		
400	PN 10	16 × M 24	151	167	-		
450	PN 6	16 × M 20	112	126	-		
450	PN 10	20 × M 24	153	133	-		
500	PN 6	20 × M 20	119	123	-		
500	PN 10	20 × M 24	155	171	-		
600	PN 6	20 × M 24	139	147	-		
600	PN 10	20 × M 27	206	219	-		
700	PN 6	24 × M 24	148	139	-		
700	PN 10	24 × M 27	246	246	-		
800	PN 6	24 × M 27	206	182	-		
800	PN 10	24 × M 30	331	316	-		
900	PN 6	24 × M 27	230	637	-		
900	PN 10	28 × M 30	316	307	-		
1000	PN 6	28 × M 27	218	208	-		
1000	PN 10	28 × M 33	402	405	-		
1200	PN 6	32 × M 30	319	299	-		
1200	PN 10	32 × M 36	564	568	-		
* Designed acc. to EN 3	1092-1 (not to DIN 2	2501)					

Promag L tightening torques for ASME

	l diame- er	ASME	Threaded fasteners	Max. tightening torque					
		Pressure rating		Hard 1	rubber	Polyur	ethane	PT	FE
[mm]	[inch]	[lbs]		[Nm]	[lbf·ft]	[Nm]	[lbf·ft]	[Nm]	[lbf·ft]
50	2"	Class 150	4 × 5/8"	-	-	15	11	40	29
80	3"	Class 150	4 × 5/8"	-	-	25	18	65	48
100	4"	Class 150	8 × 5/8"	-	-	20	15	44	32
150	6"	Class 150	8 × ¾,"	-	-	45	33	90	66
200	8"	Class 150	8 × ¾,"	-	-	65	48	125	92
250	10"	Class 150	12 × 7/8"	-	-	55	41	100	74
300	12"	Class 150	12 × 7/8"	-	-	68	56	115	85
350	14"	Class 150	12 × 1"	135	100	158	117	-	-
400	16"	Class 150	16 × 1"	128	94	150	111	-	-

Nomina te	l diame- er	ASME	Threaded fasteners	Max. tightening torque					
		Pressure rating		Hard rubber Polyurethane PTFE			FE		
[mm]	[inch]	[lbs]		[Nm]	[lbf·ft]	[Nm]	[lbf·ft]	[Nm]	$[lbf \cdot ft]$
450	18"	Class 150	16 × 1 1/8"	204	150	234	173	-	-
500	20"	Class 150	20 × 1 1/8"	183	135	217	160	-	-
600	24"	Class 150	20 × 1 ¼"	268	198	307	226	-	-

${\it Promag L tightening torques for AWWA}$

Nomina te		AWWA	Threaded fasteners		М	ax. tighte	ning torqu	ıe	
		Pressure rating		Hartg	ummi	Polyur	ethane	PT	FE
[mm]	[inch]			[Nm]	[lbf·ft]	[Nm]	[lbf·ft]	[Nm]	[lbf·ft]
700	28"	Class D	28 × 1 ¼"	247	182	292	215	-	-
750	30"	Class D	28 × 1 ¼"	287	212	302	223	-	-
800	32"	Class D	28 × 1 ½"	394	291	422	311	-	-
900	36"	Class D	32 × 1 ½"	419	309	430	317	-	-
1000	40"	Class D	36 × 1 ½"	420	310	477	352	-	-
1050	42"	Class D	36 × 1 ½"	528	389	518	382	-	-
1200	48"	Class D	44 × 1 ½"	552	407	531	392	ı	-

Promag L tightening torques for AS 2129

Nominal dia- meter	AS 2129	Threaded fasteners	Max. tightening torque			
	Pressure rating		Hard rubber	Polyurethane	PTFE	
[mm]			[Nm]	[Nm]	[Nm]	
350	Table E	12 × M 24	203	-	-	
400	Table E	12 × M 24	226	-	-	
450	Table E	16 × M 24	226	-	-	
500	Table E	16 × M 24	271	-	-	
600	Table E	16 × M 30	439	-	-	
700	Table E	20 × M 30	355	-	-	
750	Table E	20 × M 30	559	-	-	
800	Table E	20 × M 30	631	-	-	
900	Table E	24 × M 30	627	-	-	
1000	Table E	24 × M 30	634	-	-	
1200	Table E	32 × M 30	727	-	-	

Promag L tightening torques for AS 4087

Nominal dia- meter	AS 4087	Threaded fasteners	Max. tightening torque				
	Pressure rating		Hard rubber	Polyurethane	PTFE		
[mm]			[Nm]	[Nm]	[Nm]		
350	PN 16	12 × M 24	203	-	-		
375	PN 16	12 × M 24	137	-	-		
400	PN 16	12 × M 24	226	-	-		
450	PN 16	12 × M 24	301	-	-		
500	PN 16	16 × M 24	271	-	-		
600	PN 16	16 × M 27	393	-	-		
700	PN 16	20 × M 27	330	-	-		
750	PN 16	20 × M 30	529	-	-		
800	PN 16	20 × M 33	631	-	-		
900	PN 16	24 × M 33	627	-	-		
1000	PN 16	24 × M 33	595	-	-		
1200	PN 16	32 × M 33	703	-	-		

3.3.5 Installing the Promag P sensor



Caution!

- The protective covers mounted on the two sensor flanges guard the PTFE, which is turned over the flanges. Consequently, do not remove these covers until **immediately before** the sensor is installed in the pipe.
- The covers must remain in place while the device is in storage.
- Make sure that the lining is not damaged or removed from the flanges.



Note

Bolts, nuts, seals, etc. are not included in the scope of supply and must be supplied by the customer.

The sensor is designed for installation between the two piping flanges.

- Observe in any case the necessary screw tightening torques on $\rightarrow \triangleq 33$
- If grounding disks are used, follow the mounting instructions which will be enclosed with the shipment




Fig. 22: Installing the Promag P sensor

Seals

Comply with the following instructions when installing seals:

- PFA or PTFE lining → No seals are required!
- For DIN flanges, use only seals according to EN 1514-1.
- Make sure that the seals do not protrude into the piping cross-section.



Caution!

Risk of short circuit! Do not use electrically conductive sealing compounds such as graphite! An electrically conductive layer could form on the inside of the measuring tube and short-circuit the measuring signal.

Ground cable

- Information on potential equalization and detailed mounting instructions for the use of ground cables can be found on \rightarrow $\stackrel{\triangle}{=}$ 55

Installing the high-temperature version (with PFA lining)

The high-temperature version has a housing support for the thermal separation of sensor and transmitter. The high-temperature version is always used for applications in which high ambient temperatures are encountered **in conjunction with** high fluid temperatures. The high-temperature version is obligatory if the fluid temperature exceeds $+150\,^{\circ}$ C.



Note

You will find information on permissible temperature ranges on $\rightarrow \triangleq 103$

Insulation

Pipes generally have to be insulated if they carry very hot fluids, in order to avoid energy losses and to prevent accidental contact with pipes at temperatures that could cause injury. Guidelines regulating the insulation of pipes have to be taken into account.



Caution!

Risk of measuring electronics overheating. The housing support dissipates heat and its entire surface area must remain uncovered. Make sure that the sensor insulation does not extend past the top of the two sensor shells.




Fig. 23: Promag P (high-temperature version): Insulating the pipe

Tightening torques for threaded fasteners (Promag P)

Please note the following:

- The tightening torques listed below are for lubricated threads only.
- Always tighten the screws uniformly and in diagonally opposite sequence.
- Overtightening the screws will deform the sealing faces or damage the seals.
- The tightening torques listed below apply only to pipes not subjected to tensile stress.

Tightening torques for:

- EN (DIN) → 🖺 34
- ASME → 🗎 34
- JIS → 🗎 35
- AS 2129 → 🖺 35
- AS 4087 → 🖺 35

Promag P tightening torques for EN (DIN)

Nominal diameter	EN (DIN)	Threaded	Max. tightenin	g torque [Nm]
[mm]	Pressure rating [bar]	fasteners	PTFE	PFA
15	PN 40	4 × M 12	11	-
25	PN 40	4 × M 12	26	20
32	PN 40	4 × M 16	41	35
40	PN 40	4 × M 16	52	47
50	PN 40	4 × M 16	65	59
65 *	PN 16	8 × M 16	43	40
65	PN 40	8 × M 16	43	40
80	PN 16	8 × M 16	53	48
80	PN 40	8 × M 16	53	48
100	PN 16	8 × M 16	57	51
100	PN 40	8 × M 20	78	70
125	PN 16	8 × M 16	75	67
125	PN 40	8 × M 24	111	99
150	PN 16	8 × M 20	99	85
150	PN 40	8 × M 24	136	120
200	PN 10	8 × M 20	141	101
200	PN 16	12 × M 20	94	67
200	PN 25	12 × M 24	138	105
250	PN 10	12 × M 20	110	_
250	PN 16	12 × M 24	131	_
250	PN 25	12 × M 27	200	_
300	PN 10	12 × M 20	125	_
300	PN 16	12 × M 24	179	_
300	PN 25	16 × M 27	204	_
350	PN 10	16 × M 20	188	_
350	PN 16	16 × M 24	254	_
350	PN 25	16 × M 30	380	_
400	PN 10	16 × M 24	260	_
400	PN 16	16 × M 27	330	_
400	PN 25	16 × M 33	488	_
450	PN 10	20 × M 24	235	_
450	PN 16	20 × M 27	300	_
450	PN 25	20 × M 33	385	_
500	PN 10	20 × M 24	265	_
500	PN 16	20 × M 30	448	-
500	PN 25	20 × M 33	533	_
600	PN 10	20 × M 27	345	_
600 *	PN 16	20 × M 33	658	_
600	PN 25	20 × M 36	731	_
* Designed acc. to EN	1092-1 (not to DIN 2501)		I	

Promag P tightening torques for ASME

Nominal diameter ASM		ASME			Max. tighte	ning torque	2
		Pressure	Threaded	PT	'FE	PFA	
[mm]	[inch]	rating [lbs]	fasteners	[Nm]	[lbf⋅ft]	[Nm]	[lbf·ft]
15	1/2"	Class 150	4 × ½"	6	4	-	-
15	1/2"	Class 300	4 × ½"	6	4	-	-
25	1"	Class 150	4 × ½"	11	8	10	7
25	1"	Class 300	4 × 5/8"	14	10	12	9
40	1 ½"	Class 150	4 × ½"	24	18	21	15
40	1 ½"	Class 300	4 × 3/4"	34	25	31	23
50	2"	Class 150	4 × 5/8"	47	35	44	32
50	2"	Class 300	8 × 5/8"	23	17	22	16
80	3"	Class 150	4 × 5/8"	79	58	67	49

Nominal	diameter	ASME		Max. tightening torque			:	
		Pressure	Threaded	PTFE		Pl	PFA	
[mm]	[inch]	rating [lbs]	fasteners	[Nm]	[lbf · ft]	[Nm]	[lbf·ft]	
80	3"	Class 300	8 × ¾"	47	35	42	31	
100	4"	Class 150	8 × 5/8"	56	41	50	37	
100	4"	Class 300	8 × ¾,"	67	49	59	44	
150	6"	Class 150	8 × ¾,"	106	78	86	63	
150	6"	Class 300	12 × ¾"	73	54	67	49	
200	8"	Class 150	8 × ¾,"	143	105	109	80	
250	10"	Class 150	12 × 7/8"	135	100	-	-	
300	12"	Class 150	12 × 7/8"	178	131	-	-	
350	14"	Class 150	12 × 1"	260	192	-	-	
400	16"	Class 150	16 × 1"	246	181	-	-	
450	18"	Class 150	16 × 1 1/8"	371	274	-	-	
500	20"	Class 150	20 × 1 1/8"	341	252	-	-	
600	24"	Class 150	20 × 1 ¼"	477	352	ı	_	

Promag P tightening torques for JIS

Nominal diameter	JIS		Max. tightenii	ng torque [Nm]
[mm]	Pressure rating	Threaded fasteners	PTFE	PFA
25	10K	4 × M 16	32	27
25	20K	4 × M 16	32	27
32	10K	4 × M 16	38	-
32	20K	4 × M 16	38	-
40	10K	4 × M 16	41	37
40	20K	4 × M 16	41	37
50	10K	4 × M 16	54	46
50	20K	8 × M 16	27	23
65	10K	4 × M 16	74	63
65	20K	8 × M 16	37	31
80	10K	8 × M 16	38	32
80	20K	8 × M 20	57	46
100	10K	8 × M 16	47	38
100	20K	8 × M 20	75	58
125	10K	8 × M 20	80	66
125	20K	8 × M 22	121	103
150	10K	8 × M 20	99	81
150	20K	12 × M 22	108	72
200	10K	12 × M 20	82	54
200	20K	12 × M 22	121	88
250	10K	12 × M 22	133	_
250	20K	12 × M 24	212	_
300	10K	16 × M 22	99	-
300	20K	16 × M 24	183	_

Promag P tightening torques for AS 2129

Nominal diameter [mm]	AS 2129 Pressure rating	Threaded fasteners	Max. tightening torque [Nm] PTFE
25	Table E	4 × M 12	21
50	Table E	4 × M 16	42

Promag P tightening torques for AS 4087

Nominal diameter	AS 4087	Threaded fasteners	Max. tightening torque [Nm]
[mm]	Pressure rating		PTFE
50	PN 16	4 × M 16	42

3.3.6 Installing the Promag W sensor



Note!

Bolts, nuts, seals, etc. are not included in the scope of supply and must be supplied by the customer.

The sensor is designed for installation between the two piping flanges.

- Observe in any case the necessary screw tightening torques on $\rightarrow \triangleq 36$
- If grounding disks are used, follow the mounting instructions which will be enclosed with the shipment




Fig. 24: Installing the Promag W sensor

Seals

Comply with the following instructions when installing seals:

- Hard rubber lining \rightarrow additional seals are **always** necessary.
- Polyurethane lining \rightarrow **no** seals are required.
- For DIN flanges, use only seals according to EN 1514-1.
- Make sure that the seals do not protrude into the piping cross-section.



Caution!

Risk of short circuit!

Do not use electrically conductive sealing compounds such as graphite! An electrically conductive layer could form on the inside of the measuring tube and short-circuit the measuring signal.

Ground cable

- Information on potential equalization and detailed mounting instructions for the use of ground cables can be found on \rightarrow \cong 57

Screw tightening torques (Promag W)

Please note the following:

- The tightening torques listed below are for lubricated threads only.
- $\ \ \, \blacksquare$ Always tighten the screws uniformly and in diagonally opposite sequence.
- Overtightening the screws will deform the sealing faces or damage the seals.
- The tightening torques listed below apply only to pipes not subjected to tensile stress.

Tightening torques for:

- EN (DIN) → 🖹 37
- JIS→ 🖺 39
- ASME → 🖺 38
- AWWA → 🗎 39
- AS 2129 → 🗎 40
- AS 4087 → 🖺 40

Promag W tightening torques for EN (DIN)

	TTI	Max. tightening torque [Nm]	
Pressure rating [bar]	Threaded fasteners	Hard rubber	Polyurethane
_		-	15
		-	24
		-	31
		48	40
			27
			27
PN 16			34
PN 40			34
PN 16	8 × M 16		36
			50
			48
			71
			63
			88
			91
			61
			92
			71
			85
			134
			81
			118
			138
			120
			118
			165
			252
			98
			167
			215
			326
			126
			133
			196
			253
			123
			171
			300
			360
			147
			219
			443
			516
			139
			246
			318
	PN 40	PN 40 PN 16 PN 40 PN 40 PN 16 PN 40 PN 25 PN 25 PN 25 PN 16 PN 25 PN 6 PN 25 PN 6 PN 16 PN 25 PN 6 PN 16 PN 25 PN 16 PN 25 PN 16 PN 25 PN 6 PN 10 PN 16 PN 25 PN 6 PN 10 PN 16 PN 20 PN 10 PN 20 PN 10 PN 20 PN 10 PN 25 PN 33 PN 6 PN 6 PN 10 PN 10 PN 16 PN 10 PN 16 PN 10 PN 16 PN 20 PN 10 PN 16 PN 20 PN 10 PN 16 PN 20 PN 33 PN 6 PN 6 PN 10 PN 16 PN 10 PN 16 PN 20 PN 10 PN 16 PN 20 PN 33 PN 6 PN 6 PN 10 PN 16 PN 10 PN 16 PN 20 PN 33 PN 6 PN 10 PN 16 PN 20 PN 33 PN 6 PN 10 PN 16 PN 20 PN 33 PN 6 PN 10 PN 16 PN 20 PN 33 PN 6 PN 6 PN 10 PN 10 PN 10 PN 16 PN 20 PN 33 PN 6 PN 10 PN 16 PN 20 PN 33 PN 6 PN 6 PN 10 PN 24 PN 10 PN 10 PN 16 PN 20 PN 33 PN 6 PN 10 PN 25 PN 6 PN 10 PN	PN 40

Nominal	EN (DIN)		Max. tighteni	ng torque [Nm]
diameter [mm]	Pressure rating [bar]	Threaded fasteners	Hard rubber	Polyurethane
700	PN 25	24 × M 39	449	507
800	PN 6	24 × M 27	206	182
800	PN 0	24 × M 30	331	316
800	PN 16	24 × M 36	369	385
800	PN 25	24 × M 45	664	721
900	PN 6	24 × M 27	230	637
900	PN 10	28 × M 30	316	307
900	PN 16	28 × M 36	353	398
900	PN 25	28 × M 45	690	716
1000	PN 6	28 × M 27	218	208
1000	PN 10	$28 \times M33$	402	405
1000	PN 16	28 × M 39	502	518
1000	PN 25	28 × M 52	970	971
1200	PN 6	32 × M 30	319	299
1200	PN 10	32 × M 36	564	568
1200	PN 16	32 × M 45	701	753
1400	PN 6	36 × M 33	430	398
1400	PN 10	36 × M 39	654	618
1400	PN 16	36 × M 45	729	762
1600	PN 6	40 × M 33	440	417
1600	PN 10	40 × M 45	946	893
1600	PN 16	40 × M 52	1007	1100
1800	PN 6	44 × M 36	547	521
1800	PN 10	44 × M 45	961	895
1800	PN 16	44 × M 52	1108	1003
2000	PN 6	48 × M 39	629	605
2000	PN 10	48 × M 45	1047	1092
2000	PN 16	48 × M 56	1324	1261
* Designed acc. to I	EN 1092-1 (not to DIN 2501))		

Promag W tightening torques for ASME

Nominal ASME Max. tightenin		ning torque	2				
dian	neter	Pressure rating	Threaded	Hard	rubber	Polyur	ethane
[mm]	[inch]	[lbs]	fasteners	[Nm]	[lbf · ft]	[Nm]	[lbf·ft]
25	1"	Class 150	4 × ½"	-	-	7	5
25	1"	Class 300	4 × 5/8"	-	-	8	6
40	1 1/2"	Class 150	4 × ½"	-	-	10	7
40	1 1/2"	Class 300	4 × 3/4"	-	-	15	11
50	2"	Class 150	4 × 5/8"	35	26	22	16
50	2"	Class 300	8 × 5/8"	18	13	11	8
80	3"	Class 150	4 × 5/8"	60	44	43	32
80	3"	Class 300	8 × ¾"	38	28	26	19
100	4"	Class 150	8 × 5/8"	42	31	31	23
100	4"	Class 300	8 × ¾"	58	43	40	30
150	6"	Class 150	8 × ¾"	79	58	59	44
150	6"	Class 300	12 × ¾"	70	52	51	38
200	8"	Class 150	8 × ¾"	107	79	80	59
250	10"	Class 150	12 × 7/8"	101	74	75	55
300	12"	Class 150	12 × 7/8"	133	98	103	76
350	14"	Class 150	12 × 1"	135	100	158	117
400	16"	Class 150	16 × 1"	128	94	150	111
450	18"	Class 150	16 × 1 1/8"	204	150	234	173
500	20"	Class 150	20 × 1 1/8"	183	135	217	160
600	24"	Class 150	20 × 1 1/4"	268	198	307	226

Promag W tightening torques for JIS

Nominal diameter	JIS	Threaded	Max. tighteni	Max. tightening torque [Nm]		
[mm]	Pressure rating	fasteners	Hard rubber	Polyurethane		
25	10K	4 × M 16	-	19		
25	20K	4 × M 16	-	19		
32	10K	4 × M 16	-	22		
32	20K	4 × M 16	-	22		
40	10K	4 × M 16	-	24		
40	20K	4 × M 16	-	24		
50	10K	4 × M 16	40	33		
50	20K	8 × M 16	20	17		
65	10K	4 × M 16	55	45		
65	20K	8 × M 16	28	23		
80	10K	8 × M 16	29	23		
80	20K	8 × M 20	42	35		
100	10K	8 × M 16	35	29		
100	20K	8 × M 20	56	48		
125	10K	8 × M 20	60	51		
125	20K	8 × M 22	91	79		
150	10K	8 × M 20	75	63		
150	20K	12 × M 22	81	72		
200	10K	12 × M 20	61	52		
200	20K	12 × M 22	91	80		
250	10K	12 × M 22	100	87		
250	20K	12 × M 24	159	144		
300	10K	16 × M 22	74	63		
300	20K	16 × M 24	138	124		

Promag W tightening torques for AWWA

Nominal	diameter	AWWA		Max. tightening torque			
		Pressure	Threaded	Hard rubber		Polyurethane	
[mm]	[inch]	rating	fasteners	[Nm]	[lbf⋅ft]	[Nm]	[lbf·ft]
700	28"	Class D	28 × 1 1/4"	247	182	292	215
750	30"	Class D	28 × 1 1/4"	287	212	302	223
800	32"	Class D	28 × 1 ½"	394	291	422	311
900	36"	Class D	32 × 1 ½"	419	309	430	317
1000	40"	Class D	36 × 1 ½"	420	310	477	352
1050	42"	Class D	36 × 1 ½"	528	389	518	382
1200	48"	Class D	44 × 1 ½"	552	407	531	392
1350	54"	Class D	44 × 1 ¾"	730	538	633	467
1500	60"	Class D	52 × 1 ¾"	758	559	832	614
1650	66"	Class D	52 × 1 ¾"	946	698	955	704
1800	72"	Class D	60 × 1 ¾"	975	719	1087	802
2000	78"	Class D	64 × 2"	853	629	786	580

Promag W tightening torques for AS 2129

Nominal diameter [mm]	AS 2129 Pressure rating	Threaded fasteners	Max. tightening torque [Nm] Hard rubber
50	Table E	4 × M 16	32
80	Table E	4 × M 16	49
100	Table E	8 × M 16	38
150	Table E	8 × M 20	64
200	Table E	8 × M 20	96
250	Table E	12 × M 20	98
300	Table E	12 × M 24	123
350	Table E	12 × M 24	203
400	Table E	12 × M 24	226
450	Table E	16 × M 24	226
500	Table E	16 × M 24	271
600	Table E	16 × M 30	439
700	Table E	20 × M 30	355
750	Table E	20 × M 30	559
800	Table E	20 × M 30	631
900	Table E	24 × M 30	627
1000	Table E	24 × M 30	634
1200	Table E	32 × M 30	727

Promag W tightening torques for AS 4087

Nominal diameter [mm]	AS 4087 Pressure rating	Threaded fasteners	Max. tightening torque [Nm] Hard rubber
50	Table E	4 × M 16	32
80	PN 16	4 × M 16	49
100	PN 16	4 × M 16	76
150	PN 16	8 × M 20	52
200	PN 16	8 × M 20	77
250	PN 16	8 × M 20	147
300	PN 16	12 × M 24	103
350	PN 16	12 × M 24	203
375	PN 16	12 × M 24	137
400	PN 16	12 × M 24	226
450	PN 16	12 × M 24	301
500	PN 16	16 × M 24	271
600	PN 16	16 × M 27	393
700	PN 16	20 × M 27	330
750	PN 16	20 × M 30	529
800	PN 16	20 × M 33	631
900	PN 16	24 × M 33	627
1000	PN 16	24 × M 33	595
1200	PN 16	32 × M 33	703

3.3.7 Turning the transmitter housing

Turning the aluminum field housing



Warning!

The turning mechanism in devices with Ex d/de or FM/CSA Cl. I Div. 1 classification is not the same as that described here. The procedure for turning these housings is described in the Ex-specific documentation.

- 1. Loosen the two securing screws.
- 2. Turn the bayonet catch as far as it will go.
- 3. Carefully lift the transmitter housing:
 - Promag D: approx. 10 mm (0.39 inch) above the securing screws
 - Promag E/H/L/P/W: to the stop
- 4. Turn the transmitter housing to the desired position:
 - Promag D: max. 180° clockwise or max. 180° counterclockwise
 - Promag E/H/L/P/W: max. 280° clockwise or max. 20° counterclockwise
- 5. Lower the housing into position and re-engage the bayonet catch.
- 6. Retighten the two securing screws.




Fig. 25: Turning the transmitter housing (aluminum field housing)

Turning the stainless-steel field housing

- 1. Loosen the two securing screws.
- 2. Carefully lift the transmitter housing as far as it will go.
- 3. Turn the transmitter housing to the desired position (max. $2 \times 90^{\circ}$ in either direction).
- 4. Lower the housing into position.
- 5. Retighten the two securing screws.




Fig. 26: Turning the transmitter housing (stainless-steel field housing)

Endress+Hauser 41

0004302

3.3.8 Turning the onsite display

- 1. Unscrew the cover of the electronics compartment from the transmitter housing.
- 2. Press the side latches on the display module and remove it from the electronics compartment cover plate.
- 3. Turn the display to the desired position (max. $4 \times 45^{\circ}$ in both directions) and reset it onto the cover plate of the electronics compartment.
- 4. Screw the cover of the electronics compartment firmly back onto the transmitter housing.




Fig. 27: Turning the local display (field housing)

3.3.9 Installing the wall-mount housing

There are various ways of installing the wall-mount transmitter housing:

- Direct wall mounting
- Installation in control panel (with separate mounting kit, accessories) → 🗎 44



Caution

- Make sure that the ambient temperature does not exceed the permissible range at the mounting location, -20 to +60 °C (-4 to +140 °F), optional -40 to +60 °C (-40 to +140 °F). Install the device at a shady location. Avoid direct sunlight.
- Always install the wall-mount housing in such a way that the cable entries are pointing down.

Direct wall mounting

- 1. Drill the holes as illustrated in the graphic.
- 2. Remove the cover of the connection compartment (a).
- 3. Push the two securing screws (b) through the appropriate bores (c) in the housing.
 - Securing screws (M6): max. Ø 6.5 mm (0.26")
 - Screw head: max. Ø 10.5 mm (0.41")
- 4. Secure the transmitter housing to the wall as indicated.
- 5. Screw the cover of the connection compartment (a) firmly onto the housing.




Fig. 28: Mounted directly on the wall

Installation Promag 50

Panel-mounted installation

- 1. Prepare the opening in the panel as illustrated in the graphic.
- 2. Slide the housing into the opening in the panel from the front.
- 3. Screw the fasteners onto the wall-mount housing.
- 4. Place the threaded rods in the fasteners and screw them down until the housing is seated tightly against the panel. Afterwards, tighten the locking nuts. Additional support is not necessary.




Fig. 29: Panel installation (wall-mount housing)

Pipe mounting

The assembly should be performed by following the instructions in the graphic.



Caution!

If the device is mounted to a warm pipe, make certain that the housing temperature does not exceed +60 $^{\circ}$ C (+140 $^{\circ}$ F), which is the maximum permissible temperature.




Fig. 30: Pipe mounting (wall-mount housing)

Promag 50 Installation

3.4 Post-installation check

Perform the following checks after installing the measuring device in the pipe:

Device condition and specifications	Notes
Is the device damaged (visual inspection)?	-
Does the device correspond to specifications at the measuring point, including process temperature and pressure, ambient temperature, minimum fluid conductivity, measuring range, etc.?	→ 🖺 103
Installation	Notes
Does the arrow on the sensor nameplate match the actual direction of flow through the pipe?	-
Is the position of the measuring electrode plane correct?	→ 🗎 14
Is the position of the empty pipe detection electrode correct?	→ 🖺 14
Were all screws tightened to the specified torques when the sensor was installed?	Promag D \rightarrow $\stackrel{\triangle}{=}$ 22 Promag E \rightarrow $\stackrel{\triangle}{=}$ 24 Promag L \rightarrow $\stackrel{\triangle}{=}$ 30 Promag P \rightarrow $\stackrel{\triangle}{=}$ 33 Promag W \rightarrow $\stackrel{\triangle}{=}$ 36
Were the correct seals used (type, material, installation)?	Promag D → $\stackrel{\square}{=}$ 20 Promag E → $\stackrel{\square}{=}$ 23 Promag H → $\stackrel{\square}{=}$ 26 Promag L → $\stackrel{\square}{=}$ 29 Promag P → $\stackrel{\square}{=}$ 32 Promag W → $\stackrel{\square}{=}$ 36
Are the measuring point number and labeling correct (visual inspection)?	-
Process environment / process conditions	Notes
Were the inlet and outlet runs respected?	Inlet run $\geq 5 \times DN$ Outlet run $\geq 2 \times DN$
Is the measuring device protected against moisture and direct sunlight?	-
Is the sensor adequately protected against vibration (attachment, support)?	Acceleration up to 2 g by analogy with IEC 600 68-2-8

Wiring Promag 50

4 Wiring



Warning!

When connecting Ex-certified devices, see the notes and diagrams in the Ex-specific supplement to these Operating Instructions.

Please do not hesitate to contact your Endress+Hauser representative if you have any questions.



Note!

The device does not have an internal circuit breaker. For this reason, assign the device a switch or power-breaker switch capable of disconnecting the power supply line from the mains.

4.1 Connecting the remote version

4.1.1 Connecting Promag D/E/H/L/P/W



Warning!

- Risk of electric shock! Switch off the power supply before opening the device. Do **not** install
 or wire the device while it is connected to the power supply. Failure to comply with this
 precaution can result in irreparable damage to the electronics.
- Risk of electric shock! Connect the protective conductor to the ground terminal on the housing before the power supply is applied.



Caution!

- Only sensors and transmitters with the same serial number can be connected to one another. Communication problems can occur if the devices are not connected in this way.
- Risk of damaging the coil driver. Always switch off the power supply before connecting or disconnecting the coil cable.

Procedure

- 1. Transmitter: Remove the cover from the connection compartment (a).
- 2. Sensor: Remove the cover from the connection housing (b).
- 3. Feed the signal cable (c) and the coil cable (d) through the appropriate cable entries.
 - d Caution!

Route the connecting cables securely (see "Connecting cable length" $\rightarrow \triangleq 19$).

4. Terminate the signal and coil current cable as indicated in the table:

Promag D/E/L/P/W \rightarrow Refer to the table $\rightarrow \triangleq 49$

Promag H \rightarrow Refer to the "Cable termination" table $\rightarrow \triangleq 50$

5. Establish the wiring between the sensor and the transmitter.

The electrical wiring diagram that applies to your device can be found:

- ► In the corresponding graphic:
 - \rightarrow 31 (Promag D) \rightarrow 32 (Promag E/L/P/W); \rightarrow 33 (Promag H)
- ▶ In the cover of the sensor and transmitter



The cable shields of the Promag H sensor are grounded by means of the strain relief terminals (see also the "Cable termination" table $\rightarrow \triangleq 50$)

് Caution!

Insulate the shields of cables that are not connected to eliminate the risk of short-circuits with neighboring cable shields inside the connection housing.

- 6. Transmitter: Screw the cover on the connection compartment (a).
- 7. Sensor: Secure the cover on the connection housing (b).

Promag 50 Wiring

Promag D




Fig. 31: Connecting the remote version of Promag D

- Wall-mount housing connection compartment Cover of the sensor connection housing Signal cable

- Coil current cable
- Not connected, insulated cable shields

Wire colors/Terminal No.:

5/6 = braun, 7/8 = white, 4 = green, 37/36 = yellow

Promag E/L/P/W




Fig. 32: Connecting the remote version of Promag E/L/P/W

- Wall-mount housing connection compartment
- Cover of the sensor connection housing
- Signal cable c d
- Coil current cable
- Not connected, insulated cable shields

Wire colors/Terminal No.:

5/6 = braun, 7/8 = white, 4 = green, 37/36 = yellow

Wiring Promag 50

Promag H




Fig. 33: Connecting the remote version of Promag \boldsymbol{H}

- Wall-mount housing connection compartment Cover of the sensor connection housing Signal cable Coil current cable а
- b
- c d
- Not connected, insulated cable shields n.c.

Wire colors/Terminal No.: 5/6 = braun, 7/8 = white, 4 = green, 37/36 = yellow

Promag 50 Wiring

Cable termination for the remote version Promag D/E/L/P/W

Terminate the signal and coil current cables as shown in the figure below (Detail A).


Ferrules must be provided on the fine-wire cores (Detail B: \odot = red ferrules, \varnothing 1.0 mm; \circledcirc = white ferrules, \varnothing 0.5 mm).


* Stripping only for reinforced cables



- Caution!
 When fitting the connectors, pay attention to the following points: • $Signal\ cable \rightarrow Make$ sure that the ferrules do not touch the wire shield on the sensor side. Minimum distance = 1 mm (exception "GND" = green cable)
- *Coil current cable* → Insulate one core of the three-core wire at the level of the core reinforcement; you only require two cores for the connection.







Wiring Promag 50

Cable termination for the remote version Promag H

Terminate the signal and coil current cables as shown in the figure below (Detail A).


Ferrules must be provided on the fine-wire cores (Detail B: \odot = red ferrules, \varnothing 1.0 mm; \varnothing = white ferrules, \varnothing 0.5 mm).




When fitting the connectors, pay attention to the following points:

- Signal cable → Make sure that the ferrules do not touch the wire shield on the sensor side.
 Minimum distance = 1 mm (exception "GND" = green cable).
- *Coil current cable* → Insulate one core of the three-core wire at the level of the core reinforcement; you only require two cores for the connection.
- On the sensor side, reverse both cable shields approx. 15 mm over the outer jacket. The strain relief ensures an electrical connection with the connection housing.

TRANSMITTER



SENSOR



Promag 50 Wiring

4.1.2 Cable specifications


Signal cable

• $3 \times 0.38 \text{ mm}^2$ PVC cable with common, braided copper shield ($\emptyset \sim 7 \text{ mm}$) and individually shielded cores

- With Empty Pipe Detection (EPD): 4 × 0.38 mm² PVC cable with common, braided copper shield ($\emptyset \sim 7$ mm) and individually shielded cores
- Conductor resistance: \leq 50 Ω/km
- Capacitance: core/shield: ≤ 420 pF/m
- Permanent operating temperature: -20 to +80 °C
- Cable cross-section: max. 2.5 mm²

Coil cable

- 2 × 0.75 mm² PVC cable with common, braided copper shield ($\varnothing \sim 7$ mm)
- Conductor resistance: \leq 37 Ω/km
- Capacitance: core/core, shield grounded: ≤ 120 pF/m
- Operating temperature: -20 to +80 °C
- Cable cross-section: max. 2.5 mm²
- Test voltage for cable insulation: ≥1433 V AC r.m.s. 50/60 Hz or ≥2026 V DC



Fia. 34: Cable cross-section

- Signal cable
- Coil current cable
- Core
- Core insulation
- Core shield
- Core jacket
- Core reinforcement
- Cable shield
- Outer jacket

Reinforced connecting cables

As an option, Endress+Hauser can also deliver reinforced connecting cables with an additional, reinforcing metal braid. Reinforced connecting cables should be used when laying the cable directly in the ground, if there is a risk of damage from rodents or if using the measuring device below IP 68 degree of protection.

Operation in zones of severe electrical interference:

The measuring device complies with the general safety requirements in accordance with EN 61010 and the EMC requirements of IEC/EN 61326.



Caution!

Grounding is by means of the ground terminals provided for the purpose inside the connection housing. Ensure that the stripped and twisted lengths of cable shield to the ground terminal are as short as possible.

Wiring Promag 50

4.2 Connecting the measuring unit

4.2.1 Connecting the transmitter



Warning!

- Risk of electric shock! Switch off the power supply before opening the device. Do not install
 or wire the device while it is energized. Failure to comply with this precaution can result in
 irreparable damage to the electronics.
- Risk of electric shock! Connect the protective conductor to the ground terminal on the housing before the power supply is applied (not necessary if the power supply is galvanically isolated).
- Compare the specifications on the nameplate with the local voltage supply and frequency. Also comply with national regulations governing the installation of electrical equipment.
- 1. Remove the cover of the connection compartment (f) from the transmitter housing.
- 2. Feed the power supply cable (a) and the signal cable (b) through the appropriate cable entries.
- 3. Perform the wiring:
 - Wiring diagram (aluminum housing) \rightarrow **2** 35
 - Wiring diagram (stainless steel housing) → 36
 - Wiring diagram (wall-mount housing) \rightarrow 37
 - Terminal assignment → 🖺 54
- 4. Screw the cover of the connection compartment (f) firmly onto the transmitter housing.




Fig. 35: Connecting the transmitter (aluminum field housing). Cable cross-section: max. 2.5 mm²

- a Cable for power supply: 85 to 260 V AC, 20 to 55 V AC, 16 to 62 V DC
 - Terminal **No. 1**: L1 for AC, L+ for DC
- Terminal No. 2: N for AC, L- for DC b Signal cable: Terminals Nos. $20-27 \rightarrow \triangle 54$
- c Ground terminal for protective ground
- d Ground terminal for signal cable shield
- Service connector for connecting service interface FXA193 (Fieldcheck, FieldCare)
- f Cover of the connection compartment
- g Securing clamp

Promag 50 Wiring




Fig. 36: Connecting the transmitter (stainless steel field housing); cable cross-section: max. 2.5 mm²

- Cable for power supply: 85 to 260 V AC, 20 to 55 V AC, 16 to 62 V DC Terminal No. 1: L1 for AC, L+ for DC Terminal No. 2: N for AC, L- for DC Signal cable: Terminals Nos. 20–27 \Rightarrow \triangleq 54
- b
- Ground terminal for protective ground Ground terminal for signal cable shield
- Service connector for connecting service interface FXA193 (Fieldcheck, FieldCare)
- Cover of the connection compartment




Fig. 37: Connecting the transmitter (wall-mount housing); cable cross-section: max. 2.5 mm²

- Cable for power supply: 85 to 260 V AC, 20 to 55 V AC, 16 to 62 V DC Terminal **No.** 1: L1 for AC, L+ for DC Terminal **No.** 2: N for AC, L- for DC Signal cable: Terminals **Nos.** 20–27 \Rightarrow \cong 54
- h
- Ground terminal for protective ground
- Ground terminal for signal cable shield
- Service connector for connecting service interface FXA193 (Fieldcheck, FieldCare)
- Cover of the connection compartment

Wiring Promag 50

4.2.2 Terminal assignment

	Terminal No. (inputs / outputs)			
Order version	20 (+) / 21 (-)	22 (+) / 23 (-)	24 (+) / 25 (-)	26 (+) / 27 (-)
50***-********W	-	-	-	Current output HART
50***-********A	-	-	Frequency output	Current output HART
50***-********D	Status input	Status output	Frequency output	Current output HART
50***-********	-	-	Frequency output Ex i	Current output, Ex i, active, HART
50***-********T	-	-	Frequency output Ex i	Current output, Ex i, passive, HART



Functional values of the inputs and outputs $\rightarrow \triangleq 98$

4.2.3 **HART** connection

Users have the following connection options at their disposal:

- Direct connection to transmitter by means of terminals 26(+) and 27 (-)
- Connection by means of the 4 to 20 mA circuit.



- The measuring loop's minimum load must be at least 250 Ω .
- After commissioning, make the following settings:
- CURRENT SPAN function \rightarrow "4-20 mA HART"
- Switch HART write protection on or off $\rightarrow \triangleq 65$

Connection of the HART handheld communicator

See also the documentation issued by the HART Communication Foundation, and in particular HCF LIT 20: "HART, a technical summary".




Fig. 38: Electrical connection of HART handheld Field Xpert SFX100

- HART handheld Field Xpert SFX100
- Auxiliary energy Shielding
- Other devices or PLC with passive input

Promag 50 Wiring

Connection of a PC with an operating software

In order to connect a PC with operating software (e.g. "FieldCare"), a HART modem (e.g. "Commubox FXA195") is needed.




Fig. 39: Electrical connection of a PC with operating software

- 1 PC with operating software
- 2 Auxiliary energy
- 3 Shielding
- 4 Other devices or PLC with passive input
- HART modem, e.g. Commubox FXA 195

4.3 Potential equalization



Warning!

The measuring system must be included in the potential equalization.

Perfect measurement is only ensured when the fluid and the sensor have the same electrical potential. This is ensured by the reference electrode integrated in the sensor as standard.

The following should also be taken into consideration for potential equalization:

- Internal grounding concepts in the company
- Operating conditions, such as the material/grounding of the pipes (see Table)

4.3.1 Potential equalization for Promag D

- No reference electrode is integrated!
 For the two ground disks of the sensor an electrical connection to the fluid is always ensured.
- Exampels for connections \rightarrow 🗎 56

4.3.2 Potential equalization for Promag E/L/P/W

- Reference electrode integrated in the sensor as standard
- Exampels for connections \rightarrow 🗎 57

4.3.3 Potential equalization for Promag H

No reference electrode is integrated!

For the metal process connections of the sensor an electrical connection to the fluid is always ensured.



Caution

If using process connections made of a synthetic material, ground rings have to be used to ensure that potential is equalized ($\rightarrow \boxminus 27$). The necessary ground rings can be ordered separately from Endress+Hauser as accessories ($\rightarrow \boxminus 78$).

Wiring Promag 50

4.3.4 Exampels for potential equalization connections for Promag D

Standard case

Operating conditions Potential equalization When using the measuring device in a: • Metal, grounded pipe • Plastic pipe • Pipe with insulating lining Potential equalization takes place via the ground terminal of the transmitter (standard situation). Note! When installing in metal pipes, we recommend you connect the ground terminal of the transmitter housing with the piping. Fig. 40: Via the ground terminal of the transmitter

Special cases

Operating conditions Potential equalization When using the measuring device in a: Metal pipe that is not grounded This connection method also applies in situations where: Customary potential equalization cannot be ensured • Excessively high equalizing currents can be expected Potential equalization takes place via the ground terminal of the transmitter and the two pipe flanges. Here, the ground cable (copper wire, $6 \text{ mm}^2 / 0.0093 \text{ in}^2$) is mounted directly on the conductive flange coating with flange screws. Fig. 41: Via the ground terminal of the transmitter and the flanges of the pipe When using the measuring device in a: • Pipe with a cathodic protection unit The device is installed potential-free in the pipe. Only the two flanges of the pipe are connected with a ground cable (copper wire, 6 mm² (0.0093 in²)). Here, the ground cable is mounted directly on the conductive flange coating with flange screws. Note the following when installing: • The applicable regulations regarding potential-free installation must be observed. • There should be **no** electrically conductive connection a00012174 Potential equalization and cathodic between the pipe and the device. Fig. 42: protection • The mounting material must withstand the applicable torques. Power supply isolation transformer 2 Electrically isolated

Promag 50 Wiring

4.3.5 Exampels for potential equalization connections for Promag E/L/P/W

Standard case

Special cases

Operating conditions Potential equalization When using the measuring device in a: • Metal pipe that is not grounded This connection method also applies in situations where: • Customary potential equalization cannot be ensured • Excessively high equalizing currents can be expected Both sensor flanges are connected to the pipe flange by means of a ground cable (copper wire, 6 mm² / 0.0093 in²) and grounded. Connect the transmitter or sensor connection housing, as applicable, to ground potential by means of the ground terminal provided for the purpose. $DN \leq 300$ DN ≥ 350 Ground cable installation depends on the nominal diameter: • DN \leq 300 (12"): The ground cable is mounted directly on the conductive flange coating with the flange screws. $\bullet~$ DN $\geq~350$ (14"): The ground cable is mounted directly on the metal transport bracket. The ground cable for flange-to-flange connections can be ordered separately as an accessory from Endress+Hauser. Via the ground terminal of the transmitter Fig. 44: and the flanges of the pipe When using the measuring device in a: Plastic pipe Pipe with insulating lining This connection method also applies in situations where: • Customary potential equalization cannot be ensured • Excessively high equalizing currents can be expected Potential equalization takes place using additional ground disks, which are connected to the ground terminal via a ground cable (copper wire, min. 6 mm² / 0.0093 in²). When installing the ground disks, please comply with the enclosed Installation Instructions. Via the ground terminal of the transmitter Fig. 45:

Wiring Promag 50

Operating conditions Potential equalization When using the measuring device in a: Pipe with a cathodic protection unit The device is installed potential-free in the pipe. Only the two flanges of the pipe are connected with a ground cable (copper wire, 6 mm² / 0.0093 in²). Here, the ground cable is mounted directly on the conductive flange coating with flange screws. Note the following when installing: • The applicable regulations regarding potential-free installation must be observed. • There should be **no** electrically conductive connection Potential equalization and cathodic Fig. 46: between the pipe and the device. protection • The mounting material must withstand the applicable Power supply isolation transformer Electrically isolated torques.

4.4 Degree of protection

The devices meet all the requirements of IP 67 degree of protection.

Compliance with the following points is mandatory following installation in the field or servicing in order to ensure that IP 67 protection is maintained:

- The housing seals must be clean and undamaged when inserted into their grooves. The seals must be dried, cleaned or replaced if necessary.
- All threaded fasteners and screw covers must be firmly tightened.
- The cables used for connection must be of the specified outside diameter $\rightarrow \triangleq 51$.
- Firmly tighten the cable entries.
- The cables must loop down before they enter the cable entries ("water trap"). This arrangement prevents moisture penetrating the entry. Always install the measuring device in such a way that the cable entries do not point up.
- Remove all unused cable entries and insert plugs instead.
- Do not remove the grommet from the cable entry.




Fig. 47: Installation instructions, cable entries



Caution!

Do not loosen the threaded fasteners of the sensor housing, as otherwise the degree of protection quaranteed by Endress+Hauser no longer applies.



Note!

The Promag E/L/P/W sensors can be supplied with IP 68 rating (permanent immersion in water to a depth of 3 meters (10 ft)). In this case the transmitter must be installed remote from the sensor.

The Promag L sensors with IP 68 rating are only available with stainless steel flanges.

Promag 50 Wiring

4.5 Post-connection check

Perform the following checks after completing electrical installation of the measuring device:

Device condition and specifications	Notes
Are cables or the device damaged (visual inspection)?	-
Electrical connection	Notes
Does the supply voltage match the specifications on the nameplate?	 85 to 250 V AC (50 to 60 Hz) 20 to 28 V AC (50 to 60 Hz) 11 to 40 V DC
Do the cables used comply with the necessary specifications?	→ 🗎 51
Do the cables have adequate strain relief?	-
Is the cable type route completely isolated? Without loops and crossovers?	-
Are the power-supply and signal cables correctly connected?	See the wiring diagram inside the cover of the terminal compartment
Only remote version: Is the flow sensor connected to the matching transmitter electronics?	Check serial number on nameplates of sensor and connected transmitter.
Only remote version: Is the connecting cable between sensor and transmitter connected correctly?	→ 🖺 46
Are all screw terminals firmly tightened?	-
Have the measures for grounding/potential equalization been correctly implemented?	→ 🖺 55
Are all cable entries installed, firmly tightened and correctly sealed? Cables looped as "water traps"?	→ 🖺 58
Are all housing covers installed and firmly tightened?	-

Operation Promag 50

Operation 5

5.1 Display and operating elements

The local display enables you to read all important parameters directly at the measuring point and configure the device.

The display area consists of two lines; this is where measured values are displayed, and/or status variables (direction of flow, partially filled pipe, bar graph, etc.). You can change the assignment of display lines to variables at will in order to customize the display to suit your needs and preferences (\rightarrow "Description of Device Functions" manual).




Fig. 48: Display and operating elements

Liquid crystal display

The two-line liquid-crystal display shows measured values, dialog texts, error messages and information messages. The

- display as it appears when normal measuring is in progress is known as the HOME position (operating mode).

 Upper display line: Shows primary measured values, e.g. volume flow in [ml/min] or in [%].

 Lower display line: Shows supplementary measured variables and status variables, e.g. totalizer reading in [m3], bar graph, measuring point designation
- 2 Plus/minus keys
 - Enter numerical values, select parameters
 - Select different function groups within the function matrix

Press the +/- keys simultaneously to trigger the following functions:

- Exit the function matrix step by step → HOME position
- Press and hold down +/- keys for longer than 3 seconds \rightarrow Return directly to HOME position
- Cancel data entry
- Enter kev
 - HOME position → Entry into the function matrix
 - Save the numerical values you input or settings you change

Promag 50 Operation

5.2 Brief operating instructions on the function matrix




Note!

- See the general notes on $\rightarrow \triangle$ 62.
- ullet Detailed description of all the functions o "Description of Device Functions" manual

The function matrix comprises two levels, namely the function groups and the functions of the function groups.

The groups are the highest-level grouping of the control options for the device. A number of functions is assigned to each group. You select a group in order to access the individual functions for operating and configuring the device.

- HOME position $\rightarrow \blacksquare \rightarrow$ Enter the function matrix
- Select a function group (e.g. OPERATION)
- Select a function (e.g. LANGUAGE) Change parameter/enter numerical values: $\stackrel{\mathbb{H}}{\to}$ select or enter enable code, parameters, numerical values \blacksquare \rightarrow save your entries
- Exit the function matrix:
 - Press and hold down Esc key (\square) for longer than 3 seconds \rightarrow HOME position
 - Repeatedly press Esc key (\Box) \rightarrow return step by step to HOME position



Selecting functions and configuring parameters (function matrix)

Operation Promag 50

5.2.1 General notes

The Quick Setup menu ($\rightarrow \cong 72$) is adequate for commissioning in most instances. Complex measuring operations on the other hand necessitate additional functions that you can configure as necessary and customize to suit your process parameters. The function matrix, therefore, comprises a multiplicity of additional functions which, for the sake of clarity, are arranged in a number of function groups.

Comply with the following instructions when configuring functions:

- You select functions as described on $\rightarrow \triangleq 61$.
- You can switch off certain functions (OFF). If you do so, related functions in other function groups will no longer be displayed.
- Certain functions prompt you to confirm your data entries.

 Press 🕆 to select "SURE [YES]" and press 🗉 again to confirm. This saves your setting or starts a function, as applicable.
- Return to the HOME position is automatic if no key is pressed for 5 minutes.



Note!

- The transmitter continues to measure while data entry is in progress, i.e. the current measured values are output via the signal outputs in the normal way.
- If the power supply fails, all preset and configured values remain safely stored in the EEPROM.



Caution!

All functions are described in detail, including the function matrix itself, in the "Description of Device Functions" manual, which is a separate part of these Operating Instructions.

5.2.2 Enabling the programming mode

The function matrix can be disabled. Disabling the function matrix rules out the possibility of inadvertent changes to device functions, numerical values or factory settings. A numerical code (factory setting = 50) has to be entered before settings can be changed.

If you use a code number of your choice, you exclude the possibility of unauthorized persons accessing data (\rightarrow see the "Description of Device Functions" manual).

Comply with the following instructions when entering codes:

- If programming is disabled and the ⊕ operating elements are pressed in any function, a prompt for the code automatically appears on the display.
- If "0" is specified as the customer's code, programming is always enabled.
- The Endress+Hauser service organization can be of assistance if you mislay your personal code.



Caution!

Changing certain parameters such as all sensor characteristics, for example, influences numerous functions of the entire measuring system, particularly measuring accuracy. There is no need to change these parameters under normal circumstances and consequently, they are protected by a special code known only to the Endress+Hauser service organization. Please contact Endress+Hauser if you have any questions.

5.2.3 Disabling the programming mode

Programming is disabled if you do not press the operating elements within 60 seconds following automatic return to the HOME position.

You can also disable programming in the "ACCESS CODE" function by entering any number (other than the customer's code).

Promag 50 Operation

5.3 Displaying error messages

5.3.1 Type of error

Errors which occur during commissioning or measuring operation are displayed immediately. If two or more system or process errors occur, the error with the highest priority is the one shown on the display.

The measuring system distinguishes between two types of error:

- System errors \rightarrow 🗎 82:
 - This group comprises all device errors, e.g. communication errors, hardware faults, etc.




Fig. 50: Error messages on the display (example)

- 1 Error type:
 - P = process error
 - S = system error
 - Error message type:
 /= fault message
 - -! = notice message
- Error designation: e.g. EMPTY PIPE = measuring tube is only partly filled or completely empty
- 4 Error number: e.g. #401
- 5 Duration of most recent error occurrence (in hours, minutes and seconds)

5.3.2 Error message types

Users have the option of weighting certain errors differently, in other words having them classed as "Fault messages" or "Notice messages". You can define messages in this way with the aid of the function matrix (\rightarrow "Description of Device Functions" manual). Serious system errors, e.g. module defects, are always identified and classed as "fault messages" by the measuring device.

Notice message (!)

- Displayed as \rightarrow Exclamation mark (!), error type (S: system error, P: process error)
- The error in question has no effect on the outputs of the measuring device.

Fault message (4)

- Displayed as \rightarrow Lightning flash ($\frac{1}{2}$), error type (S: system error, P: process error).
- The error in question has a direct effect on the outputs.
 The response of the individual outputs (failsafe mode) can be defined in the function matrix using the "FAILSAFE MODE" function (→ "Description of Device Functions" manual).



Note!

For security reasons, error messages should be output via the status output.

Operation Promag 50

5.4 Communication

The HART protocol allows the transfer of measuring and device data between the HART master and the field devices for configuration and diagnostics purposes.

The HART master, e.g. a handheld terminal or PC-based operating programs (such as FieldCare), require device description (DD) files which are used to access all the information in a HART device. Information is exclusively transferred using so-called "commands". There are three different command classes:

• Universal commands:

All HART device support and use universal commands.

The following functionalities are linked to them:

- Identify HART devices
- Reading digital measured values (volume flow, totalizer, etc.)
- Common practice commands:

Common practice commands offer functions which are supported and can be executed by most but not all field devices.

Device-specific commands:

These commands allow access to device-specific functions which are not HART standard. Such commands access individual field device information, amongst other things, such as empty/full pipe calibration values, low flow cutoff settings, etc.



Note

5.4.1 Operating options

For the complete operation of the measuring device, including device-specific commands, there are DD files available to the user to provide the following operating aids and programs:

Field Xpert HART Communicator

Selecting device functions with a HART Communicator is a process involving a number of menu levels and a special HART function matrix.

The HART manual in the carrying case of the HART Communicator contains more detailed information on the device.

Operating program "FieldCare"

FieldCare is Endress+Hauser's FDT-based plant Asset Management Tool and allows the configuration and diagnosis of intelligent field devices. By using status information, you also have a simple but effective tool for monitoring devices. The Proline flow measuring devices are accessed via a service interface or via the service interface FXA193.

Operating program "SIMATIC PDM" (Siemens)

SIMATIC PDM is a standardized, manufacturer-independent tool for the operation, configuration,

maintenance and diagnosis of intelligent field devices.

Operating program "AMS" (Emerson Process Management)

AMS (Asset Management Solutions): program for operating and configuring devices.

Promag 50 Operation

5.4.2 Current device description files

The following table illustrates the suitable device description file for the operating tool in question and then indicates where these can be obtained.

HART protocol:

TIAKT Protocol.		
Valid for device software:	2.04.XX	\rightarrow Function DEVICE SOFTWARE
Device data HART Manufacturer ID: Device ID:	11 _{hex} (ENDRESS+HAUSER) 41 _{hex}	\rightarrow Function MANUFACTURER ID \rightarrow Function DEVICE ID
HART version data:	Device Revision 6/ DD Revision 1	L
Software release:	01.2011	
Operating program:	Sources for obtaining device de	escriptions:
Handheld Field Xpert SFX100	Use update function of handheld terminal	
FieldCare / DTM	 www.endress.com → Download CD-ROM (Endress+Hauser order number 56004088) DVD (Endress+Hauser order number 70100690) 	
	$www.endress.com \rightarrow Download$	
AMS	www.endress.com \rightarrow Download	

Tester/simulator:	Sources for obtaining device descriptions:	
Fieldcheck	Update by means of FieldCare with the flow device FXA193/291 DTM in the Fieldflash module	



Note!

The "Fieldcheck" tester/simulator is used for testing flowmeters in the field. When used in conjunction with the "FieldCare" software package, test results can be imported into a database, printed out and used for official certification. Contact your Endress+Hauser representative for more information.

5.4.3 Device variables

The following device variables are available using the HART protocol:

Code (decimal)	Device variable
0	OFF (not assigned)
1	Volume flow
250	Totalizer 1
251	Totalizer 2

At the factory, the process variables are assigned to the following device variables:

- Primary process variable (PV) \rightarrow Volume flow
- Second process variable (SV) \rightarrow Totalizer 1
- Third process variable (TV) \rightarrow not assigned
- Fourth process variable (FV) \rightarrow not assigned



Note

You can set or change the assignment of device variables to process variables using Command 51.

5.4.4 Switching HART write protection on/off

The HART write protection can be switched on and off using the HART WRITE PROTECT device function (\rightarrow "Description of Device Functions" manual).

Operation Promag 50

5.4.5 Universal and common practice HART commands

The following table contains all the universal commands supported by the device.

	nand No. Command / Access type	Command data (numeric data in decimal form)	Response data (numeric data in decimal form)		
Unive	Universal commands				
0	Read unique device identifier Access type = read	none	Device identification delivers information on the device and the manufacturer. It cannot be changed.		
			The response consists of a 12 byte device ID: - Byte 0: fixed value 254 - Byte 1: Manufacturer ID, 17 = E+H - Byte 2: Device type ID, 65 = Promag 50 - Byte 3: Number of preambles - Byte 4: Universal commands rev. no. - Byte 5: Device-specific commands rev. no. - Byte 6: Software revision - Byte 7: Hardware revision - Byte 8: Additional device information - Bytes 9-11: Device identification		
1	Read primary process variable Access type = read	none	 Byte 0: HART unit code of the primary process variable Bytes 1-4: Primary process variable 		
			Factory setting: Primary process variable = Volume flow		
			 Note! Manufacturer-specific units are represented using the HART unit code "240". You can change the assignment of device variables to process variables using Command 51. 		
2	Read the primary process variable as current in mA and percentage of the set measuring	none	 Bytes 0-3: actual current of the primary process variable in mA Bytes 4-7: % value of the set measuring range 		
	range Access type = read		Factory setting: Primary process variable = Volume flow		
			Note! You can change the assignment of device variables to process variables using Command 51.		
3	Read the primary process variable as current in mA and four dynamic process variables Access type = read	none	24 bytes are sent as a response: - Bytes 0-3: primary process variable current in mA - Byte 4: HART unit code of the primary process variable - Bytes 5-8: Primary process variable - Byte 9: HART unit code of the second process variable - Bytes 10-13: Second process variable - Byte 14: HART unit code of the third process variable - Bytes 15-18: Third process variable - Bytes 19: HART unit code of the fourth process variable - Bytes 20-23: Fourth process variable		
			Factory setting: Primary process variable = Volume flow Second process variable = Totalizer 1 Third process variable = OFF (not assigned) Fourth process variable = OFF (not assigned)		
			 Note! Manufacturer-specific units are represented using the HART unit code "240". You can change the assignment of device variables to process variables using Command 51. 		
6	Set HART shortform address Access type = write	Byte 0: desired address (0 to 15) Factory setting: 0 Note! With an address >0 (multidrop mode), the current output of the primary process variable is set to 4 mA.	Byte 0: active address		

Promag 50 Operation

	nand No.	Command data	Response data
HART	command / Access type	(numeric data in decimal form)	(numeric data in decimal form)
11	Read unique device identification using the TAG	Bytes 0-5: TAG	Device identification delivers information on the device and the manufacturer. It cannot be changed.
	(measuring point designation) Access type = read		The response consists of a 12 byte device ID if the given TAG agrees with the one saved in the device: - Byte 0: fixed value 254 - Byte 1: Manufacturer ID, 17 = E+H - Byte 2: Device type ID, 65 = Promag 50 - Byte 3: Number of preambles - Byte 4: Universal commands rev. no. - Byte 5: Device-specific commands rev. no. - Byte 6: Software revision - Byte 7: Hardware revision - Byte 8: Additional device information - Bytes 9-11: Device identification
12	Read user message Access type = read	none	Bytes 0-24: User message Note! You can write the user message using Command 17.
13	Read TAG, descriptor and date Access type = read	none	- Bytes 0-5: TAG - Bytes 6-17: descriptor
			- Bytes 18-20: Date Note! You can write the TAG, descriptor and date using Command 18.
14	Read sensor information on primary process variable	none	 Bytes 0-2: Sensor serial number Byte 3: HART unit code of sensor limits and measuring range of the primary process variable Bytes 4-7: Upper sensor limit Bytes 8-11: Lower sensor limit Bytes 12-15: Minimum span
			 Note! The data relate to the primary process variable (= volume flow). Manufacturer-specific units are represented using the HART unit code "240".
15	Read output information of primary process variable Access type = read	none	 Byte 0: Alarm selection ID Byte 1: Transfer function ID Byte 2: HART unit code for the set measuring range of the primary process variable Bytes 3-6: upper range, value for 20 mA Bytes 7-10: lower range, value for 4 mA Bytes 11-14: Damping constant in [s] Byte 15: Write protection ID Byte 16: OEM dealer ID, 17 = E+H
			Factory setting: Primary process variable = Volume flow Note! Manufacturer-specific units are represented using the HART unit code "240". You can change the assignment of device variables to process variables using Command 51.
16	Read the device production number Access type = read	none	Bytes 0-2: Production number
17	Write user message Access = write	You can save any 32-character long text in the device under this parameter: Bytes 0-23: Desired user message	Displays the current user message in the device: Bytes 0-23: Current user message in the device
18	Write TAG, descriptor and date Access = write	With this parameter, you can store an 8 character TAG, a 16 character descriptor and a date: - Bytes 0-5: TAG - Bytes 6-17: descriptor - Bytes 18-20: Date	Displays the current information in the device: - Bytes 0-5: TAG - Bytes 6-17: descriptor - Bytes 18-20: Date
19	Write the device production number Access = write	Bytes 0-2: Production number	Bytes 0-2: Production number

Operation Promag 50

The following table contains all the common practice commands supported by the device.

	and No. command / Access type	Command data (numeric data in decimal form)	Response data (numeric data in decimal form)
Comm	on practice commands		
34	Write damping value for primary process variable Access = write	Bytes 0-3: Damping value of the primary process variable "volume flow" in seconds Factory setting: Primary process variable = Current output damping	Displays the current damping value in the device: Bytes 0-3: Damping value in seconds
35	Write measuring range of primary process variable Access = write	Write the desired measuring range: - Byte 0: HART unit code of the primary process variable - Bytes 1-4: upper range, value for 20 mA - Bytes 5-8: lower range, value for 4 mA Factory setting: Primary process variable = Volume flow Note! The start of the measuring range (4 mA) must correspond to the zero flow. If the HART unit code is not the correct one for the process variable, the device will continue with the last valid unit.	The currently set measuring range is displayed as a response: - Byte 0: HART unit code for the set measuring range of the primary process variable - Bytes 1-4: upper range, value for 20 mA - Bytes 5-8: lower range, value for 4 mA Note! Manufacturer-specific units are represented using the HART unit code "240". You can change the assignment of device variables to process variables using Command 51.
38	Device status reset (configuration changed) Access = write	none	none Note! It is also possible to execute this HART command when write protection is activated (= ON)!
40	Simulate input current of primary process variable Access = write	Simulation of the desired output current of the primary process variable. An entry value of 0 exits the simulation mode: Bytes 0-3: Output current in mA Factory setting: Primary process variable = Volume flow Note! You can set the assignment of device variables to process variables using Command 51.	The momentary output current of the primary process variable is displayed as a response: Bytes 0-3: Output current in mA
42	Perform master reset Access = write	none	none
44	Write unit of primary process variable Access = write	Set unit of primary process variable. Only units which are suitable for the process variable are transferred to the device: Byte 0: HART unit code Factory setting: Primary process variable = Volume flow Note! If the written HART unit code is not the correct one for the process variable, the device will continue with the last valid unit. If you change the unit of the primary process variable, this has a direct impact on the system units.	The current unit code of the primary process variable is displayed as a response: Byte 0: HART unit code Note! Manufacturer-specific units are represented using the HART unit code "240".
48	Read additional device status Access = read	none	The device status is displayed in extended form as the response: Coding: see table $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $

Promag 50 Operation

Command No. HART command / Access type		Command data (numeric data in decimal form)	Response data (numeric data in decimal form)
50	Read assignment of the device variables to the four process variables Access = read	none	Display of the current variable assignment of the process variables: - Byte 0: Device variable code to the primary process variable - Byte 1: Device variable code to the second process variable - Byte 2: Device variable code to the third process variable - Byte 3: Device variable code to the fourth process variable - Factory setting:
			 Primary process variable: Code 1 for volume flow Second process variable: Code 250 for totalizer Third process variable: Code 0 for OFF (not assigned) Fourth process variable: Code 0 for OFF (not assigned)
51	Write assignment of the device variables to the four process variables Access = write	Setting of the device variables to the four process variables: - Byte 0: Device variable code to the primary process variable - Byte 1: Device variable code to the second process variable - Byte 2: Device variable code to the third process variable - Byte 3: Device variable code to the fourth process variable - Byte 3: Device variable code to the fourth process variable - Factory setting: - Primary process variable: Volume flow - Second process variable: Totalizer 1 - Third process variable: OFF (not assigned)	The variable assignment of the process variables is displayed as a response: - Byte 0: Device variable code to the primary process variable - Byte 1: Device variable code to the second process variable - Byte 2: Device variable code to the third process variable - Byte 3: Device variable code to the fourth process variable
53	Write device variable unit Access = write	Fourth process variable: OFF (not assigned) This command sets the unit of the given device variables. Only those units which suit the device variable are transferred: Byte 0: Device variable code Byte 1: HART unit code Code of the supported device variables: See information → ■ 65 Note! If the written unit is not the correct one for the device variable, the device will continue with the last valid unit. If you change the unit of the device variable, this has a direct impact on the system units.	The current unit of the device variables is displayed in the device as a response: - Byte 0: Device variable code - Byte 1: HART unit code Note! Manufacturer-specific units are represented using the HART unit code "240".
59	Write number of preambles in response message Access = write	This parameter sets the number of preambles which are inserted in the response messages: Byte 0: Number of preambles (4 to 20)	The current number of preambles is displayed in the response telegram: Byte 0: Number of preambles

Operation Promag 50

5.4.6 Device status and error messages

You can read the extended device status, in this case, current error messages, via Command "48". The command delivers information which is partly coded in bits (see table below).



Notel

- \blacksquare You can find a detailed explanation of the device status and error messages and their elimination on $\to riangleq 70$
- Bits and bytes not listed are not assigned.

Byte	Bit	Error No.	Short error description
	0	001	Serious device error
0	1	011	Measuring amplifier has faulty EEPROM
	2	012	Error when accessing data of the measuring amplifier EEPROM
	1	031	S-DAT: defective or missing
1	2	032	S-DAT: Error accessing saved values
	5	051	I/O and the amplifier are not compatible.
3	3	111	Totalizer checksum error
	4	121	I/O board and amplifier not compatible.
4	3	251	Internal communication fault on the amplifier board.
	4	261	No data reception between amplifier and I/O board
-	0	321	Coil current of the sensor is outside the tolerance.
5	7	339	Flow buffer:
	0	340	The temporarily buffered flow portions (measuring mode for pulsating flow) could not be cleared or output within 60 seconds.
	1	341	
	2	342	
	3	343	Frequency buffer:
6	4	344	The temporarily buffered flow portions (measuring mode for pulsating flow) could not be cleared or output within 60 seconds.
	5	345	
	6	346	
	7	347	Pulse buffer:
	0	348	The temporarily buffered flow portions (measuring mode for pulsating flow) could not be cleared or output within 60 seconds.
	1	349	
	2	350	
_	3	351	Current output:
7	4	352	Flow is out of range.
	5	353	
	6	354	
	7	355	Frequency output:
	0	356	Flow is out of range.
8	1	357	
	2	358	

Promag 50 Operation

Byte	Bit	Error No.	Short error description
	3 359		Pulse output:
8	4	360	Flow is out of range.
	5	361	
	6	362	
10	7	401	Measuring tube partially filled or empty
11	2	461	EPD calibration not possible because the fluid's conductivity is either too low or too high.
11	4	463	The EPD calibration values for empty pipe and full pipe are identical, and therefore incorrect.
12	1	474	Maximum flow value entered is overshot
	7	501	Amplifier software version is loaded. Currently no other commands are possible.
13	0	502	Upload/download of device files. Currently no other commands are possible.
14	3	601	Positive zero return active
14	7	611	Simulation current output active
	0	612	
	1	613	
	2	614	
15	3	621	Simulation frequency output active
1)	4	622	
	5	623	
	6	624	
	7	631	Simulation pulse output active
	0	632	
	1	633	
	2	634	
16	3	641	Simulation status output active
	4	642	
	5	643	
	6	644	
17	7	671	Simulation of the status input active
	0	672	
	1	673	
18	2	674	
	3	691	Simulation of response to error (outputs) active
	4	692	Simulation of volume flow active

Commissioning Promag 50

6 Commissioning


6.1 Function check

Make sure that all final checks have been completed before you start up your measuring point:

- Checklist for "Post-connection check" → 🖺 59

6.2 Switching on the measuring device

Once the connection checks have been successfully completed, it is time to switch on the power supply. The device is now operational. The measuring device performs a number of post switch-on self-tests. As this procedure progresses the following sequence of messages appears on the local display:



Normal measuring mode commences as soon as start-up completes. Various measured-value and/or status variables (HOME position) appear on the display.



Note!

If start-up fails, an error message indicating the cause is displayed.

Promag 50 Commissioning


6.3 Quick Setup

In the case of measuring devices without a local display, the individual parameters and functions must be configured via the operating program, e.g. FieldCare.

If the measuring device is equipped with a local display, all the important device parameters for standard operation, as well as additional functions, can be configured quickly and easily by means of the following Quick Setup menu.

6.3.1 "Commissioning" Quick Setup menu

This Quick Setup menu guides you systematically through the setup procedure for all the major device functions that have to be configured for standard measuring operation.



A0005413-EN

Fig. 51: "QUICK SETUP COMMISSIONING" menu for the rapid configuration of important device functions

Commissioning Promag 50

6.4 Configuration

6.4.1 Current output: active/passive

The current output is configured as "active" or "passive" by means of various jumpers on the I/O board.



Warning!

Risk of electric shock! Exposed components carry dangerous voltages. Make sure that the power supply is switched off before you remove the cover of the electronics compartment.

- 1. Switch off power supply.
- 2. Remove the I/O board $\rightarrow \blacksquare$ 89
- 3. Position the jumper $\rightarrow \blacksquare 52$
 - Caution!

Risk of destroying the measuring device. Set the jumpers exactly as shown in the graphic. Pay strict attention to the position of the jumpers as indicated in the graphic.

4. Installation of the I/O board is the reverse of the removal procedure.




Fig. 52: Configuring current outputs using jumpers (I/O board)

Active current output (factory setting)

2 Passive current output

Promag 50 Commissioning

6.5 Adjustment

6.5.1 Empty-pipe/full-pipe adjustment

Flow cannot be measured correctly unless the measuring tube is completely full. This status can be permanently monitored using the Empty Pipe Detection:

- EPD = Empty Pipe Detection (with the help of an EPD electrode)
- OED = Open Electrode Detection (Empty Pipe Detection with the help of the measuring electrodes, if the sensor is not equipped with an EPD electrode or the orientation is not suitable for using EPD).



Caution!

Detailed information on the empty-pipe/full-pipe adjustment procedure can be found in the "Description of Device Functions" manual:

- EPD/OED ADJUSTMENT (carrying out the adjustment).
- EPD (switching on and off EPD/OED).
- EPD RESPONSE TIME (input of the response time for EPD/OED).



Note!

- The EPD function is not available unless the sensor is fitted with an EPD electrode.
- The devices are already calibrated at the factory with water (approx. $500 \,\mu\text{S/cm}$). If the fluid conductivity differs from this reference, empty-pipe/full-pipe adjustment has to be performed again on site.
- The default setting for EPD when the devices are delivered is OFF; the function has to be activated if required.
- The EPD process error can be output by means of the configurable relay output.

Performing empty-pipe and full-pipe adjustment (EPD)

- 1. Select the appropriate function in the function matrix: $HOME \rightarrow \blacksquare \rightarrow \pm \rightarrow PROCESS\ PARAMETER \rightarrow \blacksquare \rightarrow \pm \rightarrow EPD\ ADJUSTMENT$
- 2. Empty the piping:
 - The wall of the measuring tube should still be wet with fluid during EPD empty pipe adjustment
 - The wall of the measuring tube/the measuring electrodes should **no longer** be wet with fluid during OED empty pipe adjustment
- 3. Start empty-pipe adjustment: Select "EMPTY PIPE ADJUST" or "OED EMPTY ADJUST" and press \blacksquare to confirm.
- 4. After empty-pipe adjustment, fill the piping with fluid.
- 5. Start full-pipe adjustment: Select "FULL PIPE ADJUST" or "OED FULL ADJUST" and press © to confirm.
- 6. Having completed the adjustment, select the setting "OFF" and exit the function by pressing \blacksquare .
- 7. Switch on empty pipe detection in the EPD function:
 - EPD empty pipe adjustment: Select ON STANDARD or ON SPECIAL and press $\ensuremath{\mathbb{E}}$ to confirm
 - OED empty pipe adjustment: Select OED and confirm with \blacksquare .
 - Caution

The adjustment coefficients must be valid before you can activate the EPD function. If adjustment is incorrect the following messages might appear on the display:

- FULL = EMPTY
 - The adjustment values for empty pipe and full pipe are identical. In cases of this nature you must repeat empty-pipe or full-pipe adjustment!
- ADJUSTMENT NOT OK
 Adjustment is not possible because the fluid's conductivity is out of range.

Commissioning Promag 50

6.6 Data storage device (HistoROM)

At Endress+Hauser, the term HistoROM refers to various types of data storage modules on which process and measuring device data are stored. It is possible to plug these modules into other devices to copy device configurations from one device to another, for example.

6.6.1 HistoROM/S-DAT (sensor-DAT)

The S-DAT is an exchangeable data storage device in which all sensor relevant parameters are stored, i.e., diameter, serial number, calibration factor, zero point.

Promag 50 Maintenance

7 Maintenance

No special maintenance work is required.

7.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing and the seals.

7.2 Seals

The seals of the Promag H sensor must be replaced periodically, particularly in the case of gasket seals (aseptic version).

The period between changes depends on the frequency of cleaning cycles, the cleaning temperature and the fluid temperature.

Replacement seals (accessories) $\rightarrow \blacksquare$ 78.

Accessories Promag 50

8 Accessories

Various accessories, which can be ordered separately from Endress+Hauser, are available for the transmitter and the sensor. Your Endress+Hauser service organization can provide detailed information on the specific order codes on request.

8.1 Device-specific accessories

Accessory	Description	Order code
Proline Promag 50 transmitter	Transmitter for replacement or storage. Use the order code to define the following specifications:	50XXX - XXXXX*****
	 Approvals Degree of protection/version Cable for remote version Cable entry Display/power supply/operation Software Outputs/inputs 	

8.2 Measuring principle-specific accessories

Accessory	Description	Order code
Mounting set for Promag 50 transmitter	Mounting set for the transmitter (remote version). Suitable for Wall mounting Pipe mounting Panel-mounted installation	DK5WM - *
	Mounting set for aluminum field housing. Suitable for: • Pipe mounting	
Wall-mounting kit for Promag H	Wall-mounting kit for the Promag H sensor.	DK5HM - **
Cable for remote version	Coil and signal cables, various lengths.	DK5CA - **
Mounting kit for Promag D, wafer version	 Mounting bolts Nuts incl. washers Flange seals Centering sleeves (if required for the flange) 	DKD** - **
Set of seals for Promag D	Set of seals consisting of two flange seals.	DK5DD - ***
Mounting kit for Promag H	2 process connectionsThreaded fastenersSeals	DKH** - ****
Set of seals for Promag H	For regular replacement of the seals of the Promag H sensor.	DK5HS - ***
Welding jig for Promag H	Weld nipple as process connection: welding jig for installation in pipe.	DK5HW - ***
Adapter connection for Promag A, H	Adapter connections for installing a Promag 10 H instead of a Promag 30/33 A or Promag 30/33 H DN 25.	DK5HA - ****
Ground rings for Promag H	Ground rings for potential equalization.	DK5HR - ***
Ground cable for Promag E/L/P/W	Ground cable for potential equalization.	DK5GC - ***
Ground disk for Promag E/L/P/W	Ground disk for potential equalization.	DK5GD - * * ***
Process display RIA45	Multifunctional 1-channel display unit: Universal input Transmitter power supply Limit relay Analog output	RIA45 - *****

Promag 50 Accessories

Accessory	Description	Order code
Process display RIA251	Digital display device for looping into the 4 to 20 mA current loop.	RIA251 - **
Field display unit RIA16	Digital field display device for looping into the 4 to 20 mA current loop.	RIA16 - ***
Application Manager RMM621	Electronic recording, display, balancing, control, saving and event and alarm monitoring of analog and digital input signals. Values and conditions determined are output by means of analog and digital output signals. Remote transmission of alarms, input values and calculated values using a PSTN or GSM modem.	RMM621 - *******

8.3 Communication-specific accessories

Accessory	Description	Order code
HART Communicator Field Xpert SFX 100	Handheld terminal for remote configuration and for obtaining measured values via the HART current output (4 to 20 mA) and FOUNDATION Fieldbus. Contact your Endress+Hauser representative for more information.	SFX100 - ******
Fieldgate FXA320	Gateway for remote interrogation of HART sensors and actuators via Web browser: 2-channel analog input (4 to 20 mA) 4 binary inputs with event counter function and frequency measurement Communication via modem, Ethernet or GSM Visualization via Internet/Intranet in Web browser and/or WAP cellular phone Limit value monitoring with alarm by e-mail or SMS Synchronized time stamping of all measured values.	FXA320 - ****
Fieldgate FXA520	Gateway for remote interrogation of HART sensors and actuators via Web browser: Web server for remote monitoring of up to 30 measuring points Intrinsically safe version [EEx ia]IIC for applications in hazardous areas Communication via modem, Ethernet or GSM Visualization via Internet/Intranet in Web browser and/or WAP cellular phone Limit value monitoring with alarm by e-mail or SMS Synchronized time stamping of all measured values Remote diagnosis and remote configuration of connected HART devices	FXA520 - ****
FXA195	The Commubox FXA195 connects intrinsically safe Smart transmitters with HART protocol to the USB port of a personal computer. This makes the remote operation of the transmitters possible with the aid of configuration programs (e.g. FieldCare). Power is supplied to the Commubox by means of the USB port	FXA195 - *

Accessories Promag 50

8.4 Service-specific accessories

Accessory	Description	Order code
Applicator Software for selecting and planning flowmeters. The Applicator software can be downloaded from the Internet or ordered on CD-ROM for installation on a local PC. Contact your Endress+Hauser representative for more information.		DXA80 - *
Fieldcheck Tester/simulator for testing flowmeters in the field. When used in conjunction with the "FieldCare" software package, test results can be imported into a database, printed out and used for official certification. Contact your Endress+Hauser representative for more information.		50098801
FieldCare	FieldCare is Endress+Hauser's FDT-based asset management tool. It can configure all intelligent field units in your system and helps you manage them. By using status information, it is also a simple but effective way of checking their status and condition.	See the product page on the Endress+Hauser Web site: www.endress.com
Memograph M graphic display recorder	The Memograph M graphic display recorder provides information on all the relevant process variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a DSD card or USB stick. Memograph M boasts a modular design, intuitive operation and a comprehensive security concept. The ReadWin® 2000 PC software is part of the standard package and is used for configuring, visualizing and archiving the data captured. The mathematics channels which are optionally available enable continuous monitoring of specific power consumption, boiler efficiency and other parameters which are important for efficient energy management.	
FXA193	Service interface from the device to the PC for operation via FieldCare.	FXA193 - *

9 Troubleshooting

9.1 Troubleshooting instructions

Always start troubleshooting with the checklist below if faults occur after start-up or during operation. The routine takes you directly to the cause of the problem and the appropriate remedial measures.

Check the display		
No display visible and no	1. Check the supply voltage \rightarrow terminals 1, 2	
output signals present.	2. Check the power line fuse $\rightarrow riangleq 93$ 85 to 260 V AC: 0.8 A slow-blow / 250 V 20 to 55 V AC / 16 to 62 V DC: 2 A slow-blow / 250 V	
	3. Measuring electronics defective \rightarrow order spare parts \rightarrow $\stackrel{\triangle}{=}$ 88	
No display visible, but output signals are present.	1. Check whether the ribbon-cable connector of the display module is correctly plugged into the amplifier board \Rightarrow \cong 89	
	2. Display module defective → order spare parts \rightarrow 🖺 88	
	3. Measuring electronics defective \rightarrow order spare parts \rightarrow $\stackrel{\triangle}{=}$ 88	
Display texts are in a foreign language.	Switch off power supply. Press and hold down both the OS buttons and switch on the measuring device. The display text will appear in English (default) and is displayed maximum contrast.	
Measured value indicated, but no signal at the current or pulse output.	r	
\		
Error messages on display	y	
2	commissioning or measuring operation are displayed immediately. a variety of icons: the meanings of these icons are as follows (example):	
 Error type: S = system error, P = process error Error message type: ½ = fault message, ! = notice message EMPTY PIPE = Type of error, e.g. measuring tube is only partly filled or completely empty 		

- **03:00:05** = duration of error occurrence (in hours, minutes and seconds)
- #401 = error number
- Caution!
- See the information on \rightarrow $\stackrel{\triangle}{=}$ 63!
- The measuring system interprets simulations and positive zero return as system errors, but displays them as notice message only.

Error number: No. 001 – 399 No. 501 – 699	System error (device error) has occurred $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $
Error number: No. 401 - 499	Process error (application error) has occurred $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $
1	

Other error (without error message) Some other error has occurred. Diagnosis and rectification → ■ 85

Troubleshooting Promag 50

9.2 System error messages

Serious system errors are **always** recognized by the device as "Fault message", and are shown as a lightning flash (*) on the display. Fault messages immediately affect the outputs.



Caution!



Notel

Also observe the information on $\rightarrow \triangleq 63$.

No.	Error message / Type	Cause	Remedy (spare part → 🖺 88)
ع = Fau	stem error alt message (with an effect tice message (without an e		
No. #	0xx → Hardware error		
001	S: CRITICAL FAILURE \$: # 001	Serious device error	Replace the amplifier board.
011	S: AMP HW EEPROM \$: # 011	Amplifier: Defective EEPROM	Replace the amplifier board.
012	S: AMP SW EEPROM \$: # 012	Amplifier: Error accessing EEPROM data	The EEPROM data blocks in which an error has occurred are displayed in the TROUBLESHOOTING function. Press Enter to acknowledge the errors in question; default values are automatically inserted instead of the errored parameter values. Note!
			The measuring device has to be restarted if an error has occurred in a totalizer block (see error No. 111 / CHECKSUM TOTAL).
031	S: SENSOR HW DAT \$: # 031	S-DAT is not plugged into the amplifier board correctly (or is missing).	Check whether the S-DAT is correctly plugged into the amplifier board.
		2. S-DAT is defective.	 Replace the S-DAT if it is defective. Check that the new replacement DAT is compatible with the measuring electronics.
032	S: SENSOR SW DAT \$: # 032		Check the: - Spare part set number - Hardware revision code
			3. Replace measuring electronics boards if necessary.
			4. Plug the S-DAT into the amplifier board.
No. #	1xx → Software error		
101	S: GAIN ERROR AMP \$: # 101	Gain deviation compared to reference gain > 25%.	Replace the amplifier board.
111	S: CHECKSUM TOTAL	Totalizer checksum error.	Restart the measuring device.
	\$: # 111		2. Replace the amplifier board if necessary.
121	S: A / C COMPATIB. !: # 121	Due to different software versions, I/O board and amplifier board are only partially compatible (possibly restricted functionality). Note! This message is only listed in the error history. Nothing is shown on the display.	Module with lower software version has either to be updated by FieldCare with the required software version or the module has to be replaced.

No.	Error message / Type	Cause	Remedy (spare part → 🖺 88)
No. # 2	$2xx \rightarrow Error in DAT / no contract 0$	ommunication	
251	S: COMMUNICATION I/O \$: # 251	Internal communication fault on the amplifier board.	Replace the amplifier board.
261	S: COMMUNICATION I/O \$: # 261	No data reception between amplifier and I/O board or faulty internal data transfer.	Check the BUS contacts.
No. # 3	Bxx → System limits excee	eded	
321	S: TOL. COIL CURR. \$: # 321	Sensor: Coil current is out of tolerance.	Warning! Switch off power supply before manipulating the coil current cable, coil current cable connector or measuring electronics boards!
			Remote version:
			1. Check wiring of terminals $41/42 \rightarrow \triangle 46$
			2. Check coil current cable connector.
			Compact and remote version: Replace measuring electronics boards if necessary
339	S: STACK CUR OUT n	The temporarily buffered flow portions (measuring	1. Change the upper or lower limit setting, as applicable.
to 342	!: # 339 to 342	mode for pulsating flow) could not be cleared or	2. Increase or reduce flow, as applicable.
	C. CTACKEDEO OUT	output within 60 seconds.	Recommendations in the event of fault category = FAULT
343 to	S: STACK FREQ. OUT n !: # 343 to 346		MESSAGE (\$)
346	5 15 60 5 10		Configure the fault response of the output to "ACTUAL VALUE" so that the temporary buffer can be cleared.
			 Clear the temporary buffer by the measures described under
			Item 1.
347	S: STACK PULSE OUT n	The temporarily buffered flow portions (measuring	1. Increase the setting for pulse weighting
to 350	!: # 343 to 346	mode for pulsating flow) could not be cleared or output within 60 seconds.	2. Increase the max. pulse frequency if the totalizer can handle a higher number of pulses.
			3. Increase or reduce flow, as applicable.
			Recommendations in the event of fault category = FAULT MESSAGE (\$)
			 Configure the fault response of the output to "ACTUAL VALUE" so that the temporary buffer can be cleared. Clear the temporary buffer by the measures described under Item 1.
351	S: CURRENT RANGE n	Current output:	1. Change the upper or lower limit setting, as applicable.
to 354	!: # 351 to 354	flow is out of range.	Increase or reduce flow, as applicable.
355	S: FREQ. RANGE n	Frequency output:	1. Change the upper or lower limit setting, as applicable.
to 358	!: # 355 to 358	flow is out of range.	2. Increase or reduce flow, as applicable.
359	S: PULSE RANGE	Pulse output:	Increase the setting for pulse weighting
to 362	!: # 359 to 362	the pulse output frequency is out of range.	 2. When selecting the pulse width, choose a value that can still be processed by a connected counter (e.g. mechanical counter, PLC etc.). Determine the pulse width: Variant 1: Enter the minimum duration that a pulse must be present at the connected counter to ensure its registration. Variant 2: Enter the maximum (pulse) frequency as the
			half "reciprocal value" that a pulse must be present at the connected counter to ensure its registration. Example: The maximum input frequency of the connected counter is 10 Hz. The pulse width to be entered is: $\frac{1}{2\cdot 10~\text{Hz}} = 50~\text{ms}$
			3. Reduce flow.

Troubleshooting Promag 50

No.	Error message / Type	Cause	Remedy (spare part → 🖺 88)			
No. # !	Vo. # $5xx$ → Application error					
501	S: SWUPDATE ACT. !: # 501	New amplifier or communication (I/O module) software version is loaded. Currently no other functions are possible.	Wait until the procedure is finished. The device will restart automatically.			
502	S: UP-/DOWNLOAD ACT !: # 502	Uploading or downloading the device data via operating program. Currently no other functions are possible.	Wait until the procedure is finished.			
No. # 6	$\delta xx \rightarrow Simulation mode according to the second contract of the sec$	rtive				
601	S: POS. ZERO-RETURN !: # 601	Positive zero return active Caution! This message has the highest display priority!	Switch off positive zero return			
611 to 614	S: SIM. CURR. OUT. n !: # 611 to 614	Simulation current output active				
621 to 624	S: SIM. FREQ. OUT. n !: # 621 to 624	Simulation frequency output active	Switch off simulation			
631 to 634	S: SIM. PULSE n !: # 631 to 634	Simulation pulse output active	Switch off simulation			
641 to 644	S: SIM. STAT. OUT n !: # 641 to 644	Simulation status output active	Switch off simulation			
671 to 674	S: SIM. STATUS IN n !: # 671 to 674	Simulation status input active	Switch off simulation			
691	S: SIM. FAILSAFE !: # 691	Simulation of response to error (outputs) active	Switch off simulation			
692	S: SIM. MEASURAND !: # 692	Simulation of a measured variable active (e.g. mass flow).	Switch off simulation			
698	S: DEV. TEST ACT. !: # 698	The measuring device is being checked on site via the test and simulation device.	-			

9.3 Process error messages



Note!

Also observe the information on $\rightarrow \triangleq 63$.

No.	Error message / Type	Cause	Remedy (spare part → 🖺 88)
P = Process error \$ = Fault message (with an effect on the outputs) ! = Notice message (without an effect on the outputs)			
401	EMPTY PIPE \$: # 401	Measuring tube partially filled or empty	 Check the process conditions of the plant Fill the measuring tube
461	ADJ. NOT OK !: # 461	EPD calibration not possible because the fluid's conductivity is either too low or too high.	The EPD function cannot be used with fluids of this nature.
463	FULL = EMPTY \$: # 463	The EPD calibration values for empty pipe and full pipe are identical, therefore incorrect.	Repeat calibration, making sure procedure is correct $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $

9.4 Process errors without messages

Symptoms	Rectification		
Remark: You may have to change or c	orrect certain settings in functions in the function matrix in order to rectify the fault.		
Flow values are negative, even though the fluid is flowing forwards through the pipe.			
Measured-value reading fluctuates even though flow is steady.	 Check grounding and potential equalization →		
Measured-value reading shown on display, even though the fluid is at a standstill and the measuring tube is full.	 Check grounding and potential equalization → \$\bigsim 55\$ Check the fluid for presence of gas bubbles. Activate the "LOW FLOW CUTOFF" function, i.e. enter or increase the value for the switching point. 		
Measured-value reading on display, even though measuring tube is empty.	 Perform empty-pipe/full-pipe adjustment and then switch on Empty Pipe detection → \$\begin{align*} \Pi \ 75 \end{align*} Remote version: Check the terminals of the EPD cable → \$\begin{align*} \Pi \ 46 \end{align*} Fill the measuring tube. 		
The current output signal is always 4 mA, irrespective of the flow signal at any given time.	 Select the "BUS ADDRESS" function and change the setting to "0". Value for creepage too high. Reduce the value in the "LOW FLOW CUTOFF" function. 		
The fault cannot be rectified or some other fault not described above has arisen. In these instances, please contact your Endress+Hauser service organization.	The following options are available for tackling problems of this nature: Request the services of an Endress+Hauser service technician If you contact our service organization to have a service technician sent out, please be ready to quote the following information: Brief description of the fault Nameplate specifications (→ 6): order code, serial number Returning devices to Endress+Hauser The necessary procedures (→ 5) must be carried out before you return a flowmeter requiring repair or calibration to Endress+Hauser. Always enclose a duly completed "Declaration of Conformity" form with the flowmeter. You will find a master copy of this form at the back of this manual. Replace transmitter electronics		
	Components in the measuring electronics defective \rightarrow order spare parts $\rightarrow \stackrel{\square}{=} 88$		

Troubleshooting Promag 50

9.5 Response of outputs to errors



Note!

The failsafe mode of totalizers, current, pulse and frequency outputs can be customized by means of various functions in the function matrix. You will find detailed information on these procedures in the "Description of Device Functions" manual.

You can use positive zero return to set the signals of the current, pulse and status outputs to their fallback value, for example when measuring has to be interrupted while a pipe is being cleaned. This function takes priority over all other device functions: simulations, for example, are suppressed.

Failsafe mode	of outputs and totalizers	
	Process/system error is current	Positive zero return is activated
Caution System or proce the information	ess errors defined as "Notice messages" have no effect whatsoeve	er on the inputs and outputs. See
Current output	MINIMUM VALUE $0-20 \text{ mA} \rightarrow 0 \text{ mA}$ $4-20 \text{ mA} \rightarrow 2 \text{ mA}$ $4-20 \text{ mA} \text{ HART} \rightarrow 2 \text{ mA}$ $4-20 \text{ mA} \text{ NAMUR} \rightarrow 3.5 \text{ mA}$ $4-20 \text{ mA} \text{ HART} \text{ NAMUR} \rightarrow 3.5 \text{ mA}$ $4-20 \text{ mA} \text{ US} \rightarrow 3.75 \text{ mA}$ $4-20 \text{ mA} \text{ HART} \text{ US} \rightarrow 3.75 \text{ mA}$ $4-20 \text{ mA} \text{ HART} \text{ US} \rightarrow 3.75 \text{ mA}$ $0-20 \text{ mA} (25 \text{ mA}) \rightarrow 0 \text{ mA}$ $4-20 \text{ mA} (25 \text{ mA}) \rightarrow 2 \text{ mA}$ $4-20 \text{ mA} (25 \text{ mA}) \text{ HART} \rightarrow 2 \text{ mA}$	Output signal corresponds to "zero flow"
	MAXIMUM VALUE $0-20 \text{ mA} \rightarrow 22 \text{ mA}$ $4-20 \text{ mA} \rightarrow 22 \text{ mA}$ $4-20 \text{ mA} \rightarrow 22 \text{ mA}$ $4-20 \text{ mA} \text{ HART} \rightarrow 22 \text{ mA}$ $4-20 \text{ mA} \text{ NAMUR} \rightarrow 22.6 \text{ mA}$ $4-20 \text{ mA} \text{ HART NAMUR} \rightarrow 22.6 \text{ mA}$ $4-20 \text{ mA} \text{ US} \rightarrow 22.6 \text{ mA}$ $4-20 \text{ mA} \text{ HART US} \rightarrow 22.6 \text{ mA}$ $4-20 \text{ mA} \text{ HART US} \rightarrow 22.6 \text{ mA}$ $0-20 \text{ mA} (25 \text{ mA}) \rightarrow 25 \text{ mA}$ $0-20 \text{ mA} (25 \text{ mA}) \rightarrow 25 \text{ mA}$ $0-20 \text{ mA} (25 \text{ mA}) \rightarrow 25 \text{ mA}$ $0-20 \text{ mA} (25 \text{ mA}) \rightarrow 25 \text{ mA}$ $0-20 \text{ mA} (25 \text{ mA}) \rightarrow 25 \text{ mA}$ $0-20 \text{ mA} (25 \text{ mA}) \rightarrow 25 \text{ mA}$	
	HOLD VALUE Last valid value (preceding occurrence of the fault) is output. ACTUAL VALUE	
	Measured value display on the basis of the current flow measurement. The fault is ignored.	
Pulse output	MIN/MAX VALUE \rightarrow FALLBACK VALUE Signal output \rightarrow no pulses HOLD VALUE	Output signal corresponds to "zero flow"
	Last valid value (preceding occurrence of the fault) is output. ACTUAL VALUE Fault is ignored, i.e. normal measured-value output on the basis of ongoing flow measurement.	
Frequency output	FALLBACK VALUE Signal output → 0 Hz	Output signal corresponds to "zero flow"
	FAILSAFE LEVEL Output of the frequency specified in the FALÌLSAFE VALUE function.	
	HOLD VALUE Measured value display on the basis of the last saved value preceding occurrence of the fault.	
	ACTUAL VALUE Measured value display on the basis of the current flow measurement. The fault is ignored.	

Failsafe mode of outputs and totalizers				
	Process/system error is current	Positive zero return is activated		
Totalizer	STOP The totalizers are paused until the error is rectified.	Totalizer stops		
	ACTUAL VALUE The fault is ignored. The totalizer continues to count in accordance with the current flow value.			
	HOLD VALUE The totalizer continues to count the flow in accordance with the last valid flow value (before the error occurred).			
Status output	In the event of a fault or power supply failure: Status output → non-conductive	No effect on status output		

Troubleshooting Promag 50

9.6 Spare parts

Detailed troubleshooting instructions are provided in the previous sections $\rightarrow \triangleq 81$ The measuring device, moreover, provides additional support in the form of continuous selfdiagnosis and error messages.

Fault rectification can entail replacing defective components with tested spare parts. The illustration below shows the available scope of spare parts.



Note!

You can order spare parts directly from your Endress+Hauser service organization by providing the serial number printed on the transmitter's nameplate $\rightarrow \stackrel{\triangle}{=} 6$

Spare parts are shipped as sets comprising the following parts:

- Spare part
- Additional parts, small items (threaded fasteners, etc.)
- Mounting instructions
- Packaging




Fig. 53: Spare parts for Promag 50 transmitter (field and wall-mounted housings)

Power unit board (85 to 260 V AC, 20 to 55 V AC, 16 to 62 V DC)

- Amplifier board
- 3
- I/O board (COM module) HistoROM / S-DAT (sensor data memory)

Display module

9.6.1 Removing and installing printed circuit boards



Field housing: removing and installing printed circuit boards $\rightarrow \blacksquare 54$

Warning!

- Risk of electric shock!
 - Exposed components carry dangerous voltages. Make sure that the power supply is switched off before you remove the cover of the electronics compartment.
- Risk of damaging electronic components (ESD protection). Static electricity can damage electronic components or impair their operability. Use a workplace with a grounded working surface purpose-built for electrostatically sensitive devices!
- If you cannot guarantee that the dielectric strength of the device is maintained in the following steps, then an appropriate inspection must be carried out in accordance with the manufacturer's specifications.
- When connecting Ex-certified devices, see the notes and diagrams in the Ex-specific supplement to these Operating Instructions.



Caution!

Use only original Endress+Hauser parts.

- 1. Switch off power supply.
- 2. Unscrew cover of the electronics compartment from the transmitter housing.
- 3. Remove the local display (1) as follows:
 - Press in the latches (1.1) at the side and remove the display module.
 - Disconnect the ribbon cable (1.2) of the display module from the amplifier board.
- 4. Remove the screws and remove the cover (2) from the electronics compartment.
- 5. Remove the boards (4, 6): Insert a suitable tool into the hole (3) provided for the purpose and pull the board clear of its holder.
- 6. Remove amplifier board (5):
 - Disconnect the plug of the electrode signal cable (5.1) including S-DAT (5.3) from the board.
 - Loosen the plug locking of the coil current cable (5.2) and gently disconnect the plug from the board, i.e. without moving it to and fro.
 - Insert a thin pin into the hole (3) provided for the purpose and pull the board clear of its holder.
- 7. Installation is the reverse of the removal procedure.

Troubleshooting Promag 50




Fig. 54: Field housing: removing and installing printed circuit boards

- Local display
- 1.1 1.2 2 3

- 4 5 5.1 5.2 5.3 6

- Local display
 Latch
 Ribbon cable (display module)
 Screws of electronics compartment cover
 Aperture for installing/removing boards
 Power supply board
 Amplifier board
 Electrode signal cable (sensor)
 Coil current cable (sensor)
 Histo-ROM / S-DAT (sensor data memory)
 I/O board

Wall-mount housing: removing and installing printed circuit boards $\rightarrow \blacksquare$ 55



Warning!

- Risk of electric shock!
 Exposed components carry dangerous voltages. Make sure that the power supply is switched off before you remove the cover of the electronics compartment.
- Risk of damaging electronic components (ESD protection). Static electricity can damage electronic components or impair their operability. Use a workplace with a grounded working surface purpose-built for electrostatically sensitive devices!
- If you cannot guarantee that the dielectric strength of the device is maintained in the following steps, then an appropriate inspection must be carried out in accordance with the manufacturer's specifications.
- When connecting Ex-certified devices, see the notes and diagrams in the Ex-specific supplement to these Operating Instructions.



Caution!

Use only original Endress+Hauser parts.

- 1. Switch off power supply.
- 2. Remove the screws and open the hinged cover (1) of the housing. Remove screws of the electronics module (2).
- 3. Then push up electronics module and pull it as far as possible out of the wall-mounted housing.
- 4. Disconnect the following cable plugs from amplifier board (7):
 - Electrode signal cable plug (7.1) including S-DAT (7.3).
 - Plug of coil current cable (7.2). To do so, loosen the plug locking of the coil current cable and gently disconnect the plug from the board, i.e. without moving it to and fro.
 - Ribbon cable plug (3) of the display module.
- 5. Remove the screws and remove the cover (4) from the electronics compartment.
- 6. Remove the boards (6, 7, 8): Insert a suitable tool into the hole (5) provided for the purpose and pull the board clear of its holder.
- 7. Installation is the reverse of the removal procedure.

Troubleshooting Promag 50




Fig. 55: Wall-mount housing: removing and installing printed circuit boards

- Housing cover
- Electronics module
- Electronics module
 Ribbon cable (display module)
 Cover of electronics compartment (3 screws)
 Aperture for installing/removing boards
 Power supply board
 Amplifier board
 Electrode signal cable (sensor)
 Coil current cable (sensor)
 Histo-ROM / S-DAT (sensor data memory)
 I/O board

9.6.2 Replacing the device fuse



Warning!

Risk of electric shock! Exposed components carry dangerous voltages. Make sure that the power supply is switched off before you remove the cover of the electronics compartment.

The main fuse is on the power supply board ($\rightarrow \blacksquare$ 56).

The procedure for replacing the fuse is as follows:

- 1. Switch off power supply.
- 3. Remove cap (1) and replace the device fuse (2). Use only fuses of the following type:
 - Power supply 20 to 55 V AC / 16 to 62 V DC \rightarrow 2.0 A slow-blow / 250 V; 5.2 × 20 mm
 - Power supply 85 to 260 V AC $\,
 ightarrow\,$ 0.8 A slow-blow / 250 V; 5.2 × 20 mm
 - Ex-rated devices \rightarrow see the Ex documentation.
- 4. Installation is the reverse of the removal procedure.



Caution!

Use only original Endress+Hauser parts.




Fig. 56: Replacing the device fuse on the power supply board


1 Protective cap

2 Device fuse

Troubleshooting Promag 50

Replacing the exchangeable electrode 9.6.3

The Promag W sensor (DN 350 to 2000 / 14 to 78") is available with exchangeable measuring electrodes as an option. This design permits the measuring electrodes to be replaced or cleaned under process conditions.



Apparatus for replacing exchangeable measuring electrodes

View A = DN 1200 to 2000 (48 to 78")

View B = DN 350 to 1050 (14 to 42")

- Allen screw
- Handle
- Electrode cable
- Knurled nut (locknut)
- Measuring electrode Stop cock (ball valve)
- Retaining cylinder
- Locking pin (for handle)
- Ball-valve housing
 Seal (retaining cylinder)
- 10 11

Coil spring

Removing the electrode		Installing the electrode		
1	Loosen Allen screw (1) and remove the cover.	1	Insert new electrode (5) into retaining cylinder (7) from below. Make sure that the seals at the tip of the electrode are clean.	
2	Remove electrode cable (3) secured to handle (2).	2	Mount handle (2) on the electrode and insert locking pin (8) to secure it in position. Caution! Make sure that coil spring (11) is inserted. This is essential to ensure correct electrical contact and correct measuring signals.	
3	Loosen knurled nut (4) by hand. This knurled nut acts as a locknut.	3	Pull the electrode back until the tip of the electrode no longer protrudes from retaining cylinder (7).	
4	Remove electrode (5) by turning handle (2). The electrode can now be pulled out of retaining cylinder (7) as far as a defined stop. Marning! Risk of injury. Under process conditions (pressure in the piping system) the electrode can recoil suddenly against its stop. Apply counter-pressure while releasing the electrode.	4	Screw the retaining cylinder (7) onto ball-valve housing (9) and tighten it by hand. Seal (10) on the cylinder must be correctly seated and clean. Note! Make sure that the rubber hoses on retaining cylinder (7) and stop cock (6) are of the same color (red or blue).	
5	Close stop cock (6) after pulling out the electrode as far as it will go. Marning! Do not subsequently open the stop cock, in order to prevent fluid escaping.	5	Open stop cock (6) and turn handle (2) to screw the electrode all the way into the retaining cylinder.	
6	Remove the electrode complete with retaining cylinder (7).	6	Screw knurled nut (4) onto the retaining cylinder. This firmly locates the electrode in position.	
7	Remove handle (2) from electrode (5) by pressing out locking pin (8). Take care not to lose coil spring (11).	7	Use the Allen screw to secure electrode cable (3) to handle (2). Caution! Make sure that the machine screw securing the electrode cable is firmly tightened. This is essential to ensure correct electrical contact and correct measuring signals.	
8	Remove the old electrode and insert the new electrode. Replacement electrodes can be ordered separately from Endress+Hauser.	8	Reinstall the cover and tighten Allen screw (a).	

Troubleshooting Promag 50

9.7 Return



Caution!

Do not return a measuring device if you are not absolutely certain that all traces of hazardous substances have been removed, e.g. substances which have penetrated crevices or diffused through plastic.

Costs incurred for waste disposal and injury (burns, etc.) due to inadequate cleaning will be charged to the owner-operator.

The following steps must be taken before returning a flow measuring device to Endress+Hauser, e.g. for repair or calibration:

- Always enclose a duly completed "Declaration of contamination" form. Only then can Endress+Hauser transport, examine and repair a returned device.
- Enclose special handling instructions if necessary, for example a safety data sheet as per EC REACH Regulation No. 1907/2006.
- Remove all residues. Pay special attention to the grooves for seals and crevices which could contain residues. This is particularly important if the substance is hazardous to health, e.g. flammable, toxic, caustic, carcinogenic, etc.



Motal

You will find a preprinted "Declaration of contamination" form at the back of these Operating Instructions.

9.8 Disposal

Observe the regulations applicable in your country!

9.9 Software history

Date	Software version	Changes to software	Operating Instructions
01.2011	Amplifier: V 2.04.XX	Introduction of new nominal diameters; calf values to 2.5	71249447 / 15.14
11.2009	Amplifier: V 2.03.XX	Introduction of Calf history	71106181 / 12.09 71105332 / 11.09
06.2009	Amplifier: V 2.02.XX	Introduction of Promag L	71095684 / 06.09
03.2009	Amplifier: V 2.02.XX	Introduction of Promag D Introduction of new nominal diameter	71088677 / 03.09
11.2004	Amplifier: 1.06.01 Communication module: 1.04.00	Software update relevant only for production	50097089 / 10.03
10.2003	Amplifier: 1.06.00 Communication module: 1.03.00	Software expASMEon: Language groups Flow direction pulse output selectable New functionalities: Second Totalizer Adjustable backlight (display) Operation hours counter Simulation function for pulse output Counter for access code Reset function (fault history) Up-/download with FieldTool	50097089 / 10.03

Date	Software version	Changes to software	Operating Instructions
08.2003	Communication module: 1.02.01	Software expASMEon: New / revised functionalities	50097089 / 08.03
		New functionalities: Current span NAMUR NE 43 Failsafe mode function Troubleshooting function System and process error messages Response of status output	
08.2002	Amplifier: 1.04.00	Software expASMEon: New / revised functionalities	50097089 / 08.02
		New functionalities: Current span NAMUR NE 43 EPD (new mode) Failsafe mode function Acknowledge fault function Troubleshooting function System and process error messages Response of status output	
03.2002	Amplifier: 1.03.00	Software expASMEon: Suitability for custody transfer measurement Promag 50/51	none
06.2001	Amplifier: 1.02.00 Communication module: 1.02.00	Software expASMEon: New functionalities: New functionalities: General device functions "OED" software function "Pulse width" software function	50097089 / 06.01
09.2000	Amplifier: 1.01.01 Communication module: 1.01.00	Software expASMEon: • Functional adaptations	none
08.2000	Amplifier: 1.01.00	Software expASMEon: • Functional adaptations	none
04.2000	Amplifier: 1.00.00 Communication module: 1.00.00	Original software Compatible with: FieldTool Commuwin II (version 2.05.03 and higher) HART Communicator DXR 275 (from OS 4.6) with Rev. 1, DD1	50097089 / 04.00



Note

Uploads or downloads between the individual software versions are only possible with a special service software.

Technical data Promag 50

10 Technical data

10.1 Technical data at a glance

10.1.1 Application

 $\rightarrow \blacksquare 4$

10.1.2 Function and system design

Measuring principle

Electromagnetic flow measurement on the basis of Faraday's Law.

Measuring system

 $\rightarrow \blacksquare 6$

10.1.3 Input

Measured variable

Flow velocity (proportional to induced voltage)

Measuring range

Typically v = 0.01 to 10 m/s (0.033 to 33 ft/s) with the specified accuracy

Operable flow range

Over 1000:1

Input signal

Status input (auxiliary input)

- Galvanically isolated
- U = 3 to 30 V DC
- $Ri = 5 k\Omega$
- Can be configured for: totalizer reset, positive zero return, error message reset.

10.1.4 Output

Output signal

Current output

- Galvanically isolated
- Active/passive can be selected:
 - Active: 0/4 to 20 mA, R_L < 700 Ω (HART: $R_L \ge 250~\Omega)$
 - Passive: 4 to 20 mA, supply voltage V_S 18 to 30 V DC, R_i ≥150 Ω)
- Time constant can be selected (0.01 to 100s)
- Full scale value adjustable
- Temperature coefficient: typ. 0.005% o.f.s./°C, resolution: 0.5 µA

o.f.s. = of full scale value

Promag 50 Technical data

Pulse/frequency output

- Galvanically isolated
- Passive: 30 V DC / 250 mA
- Open collector
- Can be configured as:
 - Pulse output

Pulse value and pulse polarity can be selected, max. pulse width adjustable (0.5 to 2000 ms)

- Frequency output

Full scale frequency 2 to 1000 Hz (f_{max} = 1.25 Hz), on/off ratio 1:1, pulse width max. 10 s

Signal on alarm

Current output

Failsafe mode can be selected (e.g. in accordance with NAMUR Recommendation NE 43)

Pulse/frequency output

Failsafe mode can be selected

Status output

"Not conductive" in the event of fault or power supply failure

Load

See "Output signal"

Switching output

Status output

- Galvanically isolated
- Max. 30 V DC/250 mA
- Open collector
- Can be configured for: error messages, empty pipe detection (EPD), flow direction, limit values

Low flow cut off

Low flow cut off, switch-on point can be selected as required

Galvanic isolation

All circuits for inputs, outputs, and power supply are galvanically isolated from each other.

10.1.5 Power supply

Electrical connections

→ 🖺 46

Supply voltage (power supply)

- 20 to 55 V AC, 45 to 65 Hz
- 85 to 260 V AC, 45 to 65 Hz
- 16 to 62 V DC

Technical data Promag 50

Cable entry

Power supply and signal cables (inputs/outputs):

- Cable entry M20 × 1.5 (8 to 12 mm/0.31 to 0.47 inch)
- Sensor cable entry for armored cables M20 × 1.5 (9.5 to 16 mm / 0.37 to 0.63 inch)
- Threads for cable entries ½" NPT, G ½"

Connecting cable for remote version:

- Cable entry M20 × 1.5 (8 to 12 mm/0.31 to 0.47 inch)
- Sensor cable entry for armored cables M20 × 1.5 (9.5 to 16 mm / 0.37 to 0.63 inch)
- Threads for cable entries ½" NPT. G ½"

Cable specifications

→ 🖺 51

Power consumption

Power consumption

- AC: <15 VA (incl. sensor)
- DC: <15 W (incl. sensor)

Switch-on current

- max. 3 A (<5 ms) for 24 V DC
- max. 8.5 A (<5 ms) for 260 V AC

Power supply failure

- Lasting min. 1 cycle frequency:
- EEPROM saves measuring system data
- S-DAT: exchangeable data storage chip which stores the data of the sensor (nominal diameter, serial number, calibration factor, zero point etc.)

Potential equalization

→ 🖺 55

10.1.6 Performance characteristics

Reference operating conditions

To DIN EN 29104 and VDI/VDE 2641:

- Fluid temperature: +28 °C ± 2 K
- Ambient temperature: +22 °C ± 2 K
- Warm-up period: 30 minutes

Installation:

- Inlet run >10 × DN
- Outlet run > 5 × DN
- Sensor and transmitter grounded.
- The sensor is centered in the pipe.

Promag 50 Technical data

Maximum measured error

- Current output: plus typically ± 5 µA
- Pulse output: ± 0.5% o.r. ± 1 mm/s
 Option: ± 0.2% o.r. ± 2 mm/s (o.r. = of reading)

Fluctuations in the supply voltage do not have any effect within the specified range.




Fig. 58: Max. measured error in % of reading

Repeatability

Max. \pm 0.1% o.r. \pm 0.5 mm/s (o.r. = of reading)

10.1.7 Installation

Installation instructions

Any orientation (vertical, horizontal), restrictions and installation instructions $\rightarrow \blacksquare 12$

Inlet and outlet run

- Inlet run: ≥ 5 × DNOutlet run: ≥ 2 × DN
- **Adapters**

→ 🖺 16

Length of connecting cable

→ 🖺 19

10.1.8 Environment

Ambient temperature range

■ Transmitter: -20 to +60 °C (-4 to +140 °F)

Note

At ambient temperatures below $-20 (-4 \,^{\circ}\text{F})$ the readability of the display may be impaired.

Sensor (Flange material carbon steel): −10 to +60 °C (+14 to +140 °F)

Technical data Promag 50



Caution!

- The permitted temperature range of the measuring tube lining may not be undershot or overshot (→ "Operating conditions: Process" → "Medium temperature range").
- Install the device in a shady location. Avoid direct sunlight, particularly in warm climatic regions.
- The transmitter must be mounted separate from the sensor if both the ambient and fluid temperatures are high.

Storage temperature

The storage temperature corresponds to the operating temperature range of the measuring transmitter and the appropriate measuring sensors.



Caution!

- The measuring device must be protected against direct sunlight during storage in order to avoid unacceptably high surface temperatures.
- A storage location must be selected where moisture does not collect in the measuring device. This will help prevent fungus and bacteria infestation which can damage the liner.

Degree of protection

- Standard: IP 67 (NEMA 4X) for transmitter and sensor
- Optional: IP 68 (NEMA 6P) for remote version of Promag E/L/P/W sensor. Promag L only with stainless steel flanges.

Shock and vibration resistance

Acceleration up to 2 g following IEC 60068-2-6 (high-temperature version: no data available)

CIP cleaning



Caution!

The maximum fluid temperature permitted for the device may not be exceeded.

CIP cleaning is possible:

Promag E (100 °C / 212 °F), Promag H/P

CIP cleaning is not possible:

Promag D/L/W

SIP cleaning



Caution!

The maximum fluid temperature permitted for the device may not be exceeded.

SIP cleaning is possible:

Promag H

SIP cleaning is not possible:

Promag D/E/L/P/W

Electromagnetic compatibility (EMC)

- As per IEC/EN 61326 and NAMUR Recommendation NE 21
- Emission: to limit value for industry EN 55011

Promag 50 Technical data

10.1.9 Process

Medium temperature range

The permissible temperature depends on the lining of the measuring tube

Promag D

0 to +60 °C (+32 to +140 °F) for polyamide

Promag E

-10 to +110 °C (+14 to +230 °F) for PTFE, Restrictions → see the following diagram




Fig. 59: Compact and remote version Promag E (TA = ambient temperature; TF = fluid temperature)

Promag H

Sensor:

- DN 2 to 25: -20 to +150 °C (-4 to +302 °F)
- DN 40 to 100: -20 to +150 °C (-4 to +302 °F)

Seals:

- EPDM: -20 to +150 °C (-4 to +302 °F)
- Silicone: -20 to +150 °C (-4 to +302 °F)
- Viton: -20 to +150 °C (-4 to +302 °F)
- Kalrez: -20 to +150 °C (-4 to +302 °F)

Promag L

- 0 to +80 °C (+32 to +176 °F) for hard rubber (DN 350 to 1200)
- -20 to +50 °C (-4 to +122 °F) for polyurethane (DN 50 to 1200)
- -20 to +90 °C (-4 to +194 °F) for PTFE (DN 50 to 300)

Promag P

Standard

- -40 to +130 °C (-40 to +266 °F) for PTFE (DN 15 to 600 / 1/2 to 24"), Restrictions \rightarrow see the following diagrams
- -20 to +130 °C (-4 to +266 °F) for PFA/HE (DN 25 to 200 / 1 to 8"), Restrictions \rightarrow see the following diagrams
- -20 to +150 °C (-4 to +302 °F) for PFA (DN 25 to 200 / 1 to 8"), Restrictions \rightarrow see the following diagrams

Technical data Promag 50

Optional High-temperature version (HT): –20 to +180 $^{\circ}\text{C}$ (–4 to +356 $^{\circ}\text{F}) for PFA (DN 25 to 200 / 1$




Abb. 60: Compact version Promag P (with PFA- or PTFE-lining)

TA = ambient temperature; TF = fluid temperature; HT = high-temperature version with insulation m = light gray area \rightarrow temperature range from -10 to -40 °C (-14 to -40 °F) is valid for stainless steel version only n = diagonal hatched area \rightarrow foam lining (HE) and degree of protection IP 68 = fluid temperature max. 130°C / 266 °F




Abb. 61: Remote version Promag P (with PFA- or PTFE-lining)

TA = ambient temperature; TF = fluid temperature; HT = high-temperature version with insulation m = light gray area \rightarrow temperature range from -10 to -40 °C (-14 to -40 °F) is valid for stainless steel version only n = diagonal hatched area \rightarrow foam lining (HE) and degree of protection IP68 = fluid temperature max. 130°C / 266 °F

Promag W

- 0 to +80 °C (+32 to +176 °F) for hard rubber (DN 50 to 2000)
- -20 to +50 °C (-4 to +122 °F) for polyurethane (DN 25 to 1200)

Promag 50 Technical data

Conductivity

The minimum conductivity is $\geq 5 \mu \text{S/cm}$ ($\geq 20 \mu \text{S/cm}$ for demineralized water)



Note

Note that in the case of the remote version, the requisite minimum conductivity is also influenced by the length of the connecting cable $\rightarrow \blacksquare 19$

Medium pressure range (nominal pressure)

Promag D

- EN 1092-1 (DIN 2501)
 - PN 16
- ASME B 16.5
 - Class 150
- JIS B2220
 - 10K

Promag E

- EN 1092-1 (DIN 2501)
 - PN 10 (DN 200 to 600 / 8 to 24")
 - PN 16 (DN 65 to 600 / 3 to 24")
 - PN 40 (DN 15 to 150 / ½ to 2")
- ASME B 16.5
 - Class 150 (½ to 24")
- JIS B2220
 - 10K (DN 50 to 300 / 2 to 12")
 - 20K (DN 15 to 40 / ½ to 1½")

Promag H

The permissible nominal pressure depends on the process connection and the seal:

- 40 bar → flange, weld nipple (with O-ring seal)
- 16 bar → all other process connections

Promag L

- EN 1092-1 (DIN 2501)
 - PN 6 (DN 350 to 1200 / 14 to 48")
 - PN 10 (DN 50 to 1200 / 2 to 48")
 - PN 16 (DN 50 to 150 / 2 to 6")
- EN 1092-1, lap joint flange, stampel plate
 - PN 10 (DN 50 to 300 / 2 to 12")
- ASME B 16.5
 - Class 150 (2 to 24")
- AWWA
 - Class D (28 to 48")
- AS2129
 - Table E (DN 350 to 1200 / 14 to 48")
- AS4087
 - PN 16 (DN 350 to 1200 / 14 to 48")

Promag P

- EN 1092-1 (DIN 2501)
 - PN 10 (DN 200 to 600 / 8 to 24")
 - PN 16 (DN 65 to 600 / 3 to 24")
 - PN 25 (DN 200 to 600 / 8 to 24")
 - PN 40 (DN 25 to 150 / 1 to 6")

Technical data Promag 50

- ASME B 16.5
 - Class 150 (1 to 24")
 - Class 300 (1 to 6")
- JIS B2220
 - 10K (DN 50 to 300 / 2 to 12")
 - 20K (DN 25 to 300 / 1 to 12")
- AS 2129
 - Table E (DN 25 / 1"), 50 / 2")
- AS 4087
 - PN 16 (DN 50 / 2")

Promag W

- EN 1092-1 (DIN 2501)
 - PN 6 (DN 350 to 2000 / 14 to 84")
 - PN 10 (DN 200 to 2000 / 8 to 84")
 - PN 16 (DN 65 to 2000 / 3 to 84")
 - PN 25 (DN 200 to 1000 / 8 to 40")
 - PN 40 (DN 25 to 150 / 1 to 6")
- ASME B 16.5
 - Class 150 (1 to 24")
 - Class 300 (1 to 6")
- AWWA
 - Class D (28 to 78")
- JIS B2220
 - 10K (DN 50 to 300 / 2 to 12")
 - 20K (DN 25 to 300 / 1 to 12")
- AS 2129
 - Table E (DN 80 / 3", 100 / 4", 150 to 1200 / 6 to 48")
- AS 4087
 - PN 16 (DN 80 / 3", 100 / 4", 150 to 1200 / 6 to 48")

Pressure tightness

Promag D

Measuring tube: 0 mbar abs (0 psi abs) with a fluid temperature of \leq 60 °C (140 °F)

Promag E (Measuring tube lining: PTFE)

Nominal o	liameter	Resistance of measuring tube lining to partial vacuum Limit values for abs. pressure [mbar] ([psi]) at various fluid temperatures									
		25	°C	80	°C	100	100 °C		110 °C		
		77	°F	176	5°F	212	2 °F	230) °F		
[mm]	[inch]	[mbar]	[psi]			[mbar]	[psi]	[mbar]	[psi]		
15	1/2"	0	0	0	0	0	0	100	1.45		
25	1"	0	0	0	0	0	0	100	1.45		
32	-	0	0	0	0	0	0	100	1.45		
40	1 ½"	0	0	0	0	0	0	100	1.45		
50	2"	0	0	0	0	0	0	100	1.45		
65	-	0	0	*	*	40	0.58	130	1.89		
80	3"	0	0	*	*	40	0.58	130	1.89		
100	4"	0	0	*	*	135	1.96	170	2.47		
125	-	135	1.96	*	*	240	3.48	385	5.58		
150	6"	135	1.96	*	*	240	3.48	385	5.58		
200	8"	200	2.90	*	*	290	4.21	410	5.95		
250	10"	330	4.79	*	*	400	5.80	530	7.69		

Promag 50 Technical data

Nominal o	liameter		Resistance of measuring tube lining to partial vacuum Limit values for abs. pressure [mbar] ([psi]) at various fluid temperatures									
		25	°C	80) °C	100)°C	110 °C				
		77	°F	17	6 °F	212 °F		230 °F				
[mm]	[inch]	[mbar]	[psi]			[mbar]	[psi]	[mbar]	[psi]			
300	12"	400	400 5.80 * * 500 7.25 630									
350	14"	470	6.82	*	*	600	8.70	730	10.59			
400	16"	540	7.83	*	*	670	9.72	800	11.60			
450	18"			Part	ial vacuum i	s impermiss	ible!					
500	20"											
600	24"											
* No value	can be quo	oted.										

Promag H (Measuring tube lining: PFA)

Nominal dia	meter	Resistance of measuring tube lining to partial vacuum Limit values for abs. pressure [mbar] ([psi]) at various fluid temperatures							
		25 ℃	25 °C 80 °C 100 °C 130 °C 150 °C 180 °C						
[mm]	[inch]	77 °F	77 °F 176 °F 212 °F 266 °F 302 °F 356 °F						
2 to 100	1/12 to 4"	0	0	0	0	0	0		

Promag L (Measuring tube lining: Polyurethane, Hard rubber)

Nominal diameter Measuring tube lining			Resistance of measuring tube lining to partial vacuum Limit values for abs. pressure [mbar] ([psi]) at various fluid temperatures					
			25 °C 50 °C 80 °C					
[mm]	[inch]		77 °F 122 °F 176 °F					
50 to 1200	2 to 48"	Polyurethane	0	_				
350 to 1200	14 to 48"	Hard rubber	0	0	0			

Promag L (Measuring tube lining: PTFE)

Nominal d	iameter		Resistance of measuring tube lining to partial vacuum Limit values for abs. pressure [mbar] ([psi]) at various fluid temperatures							
		25	°C	90	°C					
		77	°F	194	4 °F					
[mm]	[inch]	[mbar]	[psi]	[mbar]	[psi]					
50	2"	0	0	0	0					
65	-	0	0	40	0.58					
80	3"	0	0	40	0.58					
100	4"	0	0	135	1.96					
125	-	135	1.96	240	3.48					
150	6"	135	1.96	240	3.48					
200	8"	200	2.90	290	4.21					
250	10"	330	4.79	400	5.80					
300	12"	400	5.80	500	7.25					

Technical data Promag 50

Promag P (Measuring tube lining: PFA)

Promag P Nominal dia	meter	Resistance of measuring tube lining to partial vacuum Limit values for abs. pressure [mbar] ([psi]) at various fluid temperatures							
		25 ℃	80° C	100 °C	130 ℃	150 ℃	180 °C		
[mm]	[inch]	77 °F	176° F	212 °F	266 °F	302 °F	356 °F		
25	1"	0	0	0	0	0	0		
32	-	0	0	0	0	0	0		
40	1 1/2"	0	0	0	0	0	0		
50	2"	0	0	0	0	0	0		
65	-	0	*	0	0	0	0		
80	3"	0	*	0	0	0	0		
100	4"	0	*	0	0	0	0		
125	-	0	*	0	0	0	0		
150	6"	0	*	0	0	0	0		
200	8"	0	*	0	0	0	0		
* No value ca	an be quoted.	•							

Promag P (Measuring tube lining: PTFE)

Nominal di	ameter					ng to partial vacuum ar] ([psi]) at various fluid temperatures					
		25	°C	80)°C	100 ℃		130 ℃		150 ℃	180 °C
		77	°F	170	6 °F	212 °F		266 °F		302 °F	356 °F
[mm]	[inch]	[mbar]	[psi]			[mbar]	[psi]	[mbar]	[psi]		
25	1"	0	0	0	0	0	0	100	1.45	_	-
32	_	0	0	0	0	0	0	100	1.45	-	-
40	1 ½"	0	0	0	0	0	0	100	1.45	-	-
50	2"	0	0	0	0	0	0	100	1.45	-	-
65	_	0	0	*	*	40	0.58	130	1.89	-	-
80	3"	0	0	*	*	40	0.58	130	1.89	-	-
100	4"	0	0	*	*	135	1.96	170	2.47	-	-
125	_	135	1.96	*	*	240	3.48	385	5.58	-	-
150	6"	135	1.96	*	*	240	3.48	385	5.58	-	-
200	8"	200	2.90	*	*	290	4.21	410	5.95	-	1
250	10"	330	4.79	*	*	400	5.80	530	7.69	-	-
300	12"	400	5.80	*	*	500	7.25	630	9.14	-	-
350	14"	470	6.82	*	*	600	8.70	730	10.59	-	1
400	16"	540	7.83	*	*	670	9.72	800	11.60	-	_
450	18"		Partial vacuum is impermissible!								
500	20"										
600	24"										
* No value	can be qu	oted.									

Promag W

Nominal diameter Measuring tube lining			Resistance of measuring tube lining to partial vacuum Limit values for abs. pressure [mbar] ([psi]) at various fluid temperatures						
	25 ℃	50 ℃	80 °C	100 ℃	130℃	150 ℃	180 °C		
[mm]	[inch]		77 °F	122 °F	176 °F	212 °F	266 °F	302 °F	356 °F
25 to 1200	1 to 40"	Polyurethane	0	0	-	-	-	-	-
50 to 2000	2 to 78"	Hard rubber	0	0	0	-	-	ı	-

Promag 50 Technical data

Limiting flow

→ 🖺 17

Pressure loss

 No pressure loss if the sensor is installed in a pipe of the same nominal diameter (Promag H: only DN 8 and larger).

■ Pressure losses for configurations incorporating adapters according to DIN EN 545 (see "Adapters" \rightarrow 🗎 16)

10.1.10 Mechanical construction

Design, dimensions

Weight (SI units)

Promag D

Weight da	Weight data in kg										
Nominal	diameter	Compact version	Remote version	(without cable)							
[mm]	[inch]		Sensor	Transmitter							
25	1"	4.5	2.5	6.0							
40	1 1/2"	5.1	3.1	6.0							
50	2"	5.9	3.9	6.0							
65	2 1/2"	6.7	4.7	6.0							
80	3"	7.7	5.7	6.0							
100 4" 10.4 8.4 6.0											
Transmitter Promag (compact version): 3.4 kg (Weight data valid without packaging material)											

Technical data Promag 50

Promag E

Weight	Weight data in kg										
	ninal			Compact	t version						
dian	neter		EN (DIN)		ASME	JIS				
[mm]	[inch]	PN 6	PN 10	PN 10 PN 16		Class 150	10K				
15	1/2"	_	_	_	6.5	6.5	6.5				
25	1"	_	-	_	7.3	7.3	7.3				
32	-	_	-	_	8.0	-	7.3				
40	1½"	-	-	-	9.4	9.4	8.3				
50	2"	-	-	-	10.6	10.6	9.3				
65	-	-	-	12.0	_	-	11.1				
80	3"	-	-	14.0	_	14.0	12.5				
100	4"	-	-	16.0	_	16.0	14.7				
125	-	-	-	21.5	_	-	21.0				
150	6"	-	-	25.5	_	25.5	24.5				
200	8"	-	45.0	46.0	_	45.0	41.9				
250	10"	-	65.0	70.0	_	75.0	69.4				
300	12"	-	70.0	81.0	_	110.0	72.3				
350	14"	77.4	88.4	99.4	_	137.4	-				
400	16"	89.4	104.4	120.4	_	168.4	-				
450	18"	99.4	112.4	133.4	_	191.4	_				
500	20"	114.4	132.4	182.4	_	228.4	_				
600	24"	155.4	162.4	260.4	-	302.4	-				

- Transmitter (compact version): 1.8 kg
 Weight data without packaging material

Weight	data in	kg						
	ninal			Reme	ote version	(without cab	le)	
dian	neter		Transmitter					
			EN (DIN)		ASME	JIS	
[mm]	[inch]	PN 6	PN 10	PN 16	PN 40	Class 150	10K	Wall-mount housing
15	1/2"	-	-	-	4.5	4.5	4.5	
25	1"	-	-	-	5.3	5.3	5.3	-
32	-	-	-	-	6.0	-	5.3	-
40	1½"	-	-	-	7.4	7.4	6.3	-
50	2"	-	-	-	8.6	8.6	7.3	=
65	-	-	-	10.0	-	-	9.1	-
80	3"	-	-	12.0	-	12.0	10.5	-
100	4"	-	-	14.0	-	14.0	12.7	=
125	-	-	-	19.5	-	-	19.0	6.0
150	6"	_	-	23.5	-	23.5	22.5	0.0
200	8"	-	43.0	44.0	-	43.0	39.9	=
250	10"	-	63.0	68.0	-	73.0	67.4	-
300	12"	-	68.0	79.0	-	108.0	70.3	-
350	14"	73.1	84.1	95.1	-	133.1		=
400	16"	85.1	100.1	116.1	-	164.1		
450	18"	95.1	108.1	129.1	-	187.1		
500	20"	110.1	128.1	178.1	-	224.1		
600	24"	158.1	158.1	256.1	-	298.1		

- Transmitter (remote version): 3.1 kgWeight data without packaging material

Promag 50 Technical data

Promag H

Weight dat	Weight data in kg							
Nominal	diameter	Compact version	Remote version (without cable)					
[mm]	[inch]	DIN	Sensor	Transmitter				
2	1/12"	5.2	2	6.0				
4	5/32"	5.2	2	6.0				
8	5/16"	5.3	2	6.0				
15	1/2"	5.4	1.9	6.0				
25	1"	5.5	2.8	6.0				
40	1 ½"	6.5	4.5	6.0				
50	2"	9.0	7.0	6.0				
65	2 1/2"	9.5	7.5	6.0				
80	3"	19.0	17.0	6.0				
100	4"	18.5	16.5	6.0				

 $Transmitter\ Promag\ (compact\ version) \hbox{:}\ 3.4\ kg$

(Weight data valid for standard pressure ratings and without packaging material)

Promag L compact version (lap joint flanges / welded flanges DN > 350)

Weight data in kg										
Nominal	diameter				Compac	t versio	n			
			(including transmitter)							
[mm]	[inch]	Е	EN (DIN)	E	N (DIN)	ASM	E / AWWA		AS	
50	2"		10.6		-		10.6		-	
65	2 1/2"		12.0		-		-		-	
80	3"	16	14.0		-		14.0		-	
100	4"	PN 16	16.0		-		16.0		-	
125	5"		21.5		-		-		-	
150	6"		25.5		-	.50	25.5		-	
200	8"		45		-	ASME / Class 150	45		-	
250	10"		65		-	/ Cla	65		1	
300	12"		70		-	ME,	70		-	
350	14"		90		79	AS	139	lle E	101	
375	15"		-	91	-		-	PN 16. Tabelle E	107	
400	16"		106	PN	91		170	-6. T	122	
450	18"		114		101		193	N J	135/145*	
500	20"	PN 10	134		116		230		184	
600	24"	PN	157		157		304		262	
700	28"		248		200		277		354	
750	30"		-		-	3 D	329		441	
800	32"		322		248	Class	396		501	
900	36"		402		316	A / (482		698	
1000	40"		475		366	AWWA / Class D	601		769	
	42"		-		-	AV	684		-	
1200	48"		724		537		914		1227	

Transmitter Promag (compact version): 3,4 kg (Weight data valid without packaging material)
* DN 450 AS Tab E

Technical data Promag 50

Promag L remote version (lap joint flanges / welded flanges DN > 350)

Weight da	Weight data in kg								
Nominal	diameter				Remote	version	L		
			(sensor plus sensor housing without cable)						
[mm]	[inch]	E	EN (DIN)	E	N (DIN)	ASM	E / AWWA		AS
50	2"		8.6		-		8.6		-
65	2 1/2"		10.0		-		-		-
80	3"	PN 16	12.0		-		12.0		-
100	4"	PN	14.0		-		14.0		-
125	5"		19.5		-		-		-
150	6"		23.5		-	50	23.5		-
200	8"		43		-	ıss 1	43		_
250	10"		63		-	/ Cla	63	[-1	-
300	12"		68	9.	-	ASME / Class 150	108		-
350	14"		87		76	ASI	136	lle E	98
375	15"		-		-		-	Tabelle	104
400	16"		103	PN	88	•	167	.6, T	119
450	18"		111		98		190	PN 16, '	132/142*
500	20"	PN 10	131		113		227		181
600	24"	PN	154		154		301		259
700	28"		-		198		275		352
750	30"		-		-	3 D	327		439
800	32"		320		246	AWWA / Class D	394		499
900	36"		400		314	4 / C	480		696
1000	40"		473		364	VW,	599		767
	42"		-		-	ΑV	682		-
1200	48"		722		535		912		1225
Transmitte	Transmitter Promag (remote version): 6 kg								

Transmitter Promag (remote version): 6 kg (Weight data valid without packaging material) *DN 450 AS Tab E

Promag L (lap joint flanges, stamped plate)

Weight da	Weight data in kg								
Nominal	diameter	Com	pact version	Remote version (without cable)					
[mm]	[inch]	I	EN (DIN)	Sens	Sensor EN (DIN) Transmi				
50	2"		7.2		5.2	6.0			
65	2 1/2"		8.0		6.0	6.0			
80	3"		9.0		7.0	6.0			
100	4"	C	11.5	0	9.5	6.0			
125	5"	PN 10	15.0	PN 10	13.0	6.0			
150	6"	Д	19.0	Д	17.0	6.0			
200	8"		37.5		35.5	6.0			
250	10"		56.0		54.0	6.0			
300	12"		57.0		55.0	6.0			
Transmitte	r Promag (co	ompact versi	on): 3.4 kg						

(Weight data valid for standard pressure ratings and without packaging material)

Promag 50 Technical data

Promag P

Weigh	Neight data in kg													
Nominal Compact version diameter								Ren	note v	ersion (with	out cable)	
										S	ensor			Trans-
[mm]	[inch]		(DIN) / AS*		JIS		SME/ WWA		(DIN) / AS*		JIS		SME/ WWA	mitter
15	1/2"		6.5		6.5		6.5		4.5		4.5		4.5	6.0
25	1"	0	7.3		7.3		7.3	0	5.3		5.3		5.3	6.0
32	1 1/4"	PN 40	8.0		7.3		-	PN 40	6.0		5.3		-	6.0
40	1 ½"	Н	9.4		8.3		9.4	ц	7.4		6.3		7.4	6.0
50	2"		10.6		9.3		10.6		8.6		7.3		8.6	6.0
65	2 ½"		12.0		11.1		-		10.0		9.1		-	6.0
80	3"	9	14.0	10K	12.5		14.0	9	12.0	10K	10.5		12.0	6.0
100	4"	PN 16	14.4		14.7	0	16.0	PN 16	14.0		12.7	0	14.0	6.0
125	5"	Н	16.0		21.0	150	-	ц	19.5		19.0	150	-	6.0
150	6"		21.5		24.5	Class	25.5		23.5		22.5	Class	23.5	6.0
200	8"		45		41.9		45		43		39.9		43	6.0
250	10"		65		69.4		75		63		67.4		73	6.0
300	12"		70		72.3		110		68		70.3		108	6.0
350	14"	10	115				175	10	113				173	6.0
400	16"	PN	135				205	PN	133				203	6.0
450	18"		175				255		173				253	6.0
500	20"		175				285		173				283	6.0
600	24"		235				405		233				403	6.0

Transmitter Promag (compact version): 3.4 kg
High-temperature version: + 1.5 kg
(Weight data valid for standard pressure ratings and without packaging material)
* Flanges according to AS are only available for DN 25 and 50.

Technical data Promag 50

Promag W

Weight data in kg Nominal Compact version Rem diameter									ote v	ersion (v	vithou	ıt cable)	
[mm]	[inch]		(DIN) / AS*		JIS		SME/ WWA		(DIN) / AS*	Se	nsor JIS		ME/ WWA	Trans- mitter
25	1"		7.3		7.3		7.3		5.3		5.3		5.3	6.0
32	1 1/4"	40	8.0		7.3		-	40	6.0		5.3		-	6.0
40	1 1/2"	PN	9.4		8.3		9.4	PN	7.4		6.3		7.4	6.0
50	2"		10.6		9.3		10.6		8.6		7.3		8.6	6.0
65	2 1/2"		12.0		11.1		-		10.0		9.1		-	6.0
80	3"	,0	14.0	X	12.5		14.0	,,	12.0	云	10.5		12.0	6.0
100	4"	PN 16	16.0	10K	14.7		16.0	PN 16	14.0	10K	12.7		14.0	6.0
125	5"	Ы	21.5		21.0	20	-	Ы	19.5		19.0	20	-	6.0
150	6"		25.5		24.5	Class 150	25.5		23.5		22.5	Class 150	23.5	6.0
200	8"		45		41.9	Cla	45		43		39.9	Cla	43	6.0
250	10"		65		69.4		65		63		67.4		73	6.0
300	12"		70		72.3		110		68		70.3		108	6.0
350	14"		115				175		113				173	6.0
400	16"		135				205		133				203	6.0
450	18"		175				255	C	173				253	6.0
500	20"	PN 10	175				285	PN 10	173				283	6.0
600	24"	Ы	235				405	PI	233				403	6.0
700	28"		355				400		353				398	6.0
-	30"		-				460		_				458	6.0
800	32"		435				550		433				548	6.0
900	36"		575				800		573				798	6.0
1000	40"		700				900		698				898	6.0
-	42"		-				1100		-				1098	6.0
1200	48"		850				1400		848			0	1398	6.0
-	54"		-			Class D	2200		-			Class D	2198	6.0
1400	_		1300	1		Ü	_		1298			C	-	6.0
-	60"	9	-	1			2700	9	-				2698	6.0
1600	_	PN	1700	1			_	PN	1698				-	6.0
-	66"		_	1			3700		_				3698	6.0
1800	72"		2200	1			4100		2198				4098	6.0
-	78"		-	1			4600		-				4598	6.0
2000	_		2800	1			_		2798				-	6.0

Transmitter Promag (compact version): 3.4 kg (Weight data valid for standard pressure ratings and without packaging material) *Flanges according to AS are only available for DN 80, 100, 150 to 400, 500 and 600

Promag 50 Technical data

Weight (US units)

Promag D

Weight data	Weight data in lbs							
Nominal	diameter	Compact version	Remote version (without cable)					
[mm]	[inch]		Sensor	Transmitter				
25	1"	10	6	13				
40	1 1/2"	11	7	13				
50	2"	13	9	13				
80	3"	17	13	13				
100 4" 23 19 13								
Transmitter	Promag (comp	oact version): 7.5 lbs (Weight d	ata valid without packaging m	aterial)				

Promag E (ASME)

Weight	Weight data in lbs								
	ninal	Compact version	Remote version	(without cable)					
dian	ieter		Sensor	Transmitter					
		ASME	ASME						
[mm]	[inch]	Class 150	Class 150	Wall-mount housing					
15	1/2"	14.3	9.92						
25	1"	16.1	11.7						
40	1½"	20.7	16.3						
50	2"	23.4	19.0						
80	3"	30.9	26.5						
100	4"	35.3	30.9						
150	6"	56.2	51.8						
200	8"	99.2	94.8	13.2					
250	10"	165.4	161.0						
300	12"	242.6	238.1						
350	14"	303.0	293.5						
400	16"	371.3	361.8						
450	18"	422.0	412.6						
500	20"	503.6	494.1						
600	24"	666.8	657.3						

[■] Transmitter: 4.0 lbs (compact version); 6.8 lbs (remote version)

Promag H

Weight dat	Weight data in lbs							
Nominal	diameter	Compact version	Remote version (without cable)				
[mm]	[inch]		Sensor	Transmitter				
2	1/12"	11	4	13				
4	5/32"	11	4	13				
8	5/16"	12	4	13				
15	1/2"	12	4	13				
25	1"	12	6	13				
40	1 ½"	14	10	13				
50	2"	20	15	13				
65	2 1/2"	21	17	13				
80	3"	42	37	13				
100	4"	41	36	13				
Tuenemitter	Francosittas Drama a Japane et varaion), 7 F lha							

Transmitter Promag (compact version): 7.5 lbs

Weight data without packaging material

⁽Weight data valid for standard pressure ratings and without packaging material)

 $Promag\ L\ (ASME\ /\ AWWA:\ lap\ joint\ flanges\ /\ welded\ flanges\ DN > 700)$

Weight data in	lbs				
Nominal diameter		Compact version		Remote version (without cable)	
[mm]	[inch]	ASME / AWWA		ASME / AWWA	
50	2"		23		19
65	2 ½"		-		-
80	3"	50	31	ASME / Class 150	26
100	4"	ASME / Class 150	35		31
125	5"	, Cla	-		-
150	6"	Æ/	56	ME /	52
200	8"	ASI	99	ASI	95
250	10"		143		139
300	12"		243		238
350	14"		-		-
400	16"		-		-
450	18"		-		-
500	20"		-		-
600	24"		-		-
700	28"		611		606
750	30"	AWWA / Class D	725	O :	721
800	32"		873	llass	869
900	36"		1063	7/6	1058
1000	40"		1324	AWWA / Class D	1320
	42"	AV	1508	ΑV	1504
1200	48"		2015		2011

Transmitter Promag (compact version): 7,5 lbs Transmitter Promag (remote version): 13 lbs (Weight data valid without packaging material)

Promag P (ASME/AWWA)

Weight data in	lbs					
Nominal diameter		Compact version		Remote version (without cable)		
[mm]	[inch]			Sensor Transmitter		Transmitter
15	1/2"		14		10	13
25	1"		16		12	13
40	1 ½"		21		16	13
50	2"		23		19	13
80	3"		31		26	13
100	4"		35		31	13
150	6"	20	56	20	52	13
200	8"	Class 150	99	Class 150	95	13
250	10"	Cla	165	Cla	161	13
300	12"		243		238	13
350	14"		386		381	13
400	16"		452		448	13
450	18"		562		558	13
500	20"		628		624	13
600	24"		893		889	13

 $Transmitter\ Promag\ (compact\ version);\ 7.5\ lbs$

High-temperature version: 3.3 lbs

(Weight data valid for standard pressure ratings and without packaging material)

Promag 50 Technical data

Promag W (ASME/AWWA)

Weight data in	lbs					
Nominal diameter		Compact version		Remote version (without cable)		
[mm]	[inch]			S	ensor	Transmitter
25	1"		16		12	13
40	1 1/2"		21		16	13
50	2"		23		19	13
80	3"		31		26	13
100	4"		35	0	31	13
150	6"		56		52	13
200	8"	Class 150	99	Class 150	95	13
250	10"	Class	143	lass	161	13
300	12"		243		238	13
350	14"		386		381	13
400	16"		452		448	13
450	18"		562		558	13
500	20"		628		624	13
600	24"		893		889	13
700	28"		882		878	13
_	30"		1014		1010	13
800	32"		1213		1208	13
900	36"		1764		1760	13
1000	40"		1985		1980	13
-	42"	Class D	2426	Class D	2421	13
1200	48"	Clas	3087	Clas	3083	13
_	54"		4851		4847	13
-	60"		5954		5949	13
_	66"		8159		8154	13
1800	72"		9041		9036	13
_	78"		10143		10139	13

Transmitter Promag (compact version): 7.5 lbs (Weight data valid for standard pressure ratings and without packaging material)

Material

Promag D

■ Transmitter housing: powder-coated die-cast aluminum

■ Sensor housing: powder-coated die-cast aluminum

Measuring tube: polyamide, O-rings EPDM (Drinking water approvals: WRAS BS 6920, ACS, NSF 61, KTW/W270)

■ Electrodes: 1.4435 (316, 316L)

• Ground disks: 1.4301 (304)

Promag E

- Transmitter housing
 - Compact housing: powder-coated die-cast aluminum
 - Wall-mount housing: powder-coated die-cast aluminum
- Sensor housing
 - DN 25 to 300 (1 to 12"): powder-coated die-cast aluminum
 - DN 350 to 600 (14 to 24"): with protective lacquering
- Measuring tube
 - DN ≤ 300 (12"): stainless steel 1.4301 (304) or 1.4306 (304L) (with Al/Zn protective coating)
 - DN \geq 350 (14"): stainless steel 1.4301 (304) or 1.4306 (304L) (with protective lacquering)
- Electrodes: 1.4435 (316, 316L), Alloy C22, Tantalum
- Flanges (with protective lacquering)
 - EN 1092-1 (DIN2501): RSt37-2 (S235JRG2); Alloy C22; Fe 410W B
 - ANSI: A105
 - JIS: RSt37-2 (S235JRG2); HII
- Seals: to DIN EN 1514-1
- Ground disks: 1.4435 (316, 316L) or Alloy C22

Promag H

- Transmitter housing:
 - Compact housing: powder-coated die-cast aluminum or stainless steel field housing (1.4301 (316L))
 - Wall-mounted housing: powder-coated die-cast aluminum
 - Window material: glas or polycarbonate
- Sensor housing: stainless steel 1.4301 (304)
- Wall mounting kit: stainless steel 1.4301 (304)
- Measuring tube: stainless steel 1.4301 (304)
- Liner: PFA (USP class VI; FDA 21 CFR 177.1550: 3A)
- Electrodes:
 - Standard: 1.4435 (316, 316L)
 - Option: Alloy C22, Tantalum, Platinum
- Flange:
 - All connections stainless-steel 1.4404 (316L)
 - EN (DIN), ASME, JIS made of PVDF
 - Adhesive fitting made of PVC
- Seals
 - DN 2 to 25 (1/12 to 1"): O-ring (EPDM, Viton, Kalrez), gasket seal (EPDM*, Viton, Silicone*)
 - DN 40 to 100 ($1\frac{1}{2}$ to 4"): gasket seal (EPDM*, Silicone*)
 - * = USP class VI; FDA 21 CFR 177.2600: 3A
- Ground rings: 1.4435 (316, 316L) (optional: Tantalum, Alloy C22)

Promag L

- Transmitter housing:
 - Compact housing: powder-coated die-cast aluminum
 - Wall-mounted housing: powder-coated die-cast aluminum
- Sensor housing
 - DN 50 to 300 (2 to 12"): powder-coated die-cast aluminum
 - DN 350 to 1200 (14 to 84"): with protective lacquering

Promag 50 Technical data

- Measuring tube:
 - $-DN \le 300 (12")$: stainless steel 1.4301 (304) or 1.4306 (304L)
 - DN \ge 350 (14"): stainless steel 202 or 304
- Electrodes: 1.4435 (316, 316L), Alloy C22
- Flange
 - EN 1092-1 (DIN 2501): DN ≤ 300: 1.4306; 1.4307; 1.4301 (304); 1.0038 (\$235]RG2)
 - EN 1092-1 (DIN 2501): DN ≥ 350: A105; 1.0038 (S235JRG2)
 - AWWA: A181/A105; 1.0425 (316L) (P265GH); 1.0044 (S275JR)
 - AS 2129: A105; 1.0345 (P235GH); 1.0425 (316L) (P265GH); 1.0038 (S235JRG2); FE 410 WB
 - AS 4087: A105; 1.0425 (316L) (P265GH); 1.0044 (S275JR)
- Seals: to DIN EN 1514-1
- Ground disks: 1.4435 (316, 316L) or Alloy C22

Promag P

- Transmitter housing:
 - Compact housing: powder-coated die-cast aluminum
 - Wall-mounted housing: powder-coated die-cast aluminum
- Sensor housing
 - DN 15 to 300 ($\frac{1}{2}$ to 12"): powder-coated die-cast aluminum
 - DN 350 to 2000 (14 to 84"): with protective lacquering
- Measuring tube
 - DN ≤ 300 (12"): stainless steel 1.4301 (304) or 1.4306 (304L); for flanges made of carbon steel with Al/Zn protective coating
 - DN \geq 350 (14"): stainless steel 1.4301 (304) or 1.4306 (304L); for flanges made of carbon steel with Al/Zn protective coating
- Electrodes: 1.4435 (316, 316L), Platinum, Alloy C22, Tantalum, Titanium
- Flange
 - EN 1092-1 (DIN2501): 1.4571 (316L); RSt37-2 (S235JRG2); Alloy C22; FE 410W B (DN \leq 300 (12") with Al/Zn protective coating; DN \geq 350 (14") with protective lacquering)
 - ASME: A105; F316L
 - (DN \leq 300 (12") with Al/Zn protective coating; DN \geq 350 (14") with protective lacquering)
 - AWWA: 1.0425
 - JIS: RSt37-2 (S235JRG2); HII; 1.0425 (316L) (DN \leq 300 (12") with Al/Zn protective coating; DN \geq 350 (14") with protective lacquering)
 - AS 2129
 - DN 25 (1"): A105 or RSt37-2 (S235JRG2)
 - DN 40 (1½"): A105 or St44-2 (S275JR)
 - AS 4087: A105 or St44-2 (S275JR)
- Seals: to DIN EN 1514-1
- Ground disks: 1.4435 (316, 316L) or Alloy C22

Promag W

- Transmitter housing:
 - Compact housing: powder-coated die-cast aluminum
 - Wall-mounted housing: powder-coated die-cast aluminum
- Sensor housing
 - DN 25 to 300 (1 to 12"): powder-coated die-cast aluminum
 - DN 350 to 2000 (14 to 84"): with protective lacquering

- Measuring tube
 - DN ≤ 300 (12"): stainless steel 1.4301 (304) or 1.4306 (304L) (for flanges made of carbon steel with Al/Zn protective coating)
 - DN \geq 350 (14"): stainless steel 1.4301 (304) or 1.4306 (304) (for flanges made of carbon steel with protective lacquering)
- Electrodes: 1.4435 (316, 316L) or Alloy C22, Tantalum
- Flange
 - EN 1092-1 (DIN2501): 1.4571 (316L); RSt37-2 (S235JRG2); Alloy C22; FE 410 WB (DN \leq 300 (12") with Al/Zn protective coating; DN \geq 350 (14") with protective lacquering)
 - ASME: A105; F316L (DN \leq 300 (12") with Al/Zn protective coating; DN \geq 350 (14") with protective lacquering)
 - AWWA: 1.0425
 - JIS: RSt37-2 (S235JRG2); HII; 1.0425 (316L) (DN \leq 300 (12") with Al/Zn protective coating; DN \geq 350 (14") with protective lacquering)
 - AS 2129
 - DN 150 to 300 (6 to 12"), DN 600 (24"): A105 or RSt37-2 (S235JRG2)
 - DN 80 to 100 (3 to 4"), 350 to 500 (14 to 20"): A105 or St44-2 (S275JR)
 - AS 4087: A105 or St44-2 (S275JR)
- Seals: to DIN EN 1514-1
- Ground disks: 1.4435 (316, 316L), Alloy C22, Titanium, Tantalum

Pressure-temperature ratings

The material load diagrams (pressure-temperature graphs) for the process connections are to be found in the "Technical Information" documents of the device in question: List of supplementary documentation $\rightarrow \triangleq 124$.

Fitted electrodes

Promag D

• 2 measuring electrodes for signal detection

Promag E/L/P/W

- 2 measuring electrodes for signal detection
- 1 EPD electrode for empty pipe detection
- 1 reference electrode for potential equalization

Promag H

- 2 measuring electrodes for signal detection
- 1 EPD electrode for empty pipe detection (apart from DN 2 to 15)

Process connections

Promag D

Wafer version \rightarrow without process connections

Promag 50 Technical data

Promag E

Flange connections:

- EN 1092-1 (DIN 2501)
 - $-DN \le 300 (12") = form A$
 - DN ≥ 350 (14") = flat face
 - DN 65 PN 16 and DN 600 PN 16 only as per EN 1092-1
- ASME
- JIS

Promag H

With O-ring:

- Weld nipple DIN (EN), ISO 1127, ODT/SMS
- Flange EN (DIN), ASME, JIS
- Flange made of PVDF EN (DIN), ASME, JIS
- External thread
- Internal thread
- Hose connection
- PVC adhesive fitting

With gasket seal:

- Weld nipple DIN 11850, ODT/SMS
- Clamp ISO 2852, DIN 32676, L14 AM7
- Threaded joint DIN 11851, DIN 11864-1, ISO 2853, SMS 1145
- Flange DIN 11864-2

Promag L

Flange connections:

- EN 1092-1 (DIN 2501)
 - $-DN \le 300 = Form A$
 - DN ≥ 350 = Form B
- ASME
- AWWA
- AS

Promag P/W

Flange connections:

- EN 1092-1 (DIN 2501)
 - $-DN \le 300 = form A$
 - DN ≥ 350 = flat face
 - DN 65 PN 16 and DN 600 PN 16 only as per EN 1092-1
- ASME
- AWWA (only Promag W)
- JIS
- AS

Surface roughness

All data relate to parts in contact with fluid.

- Liner \rightarrow PFA: \leq 0.4 μ m (15 μ in)
- Electrodes: 0.3 to 0.5 μm (12 to 20 μin)
- Process connection made of stainless-steel (Promag H): \leq 0.8 µm (31 µin)

10.1.11 Human interface

Display elements

- Liquid crystal display: illuminated, two-line, 16 characters per line
- Custom configurations for presenting different measured-value and status variables
- 2 totalizers



Note!

At ambient temperatures below -20 (-4 °F) the readability of the display may be impaired.

Operating elements

- Local operation with three keys (□ ± €)
- "Quick Setup" menus for straightforward commissioning

Language groups

Language groups available for operation in different countries:

- Western Europe and America (WEA):
 English, German, Spanish, Italian, French, Dutch and Portuguese
- Eastern Europe/Scandinavia (EES):
 English, Russian, Polish, Norwegian, Finnish, Swedish and Czech
- Southeast Asia (SEA):
 English, Japanese, Indonesian



Vote!

You can change the language group via the operating program "FieldCare".

Remote operation

Operation via HART protocol and Fieldtool

10.1.12 Certificates and approvals

CE mark

The measuring system is in conformity with the statutory requirements of the EC Directives. Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.

C-tick mark

The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".

Ex approval

Information about currently available Ex versions (ATEX, FM, CSA, IECEx, NEPSI etc.) can be supplied by your Endress+Hauser Sales Center on request. All explosion protection data are given in a separate documentation which is available upon request.

Sanitary compatibility

Promag D/E/L/P/W

No applicable approvals or certification

Promag H

- 3A authorization and EHEDG-tested
- Seals: in conformity with FDA (except Kalrez seals)

Promag 50 Technical data

Drinking water approval

Promag D/L/W

- WRAS BS 6920
- ACS
- NSF 61
- KTW/W270

Promag E/H/P

No drinking water approval

Pressure Equipment Directive

Promag D/L

No pressure measuring device approval

Promag E/H/P/W

The devices can be ordered with or without a PED approval. If a device with a PED approval is required, this must be explicitly stated in the order. For devices with nominal diameters less than or equal to DN 25 (1"), this is neither possible nor necessary.

- With the PED/G1/x (x = category) marking on the sensor nameplate, Endress+Hauser confirms compliance with the "Essential Safety Requirements" specified in Annex I of the Pressure Equipment Directive 97/23/EC.
- Devices bearing this marking (PED) are suitable for the following types of medium:
 Media in Group 1 and 2 with a vapor pressure greater than, or smaller and equal to 0.5 bar (7.3 psi)
- Devices not bearing this marking (PED) are designed and manufactured according to good engineering practice. They meet the requirements of Art.3 Section 3 of the Pressure Equipment Directive 97/23/EC. The range of application is indicated in tables 6 to 9 in Annex II of the Pressure Equipment Directive.

Other standards and guidelines

■ EN 60529

Degrees of protection by housing (IP code).

■ EN 61010-1

Safety requirements for electrical equipment for measurement, control and laboratory use

■ IEC/EN 61326

Electromagnetic compatibility (EMC requirements)

■ ASME/ISA-S82.01

Safety Standard for Electrical and Electronic Test, Measuring, Controlling and related Equipment - General Requirements. Pollution degree 2, Installation Category II.

 CAN/CSA-C22.2 (No. 1010.1-92)
 Safety requirements for Electrical Equipment for Measurement and Control and Laboratory Use. Pollution degree 2, Installation Category I.

■ NAMUR NE 21 Electromagnetic compatibility (EMC) of industrial process and laboratory control

equipment.

• NAMUR NE 43

Standardization of the signal level for the breakdown information of digital transmitters with analog output signal.

10.1.13 Ordering information

Detailed ordering information is available from the following sources:

- In the Product Configurator on the Endress+Hauser website: www.endress.com → Select country → Instruments → Select device → Product page function: Configure this product
- From your Endress+Hauser Sales Center: www.endress.com/worldwide



Note

Product Configurator - the tool for individual product configuration

- Up-to-the-minute configuration data
- Depending on the device: Direct input of measuring point-specific information such as measuring range or operating language
- Automatic verification of exclusion criteria
- Automatic creation of the order code and its breakdown in PDF or Excel output format
- Ability to order directly in the Endress+Hauser Online Shop

10.1.14 Accessories

Various accessories, which can be ordered separately from Endress+Hauser, are available for the transmitter and the sensor $\rightarrow \blacksquare 78$.

Your Endress+Hauser service organization can provide detailed information on the specific order codes on request.

10.1.15 Documentation

- Flow measuring technology (FA00005D/06)
- Technical Information Promag 50D (TI00082D/06)
- Technical Information Promag 50E (TIO1161D/06)
- Technical Information Promag 50L (TI00097D/06)
- Technical Information Promag 50/53H (TI00048D/06)
- Technical Information Promag 50/53P (TI00047D/06)
- Technical Information Promag 50/53W (TI00046D/06)
- Description of Device Functions Promag 50 HART (BA00049D/06)
- Supplementary documentation on Ex-ratings: ATEX, FM, CSA, etc.

Index

A	Environment 101
Accessories	Error message types63
Adapters	Error messages
Ambient temperature range	Process error (application error) 84
Applicator (selection and configuration software) 80	System errors (device errors)82
Approvals	Europäische Druckgeräterichtlinie
rr	Ex approval 122
C	Exterior cleaning
Cable entry	
Cable specifications	F
Calibration factor	Field Xpert SFX10054
CE mark	FieldCare 64, 80
CE mark (Declaration of Conformity) 8	Fieldcheck (tester and simulator) 80
Centering sleeve	Fitted electrodes
Promag D 21	Flow rate/limits17
Certificates	Function matrix
CIP cleaning	Brief operating instructions 61
Cleaning (exterior cleaning)	Fuse, replacing93
Code entry (function matrix) 62	FXA19380
Commissioning	FXA19579
General	
Two current outputs 74	G
Commissioning Quick Setup menu	Galvanic isolation
Commubox FXA 195 (electrical connection) 55, 79	Gewicht
Communication	Ground cable
Conductivity of fluid 105	Promag E
Connecting cable	Promag L
Connection	Promag P
Check 59	Promag W
HART 54	Grounding rings
Remote version	Promag H
C-tick mark	Н
Current output	
Configuration (active/passive)	HART Command classes
_	
D	Commands 66 Communicator DXR 375 64
Declaration of Conformity (CE mark) 8	Device description files
Degree of protection	1
Design	Device status / Error messages
Device description files	Hazardous substances
Device variable via HART protocol	High-temperature version
Display	HOME position (operating mode)
Elements	HOME position (operating mode)
Turning the display	I
Documentation	Incoming acceptance
Drinking water approval	Inlet/outlet run
Druckgerätezulassung	Installation
E	Promag D
	Promag E
Electrical connection Commubox FXA 191	Promag H
	Promag L
HART handheld terminal	Promag P
Electrical connections	Promag W
Electrodes EDD electrode	Installation conditions
EPD electrode	Adapters16
EMC (electromagnetic compatibility)	Dimensions
Empty-pipe/full-pipe adjustment	

Down pipe 13 EPD electrode 14	Pig (cleaning)	
Foundations, supports	Check	
Inlet/outlet run	Potential equalization	
Installation of pumps	Power consumption	
Mounting location	Power supply	
Orientation14	Power supply failure	
Partially filled pipes	Pressure Equipment Directive	123
Vibrations	Pressure loss	
Installing the wall-mount housing 43	Adapters (reducers, expanders)	
•	Pressure tightness	
L 100	Pressure-temperature ratings	
Language groups	Process	
Load	Process connections	
Local display	Process error messages	
See Display	Process errors (definition)	63
Low flow cut off	Programming mode	
M	Disable	
Maintenance	Enable	62
	Promag D	
Material	Centering sleeve	
Maximum measured error	Installation	
Measured variable	Mounting bolts	
Measuring principle	Seals	
Measuring range	Tightening torques	
Measuring system	Promag D mounting kit	20
Mechanical construction	Promag E	
Medium pressure range	Ground cable	
Medium temperature range	Installation	
Mounting bolts	Seals	
Promag D	Tightening torques	24
Mounting the sensor	Promag H	
See Installing the sensor	Cleaning with pigs	28
N	Grounding ring (DN 2 to 25, $1/12$ " to 1")	
Nameplate specifications	Installation	
Connections	Seals	
Sensor	Weld nipple	28
Transmitter 6	Promag L	
Nominal diameter and flow rate	Ground cable	
Promag W	Installation	
110mag vv17	Seals	
0	Tightening torques	30
Operable flow range98	Promag P	
Operating elements 60, 122	Ground cable	
Operation	High-temperature version	
Device description files	Installation	
FieldCare64	Seals	
Operating programs	Tightening torques	33
Operational safety 4	Promag W	
Order code	Ground cable	
Accessories	Installation	
Sensor8	Seals	
Ordering code	Tightening torques	36
Sensor	0	
Transmitter 6	Q	E.C.
Output98	Quick Setup	73
Output	R	
P		100
Performance characteristics	Reference operating conditions	100

Registered trademarks	
Connection	46
Repair	96
Repeatability	101
Replacing	
Exchangeable electrode	94
Response to errors	
Returning devices	96
S	
Safety icons	
Safety instructions	4
Sanitary compatibility	122
S-DAT (HistoROM)	
Seals	
Promag D	
Promag E	
Promag H	
Promag L	
Promag P	
Promag W	36
Serial number	
Sensor	
Transmitter	
Service interface FXA 193	
Shock resistance	102
Signal on alarm	99
SIP cleaning	102
Software	
Amplifier display	72
Spare parts	
Standards, guidelines	
Storage temperature	
Supply voltage	
Surface roughness	
Switching on (measuring device)	
System error messages	
System errors (definition)	63
T	
Technical data	98
	. 50
Temperature	101
Ambient	101
Medium	103
Storage	102
Tightening torques	
Promag D	22
Promag E	24
Promag L	30
Promag P	33
Promag W	
Transmitter	
Electrical connection	52
Installing the wall-mount housing	
Turning the field housing (aluminum)	
Turning the field housing (stainless steel)	
Troubleshooting	
	01

Types of error (system and process errors) 63
V Vibration resistance
W
Wall-mount housing, installing 45 Weight 105 Wiring 46

